Vitis Command Line Flow (Cloud)

2022.1

Abstract

This lab walks you through running a simple vector addition design using the Vitis™ tool command line option using a makefile.

This lab should take approximately 60 minutes.

CloudShare Users Only

You are provided three attempts to access a lab, and the time allotted to complete each lab is 2X the time expected to complete the lab. Once the timer starts, you cannot pause the timer. Also, each lab attempt will reset the previous attempt—that is, your work from a previous attempt is not saved.

Objectives

After completing this lab, you will be able to:

- Describe the Vitis command line flow
- Create a makefile to compile a project in different modes
- Compile and execute a C application in software emulation, hardware emulation, and hardware deployment modes
- Use the Vitis analyzer tool to view and analyze reports to determine application performance

Introduction

Here, you will explore a vector addition algorithm. Becoming familiar with the details of this simple algorithm will aid you in understanding what the tools are doing. The vector addition uses a kernel found in **K_ALL.cpp** and supported by **kernel.h** and is shown here:

Figure 4-1: Vector Addition - K_ALL.cpp File

Where MAX_Nb_Of_Elements is defined in the associated header file as:

```
#define MAX_Nb_Of_Elements 1024
```

Figure 4-2: Header file - kernel.h

The function uses several arrays A, B, and R, all of the same fixed size (1024 elements).

Let's look at the example you will be working with. The main() function, in our vernacular, the "host" is found in **host.cpp**. Several additional functions are required to support this code and are found in the **help_functions.cpp** and **.h** files.

The host/main() loads the A and B arrays with data from the **data_1.txt** and **data_2.txt** files, respectively, and passes them into the function/kernel where they are represented by the variables A and B. The vector-adding kernel processes these arrays and returns the sum in variable K. The host extracts this array as RES.

The overall application structure is represented below.




Figure 4-3: Overall Application Structure

The host has five input arguments:

- **Platform:** The name of the platform vendor (Xilinx for this lab).
- **Device:** The target device (the xilinx_u50_gen3x16_xdma_[current_version] board for this lab).
- **XCLBIN:** The name of the binary container (binary_container_1.xclbin for this lab) where the K ADD kernel is precompiled.
- data_1.txt: The data file containing the values for the A array.
- data_2.txt: The data file containing the values for the B array.

The application creates the **RES.txt** output file containing the results generated by the K_VADD kernel.

Building the Software (Host Program)

The software program in this lab is written in C/C++ and uses $OpenCL^{TM}$ API calls to communicate and control the accelerated kernels. It is built using the standard GCC compiler (or g++ compiler), which is a wrapper around GCC. Each source file is compiled to an object file (.o) and linked with the Xilinx Runtime (XRT) shared library to create the executable.

To compile and link the host application:

```
Compile: g++ ... -c <source_file_1> ... <source_file_n> -o
<object_file_name> -g
Linking: g++ ... -l <object_file_1.0> ... <object_file_n.0> -o
<output file name>
```

Note: Host compilation and linking can be integrated into one step, which does not require the -c and -1 options.

Building the Hardware (Kernel Program - Accelerated Function)

Like building the host application, building the kernels also requires compiling and linking. The hardware kernels can be coded in C/C++, OpenCL C, or RTL. The C/C++ and OpenCL C kernels are compiled using the Vitis compiler, while RTL-coded kernels are compiled using the Xilinx package_xo utility.

```
Hardware compile: v++ ... -k <kernel_name> <kernel_source_file> ...
<kernel_source_file>
Hardware link: v++ -t sw_emu ... -l <kernel_xo_file.xo> ...
<kernel xo file.xo>
```

Note: You must specify the target and platform that should match the hardware compile step.

You will use these command lines in the makefile to automate the build and run configuration. Also, there are many libraries and includes to be added for host compilation, and various Vitis compiler options can be set.

Understanding the Lab Environment

Customizable environment variables enable you to tailor your environment for specific machine configurations. The only environment variable (shown below) used in the customer training environment (CustEd_VM) points to the training directory where all the lab files are located.

This environment variable can be customized according to your specific location and can be set for Linux systems in the /etc/profile file.


The following is the environment variable used in the customer training VM:

Environment Variable Name	Description
\$TRAINING_PATH	Points to the space allocated for students to work through their labs. This directory includes prebuilt images and starting points for the labs and demos. In the customer training VM, \$TRAINING_PATH sets to the /home/xilinx/training directory.

Note: Environment variables are not supported by the Vitis IDE GUI. When using this tool, you must manually replace **\$TRAINING_PATH** with the value of the variable, which in the customer training virtual machine, is **/home/xilinx/training**.

For Cloud development: Similarly, the customer training environment (CustEd_VM) sets the XRT tool install path to /opt/xilinx/xrt. Make sure that XRT (2022.1 version) is installed in your environment.

General Flow



Reviewing the Makefile

Step 1

You will begin this lab by looking at the Makefile which contains all the necessary instructions to build and run the tools.

1-1. Configure the environment to support the Vitis IDE tool for accelerator development.

Developing accelerators, as opposed to traditional software development, requires additional libraries.

- **1-1-1.** Either use an existing terminal window if available or press **< Ctrl** + **Alt** + **T>** to open a new terminal window.
- **1-1-2.** Enter the following commands to source the Xilinx XRT and Vitis tools:

```
[host]$ source /opt/xilinx/xrt/setup.sh
[host]$ source /opt/Xilinx/Vitis/2022.1/settings64.sh
```

Note: The customer training environment (CustEd_VM) sets the Vitis tool install path to /opt/Xilinx/Vitis. If the tool is installed in a different location in your environment, use that install path.

For Cloud development: Similarly, the customer training environment (CustEd_VM) sets the XRT tool install path to /opt/xilinx/xrt. Make sure that XRT (2022.1 version) is installed in your environment.

1-2. Review the files in the lab directory.

1-2-1. Enter the following command to change the path to the lab directory:

```
[host]$ cd $TRAINING PATH/accel cmd flow cloud/lab
```

1-2-2. Enter the following command to see the directories:

[host]\$ ls

```
data makefiles src
```

Figure 4-4: Directories in the Lab Directory

The table below provides further details on the directories. Note that you can always have your own preferred directory structure. Here the directory structure has been provided for learning purposes.

Directory	Content	
data	Contains data_1.txt and data_2.txt, which are the input data files for the application.	
makefiles	Contains:	
	Makefile: Host code compilation and linking commands; kernel code compilation and linking commands.	
	design.cfg: Contains the Vitis compiler options.	
	• xrt.ini: The Xilinx Runtime (XRT) library uses various control parameters to specify debugging, profiling, and message logging when running the host application and kernel execution. These control parameters are specified in a runtime initialization file (xrt.ini) and used to configure features of XRT at startup.	
src	Contains all host and kernel design sources.	

1-3. Review the Makefile file.

1-3-1. Enter the following command to open the Makefile file in the editor:

[host]\$ gedit makefiles/Makefile

Note: The editor provides an easy way to navigate the file as opposed to cat or more, which only let you scroll down (you would need to use the scroll bar in the terminal window to go up).

1-3-2. Review the Makefile.mk file.

The following describes the various steps that the makefile performs:

Help on usage of the makefile is provided.

```
.PHONY: help
help::
     @echo " Makefile Usage:"
     @echo ""
     @echo " make build TARGET=<sw_emu/hw_emu/hw>"
     @echo " Command to generate the design for specified target"
     @echo " Default TARGET is sw emu"
     @echo ""
     @echo " make run TARGET=<sw_emu/hw_emu/hw>"
     @echo " Command to generate, run and verifiy the design for specified target"
     @echo ""
     @echo " make clean TARGET=<sw_emu/hw_emu/hw>"
     @echo " Command to remove the generated files for specified target"
     @echo ""
     @echo " make view run summary TARGET=<sw emu/hw emu/hw>"
     @echo " Command to load run summary report in vitis_analyzer utility"
     @echo ""
     @echo " make view_timeline_trace TARGET=<sw_emu/hw_emu/hw>"
     @echo " Command to view application timeline report in vitis_analyzer utility"
     @echo
```

Figure 4-5: Help Command

A phony target is one that is not really the name of a file; rather it is just a name for a recipe to be executed when you make an explicit request. That is, explicitly declare the target to be phony by making it a prerequisite of the special target .PHONY as help.

Once Makefile is run, "make help" will run the recipe. This will display the makefile usage.

- Selecting the platform vendor and target platform (near line no. 26 to 27):
 - Platform vendor is Xilinx
 - Target platform is the Alveo™ U50 accelerator card

Figure 4-6: Selecting the Vendor and Platform

- o Setting the TARGET build configuration, such as software emulation (sw_emu), hardware emulation (hw emu), or system run (hw) (near line no. 29 to 36):
 - The TARGET variable defines the build configuration and is set to: sw_emu, hw_emu, or hw.
 - The default value for the TARGET variable is set to sw emu.
 - The PREBUILT variable defines to build the hardware emulation or use the prebuilt hardware emulation files: Default is NO. If you do not want to build the hardware emulation, use YES.

You can override the default build configuration by entering the following command: [host]\$ make build TARGET=hw_emu

Figure 4-7: Setting the Target Build Configuration

- Naming the host executable, XO, and XCLBIN:
 - The following will be the names after building the project:
 - ➤ The HOST EXE variable defines the executable name.
 - ➤ The XO filename will be K VADD. [sw emu | hw emu | hw].xo.
 - ➤ The XCLBIN name will be kernels.[sw emu | hw emu | hw].xclbin.

Figure 4-8: Naming the Host Executable, Kernel, and XCLBIN

- Setting the source directory, input data files (for validation), and build directory location for each build configuration (near line no. 49 to 56):
 - **Note:** If your lab files are in a different location, modify the ROOT REPO variable.

Figure 4-9: Setting the Directory Locations

- Defining the host code source files and library directories required for host compilation:
 - The HOST SRC CPP variable defines the host source file(s).
 - The HOST SRC H variable defines the host header file(s).
 - The KERNEL SRC CPP variable defines the kernel source file(s).
 - The KERNEL SRC H variable defines the kernel header file(s).
 - The KERNEL SRC H DIR variable defines the top directory of the source files.

Figure 4-10: Defining the Directories for Host Application and Kernel Source Files

- o Defining the host compiler settings and include libraries:
 - -I: This option is to specify the include directories, such as -I\$XILINX XRT/include -I\$XILINX VIVADO/include.
 - -L: This option is to specify directory searches for -I libraries, such as
 -L\$XILINX XRT/lib.
 - -1: This option is to specify libraries used during linking, such as -lopenCL -lpthread -lrt -lstdc++.
 - ➤ Important: The -lopenCL option indicates that the application is compiled against the OpenCL ICD file.
 - -00: Optimization option (execute the least optimization).
 - -q: Generate debug info.
 - -std=c++1y: Language standard (define the C++ standard instead of the include directory).
 - -L\$XILINX XRT/lib: Look in the XRT library.
 - -lxilinxopencl, -lpthread, -lrt, and -lstdc++: Search the named library during linking.

Figure 4-11: Defining the Compiler Options and Inlcude Libraries

- Defining the Vitis compiler settings and other options:
 - -t: Set the target build configuration (sw emu | hw emu | hw)
 - --config: Provide the configuration file, in this case design.cfg. In this configuration file, you will set the target platform and connectivity information.
 - --temp dir: Used to specify a location to write the intermediate files.
 - --log dir: Used to specify a directory to store log files.

Figure 4-12: Defining the Kernel Compiler and Linker Flags

- Generating the host code and kernel code:
 - Host code compilation:
 - ➤ HOST_EXE provides the name of the host.exe. This host.exe will be generated using the \$HOST SRC CPP and the \$HOST SRC H files.
 - ightharpoonup g++ is the compiler to be used.

This will create a directory with a name of \$ (BUILD_DIR). The compiled and linked files will be under the \$ (BUILD_DIR) directory.

```
# -----
# Host Executable File Generation
# ------
$(BUILD_DIR)/$(HOST_EXE): $(HOST_SRC_CPP) $(HOST_SRC_H)
mkdir -p $(BUILD_DIR)
g++ $(CXXFLAGS) $(HOST_SRC_CPP) $(CXXLDFLAGS) -0 $@
```

Figure 4-13: Building the Host Code Executable

- Kernel code compilation:
 - This is a two-step process: Kernel compilation and linking (v++ compiler command with the -c option and -1 option).

This will create a directory with a name of \$(BUILD_DIR). The compiled and linked files will be under the \$(BUILD_DIR) directory.

Figure 4-14: Building the Kernel Code - XCLBIN

- o Generating the emconfig.json file using the emconfig utility.
 - When software or hardware emulation is run in the command line flow, it is necessary to create an emulation configuration file (emconfig.json) used by the runtime library during emulation. This emulation configuration file defines the device type and quantity of devices to emulate for the specified platform. A single emconfig.json file can be used for both software and hardware emulation.
 - --nd: Optional. Specifies number of devices. The default is 1.
 - --platform: Defines the target device from the specified platform.
 - --od: Optional. Specifies the output directory. When emulation is run, the emconfig.json file must be in the same directory as the host executable. The default is to write the output in the current directory.

Figure 4-15: Generating the emconfig.json File

Reviewing the primary build target:

```
# Primary build targets
# ==> build
# ==> run
          ==> view_run_summary
        # ==> clean
       # Build the design without running host application
       build: $(BUILD_DIR)/$(HOST_EXE) $(BUILD_DIR)/$(XCLBIN) $(BUILD_DIR)/$(EMCONFIG_FILE)
       # Build the design and then run host application
2
        cp xrt.ini $(BUILD_DIR);
ifeq ($(TARGET), hw)
               cd $(BUILD_DIR) && unset XCL_EMULATION_MODE; ./$(HOST_EXE) --kernel_name K_VADD ./$(XCLBIN);
       $(DATA_REPO)/data_1.txt $(DATA_REPO)/data_2.txt;
else ifeq ($(PREBUILT), YES)

cd $(PREBUILT_DIR) && XCL_EMULATION_MODE=$(TARGET) ./$(HOST_EXE) $(PLATFORM_VENDOR) $(PLATFORM) $(XCLBIN)
        $(DATA_REPO)/data_1.txt $(DATA_REPO)/data_2
        endif
        # View profile summary report in Vitis Analyzer GUI
3
       ifeq ($(TARGET), sw_emu)
               cd $(BUILD_DIR) && vitis_analyzer xclbin.run_summary
        ifea ($(PREBUILT), NO)
               cd $(BUILD_DIR) && vitis_analyzer kernels.$(TARGET).xclbin.run_summary
        else ifeq ($(PREBUILT), YES)
cd $(PREBUILT_DIR) && vitis_analyzer kernels.$(TARGET).xclbin.run_summary
        endif
        endif
       # Clean generated files
               rm -rf $(BUILD_DIR)/$(XCLBIN) $(BUILD_DIR)/$(HOST_EXE) $(BUILD_DIR)/$(EMCONFIG_FILE) $(BUILD_DIR)/$(XO_NAME).xi
```

Figure 4-16: Reviewing the Primary Build Targets

1-3-3. Press $\langle \mathbf{Ctrl} + \mathbf{Q} \rangle$ to close the Makefile without saving any modifications.

Running Software Emulation

Step 2

Now that you have reviewed the construction of the Makefile, it is time to compile the code to run software emulation.

The main goal of software emulation is to validate the functional correctness of the design. In this mode the runtime is very fast because both the host code and the kernel code are compiled to run on an x86 processor.

2-1. Compile for software emulation.

2-1-1. Change the directory to where the compiled files will be generated:

[host]\$ cd \$TRAINING PATH/accel cmd flow cloud/lab/makefiles

2-1-2. Enter any one of the following commands to compile the design in software emulation:

```
[host]$ make build [TARGET=sw emu]
```

Note: Any items in the square brackets are optional. In this specific case, since the default value for TARGET is sw_emu , there is no need to explicitly define the TARGET argument. If this is part of a more complex script, providing the explicit setting is valuable from a documentation standpoint.

Note: Ignore any warnings.

A new build directory has been created under the \$TRAINING_PATH/
accel_cmd_flow_cloud/lab directory. Under the build directory, after you have
run a specific type of build (sw_emu, hw_emu, etc.), you will find directories
corresponding to the type of build. Each sub-directory contains the generated files for
that type of build.

Notice that many files are produced. The most important two will be used when running emulation:

- o host.exe (host executable)
- o kernels.sw_emu.xclbin(binary container)

The emconfigutil utility generates the emconfig.json file that contains information about the target device. This file is used during emulation.

The make build calls the host compilation, kernel compilation, and emconfig utility.

```
# Build the design without running host application
build: $(BUILD_DIR)/$(HOST_EXE) $(BUILD_DIR)/$(XCLBIN) $(BUILD_DIR)/$(EMCONFIG_FILE)
```

Figure 4-17: Building the Host Executable, XCLBIN, and emconfig.json File

2-2. Run the software emulation.

2-2-1. Enter the following command to run the application in software emulation mode:

[host]\$ make run

The application should run successfully and produce the following messages:

```
Lainingexhini$ make run
pwd
//home/xilinx/training/accel_cmd flow_cloud/lab/makefiles
cp xtt.ini /home/xilinx/training/accel_cmd flow_cloud/lab/build/sw_emu;
cd /home/xilinx/training/accel_cmd flow_cloud/lab/build/sw_emu;
cd /home/xilinx/training/accel_cmd flow_cloud/lab/build/sw_emu is XCL_EMULATION_MODE=sw_emu ./host.exe Xilinx xilinx_u50_gen3x16_xdma_5_202210_1 kernels.sw_emu.
HOST-Info: Device Name : xilinx u50_gen3x16_xdma_5_202210_1
SOST-Info: Device Name : xilinx u50_gen3x16_xdma_5_202210_1
SOST-Info: Datain_1 File : /home/xilinx/training/accel_cmd flow_cloud/lab/data/data_1.txt
HOST-Info: Datain_1 File : /home/xilinx/training/accel_cmd_flow_cloud/lab/data/data_2.txt

XXT build version: 2.13.466
Build hash: f5505e402c2calffe45eb6d3a9399b23a0dc8776
Build date: 2022-04-14 17:43:11
Git branch: 2022-10
Git branc
```

Figure 4-18: Application Output (Software Emulation)

The make run performs the following:

- o build (host compilation, kernel compilation, and emconfig utility) if it has not already built.
- o Copies the xrt.ini file to \$ (BUILD_DIR), which is required. This file should be placed in the same location where the application is running (host.exe).
- o Sets the XCL EMULATION MODE environment to sw emu.
- Executes the application. In this application, there are the following arguments:

```
./host.exe <PLATFORM_VENDOR> <TARGET_PLATFORM> <XCLBIN>
<.../data/data_1.txt> <.../data/data_2.txt>
```

Figure 4-19: Running the Application

2-3. Analyze the reports using the Vitis analyzer.

2-3-1. Enter the following to see the reports generated for the software emulation:

```
[host]$ ls ../build/sw emu
```

The key files that you will see are:

```
host.exe kernels.sw_emu.xclbin emconfig.json RES.txt xrt.run summary
```

The application generated the RES.txt file that contains the Run Summary report, which is accessible using the Vitis analyzer.

2-3-2. Enter the following command to open the xrt.ini file:

[host]\$ more xrt.ini

Note the presence of the <code>opencl_trace</code> line in the <code>xrt.ini</code> file—this enable the generation of additional reports.

```
[Debug]
opencl_summary=true
opencl_trace=true
data_transfer_trace=fine
[Emulation]
debug mode=batch
```

2-3-3. Open the generated reports for the software emulation run in the Vitis analyzer by entering the following into the terminal:

[host]\$ make view run summary

The Vitis analyzer opens with the Run Summary reports tab visible.



Figure 4-20: Viewing the Run Summary Reports (Software Emulation)

From this page, you will find the following details:

- o Run Summary file location and the emulation mode
- Reports generated during the run are found under xrt (Software Emulation) and include:
 - Profile Summary: Contains statistical data collected during the application run (host and kernels).
 - Timeline Trace: Provides a graphical view of the execution of the different parts of the application.
 - Run Guidance: Not available for software emulation
- **2-3-4.** Select the **Profile Summary** tab under xrt (Software Emulation) to view the Profile Summary report.




Figure 4-21: Viewing the Summary Section of the Profile Summary

This will show the total application runtime and total kernel runtime.



Figure 4-22: Viewing the Kernels and Compute Units

Note: The values may be different for you as they are based on the system configuration.

Observe the kernel execution duration.

2-3-5. Select the Kernel Data Transfers section.

Notice that not all data is available in the report. In the software emulation flow, some of the information is not available in the kernel data transfer area (Top KernelTransfer: Kernels to Global Memory). This information will be available in the hardware emulation and system run flows.

The Profile Summary report has multiple sections that can be selected.

2-3-6. Review each section.

Tab	Description
Settings	Shows the XRT configuration details.
Summary	Displays the total application runtime and total kernel runtime.
	Kernels and global memory. This tab shows a summary of the top operations. It displays the profile data for top data transfers between the device and device memory.
Kernels & Compute Units	Displays the profile data for all kernels, compute units, and kernel data transfers.
Host Data Transfers	Displays the profile data for all read and write transfers between the host and device memory through the PCIe® core link, if enabled.
API Calls	Displays the profile data for all OpenCL C host API function/XRT API calls executed in the host application.

2-3-7. Select the **Timeline Trace** tab to view the Timeline Trace report.

Hint: Zoom in to 32-36 ms to see the activity.




Figure 4-23: Reviewing the Timeline Trace Report (Software Emulation)

You can generate additional reports, such as the Estimate and HLS Synthesis reports. This can be done by setting the Report Type option under Tools > Settings. These reports are generated by default during the hardware emulation flow.

2-3-8. After you have reviewed the report, select **File** > **Exit** close the Vitis analyzer.

17

Running Hardware Emulation

Step 3

While the software emulation flow is a good measure of functional correctness, it does not guarantee the correctness of the device execution target.

The hardware emulation flow checks the correctness of the generated logic. This emulation flow invokes the hardware simulator in the Vitis environment to test the logic functionality. As a consequence, the runtime in the hardware emulation flow is longer than in the software emulation flow.

The hardware emulation flow provides more complete and precise profiling information, allowing you to analyze the application performance and identify the bottlenecks.

Building the hardware emulation in the VirtualBox environment takes approximately 7 minutes to build (based on your system configuration).

If you have time, you can follow step 3-1; otherwise, skip to step 3-2 to use a prebuilt project.

3-1. Compile for hardware emulation.

- **3-1-1.** If you are not already in the makefiles directory, change the directory to makefiles: [host]\$ cd \$TRAINING_PATH/accel_cmd_flow_cloud/lab/makefiles
- **3-1-2.** Enter the following command to compile the design in hardware emulation:

```
[host]$ make build TARGET=hw emu
```

Note: The TARGET=hw_emu is required here as the default is software emulation.

Note: Ignore any warnings. It may take approximately 20-22 minutes (based on your system configuration) to complete the compilation in the VirtualBox environment. Native Linux environments complete within 7-10 minutes.

Under the build directory, you will see one more directory in the name of the target build configuration (hw_emu). You will find all the build files under the hw_emu directory.

Notice that two files should be generated:

- o host.exe (host executable)
- o kernels.hw emu.xclbin (binary container)

The <code>emconfig.json</code> file has also been generated. The <code>emconfigutil</code> utility generates the <code>emconfig.json</code> file, which contains information about the target device. This file is used for the emulation flow.

The make build calls the host compilation, kernel compilation, and emconfig utility.

```
# Build the design without running host application
build: $(BUILD_DIR)/$(HOST_EXE) $(BUILD_DIR)/$(XCLBIN) $(BUILD_DIR)/$(EMCONFIG_FILE)
```

Figure 4-24: Building the Host Executable, XCLBIN, and emconfig.json File

3-2. Run the hardware emulation.

3-2-1. Enter the following command to run the application in hardware emulation mode:

[Own project]: [host] \$ make run TARGET=hw_emu

[Prebuilt project]: [host] \$ make run TARGET=hw emu PREBUILT=YES

If you receive the "Permission denied" message when you run the prebuilt project, change the path to the support directory and change the permission settings by using the chmod command as shown below:

[host]\$ cd \$TRAINING_PATH/accel_cmd_flow_cloud/support/
prebuilt hw emu

[host]\$ chmod 777 host.exe

Change the path back to the makefiles directory and rerun the application for the prebuilt project:

[host]\$ cd \$TRAINING PATH/accel cmd flow cloud/lab/makefiles

You should see that the application runs successfully.

Observe the following messages in the terminal:

```
training@xilinx$ make run TARGET=hw_emu
/home/xilinx/training/commandline_flow/lab/makefiles
cp xrt.ini /home/xilinx/training/commandline_flow/lab//build/hw_emu;
cd /home/xilinx/training/commandline_flow/lab//build/hw_emu &&
XCL_EMULATION_MODE=hw_emu ./host.exe Xilinx xilinx_u50_gen3x16_xdma_201920_3 kernels.hw_emu.xclbin /home/xilinx/training/commandline_flow/lab/data/data_1.txt
/home/xilinx/training/commandline_flow/lab/data/data_2.txt;
HOST-Info: Platform Vendor : Xilinx
                        : xilinx_u50_gen3x16_xdma_201920_3
HOST-Info: Device_Name
HOST-Info: XCLBIN_file
                          : kernels.hw_emu.xclbin
HOST-Info: DataIn 1 File
/home/xilinx/training/commandline_flow/lab/data/data_1.txt
HOST-Info: DataIn_2_File :
/home/xilinx/training/commandline_flow/lab/data/data_2.txt
INFO: [HW-EM 01] Hardware emulation runs simulation underneath. Using a large data
set will result in long simulation times. It is recommended that a small dataset is
used for faster execution. The flow uses approximate models for DDR memory and
interconnect and hence the performance data generated is approximate.
HOST-Info: Reading Input data from the
/home/xilinx/training/commandline_flow/lab/data/data_1.txt file ... Read 1024
HOST-Info: Reading Input data from the
/home/xilinx/training/commandline_flow/lab/data/data_2.txt file ... Read 1024
values
HOST-Info: Executing Kernel .
HOST-Info: The Output Result file: RES.txt
Host-Info: Verifying final results (only failed tests are printed)
Host-Info: ==
Host-Info: Test Successful
INFO::[ Vitis-EM 22 ] [Time elapsed: 0 minute(s) 39 seconds, Emulation time:
0.023303 ms]
Data transfer between kernel(s) and global memory(s)
WR = 4.000 KB
INFO: [HW-EMU 06-1] All the simulator processes exited successfully
HOST-Info: DONE
```

Figure 4-25: Application Output (Hardware Emulation)

The make run TARGET=hw emu performs the following:

- build (host compilation, kernel compilation, and emconfig utility) if it has not already built.
- Copies the xrt.ini file to \$ (BUILD_DIR), which is required if you have built the project yourself. This file should be placed in the same location where the application is running (host.exe).
- o Sets the XCL EMULATION MODE environment to hw emu.
- Execute the application using the following arguments:
 - ./host.exe <PLATFORM_VENDOR> Online Portal <XCLBIN>
 <../data/data_1.txt> <../data/data_2.txt>

```
# Build the design and then run host application
run: build
    pwd
        cp xrt.ini $(BUILD_DIR);
ifeq ($(TARGET), hw)
        cd $(BUILD_DIR) && unset XCL_EMULATION_MODE; ./$(HOST_EXE) --kernel_name K_VADD ./$(XCLBIN);
else
        cd $(BUILD_DIR) && XCL_EMULATION_MODE=$(TARGET) ./$(HOST_EXE) $(PLATFORM_VENDOR) $(PLATFORM) $(XCLBIN)
$(DATA_REPO)/data_1.txt $(DATA_REPO)/data_2.txt;
endif
```

Figure 4-26: Running the Application

3-3. Analyze the reports using the Vitis analyzer.

3-3-1. Enter the following to see the reports generated for the hardware emulation if you have built the project yourself; otherwise, skip to the next instruction:

```
[host]$ ls ../build/hw emu
```

You will see the generated files including the following key files:

```
host.exe kernels.hw_emu.xclbin emconfig.json RES.txt xrt.run summary
```

The application generated the RES.txt file. You will open the Run Summary report files using the Vitis analyzer.

The Run Summary report is created by the XRT library during the application execution and provides a summary of the run process. When the Run Summary report is viewed, the tool references the following reports generated during the application run:

- System Diagram
- Platform Diagram
- o Run Guidance
- Profile Summary
- Waveform
- Timeline Trace
- **3-3-2.** Enter the following command to view the Run Summary report of the application in hardware emulation mode:

[Own project]: [host] \$ make view run summary TARGET=hw emu

[Prebuilt project]: [host] \$ make view_run_summary TARGET=hw_emu PREBUILT=YES

3-3-3. Click the **Expand All** icon (\Rightarrow) to see all the available reports.

You should now see that the Vitis analyzer opens with the Run Summary reports.




Figure 4-27: Viewing the Run Summary Reports (Hardware Emulation)

The Run Summary page shows the following details:

- Run Summary file location and the emulation mode
- Additional reports are found the left pane, under xrt—all the reports generated during the application run are available:
 - Profile Summary: Contains statistical data collected during the application run (host and kernels).
 - Timeline Trace: Provides a graphical view of the execution of the different parts of the application.
- **3-3-4.** Select the **Profile Summary** tab under xrt (Hardware Emulation) to view the Profile Summary report.
- **3-3-5.** Click the **Kernels & Compute Units** section as shown below.




Figure 4-28: Reviewing the Profile Summary Report (Hardware Emulation)

Observe the following information:

- o Kernel duration: Estimated kernel duration for the hardware emulation flow.
 - The same information can be found in the Kernel Execution and Top Kernel Execution sections under Kernels & Compute Units.

3-3-6. Click the **Timeline Trace** entry under xrt (Hardware Emulation) to view the Timeline Trace report.

Hint: Zoom in on 17-19 s.




Figure 4-29: Reviewing the Timeline Trace Report (Hardware Emulation)

The Timeline Trace view contains the data transfer information that was missing in software emulation.

3-3-7. Select the **Waveform** tab under xrt (Hardware Emulation) to view the waveform.

Hint: Zoom in on 175-185 us.




Figure 4-30: Viewing the Waveform

This will show the kernel RTL waveform, which helps with debugging the kernel.

[Prebuilt project]: Skip to step 3-3-10.

3-3-8. Select **File > Open Summary**.

[Own project]: Browse to \$TRAINING_PATH/accel_cmd_flow_cloud/lab/build/hw_emu and select kernels.hw_emu.xclbin.link_summary.

[Prebuilt project]: Skip to step 3-3-10.

3-3-9. Click **Open** to open this group of reports.




Figure 4-31: Viewing the Link Summary Reports

3-3-10. Select the **System Estimate** tab under kernels.hw_emu (Hardware Emulation) to view the System Estimate report.




Figure 4-32: Reviewing the System Estimate Report

The System Estimate report provides information on every binary container in the application and every compute unit in the design, such as timing information, latency information, and the area to be used by a compute unit on the target device.

3-3-11. Select **File** > **Exit** to close the Vitis analyzer.

3-4. For more detailed analysis of the kernel, view the RTL waveform for the kernel in Vivado simulator.

Change the debug_mode option to display the waveform generation for the kernel in the xrt.ini file.

The Vitis IDE provides waveform-based HDL debugging in the hardware emulation mode. The waveform is opened in the Vivado waveform viewer, which should be familiar to Vivado logic simulation users.

The Vivado simulator lets you display kernel interfaces, internal signals, and includes debug controls such as restart, HDL breakpoints, as well as HDL code lookup and waveform markers. In addition, it provides top-level DDR data transfers (per bank) along with kernel-specific details including compute unit stalls, loop pipeline activity, and data transfers.

3-4-1. Enter the following command to open the xrt.ini file:

[Own project]:[host] \$ gedit \$TRAINING_PATH/accel_cmd_flow_cloud/lab/makefiles/xrt.ini

Note: You should already be in the makefiles directory, so only **gedit xrt.ini** is required.

[Prebuilt project]: [host] \$ gedit \$TRAINING_PATH/accel_cmd_flow_cloud/support/prebuilt hw emu/xrt.ini

3-4-2. Below the line that reads [Emulation], modify the debug_mode entry from batch to guito enable the waveform generation:

[Emulation]

debug mode=gui

With the debug_mode=gui option set, a live waveform viewer will be launched when the application is run.

If the live waveform viewer is activated, the waveform viewer automatically opens when the executable is run. By default, the waveform viewer shows all interface signals and the debug hierarchy.

- **3-4-3.** Press **<Ctrl** + **S>** to save the file.
- **3-4-4.** Press **<Ctrl** + **Q>** to close the editor.

3-5. Run the hardware emulation and view the waveform in the Vivado Design Suite GUI.

3-5-1. Enter the following command to run the application in hardware emulation mode:

[Own project]:[host]\$ make run TARGET=hw emu

[Prebuilt project]:[host]\$ make run TARGET=hw emu PREBUILT=YES

It takes a few minutes to launch the Vivado simulator. You should see a waveform similar to what is shown below.

During the execution, the Vivado Design Suite GUI will automatically open with a kernel RTL waveform. You may have to click the **Zoom Fit** icon () in the horizontal toolbar to view the waveform. You will need to zoom in on the activity to see details.




Figure 4-33: Reviewing the Waveform for Kernel Analysis

This is same as you viewed the Waveform in the step 3-3-6.

- **3-5-2.** After you are finished reviewing the waveform, select **File** > **Exit** to close the Vivado Design Suite.
- **3-5-3.** Click **OK** to exit.

3-6. Analyze the HLS report to understand the kernel performance and area usage.

The generated HLS report will be available under the

reports/<KERNAL NAME>.hw.emu directory.

3-6-1. Enter the following command to open the HLS synthesis report:

[Own project]: [host] \$ gedit ../build/hw_emu/reports/K_VADD.hw_emu/hls reports/K_VADD csynth.rpt

[Prebuilt project]: [host]\$ gedit \$TRAINING_PATH/accel_cmd_flow_cloud/ support/prebuilt hw emu/K VADD csynth.rpt

- **3-6-2.** Review the Vitis HLS Synthesis report, which helps for detailed kernel performance/area analysis.
- **3-6-3.** After you are finished reviewing the report, close the editor.

Note that you can also view this report by using

kernels.hw_emu.xclbin.link_summary, which is available under the TARGET build directory.

Known issue: From the Vitis analyzer, this report does not open.

Reviewing the Hardware Deployment

Step 4

Building the design targeting physical hardware (not emulated hardware) takes about three hours.

Do not execute the next three instructions! Review these instructions only.

4-1. Only review the steps below on how to build the design in a system configuration and run it on a board.

4-1-1. Enter the following command to compile the design in hardware emulation:

[host]\$ make build TARGET=hw

Note: Ignore the warnings. It may take approximately 4-5 hrs (based on your system configuration) to complete the compilation in the VirtualBox environment.

Under the build directory, you will see one more directory in the name of the target build configuration (hw). You will find all the build files under the hw directory.

Notice that two files should be generated:

- o host.exe (host executable)
- o kernels.hw.xclbin (binary container)

The <code>emconfig.json</code> file has also been generated. The <code>emconfigutil</code> utility generates the <code>emconfig.json</code> file, which contains information about the target device. This file is used for the emulation flow.

The make build calls the host compilation, kernel compilation and emconfig utility.

```
# Build the design without running host application
build: $(BUILD_DIR)/$(HOST_EXE) $(BUILD_DIR)/$(XCLBIN) $(BUILD_DIR)/$(EMCONFIG_FILE)
```

Figure 4-34: Building the Host Executable, XCLBIN, and emconfig.json File

4-2. Run the application on the board.

4-2-1. Enter the following command to run the application on hardware:

[host]\$ make run TARGET=hw

```
# Build the design and then run host application
run: build

pwd

cp xrt.ini $(BUILD_DIR);

ifeq ($(TARGET), hw)

cd $(BUILD_DIR) && unset XCL_EMULATION_MODE; ./$(HOST_EXE) --kernel_name K_VADD ./$(XCLBIN);

hw RUN

else

cd $(BUILD_DIR) && XCL_EMULATION_MODE=$(TARGET) ./$(HOST_EXE) $(PLATFORM_VENDOR) $(PLATFORM) $(XCLBIN)
$(DATA_REPO)/data_1.txt $(DATA_REPO)/data_2.txt;
endif
```

Figure 4-35: Running in Hardware Emulation

While running the application in hardware mode, make sure the XCL_EMULATION_MODE environment variable should be unset.

You should see that the application runs successfully.

4-3. Analyze the reports using the Vitis analyzer.

4-3-1. Enter the following command to see the reports generated for the hardware run:

```
[host] $ ls ../build/hw
```

You should see some of the following files:

```
host.exe kernels.hw.xclbin emconfig.json RES.txt xrt.run summary
```

4-3-2. Enter the following command to run the application in hardware mode:

```
[host]$ make view run summary TARGET=hw
```

You should now see that Vitis analyzer opens with the Run Summary reports.

To see the system estimate reports, run the Vitis analyzer with the Link Summary report. This will give the actual resource usage and the performance of the system.

- **4-3-3.** Select **File** > **Exit** to close the Vitis analyzer.
- **4-3-4.** Enter **exit** to close the terminal window.

VM users: Proceed with the following to free used memory:

4-4. Clean up the VirtualBox file system.

4-4-1. Enter the following command to delete the contents of the workspace:

```
[host]$ rm -rf $TRAINING PATH/accel cmd flow cloud
```

This will recursively delete all of the files in the \$TRAINING_PATH/accel_cmd_flow_cloud directory.

Summary

In this lab you have learned how to run and analyze design from the Vitis command line with a makefile.