# mShield expansion board for Microbit


## **Table of Contents**

1. Overview	2
2. Specification parameter	3
3. Interface specification	4
4. MakeCode Extension for mShield	5
4.1 Add mShield extension	5
4.2 Refresh mShield extension	6
4.3 Parsing of mShield extension statement	7
5. Example code	9
5.1 Firmware version	9
5.2 LEDs	. 10
5.3 IR receiver	11
5.4 PWM	. 13
5.5 Battery voltage	.14
5.6 Motors	.15
5.7 180 degree Servo	. 18
5.8.360 degree Servo	10

## 1. Overview

The mShield expansion board is an easy to use micro:bit shield, integrating powerful features such as dual motor drivers, infrared reception, battery level reading, four servo drivers, four PWM signal outputs, LED indicators, and optional 3V or 5V power output.


The board extends the commonly used pins of the micro:bit in the form of pin headers, allowing for the connection of additional sensors. It supports two types of multi-cell batteries and includes a micro USB port for external power banks, enhancing power adaptability and safety. To facilitate installation on other devices, the expansion board is equipped with four 4MM mounting holes, which are also compatible with universal building blocks, making it highly convenient for use in building block projects.



# 2. Specification parameter

Shield			
Name	mShield expansion board for Microbit		
SKU	M1E0002		
USB connector	Applicable motherboard		
Micro USB	Micro:bit		
Pins			
Digital I/O Pins	9 (P0, P1, P2, P8, P9, P13, P14, P15, P16)		
Analog read pins	3 (P0, P1, P2)		
Analog write pins	9 (P0, P1, P2, P8, P9, P13, P14, P15, P16)		
PWM pins	4 (S1~, S2~, S3~, S4~), period: 2ms.		
Servo pins	4 (S1~, S2~, S3~, S4~)		
Communication			
UART	Yes		
I2C	Yes		
SPI	Yes		
IR receiver	Yes (NEC)		
Power			
Input voltage (nominal)	39V		
DC Current for 3.3V Pin	500 mA		
DC Current for 5V Pin	2000 mA		
Motors			
Connectors	Motor1, Motor2 (XH2.54 2P)		
Output voltage	39V		
LEDs			
Number	4 (20%, 40%, 60%, 80%)		
Dimensions			
Width	62 mm		
Length	73 mm		
Height	14mm		
Weight	29.16 g		

# 3. Interface specification



Number	Description
1	Micro USB port, only used for external power supply(5V)
2	Infrared receiver, using P12 pin
3	Micro:bit slot
4	LED Indicator, controlled by an internal I2C chip.
5	Power socket, accepts input voltage of 3-9V, can be connected to 3, 4, 5, or 6 AA batteries, or 1 or 2 lithium batteries, with reverse connection protection
6	Power socket switch
7、8	Motor interface, can connect to 3-9V DC motors, the motor voltage equals the power socket voltage. Controlled by an internal I2C chip
9、10	V1 and V2 pin header output voltage selection switch
11、12	Microbit IO expansion port
13	mShield internal expansion por, controlled by an internal I2C chip.
14	3.3V power I2C interface,P19(SCL), P20(SDA)。
15	5V power I2C interface, P19(SCL), P20(SDA)。


## 4. MakeCode Extension for mShield

We have developed an extension for mShield expansion board, which makes it easier for us to use MakeCode to program mShield.

### 4.1 Add mShield extension

The steps to add the extension to the Makecode are as follows:


Click the **Settings** button in the upper right corner of the interface and click **"Extensions"** 




Extension link for mShield: https://github.com/siyeenove/pxt\_mshield

Copy the above link into the search box on the extension page and click the search button on the right.

Click on the extension named mshield in the search results.




After a few seconds the page will jump to the Makecode main interface, and you will see the added **mShield** extension in the toolbox list.



### 4.2 Refresh mShield extension


Open the project with the mCar extension added, and switch to the JavaScript programming interface to refresh the extension:




After refreshing, switch back to the "Blocks" interface.

## 4.3 Parsing of mShield extension statement

All Makecode statements based on mShield are integrated in the mShield extension package. The statement analysis is as follows:





## 5. Example code


All sample codes are saved in the "sample code" folder.



sample code

## 5.1 Firmware version

#### Prepare:



### Wiring:

Insert the Micro:bit V2 into the mShield expansion board with the LED matrix facing upwards, then connect the Micro:bit V2 to the computer using a USB cable.



### Code:




#### Result:

The mShield expansion board integrates an 8-bit microcontroller for driving motors, LEDs and S1-S4 ports. We have burned the firmware into it before leaving the factory. Through the above code, you can read the firmware version and display the version number in the microbit LED dot matrix.


### **5.2 LEDs**

#### Prepare:




#### Wiring:

Insert the Micro:bit V2 into the mShield expansion board with the LED matrix facing upwards, then connect the Micro:bit V2 to the computer using a USB cable.



### Code:




### Result:

It will cycle through lighting each LED.


## 5.3 IR receiver

## Prepare:



### Wiring:

Insert the Micro:bit V2 into the mShield expansion board with the LED matrix facing upwards, then connect the Micro:bit V2 to the computer using a USB cable.



### Code:



#### Result:

Point the remote control at the infrared receiver sensor on the expansion board and press any key; the corresponding key value will be displayed on the Micro:bit's LED matrix.


## **5.4 PWM**

### Prepare:

PC	Micro:bit V2.x.x	USB cable	LED
1K resistor	Female-to-female Dupont wires		
-(1111)-			

### Wiring:

## Connect to computer with usb cable



### Code:



### Result:

The S1, S2, S3, and S4 pins output PWM signals with duty cycles of 20%, 40%, 60%, and 80% respectively, resulting in the following LED brightness levels: LED1 < LED2 < LED3 < LED4.

## 5.5 Battery voltage

### Prepare:



### Wiring:

Insert the Micro:bit V2 into the mShield expansion board with the LED matrix facing upwards, then connect the Micro:bit V2 to the computer using a USB cable.

Connect an external DC 3-9V power supply to the shield and turn on its power switch.



#### Code:



#### Result:


When the mShield is connected to three AA batteries in series, the micro:bit can read the voltage ratio of the batteries (0-100%) and display this value on the micro:bit LED matrix.

## 5.6 Motors

## Prepare:

PC	Micro:bit V2.x.x	USB cable	
3xAA battery power			

## Wiring::



### Code1:

```
on start

forever

set all motors ▼ clockwise ▼ speed 100 %

pause (ms) 1000 ▼

set all motors ▼ to stop

pause (ms) 1000 ▼


set all motors ▼ counterclockwise ▼ speed 100 %

pause (ms) 1000 ▼

set all motors ▼ to stop

pause (ms) 1000 ▼
```

#### Code2:



The results of these two codes are the same:

When external motors are connected to the Motor1 and Motor2 interfaces, Motor 1 and Motor 2 will first rotate clockwise for 1 second, then stop for 1 second; next, they will rotate counterclockwise for 1 second, and then stop for 1 second, repeating this cycle continuously.

#### Additional:


If, due to hardware differences in the motors, the two motors connected to the expansion board's motor interfaces have varying speeds despite being given the same speed value, we can address this discrepancy using the following statements. The compensated speed parameters can then be permanently saved in the mShield.




Motor speed compensation is achieved by reducing the speed of one motor to align the speeds of both motors. The compensation value ranges from -10 to 0. This statement only needs to be executed once during program runtime to permanently save the compensated speed parameters in the mShield. Subsequent code implementations do not require the inclusion of this statement unless further adjustments to the motor compensation speed are desired.

## 5.7 180 degree Servo

## Wiring:



### Code:




#### Result:

When the S1, S2, S3, and S4 pins are connected to an external 180-degree servo, the servo swings between 0 and 180 degrees at intervals of 1 second.


Note: The usage of a 90-degree servo is similar to the above code.

## 5.8 360 degree Servo

### Wiring:



#### Code:



## Result:

When the S1, S2, S3, and S4 pins are connected to an external 360-degree servo, the servo will rotate forward and reverse at the maximum speed at an interval of 1 second.

## 6.Contact us

If you encounter technical problems or want to share your ideas and opinions with us, please contact us at any time.



