

The size of materials

board size=Rear board width(Cabinet width-85mm)*Rea rboard height (P=68mm/G=127mmGH=180mm)*16mm rd size=Bottom board width(Cabinet width-75mm)* Bottom board length(Size) -8mm Rei Bo!


n Illustration Instalia


- * Simple and precise adjustment on front panel Tune plastic philip's screw in front fixing braket for ±3mm left/right movement on front panel
- * Efficient and swift drawer put-in & take-out When drawer put-in, box on glides and move backward for self block; Lift box upward for drawer take-out.

Demonstration of the type(mm)

	Size	Min Cabinet Length	Drawer Height
Туре	1	320mm	83mm
P300	300mm	370mm	83mm
P350	350mm		83mm
P400	400mm	420mm	83mm
F150	450mm	470mm	
P50	500mm	520mm	83mm
P550	550mm	570mm	142mm
G300	300mm	320mm	142mm
G351	350mm	370mm	142mm
G4C	400mm	420mm	142mm
G	10mm	470mm	142mm
1	8 3	520mm	142mm
G	Side nm Sar Connectate Ses mark Co.	570mm	142mm

Slie installation size of hole(mm)





Take out front fixing braket and fix to inner front panel side with two M3.5*12 self tapping screws Installation Illustration

Turn Philip's screw clockwise to release front fixing braket, unscrew the * Front panel disassembly braket from the panel

Installation Steps▶▶

