Chapter 6 Exercises: Architecture

Kyle Swanson

April 16, 2015

Exercise 6.4 - Repeat Exercise 6.3 for memory storage of a 32-bit word stored at memory word 15 in a byte-addressable memory.

a) What is the byte address of memory word 15?

$$15 \times 4 = 15 \times 2^2 = 1111 << 2$$

$$= 111100 = 0x3C$$


b) What are the byte address that memory word 15 spans?

0x3Cto111100 + 11

$$= 1111111 = 0x3F$$

0x3Cto0x3F

c) Draw the number 0xFF223344 stored at word 15 in both big-endian and little-endian machines. Your drawing should be similar to Figure 6.4. Clearly label the byte address corresponding to each data byte value.



Exercise 6.10 - Convert the following MIPS assembly code into machine language. Write the instructions in hexadecimal.

add \$t0, \$s0, \$s1

This is an R-type instruction. Add

opcode = 000000

rs = \$s0 = 16 = 10000

rt = \$s1 = 17 = 10001

rd = \$t0 = 8 = 01000

shamt = 00000

func = add = 100000

Put it together:

000000 10000 10001 01000 00000 100000

= 0x2114020

lw \$t0, 0x20(\$t7)

This is a I-type instruction. Load Word - lw rt, imm(rs)

opcode = 100011

rs = \$t7 = 15 = 01111

rt = \$t0 = 8 = 01000

imm = 0x20 = 000000000100000

Put it together:

 $100011\ 01111\ 01000\ 0000000000100000$

= 0x8DE80020

addi \$s0, \$0, -10

This is a I-type instruction. Add Immediate - addi rt, rs, imm

```
opcode = 001000
rs = 00000
rt = 16 = 10000
Put it together:
= 0x2010FFF6
Exercise 6.12 - Consider I-type instructions.
a) Which instructions from Exercise 6.10 are I-type instructions?
addi and lw are both I-type.
b) Sign-extend the 16-bit immediate of each instruction from part (a) so that it becomes a 32bit number.
lw immediate = 0000000000100000
Exercise 6.14 - Do not complete the reverse engineering. Do not explain function. Just
convert.
I-type
opcode = 001000 = addi
rs = 00000 = $0
rt = 01000 = $t0
addi $t0, $0, 0
I-type
opcode = 001000 = addi
rs = 00000 = $0
rt = 01001 = 9 = $t1
imm = 0000000000000001 = 1
addi $t1, $0, 1
0 \times 0089502 A = 000000 \ 00100 \ 01001 \ 01010 \ 00000 \ 101010
R-type
opcode = 000000
rs = 00100 = 4 = $a0
rt = 01001 = 9 = $t1
rd = 01010 = 10 = $t2
shamt = 00000 = 0
func = 101010 = slt
slt $t2, $a0, $t1
```

```
I-type
opcode = 000101 = bne
rs = 01010 = 10 = $t2
rt = 00000 = $0
imm = 000000000000011 = 3 = 0x3
bne $t2, $0, 0x3
0 \times 01094020 = 000000 \ 01000 \ 01001 \ 01000 \ 00000 \ 100000
R-type
opcode = 000000
rs = 01000 = 8 = $t0
rt = 01001 = 9 = $t1
rd = 01000 = 8 = $t0
shamt = 00000 = 0
func = 100000 = add
add $t0, $t0, $t1
I-type
opcode = 001000 = addi
rs = 01001 = 9 = $t1
rt = 01001 = 9 = $t1
imm = 0000000000000010 = 2
addi $t1, $t1, 2
opcode = 000010 = j
j 0x100002
0 \times 01001020 = 000000 \ 01000 \ 00000 \ 00010 \ 00000 \ 100000
R-type
opcode = 000000
rs = 01000 = 8 = $t0
rt = 00000 = 0 = $0
rd = 00010 = 2 = v1
shamt = 00000 = 0
func = 100000 = add
add $v1, $t0, $0
0x03E00008 = 000000 11111 00000 00000 00000 001000
R-type
R-type = opcode, rs, rt, rd, shamt, func opcode = 000000
rs = 11111 = 31 = ra
rt = 00000 = 0 = $0
rd = 00000 = 0 = $0
shamt = 00000 = 0 = $0
func = 001000 = jr
```

Exercise 6.16 - The nori instruction is not part of the MIPS instruction set, because the same functionality can be implemented using existing functions. Write a short assembly code snippet that has the following functionality: \$t0 = \$t1 NOR 0xF234. Use as few instructions as possible.

ARM Assignment Portion

Please excuse the use of 'to denote a comment about the assembly code. It seemed like the most clear/obvious way.

```
1 - If
```

```
int main() {
    int counter = 0;

    if (counter == 1) {
        counter = 10;
    }

    return 0;
}
```

A C language If loop.

main:

```
0x7a: 0x2000
                      MOVS
                                 R0, #0
0x7c: 0x2801
                      CMP
                                 R0, #1
^^ Compare the counter to 1.
0x7e: 0xd100
                      BNE.N
                                 ??main_0
                                                            0x82
^^ Skip the if, if these are not equal. Branch to ??main_0 ^^
0x80: 0x200a
                      MOVS
                                 R0. #10
                                                           ; \theta xa
\hat{if} (counter = 1) do this line.
0x82: 0x2000
                      MOVS
                                 R0, #0
^^ Put 0 into the return register.
```

LR

A Assembler If loop

BX

2 - If Else

 $??main_0:$

0x84: 0x4770

```
main:
         0x82: 0x2000
                                MOVS
                                           R0, #0
         0x84: 0x2801
                                           R0, #1
                                CMP
          ^^ Compare counter to 1. The if statement.
         0x86: 0xd101
                                BNE.N
                                           0x8c
          ^^ if counter isnt equal to 1. Go to the else. ^^
         0x88: 0x200a
                                MOVS
                                           R0, #10
                                                                      ; 0xa
                                           1 ^^
          ^^ Set counter to 10 if it was
         0x8a: 0xe000
                                B.N
                                           0x8e
         0x8c: 0x2014
                                MOVS
                                           R0, #20
                                                     ; 0x14
          ^^ This is the else portion.
         0x8e: 0x2000
                                MOVS
                                           R0, #0
         0x90: 0x4770
                                BX
                                           LR
                                A If Else in Assembler
3 - Switch Case
int main() {
    int counter = 0;
    int a = 0;
    while (1) {
        switch (counter) {
                 case 0:
                     a = 1;
                     break;
        case 1:
                     a = 2;
                 case 2:
                     a = 3;
                     break;
                 default:
                     return 0;
        counter++;
    }
}
                             A Switch Case in C Language
main:
         0x40: 0x2000
                                           R0, #0
                                MOVS
                                           R1, #0
         0x42: 0x2100
                                MOVS
          ^^ Set the counter and a ^^
         0x44: 0xe001
                                B.N
                                           ??main_0
                                                                      ; 0x4a
??main_1:
                                MOVS
         0x46: 0x2101
                                           R1, #1
??main_2:
```

ADDS

R0, R0, #1

0x48: 0x1c40

```
??main_0:
                                        R0, #0
         0x4a: 0x2800
                              CMP
         \hat{} See if counter = 0. The first Case \hat{}
         0x4c: 0xd0fb
                              BEQ.N
                                         ??main_1
                                                                  ; 0x46
         0x4e: 0x2802
                              CMP
                                        R0, #2
         \hat{} see if counter = 2. The case 2. \hat{}
         0x50: 0xd001
                              BEQ.N
                                         ??main_3
                                                                   0x56
         0x52: 0xd202
                              BCS.N
                                         ??main_4
                                                                  : 0x5a
??main_5:
                                        R1, #2
         0x54: 0x2102
                              MOVS
??main_3:
         0x56: 0x2103
                              MOVS
                                        R1, #3
                                         ??main_2
         0x58: 0xe7f6
                              B.N
                                                                  ; 0x48
?? main_4:
         0x5a: 0x2000
                                        R0, #0
                              MOVS
         0x5c: 0x4770
                              BX
                                        LRs
                            A Switch Case in Assembler
4 - While
int main() {
    int counter = 0;
    while (counter < 10) {
        ++counter;
    return 0;
}
                           A While loop in the C language
main:
         0x82: 0x2000
                              MOVS
                                        R0, #0
         ^^ Set counter to 0 ^^
         0x84: 0xe000
                              B.N
                                         0x88
                                        Go to 0x88 ^^
         ^^ Skip this next instruction.
         0x86: 0x1c40
                                        R0, R0, #1
                              ADDS
         0x88: 0x280a
                              CMP
                                        R0, #10
                                                                  ; 0xa
         \hat{if} counter = 10 \hat{if}
         0x8a: 0xdbfc
                              BLT.N
                                        0x86
         ^^ if it 's_less_than,_go_to_0x86._This_is_the_while._^^
____0x8e:_0x4770____BX____LR
```

A While loop in Assembler

5 - For

```
int main() {
    int counter = 0;
    for (int i=0; i<10; i++) {
         counter++;
    return 0;
}
                             A For Loop in the C Language
main:
          0x7a: 0x2000
                                 MOVS
                                            R0, #0
          0x7c: 0x2100
                                            R1, #0
                                 MOVS
          ^^ Set counter and i to 0 ^^
          0x7e: 0xe001
                                 B.N
                                            ??main_0
                                                                       ; 0x84
??main_1:
          0x80: 0x1c40
                                 ADDS
                                            R0, R0, #1
          0x82: 0x1c49
                                 ADDS
                                            R1, R1, #1
          ^^ Increment both i and counter
??main_0:
          0x84: 0x290a
                                            R1, #10
                                 CMP
                                                                        \theta xa
          \hat{if} i is 10.
          0x86: 0xdbfb
                                 BLT.N
                                            ??main_1
                                                                         0x80
          ^^ If its less than, go back up. This is the for loop
                                            R0, #0
          0x88: 0x2000
                                 MOVS
          0x8a: 0x4770
                                 BX
                                            LR
                               A For Loop in Assembler
6 - Array
int main() {
    int volatile array [5];
    for (int i=0; i < 5; i++) {
         \operatorname{array}[i] = i;
    }
    return 0;
}
                               An array in the C language
main:
                                 SUB
          0x82: 0xb085
                                            SP, SP, #0x14
          ^^ Allocate the array ^^
          0x84: 0x2000
                                 MOVS
                                            R0, #0
          0x86: 0xe003
                                 B.N
                                            0x90
          0x88: 0xa900
                                 ADD
                                            R1, SP, \#0x0
          0x8a: 0xf841 0x0020
                                 STR.W
                                            R0, [R1, R0, LSL #2]
```

```
0x8e: 0x1c40
                      ADDS
                                R0, R0, #1
0x90: 0x2805
                      CMP
                                R0, #5
0x92: 0xdbf9
                      BLT.N
                                 0x88
0x94: 0x2000
                      MOVS
                                R0, #0
                                SP, SP, \#0x14
0x96: 0xb005
                      ADD
^^ Overwrite the array? ^^
0x98: 0x4770
                      BX
                                LR
```

An array in Assembler

7 - Function Call

```
int main() {
    int counter = 0;
    int a = 1;
    int b = 2:
    int c = 3;
    int d = 4;
    int e = 5;
    int f = 6;
    while (counter < 5) {
        ++counter;
        int added = sum(counter, a, b, c, d, e, f);
    }
    return 0;
}
int sum(int counter, int a, int b, int c, int d, int e, int f) {
    int sum = counter + a + b + c + d + e + f;
    return sum;
}
```

A selection of the vector table values.

```
main:
```

```
0x40: 0xe92d 0x47f0
                                           \{R4-R10, LR\}
                               PUSH.W
         0x44: 0xb084
                               SUB
                                          SP, SP, #0x10
         0x46: 0x2400
                               MOVS
                                          R4, #0
         0x48: 0x2501
                               MOVS
                                          R5, #1
         0x4a: 0x2602
                               MOVS
                                          R6, #2
                                          R7, #3
         0x4c: 0x2703
                               MOVS
                                          R8, #4
         0x4e: 0xf05f 0x0804
                               MOVS.W
                                          R9, #5
         0x52: 0xf05f 0x0905
                               MOVS.W
                                          R10, #6
         0x56: 0xf05f 0x0a06
                               MOVS.W
         0x5a: 0xe00c
                                                                    ; 0x76
                                B.N
                                           ??main_0
??main_1:
         0x5c: 0x1c64
                                ADDS
                                          R4, R4, #1
         0x5e: 0xf8cd 0xa008
                               STR.W
                                          R10, [SP, \#0x8]
         0x62: 0xf8cd 0x9004
                                STR.W
                                          R9, [SP, \#0x4]
```

R8, [**SP**]

STR.W

0x66: 0xf8cd 0x8000

$0 \times 003 b$	MOVS	R3, R7	
0x0032	MOVS	R2, R6	
0x0029	MOVS	R1, R5	
0x0020	MOVS	R0, R4	
0 x f 0 0 0 0 x f 8 0 6	BL	sum	; $0x82$
0x2c05	CMP	R4, #5	
$0 \times dbf0$	BLT.N	??main_1	; $0x5c$
0x2000	MOVS	R0, #0	
0xb004	ADD	$\mathbf{SP}, \ \mathbf{SP}, \ \#0\mathbf{x}10$	
0xe8bd 0x87f0	POP.W	$\{R4-R10, PC\}$	
0x1808	ADDS	R0, $R1$, $R0$	
0x1810	ADDS	R0, $R2$, $R0$	
0x1818	ADDS	R0, R3, R0	
0x9900	LDR	R1, [SP]	
0x1808	ADDS	R0, $R1$, $R0$	
0x9901	LDR	R1, $[SP, \#0x4]$	
0x1808	ADDS	R0, $R1$, $R0$	
0x9902	LDR	R1, $[SP, \#0x8]$	
0x1808	ADDS	R0, $R1$, $R0$	
0x4770	$\mathbf{B}\mathbf{X}$	LR	
	0x0032 0x0029 0x0020 0xf000 0xf806 0x2c05 0xdbf0 0x2000 0xb004 0xe8bd 0x87f0 0x1808 0x1810 0x1818 0x9900 0x1808 0x9901 0x1808 0x9901 0x1808 0x9902 0x1808	0x0032 MOVS 0x0029 MOVS 0x0020 MOVS 0xf000 0xf806 BL 0x2c05 CMP 0xdbf0 BLT.N 0x2000 MOVS 0xb004 ADD 0xe8bd 0x87f0 POP.W 0x1808 ADDS 0x1818 ADDS 0x1818 ADDS 0x1808 ADDS	0x0032 MOVS R2, R6 0x0029 MOVS R1, R5 0x0020 MOVS R0, R4 0xf000 0xf806 BL sum 0x2c05 CMP R4, #5 0xdbf0 BLT.N ??main_1 0x2000 MOVS R0, #0 0xb004 ADD SP, SP, #0x10 0xe8bd 0x87f0 POP.W {R4-R10, PC} 0x1808 ADDS R0, R1, R0 0x1810 ADDS R0, R2, R0 0x1818 ADDS R0, R3, R0 0x9900 LDR R1, [SP] 0x1808 ADDS R0, R1, R0 0x9901 LDR R1, [SP, #0x4] 0x1808 ADDS R0, R1, R0 0x9902 LDR R1, [SP, #0x8] 0x1808 ADDS R0, R1, R0 0x9802 LDR R1, [SP, #0x8] 0x1808 ADDS R0, R1, R0

A selection of the vector table values.