Improving Compressible BC Robustness in PHASTA

1 PROPOSAL

For the final project, I propose a detailed investigation and improvement of boundary condition implementation in the compressible version of PHASTA. Currently, the incompressible version's non-linear convergence is much more robust than that of the compressible version; it often takes considerable manual effort to push a compressible case through its initial transient. By studying the incompressible version's implementation of BCs, I will identify aspects of the compressible code for improvement. The final deliverable will be a detailed algorithmic outline of both codes' BC implementation, a discussion of improvements selected for study, and benchmarks of the degree to which they affect non-linear convergence of a familiar compressible case: that of the aggressive subsonic diffuser.

2 Initial Outline of PHASTA: Incompressible

Though the final deliverable will include outlines of the BC implementation in both compressible and incompressible versions of PHASTA, the initial outline will be presented here using the latter version due to its robustness. In the following outline, routines followed by an asterisk (*) are expanded and described in their own separate block. Important integers and arrays are listed in Table 2. Furthermore, we ignore cardiovascular impedance and RCR boundary condition statements.

PHASTA begins execution at main, located in phSolver/[in]compressible, depending on which branch is desired. This function initializes MPI, and then calls phasta, located in /phSolver/common. Here, inputs are read and computed in input, and then the solver is run by calling proces.

- main
 - initialize MPI
 - phasta
 - initialize PETSc
 - input_fform read ASCII data from input.config and solver.inp
 - input*— populate data structures with problem set-up and solver parameters
 - proces*— generate problem data and calls the solution driver
 - finalize PETSc
 - □ finalize MPI

Most file input occurs in input, which populates data structures with problem and solver parameters.

- input
 - readnblk read and blocks data
 - read numstart.dat and finds appropriate restart.dat files
 - read geometry from Posix or SyncIO files using phio_readheader

- calculate maximum number of boundary element nodes
- initialize constants like ndof, ndofBC, ndiBCB, and ndBCB
- ctypes initialize variables for parallel processing
- genblk read and block connectivity for interior elements; there are two other versions of this function, genblkPosix and genblkSyncIO, which just address idiosyncrasies of the file formats; all call gensav
 - gensav save element block data to and return an ien array, mapping element and local node numbers to global node number, and a material type flag mater
- read BC mapping array into nBC
- read temporary boundary condition code into iBCtmp
- read BC data into BCinp
- read periodic BC data into iperread
- genbkb generate boundary element blocks and traces for gather/scatter operations; there are two other versions of this function, genbkbPosix and genbkbSyncIO, which just address idiosyncrasies of the file formats; all call gensvb
 - gensvb save boundary element block data to and return boundary nodal connectivity ienb, boundary condition codes iBCB, boundary condition values BCB, and material type flag materb
- read restart data for solution gold, displacement uold, and accelerations acold
- □ assert valid input constants (e.g. icoord, navier, iexec) defined in common.h
- genint generate integration information: number of quadrature points on the interior nint and boundary nintb, their weights Qwt and Qwtb, and locations Qpt and Qptb; the following routines are called to populate these variables depending on type of element and whether it is on the boundary
 - symtet interior tetrahedra
 - symtri boundary tetrahedra, boundary wedges (if boundary face is a triangle)
 - symhex interior hexahedra
 - symquad boundary hexahedra, boundary pyramids (if boundary face is a quadrilateral)
 - sympyr— interior pyramids
 - symtripyr boundary pyramids (if boundary face is a triangle)
 - symwdg interior wedges
 - symquadw boundary wedges (if boundary face is a quadrilateral)
- estimate number of global nonzeros nnz based on basis function order ipord
- compute fluid thermodynamic properties, such as specific heats and the gas constant

The next overarching routine, proces, generates problem data and calls the solution driver.

proces

- gendat generate geometry and BC data
 - xyzbound compute length scales (domain size) of the problem by looking at minima and maxima of the x array
 - genshp generate interior element shape functions and shape function derivatives
 - loop through element topologies, getting their coordinate system and element type, and then generate the parent element shape functions and their derivatives by calling either shpTet (tets), shphex (hexes), shp6w (wedges), or shppyr (pyramids)

- these are all Fortran wrappers (located in phasta/common/*.c) for the C routines called TetShapeAndDrv (in shapeFunction/src/uniformP.c), HexShapeAndDrv, WedgeShapeAndDrv, and PyrShapeAndDrv (these three in phasta/common/newshape.cc) respectively
- o return shp(a,i,j,p) and shgl(a,i,p), which are indexed by topology index a, spatial dimension(s) i and j, and the integration point index p = 1, ..., nint
- geniBC generate boundary condition codes, stored as a bitmap for each global node number (bitmap described just before description of iBC routine in this document)
 - set iBC(:)= iBCtmp(nBC(:)) if this partition has boundary nodes; nBC is used to map from the iBCtmp data read in readnblk to iBC, which is indexed by the full global node number
- genBC generate the essential boundary conditions
 - o set BCtmp = BCinp if this partition has boundary nodes; BCtmp(nshg,6+5*I3nsd) has a second index of ρ , T, p, velocities, scalars (?)
 - o genwnm calculate wall normals and modify BCtmp with the appropriate constraints
 - o genotwn determine first "off-the-wall-node" for each node, store result in otwn(nshg)
 - o genBC1 account for arbitrarily-oriented velocity constraints u_r , u_s , and u_t , finally storing the simplified boundary condition constraint result in BC; note that second index of BC holds ρ , T, p, u_1 , u_2 , u_3 , and scalars
- genshpb generate boundary element shape functions and derivatives, storing results in shpb and shglb; this routine is analogous to genshp
- LES: call setfilt, filtprep, and depending on iLES' value, setave and aveprep
- genini generate initial values of solution variables
 - restar sort initial values into y (called q inside restar) and ac from qold and acold,
 respectively, that were read in readnblk
 - o itrBC*and itrBCSclr*— satisfy BCs
- setper and perprep store inverse of sum of one and number of slaves in recount
- □ LES: keeplhsG and setrls
- initStats allocate arrays to store flow statistics
- □ RANS: initTurb
- □ itrdrv*— iterate the discrete solution using the predictor multi-corrector algorithm

Numerical solution of the time-integrated unsteady Navier-Stokes equations occurs within itrdrv.

■ itrdrv

- $\verb| | init Time Series --- initialize time series collection to varts.*. dat files using xyzts. dat input$
- □ initialize istep and ifuncs(:) to zero
- set yold = y and acold = ac, that is, populate $\underline{\underline{Y}}$ and $\underline{\underline{Y}}_{,t}^n$ with their converged solutions from the previous time step, which came from a restart file
- □ initEQS create the rowp and colm maps to facilitate sparse storage of the tangent matrix
 - determine how many scalar equations need solution, nsclrsol (# scalars + 1 if temperature)
 - determine whether we are solving the flow
 - genadj pre-process the adjacency list
 - o do iblk = 1, nelblk loop over blocks (groups of elements with the same topology)
 - ► Asadj generate adjacency data structures row_fill_list and adjcnt

```
    ▶ declare row_fill_list to have dimension (nshg, 15*nnz), where 15*nnz is a high estimate of the maximum number of adjacent nodes
```

- ▷ row_fill_list(A,:) holds global nodes that share local support with global node A
- adjcnt(A) holds the number of nodes adjacent to A, that is, how many entries row_fill_list(A,:) was populated with on purpose
- ▶ *note*: some operations here are $\mathcal{O}(n^2)$, but *n* is relatively small on each processor, and this process only needs to be done once for a given mesh connectivity
- build the colm array (which is trivial to do at this point)
- o sort rowp, because we binary search it when computing the sparse $\underline{\underline{A}}\underline{p}$ -product, and also compute the number of non-zero blocks icnt on this partition
- set nnz_tot = icnt
- depending on nsolflow and nsclrsol (whether this is a flow or scalar solve), initialize
 certain constants, such as equType, nDofs, nPermDims, nTmpDims, and allocate certain arrays,
 such as apermS and atempS
- □ initialize lstep0 = lstep + 1 to hold the first time step solved by the current run
- □ do itsq = 1, ntseq loop over time sequences; as far as I can tell ntseq = 1 is the default in input.config, and time sequences are not often used
 - set itseq = itsq
 - set iteration-specific variables nstp = nstep, nitr = niter, LCtime = loctim, and dtol(:)= deltol(:), where all of the longer-named variables are indexed by itseq
 - itrSetup set up time integration parameters
 - \circ calculate a_m , a_f , and γ as functions of ho_∞ (almi, alfi, and gami as functions of rhoinf)
 - o set inverse of global time step Dtgl and CFL data CFLfl
 - calculate number of flow solves per time step, store in nitr (IC), niter (C)
 - initialize istop = 0; flag can be set to stop the solver based on statistics of the residual
 - do istp = 1, nstp main loop over time steps
 - LES: lesmodels
 - o asbwmod set traction BCs if turbulence wall model is set (itwmod)
 - o itrPredict*— predict primitive variables at time n+1
 - o itrBC*— satisfy BCs on primitive variables; return a modified y
 - o itrBCSclr satisfy BCs on scalar isclr; return a modified y
 - o do istepc = 1, segsize loop over individual solves of flow and scalar
 - ▶ icode = stepseq(istepc) get sequence code
 - ▶ if this is a flow solve
 - SolFlow^{*} perform a flow solve
 - ▶ else if this is a scalar solve
 - ▶ else this is an update
 - ▶ itrCorrect*and itrBC*— update flow if desired
 - ▷ itrCorrectSclr and itrBCSclr update scalar if desired
 - stsGetStats obtain time averaged statistics
 - o find solution at end of time step and move it to old solution variables
 - increment istep and lstep
 - o Bflux compute the consistent boundary flux if desired

- deallocate variables and close files
- deallocate variables and close files

Iteration routines...

- itrPredict predict solution variables at time n + 1
 - □ if (ipred .eq. 1) we are using same-velocity prediction, as discussed in class
 - $\operatorname{set} \frac{\overset{n+1}{\underline{Y}}(i)}{\overset{n}{\underline{Y}}} = \overset{n}{\underline{Y}} \text{ with y = yold}$ • $\operatorname{set} \overset{n+1}{\overset{n+1}{\underline{Y}},t} = (1-1/\gamma)\overset{n}{\overset{n}{\underline{Y}},t} \text{ with ac = acold * (gami-one)/gami}$
 - other prediction methods (zero-acceleration, same-acceleration, and same-delta) are also supported with different values of ipred

Boundary conditions are set with the iBC and BC arrays. The bits of iBC, in increasing order, indicate whether the following BCs are set: ρ , T, p, u_1 , u_2 , u_3 , scalars 1–4, periodicity, scaled plane extraction (SPEBC), axisymmetry, and deformable wall (for cardiovascular cases). This means for each global node, iBC has at least 14 bits. Note that ibits(i,a,l) extracts bits a+1 through a+l of the integer i, and returns the base-10 integer. This routine is used to help identify and process boundary condition flags held in iBC. For example, if ibits(iBC,3,3).eq. 1 then u_1 is the only velocity component specified essential BC.

- itrBC satisfy BCs on the primitive variables
 - impose limits on flow variables in y, using the ylimit data structure of dimension (3, nflow), whose first index contains the limit flag, lower limit, and upper limit for each flow variable
 - velocity
 - pressure
 - local periodic
 - global periodic

Once boundary conditions have been satisfied, SolFlow is called to perform a flow solve:

- SolFlow perform a flow solve; output res preconditioned residual,
 - □ itrYAlpha compute $\underline{\underline{Y}}^{n+\alpha_f}(i)$ and $\underline{\underline{Y}}^{n+\alpha_m(i)}$, store respectively in yAlpha and acAlpha □ ElmGMR compute tangent matrix, residual vector, and preconditioning matrix for GMRES

Going through lectures 26 and 27.

First in the compressible code. Data structures are used in <code>solgmr</code> -> <code>elmgmrs</code> (sparse). Section on diffusive flux reconstruction, set up some arrays for interior elements. call <code>asigmr</code>, took care of volume integrals. now come to boundary elements, which is where integral over gamma takes place. block boundary elements as a separate list of elements with separate connectivity. as <code>asbmfg</code> is called, <code>mienb</code> holds boundary elements. computing normal gradients requires nodes off of the boundary. solution goes into <code>asbmfg</code> (no time derivatives are input, unlike <code>asigmr</code>), out comes a modified solution. in <code>asibmfg</code>: working with a block of elements; solution and coordinates are localized, local residual is zeroed, call <code>e3b</code>, assemble local residual. in <code>e3b</code>: loop over quadrature points (<code>ngaussb</code>), <code>getshpb</code> to get boundary shape functions, <code>e3bvar</code> called with surface normals, need <code>Fv{2,3,4}</code> to evaluate the floating flux, let <code>e3bvar</code> compute <code>Fv</code> values and fluxes, then test if we should use computed value or value from prescribed boundary condition. in <code>e3bvar</code>: interpolate nodal values to quadrature points, call <code>getthm</code> to compute thermodynamic state, compute element metrics

for mapping physical space to get wdetj, compute rou,p and tau*n,heat (normal flux, pressure, traction vector, heat flux) that is, rou takes $h^m(\xi_l)$, p takes $h^p(\xi_l)$, tau*n takes $h^\nu_*(\xi_l)$, etc. what's passed out is these things and the raw variables, their gradients, and the derived thermodynamic state. Back to e3b, do convective pressure, n-s, heat terms. after return from e3bvar, if no natural bc flag is set, we overwrite rou,p with floating values. compute euler stuff; then compute viscous stuff. get floating flux tau*n, overwrite where bits are not set. be careful what's passed out and in. also compute aerodynamic forces and heat flux in e3b, since we're doing surface integrals anyway.

incompressible is different, slightly. don't interpolate temperature at the outset; compute normal via cross-product; compute deformation gradient, local and global variable gradients; unm has the floating value of $\underline{u} \cdot \underline{n}$. eventually compute tau*n, which has the total stress floating value. skip over a bunch of deforming-wall stuff. iBCB did not come in to e3bvar; only floating flux stuff is computed in e3bvar for incompressible. all nodal interpolation is now done in e3b:

for Dirichlet bcs, iBC was a bitmap to boundary conditions BC

for natural bcs, $ibcb(1:nel_{in\ block\ (npro)},...)$ is a bitmap to boundary conditions BCB(:,...), where ... takes normal flux, pressure, traction vector, and heat flux take values 1–4.

going through more code... (2016-03-30)

this stuff is used in irdrv when it calls solgmrs, calls elmgmrs to populate lshk with current iteration's tangent values (same for res). allows us to start gmres; factorize matrix; precondition rhs with i3lu; spsi3pre sparse matrix preconditioning of lhsk; copy preconditioned residual into uBrg, which is a collection or Krylov vectors; calculate it's norm, make orthonormal; outer gmres loop do 2000 can be skipped, which is the gmres restart; actual start of GMRES discussed in class is uBrg statement just before do 1000; sumgat does off-processor (communication).

Symbol	Dimension	Description
nshg		# global shape functions (nshg = nnp if piecewise linear)
nnp		# global nodal points
npro		# elements in a block of same-topology elements, indexed by e
nshl		# nodes per element, indexed by a
ndof		# degrees of freedom, including scalars for turbulence models
nflow		# flow variables (4 incompressible, 5 compressible)
ntseq		# time sequences, which seems seldom used and defaults to 1
nstep		# time steps requested per sequence
nelblk		# blocks
ipord		order of basis functions
lstep		current time step
lstep0		first time step solved by current run, initialized to lstep+1
istep		step number relative to start of run
iter		iteration number
niter	(MAXTS)	# multi-corrector iterations per time step
loctim	(MAXTS)	local time stepping flag (?)
deltol	(MAXTS, 2)	velocity and pressure delta ratios
impl	(MAXTS)	heat, flow, and scalar solver flags (1's, 10's and 100's places)
iturb		indicates which turbulence model to use
ifunc		<pre>function evaluation counter, niter*(lstep-lstep0)+iter</pre>
ifuncs	(6)	function evaluation counter (?)
у	(nshg, ndof)	$\underbrace{Y}_{n+\alpha_{m(i)}}^{(i)}$ (meaning changes throughout)
ac	(nshg, ndof)	$\underline{\underline{Y}}_{A,t}^{n+\alpha_m(i)}$ (meaning changes throughout)
yold	(nshg, ndof)	$\underline{\underline{Y}}_{A}^{n(i)}$ (meaning changes throughout)
acold	(nshg, ndof)	$\underline{\underline{Y}}_{A,t}^{n(i)}$ (meaning changes throughout)
X	(nshg, nsd)	node coordinates
iBC	(nshg)	BC codes
ВС	(nshg, ndofBC)	BC constraint parameters
iper	(nshg)	periodicity table
mien	(nelblk)	pointer to IEN array (interior): has dimension (nshg, 15*nnz)
mienb	(nelblk)	pointer to IEN array (boundary): has dimension (nshg, 15*nnz)
shp	(nshape, ngauss)	physical shape functions at Gauss points (interior)
shb	(nshapeb, ngaussb)	physical shape functions at Gauss points (boundary)
shgl	(nsd, nshape, ngauss)	parent shape function gradients at Gauss points (interior)
shglb	(nsd, nshapeb, nguassb)	parent shape function gradients at Gauss points (boundary)

General Notes 8 / 8

3 GENERAL NOTES

■ In PHASTA, a block contains elements of the same topology.

4 Life's Persistent PHASTA Questions

- Is gold, allocated in readnblk.f ever deallocated? Can't find it.
- Why do most of the time step parameters have dimension MAXTS?
 - □ It also seems that some parameters are indexed by itseq, but don't change from step to step.
- When is it the case that $ndof \neq nflow$? For example during its limit-imposing stage, itrbc loops over nflow when indexing y's dimension of size ndof.
- Often the value of datmat(1,2,1) is assigned to a variable like rmu; where it it calculated? Kinematic viscosity? See getdiff.
- In genBC1, BC(:,1) gets assigned both density and pressure, so what goes in BC(:,6)???