Digital Signal Processing: Tutorial 3

Due on March 31, 2017 at $3\!:\!00\mathrm{pm}$

 $Friso\ DeBoer$

S.Reynolds (262538)

2.1 MATLAB Synthesis of Chirp Signal

Part A

This section requires a chirp signal to be synthesised. The code used to answer this question is as follows:

A chirp signal is a signal with a time varying phase. Generally, this can be written as:

$$x(t) = A \cdot \cos(\psi(t)) \tag{1}$$

The time varying phase is denoted as $\psi(t)$, and for a chirp signal this function is given by:

$$\psi(t) = 2\pi\mu t^2 + 2\pi f_0 t + \phi \tag{2}$$

The instantaneous frequency for a signal with a time varying phase is given by:

$$f_i(t) = \frac{1}{2pi} \cdot \frac{d}{dt} \psi(t) \tag{3}$$

For a chirp signal the instantaneous frequency, $f_i(t)$, is linear - shown below:

$$f_i(t) = 2\mu t + f_0 \tag{4}$$

Since the instantaneous is monotonic and linearly increasing, we note that the minimum frequency will occur when t = 0 and the maximum frequency will occur when $t = t_{max}$. We first need to find the parameters μ and f_0 . In the script, we note that:

$$\psi(t) = 2\pi\mu t^2 + 2\pi f_0 t + \phi = 2\pi \cdot 500 \cdot t^2 + 2\pi \cdot 200 \cdot t + 2\pi \cdot 100 \tag{5}$$

Polynomial equality suggests that $\mu = 500$, and $f_0 = 200$. Hence, we can find both f_{min} and f_{max} :

$$f_{min} = 2\mu \cdot 0 + f_0 = 200 \text{Hz} \tag{6}$$

$$f_{max} = 2\mu \cdot 0 + f_0 = 2\cot 500 \cdot 1.8 + 200 = 2000 \text{Hz}$$
 (7)

A sketch of the instantaneous frequency versus time can be seen in Figure 1.




Figure 1: A plot of the linear instantaneous frequency for the chirp signal with parameters $\mu = 500 \text{Hz}$, and $f_0 = 200 \text{Hz}$

Part B

A function was implemented in MATLAB which created a chirp signal between two frequencies for some duration at a given sampling frequency. The code is as follows:

```
function xx = mychirp(f1, f2, dur, fsamp)
% usage: xx = mychirp(f1, f2, dur, fsamp)
% f1 = starting frequency
% f2 = ending frequency
% dur = total time duration
% fsamp = sampling frequency (OPTIONAL: default is 8000)

if (nargin < 4) %--Allow optional input arguement
    fsamp = 8000;
end

dt = 1/fsamp;
tt = 0:dt:dur;

f0 = f1;
mu = (f2 - f1)/(2*dur);

psi = 2*pi*(mu*tt.^2 + f0*tt + 100);

xx = real(exp(j*psi));</pre>
```

The function was executed to create a signal identical to that in part A. A spectrogram of the created waveform can be seen in Figure 2.




Figure 2: A spectrogram of a chirp signal with starting frequency of 200 Hz and a final frequency of 2000 Hz

3.1 Synthesise a Chirp

A chirp signal was synthesised between 15000Hz and 300Hz. The script is shown below:

The chirp sound goes up then down. The cycle repeats again - up then down. A spectrogram showing how the frequency changes with respect to time can be seen in Figure 3.




Figure 3: Spectogram of a chirp signal with start frequency of 15000Hz and stop frequency of 300Hz. The sampling frequency is 8000Hz

The frequency rises, and then falls because the sampling rate is not high enough. Shannon's sampling theorem tells us that in order to avoid the effects of aliasing, we need to ensure that:

$$f_s \ge 2 \cdot f_{max} \tag{8}$$

Equation (3) tells us that the sampling frequency needs to be at least twice as big as the maximum frequency in the waveform. We see that at the signal starts at a frequency of 15000Hz, and the sampling frequency is only 8000Hz. Hence, we experience aliasing.

3.2 Beat Notes

A beat note can be thought of in two different ways: one as a modulated signal, and the second as a the sum of two distinct signals with frequencies which differ by a small amount, f_{Δ} . The expression for the second way of thinking about beat notes can be seen in equation (4):

$$x(t) = A \cdot \cos(2\pi(f_c - f_\Delta)t) + B \cdot \cos(2\pi(f_c + f_\Delta)t) \tag{9}$$

A MATLAB function was implemented which created a beat note with the following script:

```
function [xx, tt] = beat(A, B, fc, delf, fsamp, dur)
% BEAT compute samples of the sum of two cosine waves
% usage:
% [xx, tt] = beat(A, B, f, delf, fsamp, dur)
% A = amplitude of lower frequency cosine
% B = amplitude of higher frequency cosine
% fc = center frequency
% delf = frequency difference
% fsamp = sampling rate
```




Figure 4: A plot of the beat waveform with parameters as described above.

```
% dur = total time duration in seconds
% xx = output vector of samples
%--OPTIONAL Output:
% tt = time vector corresponding to xx

% Create the time vector
   tt = 0:(1/fsamp):dur;

% Create the lower frequency waveform
   x1 = A*exp(j*2*pi*(fc - delf)*tt);
% Create the upper frequency waveform
   xu = B*exp(j*2*pi*(fc + delf)*tt);

% Create the beat signal
   xx = real(x1 + xu);
end
```

The function was tested using a GUI provided by the tutorial, accessed with the command beatcon. The beat wave form for a signal with A = 10, B = 10, $f_c = 1000$, $f_{\Delta} = 10$, $f_s = 8000$, and a duration of 1 second is shown in Figure 4. The period of the envelope can be clearly seen from the graph and is equal to 0.05 seconds.

3.3 More on Spectrograms

Another beat waveform was created, using the following code:

```
% Specify parameters for signal generation
delf = 32;
fsamp = 8000;
dur = 0.26;
f0 = 2000;
A = 1;
B = 1;
% Generate signal
xx = beat(A,B,f0,delf,fsamp,dur);
plot(xx)
```

Two spectrograms were plotted, and can be seen in Figures 5 and 6.




Figure 5: A spectrogram of the beat signal created above using 2048 as input.




Figure 6: A spectrogram of the beat signal created above using 16 as input.

4.1 Generating the Bell Envelopes

To create a signal that sounds more like an instrument the time varying phase, $\psi(t)$, is implemented as:

$$\psi(t) = 2\pi \cdot f_c \cdot t + I(t) \cdot \cos(2\pi \cdot f_m \cdot t + \phi_m) + \phi_c \tag{10}$$

The composed signal is given by:

$$x(t) = A(t) \cdot \cos(\psi(t)) \tag{11}$$

We note that there are two envelopes that we need to consider: A(t) and I(t). A decaying exponential envelope was implemented in a MATLAB function to create these envelopes:

```
function yy = bellenv(tau, dur, fsamp)
% BELLENV produces envelope function for bell sounds
% usage: yy = bellenv(tau, dur, fsamp)
% tau = time constant
% dur = duration of the envelope
% fsamp = sampling frequency
% returns:
% yy = decaying exponential envelope
    tt = 0:(1/fsamp):dur;
    yy = exp(-tt./tau);
end
```

4.2 Parameters for the Bell

A function which creates the discrete time bell signal is as follows:

```
function xx = bell(ff, Io, tau, dur, fsamp)
% BELL produces a bell sound
% usage: xx = bell(ff, Io, tau, dur, fsamp)
% ff = frequency vector (containing fc and fm)
% Io = scale factor for modulation index
% tau = decay parameter for A(t) and I(t)
% dur = duration (in sec.) of the output signal
% fsamp = sampling rate
    % Create the time vector
    tt = 0: (1/fsamp): dur;
    % Specify the parameters to be used
    A = 1; % amplitude
    phm = -pi/2; % phase constant
    phc = -pi/2; % phase constant
    fc = ff(1);
    fm = ff(2);
    % Create the exponential decay envelope
    envel = bellenv(tau, dur, fsamp);
    % Create the envelope functions A(t) and I(t)
    At = A \times envel;
    It = Io*envel;
    % Create bell signal
    arg = 2*pi*fc*tt + It.*real(exp(j*(2*pi*fm*tt + phm))) + phc;
    xx = At.*real(exp(j*arg));
end
```

4.3 The Bell Sound

The Bell function, which relies on the Bell Envelope function, was tested on a series of cases using the following script:

end

A time series plot was created for each of the configuration of parameters a sound was played for - the time series plots can be seen in Figures 7 through 12.




Figure 7: Time series plot of bell with the parameters $f_c=110$, $f_m=220$, $I_0=10$, $\tau=2$, $T_{dur}=6$, $f_s=11025$




Figure 9: Time series plot of bell with the parameters $f_c=110$, $f_m=220,\ I_0=10,\ \tau=12,$ $T_{dur}=3,\ f_s=11025$




Figure 11: Time series plot of bell with the parameters $f_c=250, f_m=350, I_0=5, \tau=2, T_{dur}=5, f_s=11025$




Figure 8: Time series plot of bell with the parameters $f_c = 220$, $f_m = 440$, $I_0 = 5$, $\tau = 2$, $T_{dur} = 6$, $f_s = 11025$




Figure 10: Time series plot of bell with the parameters $f_c=110,\,f_m=220,\,I_0=10,\,\tau=0.3,\,T_{dur}=3,\,f_s=11025$




Figure 12: Time series plot of bell with the parameters $f_c=250,\ f_m=350,\ I_0=3,\ \tau=1,$ $T_{dur}=5,\ f_s=11025$

A spectrogram was created for each configuration of parameters a sound was played for - the spectrograms can be seen in Figures 13 through 18.




Figure 13: Spectrogram of bell with the parameters $f_c = 110$, $f_m = 220$, $I_0 = 10$, $\tau = 2$, $T_{dur} = 6$, $f_s = 11025$




Figure 15: Spectrogram of bell with the parameters $f_c=110$, $f_m=220$, $I_0=10$, $\tau=12$, $T_{dur}=3$, $f_s=11025$




Figure 17: Spectrogram of bell with the parameters $f_c=250$, $f_m=350$, $I_0=5$, $\tau=2$, $T_{dur}=5$, $f_s=11025$




Figure 14: Spectrogram of bell with the parameters $f_c = 220$, $f_m = 440$, $I_0 = 5$, $\tau = 2$, $T_{dur} = 6$, $f_s = 11025$




Figure 16: Spectrogram of bell with the parameters $f_c=110$, $f_m=220$, $I_0=10$, $\tau=0.3$, $T_{dur}=3$, $f_s=11025$




Figure 18: Spectrogram of bell with the parameters $f_c=250$, $f_m=350$, $I_0=3$, $\tau=1$, $T_{dur}=5$, $f_s=11025$

Time series plots of the middle 300 samples of each of the bell signals for the parameter configuration were taken. The plots can be seen in Figures 19 through 24.




Figure 19: 300 samples of the time series plot of bell with the parameters $f_c = 110$, $f_m = 220$, $I_0 = 10$, $\tau = 2$, $T_{dur} = 6$, $f_s = 11025$




Figure 21: Spectrogram of bell with the parameters $f_c = 110$, $f_m = 220$, $I_0 = 10$, $\tau = 12$, $T_{dur} = 3$, $f_s = 11025$




Figure 23: 300 samples of the time series plot of bell with the parameters $f_c = 250$, $f_m = 350$, $I_0 = 5$, $\tau = 2$, $T_{dur} = 5$, $f_s = 11025$




Figure 20: 300 samples of the time series plot of bell with the parameters $f_c = 220$, $f_m = 440$, $I_0 = 5$, $\tau = 2$, $T_{dur} = 6$, $f_s = 11025$




Figure 22: 300 samples of the time series plot of bell with the parameters $f_c = 110$, $f_m = 220$, $I_0 = 10$, $\tau = 0.3$, $T_{dur} = 3$, $f_s = 11025$




Figure 24: 300 samples of the time series plot of bell with the parameters $f_c = 250$, $f_m = 350$, $I_0 = 3$, $\tau = 1$, $T_{dur} = 5$, $f_s = 11025$

5.1 Generating the Envelopes for Woodwinds

A function was provided which created the envelopes for Woodwind Synthesis, called woodwenv.m, which produces the functions needed to create both A(t) and I(t). This was tested using the following script:

```
%%%%%%%% 5.1 Generating the Envelopes for Woodwinds %%%%%%%%%%
% Clear the work space and any stored variables
clear; clc;

fsamp = 8000;
Ts = 1/fsamp;
delta = 1e-4;
tt = delta:Ts:0.5;
[y1, y2] = woodwenv(0.1, 0.35, 0.05, fsamp);
subplot(2,1,1), plot(tt,y1), grid on
subplot(2,1,2), plot(tt,y2), grid on
```

5.2 Scaling the Clarinet Envelopes

Scaling of the envelope functions was required. A linear mapping was used to scale normalised envelope values, seen below:

$$y_{new}(t) = \alpha \cdot y_{norm}(t) + \beta$$

The section asks (seemingly as busy work) to map the normalised value of 1 to $(y_{new})_{max}$ and the normalised value of 0 to $(y_{new})_{min}$. If $y_{norm} = 0$, then:

$$(y_{new})_{min} = \alpha \cdot 0 + \beta = \beta$$

Similarly, if $y_{norm} = 1$, then:

$$(y_{new})_{max} = \alpha \cdot 1 + \beta = \alpha + (y_{new})_{min}$$

Hence, we have that $\beta = (y_{new})_{min}$, and $\alpha = (y_{new})_{max} - (y_{new})_{min}$, in order to create the desired linear mapping outlined in the exercise. A function was used to implement the scaling operation in MATLAB, which can be seen below:

```
function y = scale(data, alpha, beta)
    y = alpha*data + beta;
end
```

5.3 Clarinet Envelopes

The I(t) clarinet envelope needs to be scaled, and inverted. In this instance, the profile that is provided sees the normalised value of 0 mapped to 4, and the normalised value of 1 is mapped to 2. Applying a similar logic to the previous exercise, we see that if $y_{norm} = 0$, then:

$$(y_{new})_{max} = 4 = \alpha \cdot 0 + \beta$$

Similarly, if $y_{norm} = 1$, then:

$$(y_{new})_{min} = 2 = \alpha \cdot 1 + \beta = \alpha + 4$$

Hence, we see that we should set the parameters as $\alpha = -2$, and $\beta = 4$. This was implemented using the following script:

5.4 Parameters for the Clarinet

A MATLAB function was implemented to create the signal for a clarinet, noting that the fundamental frequency, f_0 , is used to derive the carrier and modulation frequencies f_c and f_m , respectively. The section asks the envelopes A(t) and I(t) to be implemented using the functions textttscale and textttwoodwenv, however, these functions were not available. The previously defined functions scale and woodwenv were employed instead. The function is as follows:

```
function yy = clarinet(f0, Aenv, Ienv, dur, fsamp)
%CLARINET produce a clarinet note signal
% usage: yy = clarinet(f0, Aenv, Ienv, dur, fsamp)
% where:
% f0 = note frequency
% Aenv = the array holding the A(t) envelope
% Ienv = the array holding the I(t) envelope
% dur = the amount of time the signal lasts
% fsamp = the sampling rate
    % Create time vector
    tt = 1e-4: (1/fsamp): dur;
    % Set up alpha and beta for use in scaling function
    alpha = -2;
    beta = 4;
    % Scale the I(t) envelope
    I_new = scale(Ienv,alpha,beta);
    % Determine the fc and fm parameters
    fc = 2*f0;
    fm = 3 * f0;
    phm = -pi/2;
    phc = -pi/2;
    % Create the clarinet sound
    arg = 2*pi*fc*tt + I_new.*real(exp(j*(2*pi*fm*tt + phm))) + phc;
    yy = Aenv.*real(exp(j*arg));
end
```

5.5 Experiment with the Clarinet Sound

The clarinet sound was tested using the following script:

```
% Clear the workspace and any stored variables
clear; clc;
% Set the parameters for the sound
f0 = 290;
% Set the duration of the tone
dur = 2;
\mbox{\%} Set the sampling frequency
fsamp = 8000;
\ensuremath{\mbox{\ensuremath{\$}}} Create the envelopes for the sound
a = (0.1/0.5) *2; s = (0.35/0.5) *2; r = (0.05/0.5) *2;
[Aenv, Ienv] = woodwenv(a, s, r, fsamp);
% Build the discrete time waveform
xx = clarinet(f0, Aenv, Ienv, dur, fsamp);
% Play the sound
sound(xx,fsamp)
```

The generated sound is roughly like a woodwind instrument at lower frequencies. Higher frequencies sound artificial.