AEEM 3062

HOMEWORK #3

2022-2023 SPRING

Name: Slade Brooks

M#: 13801712

DUE: 11.59 PM on 2/2/2023

Problem 1

A bar of width w = 10 mm, height h = 15 mm, and length L = 500 mm is subject to a tensile force P = 22.5 kN as shown in Fig. 1. The state of stress at any point inside the bar is characterized by the stress matrix:

$$\begin{bmatrix} \sigma_{xx} & \tau_{xy} & \tau_{xz} \\ \tau_{yx} & \sigma_{yy} & \tau_{yz} \\ \tau_{zx} & \tau_{zy} & \sigma_{zz} \end{bmatrix} = \begin{bmatrix} \frac{P}{wh} & 0 & 0 \\ 0 & 0 & 0 \\ 0 & 0 & 0 \end{bmatrix}$$

Find the expressions of the functions that describe how the normal stress σ_n and the shear stress τ_n vary with the angle θ that determines the orientation of the plane π shown in Fig. 1. Plot the two functions for ranging θ from 0 to 360 (provide appropriate scales and labels in the plots) and give the values of angle θ for which τ_n is maximum. [50 pts]




Figure 1

The stress matrices are given by:
$$\sigma_n = egin{bmatrix} rac{P}{wh} & 0 & 0 \\ 0 & 0 & 0 \\ 0 & 0 & 0 \end{bmatrix}$$


From the notes:

$$\sigma_n = t*n = \left[egin{array}{cccc} n_x & n_y & n_z
ight]* \left[egin{array}{cccc} \sigma_{xx} & au_{xy} & au_{xz} \ & \sigma_{yy} & au_{yz} \ sim & \sigma_{zz} \end{array}
ight]* \left[egin{array}{c} n_x \ n_y \ n_z \end{array}
ight]$$

$$au_n = t - (t*n)n = egin{bmatrix} \sigma_{xx} & au_{xy} & au_{xz} \ & \sigma_{yy} & au_{yz} \ sim & \sigma_{zz} \end{bmatrix} * egin{bmatrix} n_x \ n_y \ n_z \end{bmatrix} - \sigma_n * egin{bmatrix} n_x \ n_y \ n_z \end{bmatrix}$$

 \boldsymbol{n} can never act in the y direction so $\boldsymbol{n_y}$ is 0

 n_x and n_z are based on heta, with $n_x = \cos heta$ and $n_z = \sin heta$



Substituting
$$n$$
 and $\hat{\sigma}$ into σ_n gives: $\sigma_n = [\cos\theta \quad 0 \quad \sin\theta] * \begin{bmatrix} \frac{P}{wh} & 0 & 0 \\ 0 & 0 & 0 \\ 0 & 0 & 0 \end{bmatrix} * \begin{bmatrix} \cos\theta \\ 0 \\ \sin\theta \end{bmatrix}$

Multiply the first two matrices using matlab.

$$\sigma_n = egin{bmatrix} rac{P}{wh} \cos heta & 0 & 0 \end{bmatrix} * egin{bmatrix} \cos heta \ 0 \ \sin heta \end{bmatrix}$$

Multiply the remaining two matrices using matlab.

$$\sigma_n = rac{P\cos^2 heta}{wh}$$

Do the same for τ_n giving:

$$au_n = t - (t*n)n = egin{bmatrix} rac{P}{wh} & 0 & 0 \ 0 & 0 & 0 \ 0 & 0 & 0 \end{bmatrix} * egin{bmatrix} \cos heta \ 0 \ \sin heta \end{bmatrix} - rac{P\cos^2 heta}{wh} * egin{bmatrix} \cos heta \ 0 \ \sin heta \end{bmatrix}$$


$$au_n = egin{bmatrix} rac{P\cos heta}{wh} \ 0 \ 0 \end{bmatrix} - egin{bmatrix} rac{P\cos^3 heta}{wh} \ 0 \ rac{P\cos^2 heta\sin heta}{wh} \end{bmatrix}$$

$$au_n = \left[egin{array}{c} rac{P\cos heta - P\cos^3 heta}{wh} \ 0 \ rac{-P\cos^2 heta\sin heta}{wh} \end{array}
ight]$$

 au_n at each angle equals the length of the vector au_n to be found using Matlab's norm() function.

The two functions σ_n and τ_n are plotted using Matlab's plot() function.





This shows that tau_n has maximums at angles:

$$\theta=45^\circ,135^\circ,225^\circ,315^\circ$$

Problem 2

Consider a reference frame $\{x,y,z\}$ and a stress tensor represented by matrix

$$\begin{bmatrix} \sigma_{xx} & \tau_{xy} & \tau_{xz} \\ \tau_{yx} & \sigma_{yy} & \tau_{yz} \\ \tau_{zx} & \tau_{zy} & \sigma_{zz} \end{bmatrix} = \begin{bmatrix} 50 & -6 & 14 \\ -6 & -120 & 8 \\ 14 & 8 & -4 \end{bmatrix} \text{ in MPa units}$$

Part A


Plot the Mohr's circles. Clearly indicate the procedure that you follow and show in the plots scales, values at relevant points, and labels. [35 pts]

The locations of the values of the Mohr's circles σ_1, σ_2 , and σ_3 are the eigenvalues of the stress tensor σ .

Using Matlab's eig() function we can get the eigenvalues of σ .

$$\begin{bmatrix} \sigma_1 & 0 & 0 \\ 0 & \sigma_2 & 0 \\ 0 & 0 & \sigma_3 \end{bmatrix} = \begin{bmatrix} -120.834 & 0 & 0 \\ 0 & -6.6697 & 0 \\ 0 & 0 & 53.5037 \end{bmatrix}$$

Then we plot these points on a graph. The largest point becomes σ_1 , the next largest is σ_2 , and so on. Then, the Mohr's circles are plotted. This is done by plotting one circle with a diameter from σ_1 to σ_3 , one from σ_1 to σ_2 , and one from σ_2 to σ_3 .



Part B

Find the coordinates of the unit vectors orthogonal to the planes which experience the largest compressive and tensile stresses [15 pts]

The largest compressive stress is found at σ_3 since negative normal stress is compressive. Using Matlab's eig() function on the stress tensor σ we can determine the corresponding eigenvector for $\sigma_3=-120.834$:

T	-0.0410	
	-0.9965	
	0.0731	

The largest tensile stress is found at σ_1 since positive normal stress is tensile. Using Matlab's eig() function on the stress tensor σ we can determine the corresponding eigenvector for $\sigma_1=55.5037$:

$$\begin{bmatrix}
-0.9721 \\
0.0229 \\
-0.2335
\end{bmatrix}$$