

Preparation

Part Number: PT976-03200**Kit Contents**

Item #	Quantity Reqd.	Description
1	1	Cable Charge Kit
2		
3		

Vehicle Service Parts (may be required for reassembly)

Item #	Quantity Reqd.	Description
1		
2		
3		

Hardware Bag Contents

Item #	Quantity Reqd.	Description
1		
2		
3		

Additional Items Required For Installation

Item #	Quantity Reqd.	Description
1		
2		
3		

Conflicts

None

Recommended Tools

Personal & Vehicle Protection	Notes
None	
Special Tools	Notes
None	
Installation Tools	Notes
None	
Special Chemicals	Notes
None	

General Applicability

MY20 and newer Various Vehicles

Recommended Sequence of Application

Item #	Accessory
1	
2	
3	

*Mandatory

Legend**STOP:** Damage to the vehicle may occur. Do not proceed until process has been complied with.**OPERATOR SAFETY:** Use caution to avoid risk of injury.**CAUTION:** A process that must be carefully observed in order to reduce the risk of damage to the accessory/vehicle and to ensure a quality installation.**TOOLS & EQUIPMENT:** Used in Figures calls out the specific tools and equipment recommended for this process.**REVISION MARK:** This mark highlights a change in installation with respect to previous issue.**SAFETY TORQUE:** This mark indicates that torque is related to safety.**REGULATORY MARK:** This mark indicates the component is related to regulatory compliance

Procedure


Care must be taken when installing this accessory to ensure damage does not occur to the vehicle. The installation of this accessory should follow approved guidelines to ensure a quality installation.

These guidelines can be found in the "Accessory Installation Practices" document.

This document covers such items as:

- Vehicle Protection (use of covers and blankets, cleaning chemicals, etc.).
- Safety (eye protection, rechecking torque procedure, etc.).
- Vehicle Disassembly/Reassembly (panel removal, part storage, etc.).
- Electrical Component Disassembly/Reassembly (battery disconnection, connector removal, etc.).

Please see your Toyota dealer for a copy of this document.



1. Install the Cable Charge Kit.

- (a) Open the console box lid (Fig. 1-1).

⚠ NOTE: Console boxes vary by vehicle.

- (b) Place the cable charge kit in the console box (Fig. 1-2).

⚠ NOTE: Do NOT open the cable charge kit.

⚠ NOTE: If the vehicle is equipped with a Console Vault, place the cable charge kit inside of the console vault.

- (c) Close the console box lid.

⚠ NOTE: Primary storage location is Console Box. If vehicle is on conveyor, alternate storage location is Glove Box.

Checklist - these points **MUST** be checked to ensure a quality installation.

Check:	Look For:
<u>Accessory Function Checks</u> <input type="checkbox"/> Confirm proper placement of Cable Charge Kit <input type="checkbox"/> Confirm Cable Charge Kit has NOT been opened	Cable Charge Kit located in Console Box Packaging remains sealed
<u>Vehicle Function Checks</u> <input type="checkbox"/>	
<u>Vehicle Appearance Check</u> <input type="checkbox"/> After accessory installation and removal of protective cover(s), perform a visual inspection.	Ensure no damage (including scuffs and scratches) was caused during the installation process. (For PPO installations, refer to TMNA Accessory Quality Shipping Standard.)