

The Launchpad image refers to the revision 1.0 of the hardware. In that version the DIO2 and DIO3 pins were incorrectly labelled (labels are swapped with respect to actual pin location). This scheme refers to the actual wiring position, then discard any label on the board and just wire as shown.