Module Interface Specification for Solar Water Heating Systems Incorporating Phase Change Material

Brooks MacLachlan

August 4, 2016

Contents

1	Inti	oduction	4
2	Not	ation	4
3	Mo	dule Decomposition	4
4	MIS	S of Control Module	5
	4.1	Module	5
	4.2	Uses	5
	4.3	Syntax	5
		4.3.1 Exported Access Programs	5
	4.4	Semantics	5
		4.4.1 State Variables	5
		4.4.2 Environment Variables	6
		4.4.3 Access Routine Semantics	6
5	MIS	of Input Parameters Module	6
	5.1	Module	6
	5.2	Uses	6
	5.3	Syntax	6
		5.3.1 Exported Data Types	6
		5.3.2 Exported Access Programs	6
	5.4	Semantics	6
	<u> </u>	5.4.1 State Variables	6
		5.4.2 Access Routine Semantics	7

6	MIS	of Input Format Module	7
	6.1	Module	7
	6.2	Jses	7
	6.3	Syntax	8
	6.4	Exported Access Programs	8
	6.5	Semantics	8
		5.5.1 State Variables	8
		5.5.2 Assumptions	8
		3.5.3 Access Routine Semantics	8
7	MIS	of Input Verification Module	8
•	7.1	Module	8
	7.2	Jses	9
	7.3	Syntax	9
		7.3.1 Exported Access Programs	9
	7.4	Semantics	9
	1.1	7.4.1 Environment Variables	9
		7.4.2 Assumptions	9
		1	10
8		· · · · · · · · · · · · · · · · · · ·	10
	8.1		10
	8.2		10
	8.3	V	11
			11
	8.4		11
			11
		1	11
		3.4.3 Access Routine Semantics	12
9	MIS	of ODE Solver Module	12
	9.1	Module	12
	9.2	Jses	12
	9.3		13
			13
	9.4	· · · · · · · · · · · · · · · · · · ·	13
			13
			13
			13
10	ултс	of Energy Module	13
τU			то 13
			13
	111.7	LOED CONTRACTOR CONTRA	

14 App	pendix	17
	13.4.4 Local Constants	17
	13.4.3 Access Routine Semantics	17 17
	13.4.2 Environment Variables	17
	13.4.1 State Variables	17 17
13.4	Semantics	-
19 4	13.3.1 Exported Access Program	17 17
13.3	Syntax	
	Uses	16 17
_		16 16
	S of Output Module Module	16
		10
	12.4.4 Access Routine Semantics	16
	12.4.3 Assumptions	16
	12.4.2 Environment Variables	16
12.1	12.4.1 State Variables	16
12.4	Semantics	16
12.0	12.3.1 Exported Access Programs	16
	Syntax	16
	Uses	16
	Module	15
12 MIS	S of Plotting Module	15
	11.4.5 Access Routine Semantics	15
	11.4.4 Assumptions	15
	11.4.3 Local Variables	15
	11.4.2 Environment Variables	15
	11.4.1 State Variables	15
11.4	Semantics	15
	11.3.1 Exported Access Programs	15
	Syntax	15
	Uses	15
	Module	$\frac{-1}{14}$
11 MIS	S of Output Verification Module	14
	10.4.3 Access Routine Semantics	14
	10.4.2 Assumptions	14
	10.4.1 State Variables	14
10.4	Semantics	14
	10.3.1 External Access Programs	13
10.3	Syntax	13

1 Introduction

The following document details the Module Interface Specifications for the implemented modules in a program simulation Solar Water Heating System with Phase Change Material. It is intended to ease navigation through the program for design and maintenance purposes. Complementary documents include the System Requirement Specifications and Module Guide.

2 Notation

The following table summarizes the primitive data types used by SWHS. SWHS also uses some derived data types: arrays, strings, and structures. Arrays are lists filled with elements of the same data type. Strings are arrays of characters. Structures contain pairs of keys and values, where keys are unique variable names used to identify their corresponding value, and values can be of any data type. SWHS also uses functions, which are defined by the data types of their inputs and outputs. Functions are described by showing their input data types on the left side of an arrow and their output data types on the right side.

Data Type	Notation	Description
character	char	a single symbol or digit
integer	${\mathbb Z}$	a number without a fractional component in $(-\infty, \infty)$
real	\mathbb{R}	any number in $(-\infty, \infty)$

3 Module Decomposition

The following table is taken directly from the Module Guide document for this project.

Level 1	Level 2
Hardware-Hiding Module	
Behaviour-Hiding Module	Input Format Module Input Parameters Module Input Verification Module Output Format Module Output Verification Module Temperature ODEs Module Energy Equations Module Control Module
Software Decision Module	Sequence Data Structure Module ODE Solver Module Plotting Module

Table 1: Module Hierarchy

4 MIS of Control Module

4.1 Module

main

4.2 Uses

parameters (5), load_params (6), verify_params (7), temperature (8), ODE Solvers Module (9), energy (10), verify_output (11), plot (12), output (13)

4.3 Syntax

4.3.1 Exported Access Programs

Name	In	Out	Exceptions
main	string	-	-

4.4 Semantics

4.4.1 State Variables

time: array of reals tempW: array of reals tempP: array of reals latHeat: array of reals eW: array of realseP: array of realseTot: array of reals

4.4.2 Environment Variables

win: 2D array of pixels displayed on the screen

4.4.3 Access Routine Semantics

main(s): transition: $time, tempW, tempP, latHeat\ eW, eP, eTot, win := results[0],$

results[1], results[2], results[3], eW1||eW2||eW3, eP1||eP2||eP3, $(\forall i \in [0..|post(eW)|-1])$ (post(eW[i]) + post(eP[i])), Prints infor-

mation about the melting of PCM.

exception: none

5 MIS of Input Parameters Module

5.1 Module

parameters

5.2 Uses

N/A

5.3 Syntax

5.3.1 Exported Data Types

parameters := structure

5.3.2 Exported Access Programs

N/A

5.4 Semantics

5.4.1 State Variables

params.L: real params.diam: real params.Vp: real params.Ap: real params.rho_p: real

params.Tmelt: real $params.C_ps:$ real $params.C_pl$: real params.Hf: real params.Ac: real params.Tc: real params.rho_w: real $params.C_w: real$ params.hc: real params.hp: real params.Tinit: real params.tstep: real params.tfinal: real params.AbsTol: real params.RelTol: real params.ConsTol: real params.Vt: real params.Mw: real params.tau_w: real params.eta: real params.Mp: real params.tau_ps: real params.tau_pl: real $params.Epmelt_init:$ real params.Ep_melt3: real params.Mw_noPCM: real $params.tau_w_no_PCM$: real

5.4.2 Access Routine Semantics

N/A

6 MIS of Input Format Module

6.1 Module

 $load_params$

6.2 Uses

parameters (5)

6.4 Exported Access Programs

Name	In	Out	Exceptions
load_params	string	parameters	-

6.5 Semantics

6.5.1 State Variables

params: parameters param: array of reals

6.5.2 Assumptions

The input string corresponds to an existing filename in the current directory. The input file is formatted correctly.

6.5.3 Access Routine Semantics

 $load_params(s)$: transition: params.L, params.diam

params.L, params.diam, params.Vp, params.Ap, params.rho_p, params.Tmelt, params.C_ps, params.C_pl,

params.Hf, params.Ac, params.Tc, params.rho_w, params.C_w, params.hc, params.hp, params.Tinit, params.tstep, params.tfinal, params.AbsTol,

params.RelTol, params.ConsTol, params.Vt, params.Mw, params.tau_w, params.eta, params.Mp, params.tau_ps, params.tau_pl, params.Epmelt_init, params.Ep_melt3

:= param[0], param[1], param[2], param[3], param[4], param[5], param[6], param[7], param[8], param[9],

param[5], param[6], param[7], param[8], param[9], param[10], param[11], param[12], param[13], param[14],

param[15], param[16], param[17], param[18], param[19],

param[20], param[21], param[22], param[23], param[24], param[25], param[26], param[27], param[28], param[29],

param[23], param[23], param[23], param[23], param[30], param[31], where param is the array of parame-

ters obtained from the input file s

exception: none

7 MIS of Input Verification Module

7.1 Module

verify_params

7.2 Uses

parameters (5)

7.3 Syntax

7.3.1 Exported Access Programs

Name	In	Out	Exceptions	
verify_valid	parameters	-	badLength, badDiam, bad-	
			PCMVolume, badPCMAnd-	
			TankVol, badPCMArea, bad-	
			PCMDensity, badMeltTemp,	
			badCoilAndInitTemp, badCoil-	
			Temp, badPCMHeatCapSolid,	
			badPCMHeatCapLiquid, bad	
			HeatFusion, badCoilArea, bad-	
			WaterDensity, badWaterHeat-	
			Cap, badCoilCoeff, badPCMCo-	
			eff, badInitTemp, badFinalTime,	
			${\bf badInit And Melt Temp}$	
verify_recommended	parameters	=	-	

7.4 Semantics

7.4.1 Environment Variables

win: 2D array of pixels displayed on the screen.

7.4.2 Assumptions

All of the fields of the input parameters structure have been assigned a value.

7.4.3 Access Routine Semantics

verify_valid(params): transition: win: (error is thrown \Rightarrow Prints error mes-

sage)

exceptions: $exc := (params.L \leq 0 \Rightarrow badLength)$

params.diam < 0 \Rightarrow badDiam $params.Vp < 0 \Rightarrow badPCMVolume$ $params.Vp > params.Vt \Rightarrow badPCMAnd-$ TankVol | $params.Ap \leq 0 \Rightarrow badPCMArea$ $params.rho_p \leq 0 \Rightarrow badPCMDensity$ $| params.Tmelt \leq 0 \lor params.Tmelt \geq$ $params.Tc \Rightarrow badMeltTemp \mid params.Tc \leq$ $params.Tinit \Rightarrow badCoilAndInitTemp$ $params.Tc \geq 100 \lor params.Tc \leq 0 \Rightarrow$ badCoilTemp | $params.C_ps < 0 \Rightarrow bad PCMHeatCapSolid \mid params.C_pl \leq 0 \Rightarrow$ badPCMHeatCapLiquid | $params.Hf \leq$ $0 \Rightarrow \text{badHeatFusion} \mid params. Ac \leq 0 \Rightarrow$ badCoilArea | $params.rho_w < 0 \Rightarrow bad-$ WaterDensity | $params.C_w \leq 0 \Rightarrow bad$ WaterHeatCap | $params.hc \leq 0 \Rightarrow bad$ CoilCoeff | $params.hp \leq 0 \Rightarrow badPCMCo$ $eff \mid params.Tinit < 0 \lor params.Tinit >$ $100 \Rightarrow \text{badInitTemp} \mid params.tfinal$ \Rightarrow badFinalTime | params.Tinit $params.Tmelt \Rightarrow badInitAndMeltTemp)$ See Appendix (14) for the complete list of exceptions and associated error messages.

verify_recommended(params): transition: win: (Warning is thrown \Rightarrow Prints warning

message)

exception: none

8 MIS of Temperature ODEs Module

8.1 Module

temperature

8.2 Uses

parameters (5)

8.3.1 Exported Access Programs

Name	In	Out	Exceptions
temperature1	array of reals, array of reals,	array of functions	
	array of reals, parameters		
temperature2	array of reals, array of reals,	array of functions	_
	array of reals, array of reals,		
	parameters		
temperature3	array of reals, array of reals,	array of functions	_
	array of reals, parameters		
event1	array of reals, array of reals,	function	-
	array of reals, parameters		
event2	array of reals, array of reals,	function	_
	array of reals, array of reals,		
	parameters		

8.4 Semantics

8.4.1 State Variables

t: array of reals

Tw1: array of reals

Tw2: array of reals

Tw3: array of reals

Tp1: array of reals

Tp2: array of reals

Tp3: array of reals

Qp2: array of reals

8.4.2 Assumptions

All of the fields of the input parameters structure have been assigned a value. The values have been properly constrained.

8.4.3 Access Routine Semantics

temperature 1(t, Tw1, Tp1, params): output: out := $\{dTw : real \times rea$

 $real \rightarrow real, \ dTp: real \times real \times$

 $real \rightarrow real \}$

exception: none

temperature 2(t, Tw2, Tp2, Qp2, params): output: out := $\{dTw : real \times real$

 $real \rightarrow real, \ dTp: real \times r$

 $real \times real \times real \rightarrow real$

exception: none

temperature 3(t, Tw3, Tp3, params): output: out := $\{dTw : real \times rea$

 $real \rightarrow real, \ dTp: real \times real \times$

 $real \rightarrow real$

exception: none

event1(t, Tw1, Tp1, params): output: out := $Ev : real \times real \times real \rightarrow$

real

exception: none

event2(t, Tw2, T2p, Qp2, params): output: out := $Ev : real \times r$

 $real \rightarrow real$

exception: none

9 MIS of ODE Solver Module

9.1 Module

ODE Solver Module

9.2 Uses

N/A

9.3.1 Exported Access Programs

Name	In	Out	Exceptions
solve	function, array of reals, array of reals, function, real, real	array of reals (NUM_EQS of them)	-

9.4 Semantics

9.4.1 State Variables

results: array of reals $(NUM_EQS \text{ of them})$

9.4.2 Local Constants

 NUM_EQS : integer

9.4.3 Access Program Semantics

solve(f, domain, ics, events, abstol, reltol) output: out := results

exceptions: none

10 MIS of Energy Module

10.1 Module

energy

10.2 Uses

parameters (5)

10.3 Syntax

10.3.1 External Access Programs

Name	In	Out	Exceptions
energy1Wat	array of reals, parameters	array of reals	-
energy1PCM	array of reals, parameters	array of reals	_
energy2Wat	array of reals, parameters	array of reals	-
energy2PCM	array of reals, parameters	array of reals	-
energy3Wat	array of reals, parameters	array of reals	-
energy3PCM	array of reals, parameters	array of reals	_

10.4 Semantics

10.4.1 State Variables

eW1: array of reals eP1: array of reals eW2: array of reals eP2: array of reals eW3: array of reals eP3: array of reals

10.4.2 Assumptions

All of the fields of the input parameters structure have been assigned a value. The values have been properly constrained.

10.4.3 Access Routine Semantics

energy1Wat(Tw1, params): output: out := eW1[0..|Tw1|]

exception: none

energy1PCM(Tp1, params): output: out := eP1[0..|Tp1|]

exception: none

energy2Wat(Tw2, params): output: out := eW2[0..|Tw2|]

exception: none

energy2PCM(Qp2, params): output: out := eP2[0..|Qp2|]

exception: none

energy3Wat(Tw3, params): output: out := eW3[0..|Tw3|]

exception: none

energy3PCM(Tp3, params): output: out := eP3[0..|Tp3]

exception: none

11 MIS of Output Verification Module

11.1 Module

verify_output

11.2 Uses

parameters (5)

11.3 Syntax

11.3.1 Exported Access Programs

Name	In	Out	Exceptions
verify_output	array of reals, array of reals, array of reals, array of reals, parameters		-

11.4 Semantics

11.4.1 State Variables

errorWater: real errorPCM: real

11.4.2 Environment Variables

win: 2D array of pixels displayed on the screen

11.4.3 Local Variables

11.4.4 Assumptions

All of the fields of the input parameters structure have been assigned a value. The values have been properly constrained. The input arrays are not empty.

11.4.5 Access Routine Semantics

12 MIS of Plotting Module

12.1 Module

plot

12.2 Uses

N/A

12.3 Syntax

12.3.1 Exported Access Programs

Name	In	Out	Exceptions
plot	array of reals, array of reals, array of reals,	-	-
	array of reals, array of reals, string		

12.4 Semantics

12.4.1 State Variables

plotFilename: string

12.4.2 Environment Variables

directory: The current directory of files from which the program is run.

12.4.3 Assumptions

The input arrays are all of the same size.

12.4.4 Access Routine Semantics

 $\operatorname{plot}(t,\,Tw,\,Tp,\,Ew,\,Ep,\,filename)$: transition: $\operatorname{directory}$: writes a .png file

named *plotFilename* containing the graphs of the simulation re-

sults.

exception: none

13 MIS of Output Module

13.1 Module

output

13.2 Uses

parameters (5)

13.3.1 Exported Access Program

Name	In	Out	Exceptions
output	string, array of reals, array of reals, ar-	=	=
	ray of reals, array of reals, array of re-		
	als, array of reals, parameters		

13.4 Semantics

13.4.1 State Variables

outFilename: string

13.4.2 Environment Variables

directory: The current directory of files from which the program is run.

13.4.3 Access Routine Semantics

output(params, t, Tw, Tp, Ew, Ep, filename): transition: directory: writes a .txt file

named *outFilename* containing the input parameters, calculated parameters, and results of the simula-

tion.

exception: none

13.4.4 Local Constants

 max_width : integer

14 Appendix

Table 2: Possible Exceptions

Message ID	Error Message
badLength	Error: Tank length must be > 0
badDiam	Error: Tank diameter must be > 0
${\it badPCMVolume}$	Error: PCM volume must be > 0
bad PCMAnd Tank Vol	Error: PCM volume must be < tank volume

badPCMArea Error: PCM area must be > 0badPCMDensity Error: rho_p must be > 0

badMeltTemp Error: Tmelt must be > 0 and < Tc

 $badCoilAndInitTemp \qquad Error: \ Tc \ must \ be > Tinit$

badCoilTemp Error: Tc must be > 0 and < 100

 ${\bf badPCMHeatCapSolid}$ Error: C_ps must be > 0badPCMHeatCapLiquid Error: C_{-pl} must be > 0badHeatFusion Error: Hf must be > 0badCoilArea Error: Ac must be > 0badWaterDensity Error: rho_w must be > 0Error: C_{-w} must be > 0badWaterHeatCap badCoilCoeff Error: hc must be > 0 ${\it badPCMCoeff}$ Error: hp must be > 0

badInitTemp Error: Tinit must be > 0 and < 100

 $\begin{array}{ll} \mbox{badFinalTime} & \mbox{Error: tfinal must be} > 0 \\ \mbox{badInitAndMeltTemp} & \mbox{Error: Tinit must be} < \mbox{Tmelt} \end{array}$