Verification ContinuumTM

VC Formal Quick Reference Guide

Version T-2022.06-SP1, September 2022



Copyright Notice and Proprietary Information

© 2022 Synopsys, Inc. All rights reserved. This software and documentation contain confidential and proprietary information that is the property of Synopsys, Inc. The software and documentation are furnished under a license agreement and may be used or copied only in accordance with the terms of the license agreement. No part of the software and documentation may be reproduced, transmitted, or translated, in any form or by any means, electronic, mechanical, manual, optical, or otherwise, without prior written permission of Synopsys, Inc., or as expressly provided by the license agreement.

Destination Control Statement

All technical data contained in this publication is subject to the export control laws of the United States of America. Disclosure to nationals of other countries contrary to United States law is prohibited. It is the reader's responsibility to determine the applicable regulations and to comply with them.

Disclaimer

SYNOPSYS, INC., AND ITS LICENSORS MAKE NO WARRANTY OF ANY KIND, EXPRESS OR IMPLIED, WITH REGARD TO THIS MATERIAL, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE.

Trademarks

Synopsys and certain Synopsys product names are trademarks of Synopsys, as set forth at http://www.synopsys.com/company/legal/trademarks-brands.html.

All other product or company names may be trademarks of their respective owners.

Free and Open-Source Software Licensing Notices

If applicable, Free and Open-Source Software (FOSS) licensing notices are available in the product installation.

Third-Party Links

Any links to third-party websites included in this document are for your convenience only. Synopsys does not endorse and is not responsible for such websites and their practices, including privacy practices, availability, and content.

www.synopsys.com

Synopsys Statement on Inclusivity and Diversity

Synopsys is committed to creating an inclusive environment where every employee, customer, and partner feels welcomed. We are reviewing and removing exclusionary language from our products and supporting customer-facing collateral. Our effort also includes internal initiatives to remove biased language from our engineering and working environment, including terms that are embedded in our software and IPs. At the same time, we are working to ensure that our web content and software applications are usable to people of varying abilities. You may still find examples of non-inclusive language in our software or documentation as our IPs implement industry-standard specifications that are currently under review to remove exclusionary language.



Quick Reference Guide - VC Formal

INTRODUCTION

This Quick Reference Guide is to help you get started with VC Formal by showing you the most common flows, commands, and variables. The command options shown are only a sample of the many options that are available.

For detailed information, see the user guides and reference material, available through Documentation on SolvNet:

https://spdocs.synopsys.com/dow_retrieve/latest/home_public/vc_formal.html


Use the FPV Quick Reference Guide as reference for commands and variables applicable to most VC Formal Apps.



The Formal Property
Verification (FPV) App verifies
properties in the design
including user-defined and
Assertion IP (AIP) properties.




The Formal Coverage Analyzer (FCA) App assists simulation-based verification coverage signoff and qualifies formal property verification with coverage signoff.




The Formal Connectivity
Checking (CC) App checks if
there is a structural and
functional connection between
the source and the destination.




The Automatically Extracted Properties (AEP) App automatically extracts properties from the design and verify them.




The Sequential Equivalence Checking (SEQ) App compares two RTL designs and verifies that they are functionally equivalent.




The Formal Testbench Analyzer (FTA) checks if injected faults can be detected by the formal testbench thus measuring the quality of the formal testbench.











The Formal Register Verification (FRV) App automatically creates and formally verifies checks based on IP-XACT or RALF format for registers in the design


The Formal Security
Verification (FSV) App ensures
that unexpected data
propagation does not happen
between secure and nonsecure areas.

The X-Propagation Verification (FXP) App checks whether unknown signal values (X's) can propagate to dangerous points within the design.

The Data Path Validation (DPV) App uses HECTOR technology to verify data transformation blocks between untimed C/C++ and RTL models.

The Functional Safety (FuSa) App analyzes the controllability and observability of Z01X faults to calculate FMEDA (Failure Mode Effects and Diagnostic Analysis) metrics.

Quick Reference Guide - VC Formal - Formal Property Verification App



INPUT FILES FORMAT

RTL (Verilog, SystemVerilog, VHDL) file(s) SystemVerilog Assertion (SVA) file(s) Tool Command Language (Tcl) file(s)

TOOL COMMAND HELP

VF Formal launch help %vcf -help
General help groups vcf> help

List matching commands vcf> help *report**

Help for command vcf> report_fv -help

Man page for command vcf> man report fv

List matching fml vars vcf> report_fml_var *fml_max_**

List matching app vars vcf> report_app_var *fml*

RUNNING VC FORMAL <Same as FPV>

Interactive with Verdi %vcf -f run.tcl -verdi

Interactive without Verdi %vcf -f run.tcl

Batch/regression mode %vcf -f *run.tcl* -batch

Using Ultra or Elite license configuration

%vcf -f *run.tcl* -verdi -fml_ultra %vcf -f *run.tcl* -verdi -fml_elite

DESIGN SETUP & INITIALIZATION

SET VC FORMAL APP MODE

Set App mode set_fml_appmode FPV

ADD BLACKBOXES

Modules set_blackbox -designs module
Instances set_blackbox -cells hier_instance

List blackboxes report_blackbox

LOAD ASSERTION IPS

Load AIPs aip_load -protocol "AHB AXI5"

COMPILE DESIGN

Read files read_file -top *top* -sva -format verilog \

-vcs {-f filelist}

Analyze & elaborate

analyze -format verilog -vcs {-f filelist}

elaborate top -sva

CLOCKS, RESETS, AND CONSTANTS

Create clockscreate_clock clk -period 100Create resetscreate_reset rst -sense high

Add constants set_constant *testmode* -value 1'b0

Set input transition set change at -clock *clk* -default

INFER FORMAL SETUP

Infer clocks infer formal setup -type clock

Configure formal_setup_config

Report results report_formal_setup

INITIALIZE DESIGN BY SIMULATION

To stable state sim_run -stable

Or force value sim_force *signal* -apply *3'b000*

sim_run 3 -clk clk

Override state sim set state -uninitialized -user only

-apply 0

Save initial state sim_save_reset

View waveform view_trace -reset

Get initial state sim_get -signals {control_reg*}

DESIGN COMPLEXITY QUERY

Report design complexity report_fv_complexity

CHECK DESIGN SETUP

Check setup check_fv_setup

Configure check fv_setup_config

Report results report_fv_setup -list

MANAGE PROPERTIES

Create property fvassume < name > -expr {< expression > }

fvassert <name> -expr {<expression>}
fvcover <name> -expr {<expression>}

Disable propertyfvdisable propertyEnable propertyfvenable propertyChange property to assertionfvassert propertyChange property to constraintfvassume propertyChange property to coverfvcover property

CONFIGURE COMPUTE RESOURCES

Set max run time set_fml_var fml_max_time 24H

Set max memory set_fml_var fml_max_memory *32GB*

Set engine progress timeout

set_fml_var fml_progress_time_limit 2H

Set grid settings set_grid_usage -type RSH=12

set_grid_usage -file hostfile

ENABLE/DISABLE VACUITY CHECK

Check vacuity set_fml_var fml_vacuity_on true

ENABLE/DISABLE WITNESS TRACE GENERATION

Find witness set fml var fml witness on false

ENABLE REGRESSION MODE ACCELERATOR (RMA)

Enable RMA fylearn config -local dir *rma db*

RUN VERIFICATION

Run check_fv

Stop run check_fv -stop

Blocking mode check_fv -block

Callback task check_fv -run_finish {report_fv -list}

REPORT VERIFICATION RESULTS

Report results report_fv [-list|-verbose]

SAVE/RESTORE SESSION

Save session save_session -session session **Restore session** restore_session -session session

Start from stored session %vcf -restore -session session

MANAGE TRACES FOR DEBUGGING

Open trace view_trace -property property

Save trace fvtrace -property property

GENERATE VERIFICATION SUMMARY

Compute summary compute verification summary

Configure tagsset_verification_summaryWaive/unwaive tagswaive_verification_summaryReport results summaryreport_verification_summary

PERFORMANCE & CONVERGENCE

SET RUN EFFORT LEVEL

 Standard proof recipe
 set_fml_var fml_effort default

 Quick proof recipe
 set_fml_var fml_effort low

 Heavy proof recipe
 set_fml_var fml_effort high

 Bounded proof
 set_fml_var fml_effort bounded

 Falsification/covers
 set_fml_var fml_effort bug_hunting

 Target hard property
 set_fml_var fml_effort discovery

MONITOR PROGRESS QUERY

Engine status report_fml_engines
Grid job status report_fml_jobs
Grid hosts status report_fml_hosts

ADD ABSTRACTIONS

Create cutpoints snip_driver net

Abstract design constructs

set_abstractions -construct {mult=16 \
count=4}

Report abstracted constructs

report abstractions

IDENTIFY REDUCED CONSTRAINTS FOR PROOFS

Compute reduced constraints

compute_reduced_constraints \
 -property property

Report results report_reduced_constraints

Get results (Tcl) get_reduced_constraints

IDENTIFY FORMAL CORE FOR PROOFS

Compute Formal Core

compute formal core-property property

Report results report_formal_core

Get results (Tcl) get_formal_core

MANAGE TASKS

Create task fvtask -create task

Copy task fvtask *new task* -copy *task*

Copy elements between tasks


fvtask new_task -copy task \
[-assumes < list>] [-asserts < list>] \
[-covers < list>] [-constants < list>] \
[-snips < list>] [-changeats < list>] \
[-keep status] [-keep task]

Set active task fvtask task

Get active task get_fvtask

EXIT VC FORMAL

Quick Guide - VC Formal - Automatically Extracted Property App



INPUT FILES FORMAT

RTL Format (Verilog, SystemVerilog, VHDL) file(s) RTL_Format keyword < verilog | sverilog | vhdl > Tool Command Language (Tcl) file(s)

TOOL COMMAND HELP

VF Formal launch help %vcf -help

General help groups vcf> help vcf> help Formal_AEP

List matching commands vcf> help report*

Help for command vcf> report_fv -help

Man page for command vcf> man report fv

List matching fml vars vcf> report_fml_var *max*
vcf> report_app var *fml*

RUNNING VC FORMAL <Same as FPV>

Interactive with Verdi %vcf -f run.tcl -verdi

Interactive without Verdi %vcf -f run.tcl

Batch/regression mode %vcf -f run.tcl -batch

Using Ultra or Elite license configuration

%vcf -f *run.tcl* -verdi -fml_ultra %vcf -f *run.tcl* -verdi -fml_elite

DESIGN SETUP & INITIALIZATION

VC FORMAL APP MODE

Set App mode set_fml_appmode AEP

Enable AEP for VHDL designs

Set App var set app var fml enable vhdl aep true

Enable AEP for VHDL Bus checks

Set App var set_app_var fml_enable_vhdl_bus_check true

Enable AEP for VHDL FSM check

Set App var set_app_var fml_enable_vhdl_cov true

Enable AEP for Unique Name setting

Set Fml var set_fml_var fml_aep_unique_name true

COMPILE DESIGN

Read files <Normal> read_file -top my_top -aep AEP_type \

-format *RTL_format* -vcs {-f *my_filelist*}

Read files <Special type, like fsm sss>

read_file -top my_top -aep fsm_sss -cov fsm_state+fsm_trans \
-format RTL format -vcs {-f my filelist}

Analyze & elaborate

analyze -format RTL_format -vcs {-f my_filelist}

elaborate my_top -aep AEP_type

CLOCKS, RESETS AND CONSTANTS <Same as FPV >

Create clocks create_clock my_clk -period 100
Create resets create_reset my_rst -sense high
Add constants set_constant testmode -value 1'b0

INITIALIZE DESIGN BY SIMULATION <Same as FPV>

To stable state sim_run -stable

Or force value sim force sig name -apply 3'b000

sim_run 3 -clk my_clk

Override state sim_set_state -unitialized -user_only -apply 0

Save initial state sim_save_reset
View waveform view trace -reset

Get initial state sim_get -signals {control_reg*}

DESIGN SETUP QUERY <Same as FPV>

Check etup check_fv_setup

Configure check fv_check_config

Report results report_fv_setup -list

MANAGE PROPERTIES

Disable propertyfvdisable prop_nameEnable propertyfvenable prop_nameWaive propertyfvwaive prop_nameUnwaive propertyfvunwaive prop_name

CONFIGURE COMPUTE RESOURCES <Same as FPV>

Set max run time set_fml_var fml_max_time 24H

Set max memory set_fml_var fml_max_memory *32GB*

Set engine progress timeout

set_fml_var fml_progress_time_limit 2H

Set grid settings set grid usage -type RSH=10

RUN VERIFICATION <Same as FPV>

Run check_fv

Stop run check_fv -stop

Blocking mode check_fv -block

Callback task check_fv -run_finish {report_fv -list}

REPORT VERIFICATION RESULTS <Same as FPV>

Report results report_fv

Report as list report_fv -list

Report details report_fv -verbose

Save Waiver Results save_waiver_file -file aep.el

Reuse Waiver Results read_waiver_file -elfiles aep.el

SAVE/RESTORE SESSION <Same as FPV>

Save session save_session -session my_session **Restore session** restore_session -session my_session

Start from stored session %vcf -restore -session *my_session*

VIEW TRACES FOR DEBUGGING

Open falsified trace view_trace -property *prop_name*

PERFORMANCE & CONVERGENCE

MONITOR PROGRESS QUERY <Same as FPV>

Engine status report_fml_engines

Grid job status report_fml_jobs

Grid hosts status report_fml_hosts

MANAGE TASKS <Same as FPV>

Create task fvtask -create *task*

Copy task fvtask new_task -copy task

Copy elements between tasks


fvtask new_task -copy task \
 [-assumes <list>] [-asserts <list>] \
 [-covers <list>] [-constants <list>] \
 [-snips <list>] [-changeats<list>] \
 [-keep_status] [-keep_task]

Set active task fvtask task

Get active task get fvtask

EXIT VC FORMAL <Same as FPV>

Quick Guide - VC Formal - Connectivity Check App



INPUT FILES FORMAT

RTL Format (Verilog, SystemVerilog, VHDL) file(s) RTL_Format keyword < verilog | sverilog | vhdl > Tool Command Language (Tcl) file(s) Connections definition TCL or CSV

TOOL COMMAND HELP

VF Formal launch help %vcf -help

General help groups vcf> help vcf> help Formal_CC

List matching commandsvcf> help report*Help for commandvcf> report_fv -helpMan page for commandvcf> man report_fv

List matching fml vars vcf> report_fml_var *max*

List matching app vars vcf> report_app_var *fml*

RUNNING VC FORMAL <Same as FPV>

Interactive with Verdi %vcf -f *run.tcl* -verdi

Interactive without Verdi %vcf -f run.tcl

Batch/regression mode %vcf -f *run.tcl* -batch

Using Ultra or Elite license configuration

%vcf -f *run.tcl* -verdi -fml_ultra %vcf -f *run.tcl* -verdi -fml_elite

DESIGN SETUP & INITIALIZATION

VC FORMAL APP MODE

Set App mode set_fml_appmode CC

BLACKBOX SETUP

Modules set_blackbox -designs module
Instances set_blackbox -cells hier_instance

List blackboxes report_blackbox

Disable auto-blackboxing

set_fml_var fml_cc_autobbox false

COMPILE DESIGN

Read files read_file -top *top* -format verilog \

-vcs {-f filelist}

Analyze & elaborate

analyze -format verilog -vcs {-f filelist}

elaborate top

CLOCKS, RESETS AND CONSTANTS <Same as FPV>

Create clocks create_clock clk -period 100
Create resets create reset rst -sense high

Add constants set_constant testmode -value 1'b0

SPECIFY CONNECTIONS

TCL Format add_cc -src *signal* -dest *signal*

CSV Format load_cc_set_param param_name "%<value>%"

load_cc -format csv csv file

SAVE INITIAL STATE

Save initial state sim_save_reset

DESIGN SETUP QUERY <Same as FPV>

Check setup check_fv_setup

Configure check fv_setup_config

Report results report_fv_setup -list

DESIGN COMPLEXITY QUERY <Same as FPV>

Get design data report_fv_complexity

CONNECTIVITY EXTRACTION

Extraction of connections

generate_cc -src signal -dest signal -run

MANAGE PROPERTIES

Disable propertyfvdisable prop_nameEnable propertyfvenable prop_name

CONFIGURE COMPUTE RESOURCES <Same as FPV>

Set max run time set_fml_var fml_max_time *24H* **Set max memory** set_fml_var fml_max_memory *32GB*

Set engine progress timeout

set_fml_var fml_progress_time_limit 2H

Set grid settings set_grid_usage -type RSH=10

set grid usage -file hostfile

ENABLE VACUITY CHECK <Same as FPV>

Check vacuity set_fml_var fml_vacuity_on true

ENABLE REVERSE CONNECTION

Reverse connection

set_fml_var fml_allow_reverse_cc_path true

RUN VERIFICATION <Same as FPV>

Run check_fv

Stop run check_fv -stop

Blocking mode check_fv -block

Callback task check_fv -run_finish {report_fv -list}

REPORT VERIFICATION RESULTS

Report load cc connection report load cc

Report resultsreport_fvReport as listreport_fv -listReport detailsreport_fv -verbose

Report in CC format report_fv -formatCC csv|tcl|path

SAVE/RESTORE SESSION <Same as FPV>

 Save session
 save_session -session session

 Restore session
 restore_session -session session

Start from stored session %vcf -restore -session session

VIEW TRACES FOR DEBUGGING

Open falsified trace view_trace -property *prop_name*

VIEW SCHEMATIC FOR DEBUGGING

Open schematic view_schematic -prop *prop_name*

DEBUG SPECIFIC PATH

List specific path list_path -src signal -dest signal

List property path list_path -cc_prop_prop_name

CONNECTIVITY CHECK COVERAGE

Enable CC coverage

set_app_var fml_cc_coverage_analyzer true

Enable toggle coverage monitoring on input port

set_app_var fml_cov_tgl_input_port true

Enable toggle coverage at read_file/analyze

read file -top top -cov tgl

Run CC Coverage compute_cc_cov
Save CC Coverage save_cc_cov_results

PERFORMANCE & CONVERGENCE

MONITOR PROGRESS QUERY <Same as FPV>

Engine status report_fml_engines

Grid job status report_fml_jobs

Grid hosts status report_fml_hosts

MANAGE TASKS <Same as FPV>

Create task fvtask -create task

Copy task fvtask new_task -copy task

Copy elements between tasks


fvtask new_task -copy task \
 [-assumes < list >] [-asserts < list >] \
 [-covers < list >] [-constants < list >] \
 [-snips < list >] [-changeats < list >]

Set active task fvtask task

Get active task get_fvtask

EXIT VC FORMAL <Same as FPV>

Quick Reference Guide - VC Formal - Formal Coverage Analyzer App



INPUT FILES FORMAT <Same as FPV>

RTL (Verilog, SystemVerilog, VHDL) file(s) SystemVerilog Assertion (SVA) file(s) Tool Command Language (Tcl) file(s)

TOOL COMMAND HELP

VF Formal launch help %vcf -help

General help groups vcf> help Formal_FCA

List matching commands vcf> help report*

Help for command vcf> report_fv -help

Man page for command vcf> man report_fv

List matching fml vars vcf> report_fml_var fml_max_*

List matching app vars vcf> report_app_var *fml*

RUNNING VC FORMAL <Same as FPV>

Interactive with Verdi %vcf -f run.tcl -verdi

Interactive without Verdi %vcf -f run.tcl

Batch/regression mode %vcf -f *run.tcl* -batch

Using Ultra or Elite license configuration

%vcf -f *run.tcl* -verdi -fml_ultra %vcf -f *run.tcl* -verdi -fml_elite

DESIGN SETUP & INITIALIZATION

VC FORMAL APP MODE

Set App mode set_fml_appmode COV

Enable Coverage for VHDL designs

Set App var set_app_var fml_enable_vhdl_cov true

Enable the reset reachable check

Set App var set_fml_var fml_reset_property_check true

Enable Branch Coverage, if required

Set App var set_fml_var fml_cov_enable_branch_cov true

Enable Toggle Coverage for input ports, if required

Set App var set_app_var fml_cov_tgl_input_port true

Extraction of Coverage Options used in Simulation

Set App var set_app_var fml_cov_override_db_opt false

Read Simulation Coverage Database, if available

read covdb -cov input simv.vdb -cov dut

Testbench.Dut_instance [-elfile elfilename] [-check_el]

BLACKBOX SETUP <Same as FPV>

Modules set_blackbox -designs module

Instances set_blackbox -cells hier_instance

List blackboxes report blackbox

COMPILE DESIGN

Read files read file -top my top [-sva] -cov

Coverage Metric -format RTL format -vcs {-f my filelist}

Analyze & elaborate

analyze -format RTL_format -vcs {-f my_filelist}

elaborate my_top [-sva] -cov Coverage_Metric

##Where Coverage_Metric:

line+cond+tgl+fsm_state+fsm_transition+branch+cg

MANAGE CERTITUDE FAULT DATABASE

Read database read_faultdb –name *certitude_db*

Save database save faultdb -name *certitude db*

CLOCKS, RESETS AND CONSTANTS <Same as FPV>

Create clocks create_clock clk -period 100

Create resets create reset *rst* -sense high

Add constants set_constant testmode -value 1'b0

INITIALIZE DESIGN BY SIMULATION

To stable state sim_run -stable Save initial state sim_save_reset

DESIGN SETUP QUERY <Same as FPV>

Configure check fv_check_config
Check setup check_fv_setup
Report results report_fv_setup -list

VERIFICATION & DEBUG

MANAGE PROPERTIES

Disable propertyfvdisable prop_nameDisable property by typefvdisable -type toggleEnable propertyfvenable prop_name

CONFIGURE COMPUTE RESOURCES

Set max run time set_fml_var fml_max_time *24H* **Set max memory** set_fml_var fml_max_memory *16GB*

Set engine progress timeout

set_fml_var fml_progress_time_limit 2H

Set grid settings set_grid_usage -type LSF=100 -control {bsub -q ...}

REPORT VERIFICATION RESULTS

Report results report fv

Report as list report fv -list > list report.txt

Report details report_fv -verbose > verbose_report.txt

Save Exclusion file save_cov_exclusion -file exclusion.el

Save Coverage db save_covdb -status covered -name
cov.db

View Coverage view_coverage -cov_input cov.db -elfiles exclusion.el

SAVE/RESTORE SESSION <Same as FPV>

Save sessionsave_session -session sessionRestore sessionrestore_session -session session

Start from stored session %vcf -restore -session session

Enable Trace for Covered goals

Set App var set_fml_var fml_cov_gen_trace on

VIEW TRACES FOR DEBUGGING

Open covered trace view_trace -property *prop_name*

PERFORMANCE & CONVERGENCE

SET RUN EFFORT LEVEL <Same as FPV>

 Standard proof recipe
 set_fml_var fml_effort default

 Quick proof recipe
 set_fml_var fml_effort low

 Heavy proof recipe
 set_fml_var fml_effort high

 Bounded proof
 set_fml_var fml_effort bounded

 To get Covered quickly
 set_fml_var fml_effort bug_hunting

 Target hard property
 set_fml_var fml_effort discovery

MONITOR PROGRESS QUERY

Engine status report_fml_engines -engineStats

Grid job status report_fml_jobs -list > jobs_list.txt

Grid hosts status report_fml_hosts > workers_list.txt

MANAGE TASKS <Same as FPV>

Create task fvtask -create *task*

Copy task fvtask new_task -copy task

Copy elements between tasks

fvtask new_task -copy task \


[-assumes </ist>] [-asserts </ist>] \
[-covers </ist>] [-constants </ist>] \
[-snips </ist>] [-changeats</ist>]

Set active task fvtask task

Get active task get_fvtask

EXIT VC FORMAL <Same as FPV>

Quick Guide - VC Formal - Formal X-Propagation Verification App



INPUT FILES FORMAT

RTL Format (Verilog, SystemVerilog, VHDL) file(s) RTL_Format keyword < verilog | sverilog | vhdl > Tool Command Language (Tcl) file(s)

TOOL COMMAND HELP

VF Formal launch help %vcf -help

General help groups vcf> help vcf> help Formal_FXP

List matching commands vcf> help *report**

Help for command vcf> report_fv -help

Man page for command vcf> man report_fv

List matching fml vars vcf> report_fml_var *max*

List matching app vars vcf> report_app_var *fml*

RUNNING VC FORMAL <Same as FPV>

Interactive with Verdi %vcf -f *run.tcl* -verdi

Interactive without Verdi %vcf -f run.tcl

Batch/regression mode %vcf -f run.tcl -batch

Using Ultra or Elite license configuration

%vcf -f *run.tcl* -verdi -fml_ultra %vcf -f *run.tcl* -verdi -fml_elite

DESIGN SETUP & INITIALIZATION

VC FORMAL APP MODE

Set App mode set_fml_appmode FXP

BLACKBOX SETUP <Same as FPV >

 Modules
 set_blackbox -design my_module_name

 Instances
 set_blackbox -cells my_hier_instance_name

List blackboxes report_blackbox

COMPILE DESIGN <Same as FPV >

Read files

read file -top my top -sva -format sverilog -vcs {-f my filelist}

Analyze & elaborate

analyze -format sverilog -vcs {-f my_filelist}

elaborate -sva my_top

CLOCKS, RESETS AND CONSTANTS <Same as FPV >

Create clocks create_clock my_clk -period 100
Create resets create_reset my_rst -sense high
Add constants set constant testmode -value 1'b0

INITIALIZE DESIGN BY SIMULATION <Same as FPV >

To stable state sim_run -stable

Or force value sim_force *sig_name* -apply *3'b000*

sim_run 3 -clk my_clk

Override state sim set state -unitialized -user only -apply 0

Save initial state sim_save_reset
View waveform view trace -reset

Get initial state sim_get -signals {control_reg*}

DESIGN SETUP QUERY <Same as FPV >

Check setup check_fv_setup

Configure check fv_check_config

Report results report_fv_setup -list

CONFIGURE FXP

Create observe points fxp_generate <name> <type>

Custom X injection fxp_assume -injecx <options*>
Custom X remove fxp assume -nox <options*>

Custom X observe fxp assert <options*>

MANAGE PROPERTIES

Disable property fvdisable prop_name

Enable property fvenable prop_name

CONFIGURE COMPUTE RESOURCES <Same as FPV >

Set max run time set_fml_var fml_max_time 24H

Set max memory set fml var fml max memory 32GB

Set engine progress timeout

set fml var fml progress time limit 2H

Set grid settings set_grid_usage -type RSH=10

RUN VERIFICATION <Same as FPV >

Run check_fv

Stop run check_fv -stop

Blocking mode check_fv -block

Callback task check_fv -run_finish {report_fv -list}

REPORT VERIFICATION RESULTS <Same as FPV >

Report results report_fv

Report as list report_fv -list

Report details report_fv -verbose

DEBUG METHODOLOGY

Compute X Root Cause fxp compute rootcause prop name

Report X Root Cause fxp_report_rootcause

SAVE/RESTORE SESSION <Same as FPV >

Save session save_session -session my_session

Restore session restore_session -session *my_session*

Start from stored session %vcf -restore -session *my_session*

VIEW TRACES FOR DEBUGGING

Open falsified trace view_trace -property *prop_name*

PERFORMANCE & CONVERGENCE

MONITOR PROGRESS QUERY <Same as FPV >

Engine status report_fml_engines
Grid job status report_fml_jobs
Grid hosts status report_fml_hosts

MANAGE TASKS <Same as FPV>

Create task fvtask -create task

Copy task fvtask new_task -copy task

Copy elements between tasks


fvtask new_task -copy task \
 [-assumes <list>] [-asserts <list>] \
 [-covers <list>] [-constants <list>] \
 [-snips <list>] [-changeats<list>] \
 [-keep_status] [-keep_task]

Set active task fvtask task

Get active task get_fvtask

EXIT VC FORMAL < Same as FPV >

Quick Reference Guide - VC Formal - Sequential Equivalence Checking App



INPUT FILES FORMAT <Same as FPV>

RTL (Verilog, SystemVerilog, VHDL) file(s) SystemVerilog Assertion (SVA) file(s) Tool Command Language (Tcl) file(s)

TOOL COMMAND HELP <Same as FPV>

VF Formal launch help %vcf -help
General help groups vcf> help

List matching commands vcf> help report*

Help for command vcf> report_fv -help

Man page for command vcf> man report_fv

List matching fml vars vcf> report_fml_var fml_max_*

List matching app vars vcf> report_app_var *fml*

RUNNING VC FORMAL <Same as FPV>

Interactive with Verdi %vcf -f run.tcl -verdi

Interactive without Verdi %vcf -f run.tcl

Batch/regression mode %vcf -f *run.tcl* -batch

Using Ultra or Elite license configuration

%vcf -f *run.tcl* -verdi -fml_ultra %vcf -f *run.tcl* -verdi -fml_elite

DESIGN SETUP & INITIALIZATION

VC FORMAL APP MODE

Set App mode set_fml_appmode SEQ

CONFIGURE SEQ APP

Proof recipe seq_config -recipe orch_generic_medium

Mapping seq_config -map_uninit -map_x zero

BLACKBOX SETUP <Same as FPV>

 Modules
 set_blackbox -designs module

 Instances
 set_blackbox -cells hier_instance

List blackboxes report_blackbox

COMPILE DESIGNS

Analyze & elaborate

analyze -format verilog -library *spec* -vcs {-f *sfilelist*} analyze -format verilog -library *impl* -vcs {-f *ifilelist*}

elaborate_seq -spectop spec -impltop impl

CLOCKS, RESETS AND CONSTANTS <Same as FPV>

Create clocks create_clock clk -period 100
Create resets create_reset rst -sense high

Add constants set constant testmode -value 1'b0

INITIALIZE DESIGN BY SIMULATION <Same as FPV>

To stable state sim_run -stable

Or force value sim_force signal -apply 3'b000

sim run 3 -clk clk

Override state sim_set_state -uninitialized -user_only \

-apply (

Save initial state sim_save_reset
View waveform view_trace -reset

Get initial state sim_get -signals {control_reg*}

MAP DESIGNS

Map ports map_by_name

Map registers sequemap

Unmap registers sequemap

Map by file seq_read_mapping_file mappings.tcl

Report mappings report_seq_mappings

DESIGN SETUP QUERY <Same as FPV>

Check setup check_fv_setup

Configure check fv_setup_config

Report results report_fv_setup -list

DESIGN SETUP & INITIALIZATION (Continued)

DESIGN COMPLEXITY QUERY <Same as FPV>

Get design data report_fv_complexity

VERIFICATION & DEBUG

MANAGE PROPERTIES <Same as FPV>

Create property fvassume < name > -expr {< expression > }

fvassert <name> -expr {<expression>}
fvcover <name> -expr {<expression>}

Disable propertyfvdisable propertyEnable propertyfvenable propertyChange property to assertionfvassert propertyChange property to constraintfvassume propertyChange property to coverfvcover property

CONFIGURE COMPUTE RESOURCES

Set max run time set_fml_var fml_max_time 24H

Set max memory set fml var fml max memory 32GB

Set engine progress timeout

set fml var fml progress time limit 2H

Set grid settings set_grid_usage -type RSH=10

set_grid_usage -file hostfile

Set backup grid settings

set_backup_grid_usage -file hostfile

ENABLE/DISABLE VACUITY CHECK <Same as FPV>

Check vacuity set_fml_var fml_vacuity_on true

ENABLE/DISABLE WITNESS TRACE GENERATION

<Same as FPV>

Find witness set_fml_var fml_witness_on false

RUN VERIFICATION

Run check_fv

Stop run check_fv -stop

Blocking mode check_fv -block

Callback task check_fv -run_finish {report_fv -list}

Resume analysis resume_seq

REPORT VERIFICATION RESULTS <Same as FPV>

Report results report_fv

Report as list report_fv -list

Report details report_fv -verbose

QUERY SEQ PROOFS STATUS

Report proofs report_proofs

VERIFICATION & DEBUG (Continued)

SAVE/RESTORE SESSION <Same as FPV>

Save session save_session -session session

Restore session restore session -session session

Start from stored session %vcf -restore -session session

VIEW TRACES FOR DEBUGGING <Same as FPV>

 Open trace
 view_trace -property property

 Open vacuity
 view_trace -vacuity property

 Open witness
 view_trace -witness property

PERFORMANCE & CONVERGENCE

SET RUN EFFORT LEVEL

 Standard proof recipe
 set_fml_var fml_effort default

 Quick proof recipe
 set_fml_var fml_effort low

 Heavy proof recipe
 set_fml_var fml_effort high

 Bounded proof
 set_fml_var fml_effort bounded

 Falsification/covers
 set_fml_var fml_effort bug_hunting

Easy proof recipe set_fml_var fml_effort easy

Hard bit-level proof recipe

set_fml_var fml_effort bitlevel_hard

No expensive decomposition proof recipe

set_fml_var fml_effort no_decompose_expensive

ENABLE REGRESSION MODE ACCELERATOR (RMA)

<Same as FPV>

Enable RMA fylearn config -local dir rma db

MONITOR PROGRESS QUERY <Same as FPV>

Engine status report_fml_engines
Grid job status report_fml_jobs
Grid hosts status report_fml_hosts

ADD ABSTRACTIONS

Create cutpoints snip driver net

Abstract design constructs

set_seq_abstractions -construct {mult=16 \
 add=4}

Report abstracted constructs

report_abstractions

IDENTIFY REDUCED CONSTRAINTS FOR PROOFS <Same as FPV>

Compute reduced constraints

compute_reduced_constraints \
 -property property

Report results report_reduced_constraints

Get results (Tcl) get_reduced_constraints

PERFORMANCE & CONVERGENCE (Continued)

IDENTIFY FORMAL CORE FOR PROOFS <Same as FPV>

Compute Formal Core

compute_formal_core -property property

Report results report_formal_core
Get results (Tcl) get_formal_core

MANAGE TASKS <Same as FPV>

Create task fvtask -create *task*

Copy task fvtask new_task -copy task

Copy elements between tasks


fvtask new_task -copy task \
 [-assumes < list >] [-asserts < list >] \
 [-covers < list >] [-constants < list >] \
 [-snips < list >] [-changeats < list >]

Set active task fvtask task

Get active task get_fvtask

EXIT VC FORMAL <Same as FPV>

Quick Reference Guide - VC Formal - Formal Register Verification App



INPUT FILES FORMAT

RTL (Verilog, SystemVerilog, VHDL) file(s) SystemVerilog Assertion (SVA) file(s) Tool Command Language (Tcl) file(s) IPXACT file: XML file with register definitio

IPXACT file: XML file with register definitions RALF file: RALF file with register definitions

TOOL COMMAND HELP <Same as FPV>

VF Formal launch help %vcf -help
General help groups vcf> help

List matching commands vcf> help report*

Help for command vcf> report_fv -help

Man page for command vcf> man report_fv

List matching fml vars vcf> report_fml_var *fml_max_**

List matching app vars vcf> report_app_var *fml*

RUNNING VC FORMAL <Same as FPV>

Interactive with Verdi %vcf -f *run.tcl* -verdi

Interactive without Verdi %vcf -f run.tcl

Batch/regression mode %vcf -f *run.tcl* -batch

Using Ultra or Elite license configuration

%vcf -f *run.tcl* -verdi -fml_ultra %vcf -f *run.tcl* -verdi -fml_elite

DESIGN SETUP & INITIALIZATION

VC FORMAL APP MODE

Set App mode set_fml_appmode FRV

BLACKBOX SETUP <Same as FPV>

Modules set_blackbox -designs module
Instances set_blackbox -cells hier_instance

List blackboxes report_blackbox
LOAD FRV CONFIGURATION

Load IPXACT file frv_load -ipxact axi4lite_dmac.xml -

auto load

Load RALF file frv load -ral axi4lite dmac.ralf -auto load

COMPILE DESIGN & BIND FRV CHECKER

Read files read file -top top -sva -format verilog \

-vcs {-f filelist} bind_frv.sv

Analyze & elaborate (unified flow)

analyze -format verilog -vcs {-f filelist}

bind_frv.sv
elaborate top -sva

CLOCKS, RESETS AND CONSTANTS <Same as FPV>

Create clocks create_clock clk -period 100
Create resets create_reset rst -sense high

Add constants set constant testmode -value 1'b0

INITIALIZE DESIGN BY SIMULATION <Same as FPV>

To stable state sim_run -stable

Or force value sim_force *signal* -apply *3'b000*

sim run 3 -clk clk

Override state sim_set_state -uninitialized -user_only \

-apply 0

Save initial state sim_save_reset

View waveform view trace -reset

Get initial state sim_get -signals {control_reg*}

DESIGN SETUP QUERY <Same as FPV>

Check setup check_fv_setup

Configure check fv_setup_config

Report results report fv setup-list

DESIGN COMPLEXITY QUERY <Same as FPV>

Get design data report_fv_complexity

MANAGE PROPERTIES <Same as FPV>

Create property fvassume < name > -expr {< expression > }

fvassert <name> -expr {<expression>}
fvcover <name> -expr {<expression>}

Disable propertyfvdisable propertyEnable propertyfvenable propertyChange property to assertionfvassert propertyChange property to constraintfvassume propertyChange property to coverfvcover property

CONFIGURE COMPUTE RESOURCES <Same as FPV>

Set max run time set_fml_var fml_max_time 24H

Set max memory set_fml_var fml_max_memory *32GB*

Set engine progress timeout

set_fml_var fml_progress_time_limit 2H

Set grid settings set_grid_usage -type RSH=10

set_grid_usage -file hostfile

ENABLE/DISABLE VACUITY CHECK <Same as FPV>

Check vacuity set_fml_var fml_vacuity_on true

ENABLE/DISABLE WITNESS TRACE GENERATION <Same as FPV>

Find witness set_fml_var fml_witness_on false

RUN VERIFICATION <Same as FPV>

Run check_fv

Stop run check_fv -stop

Blocking mode check_fv -block

Callback task check fv -run finish {report fv -list}

REPORT VERIFICATION RESULTS

Report results report_fv -class register

Report as list report_fv -class register -list

Report details report_fv -class register -verbose

Report register data frv_report

SAVE/RESTORE SESSION <Same as FPV>

Save session save_session -session session

Restore session restore_session -session session

Start from stored session %vcf -restore -session session

VIEW TRACES FOR DEBUGGING <Same as FPV>

 Open trace
 view_trace -property property

 Open vacuity
 view_trace -vacuity property

 Open witness
 view trace -witness property

PERFORMANCE & CONVERGENCE

SET RUN EFFORT LEVEL <Same as FPV>

 Standard proof recipe
 set_fml_var fml_effort default

 Quick proof recipe
 set_fml_var fml_effort low

 Heavy proof recipe
 set_fml_var fml_effort high

 Bounded proof
 set_fml_var fml_effort bounded

 Falsification/covers
 set_fml_var fml_effort bug_hunting

 Target hard property
 set_fml_var fml_effort discovery

ENABLE REGRESSION MODE ACCELERATOR (RMA)

<Same as FPV>

Enable RMA fvlearn_config -local_dir *rma_db*

MONITOR PROGRESS QUERY <Same as FPV>

Engine status report_fml_engines
Grid job status report_fml_jobs
Grid hosts status report_fml_hosts

ADD ABSTRACTIONS <Same as FPV>

Create cutpoints snip_driver net

Abstract design constructs

set_abstractions -construct {mult=16 \
count=4}

Report abstracted constructs

report abstractions

IDENTIFY REDUCED CONSTRAINTS FOR PROOFS <Same as FPV>

Compute reduced constraints

compute_reduced_constraints \
 -property property

Report results report_reduced_constraints

Get results (Tcl) get_reduced_constraints

IDENTIFY FORMAL CORE FOR PROOFS <Same as FPV>

Compute Formal Core

compute_formal_core -property property

Report results report_formal_core
Get results (Tcl) get_formal_core

MANAGE TASKS <Same as FPV>

Create task fvtask -create *task*

Copy task fvtask new_task -copy task

Copy elements between tasks


fvtask new_task -copy task \
 [-assumes < list >] [-asserts < list >] \
 [-covers < list >] [-constants < list >] \
 [-snips < list >] [-changeats < list >]

Set active task fvtask task

Get active task get_fvtask

PERFORMA	ANCE & CONVERGENCE (Continued)
##### EXIT VC FORMAL <same as="" fpv=""></same>	
Exit VC Formal	

Quick Reference Guide - VC Formal - Formal Testbench Analyzer App



INPUT FILES FORMAT <Same as FPV>

RTL (Verilog, SystemVerilog, VHDL) file(s) SystemVerilog Assertion (SVA) file(s) Tool Command Language (Tcl) file(s)

TOOL COMMAND HELP <Same as FPV>

VF Formal launch help %vcf -help
General help groups vcf> help

List matching commands vcf> help *report**

Help for command vcf> report_fv -help

Man page for command vcf> man report_fv

List matching fml vars vcf> report_fml_var *fml_max_**

List matching app vars vcf> report_app_var *fml*

RUNNING VC FORMAL <Same as FPV>

Interactive with Verdi %vcf -f run.tcl -verdi

Interactive without Verdi %vcf -f run.tcl

Batch/regression mode %vcf -f *run.tcl* -batch

Using Ultra or Elite license configuration

%vcf -f *run.tcl* -verdi -fml_ultra %vcf -f *run.tcl* -verdi -fml_elite

DESIGN SETUP & INITIALIZATION

SET VC FORMAL APP MODE

Set App mode set_fml_appmode FTA

ADD BLACKBOXES <Same as FPV>

Modules set_blackbox -designs module
Instances set_blackbox -cells hier_instance

List blackboxes report_blackbox

CONFIGURE FAULT INJECTION

Specify targets fta_init

Configure faults configure_fta_props

COMPILE DESIGN & INJECT FAULTS

Read files read file -top top -sva -format verilog \

-vcs {-f filelist} -inject_fault all

Analyze & elaborate (unified flow)

set_app_var fml_multi_step_fta_flow true
analyze -format verilog -vcs {-f filelist}
elaborate top -sva -inject_fault all

MANAGE CERTITUDE FAULT DATABASE

Read database read_faultdb –name certitude_db
Save database save faultdb -name certitude db

CLOCKS, RESETS, AND CONSTANTS <Same as FPV>

 Create clocks
 create_clock clk -period 100

 Create resets
 create_reset rst -sense high

 Add constants
 set_constant testmode -value 1'b0

Set input transition set_change_at -clock *clk* -default

INITIALIZE DESIGN BY SIMULATION <Same as FPV>

To stable state sim_run -stable

Or force value sim_force signal -apply 3'b000

sim run 3 -clk clk

Override state sim_set_state -uninitialized -user_only \

-apply 0

Save initial state sim_save_reset
View waveform view_trace -reset

Get initial state sim_get -signals {control_reg*}

DESIGN COMPLEXITY QUERY <Same as FPV>

Report design complexity report_fv_complexity

CHECK DESIGN SETUP <Same as FPV>

Check setup check_fv_setup
Configure check fv_setup_config
Report results report_fv_setup -list

MANAGE PROPERTIES <Same as FPV>

Create property fvassume < name > -expr {< expression > }

fvassert <name> -expr {<expression>}
fvcover <name> -expr {<expression>}

Disable propertyfvdisable propertyEnable propertyfvenable propertyChange property to assertionfvassert propertyChange property to constraintfvassume propertyChange property to coverfvcover property

CONFIGURE COMPUTE RESOURCES <Same as FPV>

Set max run time set_fml_var fml_max_time 24H

Set max memory set_fml_var fml_max_memory *32GB*

Set engine progress timeout

set_fml_var fml_progress_time_limit 2H

Set grid settings set_grid_usage -type RSH=12

set_grid_usage -file hostfile

ENABLE/DISABLE VACUITY CHECK <Same as FPV>

Check vacuity set_fml_var fml_vacuity_on true

ENABLE/DISABLE WITNESS TRACE GENERATION <Same as FPV>

Find witness set_fml_var fml_witness_on false

RUN VERIFICATION

Run compute_fta -par_task FPV

check fv

Stop run check_fv -stop

Blocking mode compute_fta -par_task FPV -block

check fv-block

Callback task compute_fta -par_task FPV \

-run_finish {report_fv -list}

check_fv -run_finish {report_fv -list}

REPORT VERIFICATION RESULTS <Same as FPV>

Report results report_fv [-list | -verbose]

QUERY FAULT INFORMATION

Report faults fta_report -instance *instance*

get_fta_faults instance

Report activated properties

get_activated_props fault_id

SAVE/RESTORE SESSION <Same as FPV>

Save session save_session -session session

Restore session restore_session -session session

Start from stored session %vcf -restore -session session

VERIFICATION & DEBUG (Continued)

VIEW TRACES FOR DEBUGGING <Same as FPV>

Open trace view_trace -property property

Save trace fvtrace -property property

GENERATE VERIFICATION SUMMARY <Same as FPV>

Compute summary compute_verification_summary

Configure tags set_verification_summary
Waive/unwaive tags waive_verification_summary
Report results summary report_verification_summary

CLUSTER FAULTS FOR ANALYSIS

Cluster faults cluster_fta_faults

Report clusters report_fta_fault_clusters

SWITCH TO ADVANCED DEBUGGING

Export detected faults to parent task

export_fault

Debug non-detected faults in SEQ App

debug fta

PERFORMANCE & CONVERGENCE

SET RUN EFFORT LEVEL

Standard proof recipe set fml var fml effort default

Heavy proof recipe for parent task sanity check

set_fml_var fml_fta_par_app_high_effort true

Heavy proof recipe for fault analysis

set_fml_var fml_fta_high_effort true

SET RUN SCOPE

Check faults in Formal Core only

set_fml_var fml_qual_fault_in_fcore true

Include cover properties for fault analysis

set_fml_var fml_fta_enable_cover true

MONITOR PROGRESS QUERY <Same as FPV>

Engine status report_fml_engines
Grid job status report_fml_jobs
Grid hosts status report_fml_hosts

ADD ABSTRACTIONS <Same as FPV>

Create cutpoints snip driver net

Abstract design constructs

set_abstractions -construct {mult=16 \
count=4}

Report abstracted constructs

report_abstractions

PERFORMANCE & CONVERGENCE (Continued)

IDENTIFY REDUCED CONSTRAINTS FOR PROOFS <Same as FPV>

Compute reduced constraints

```
compute_reduced_constraints \
    -property property
```

Report results report_reduced_constraints **Get results (Tcl)** get_reduced_constraints

IDENTIFY FORMAL CORE FOR PROOFS <Same as FPV>

Compute Formal Core

compute_formal_core -property property

Report results report_formal_core
Get results (Tcl) get_formal_core

MANAGE TASKS <Same as FPV>

Create task fvtask -create *task*

Copy task fvtask new_task -copy task

Copy elements between tasks


fvtask new_task -copy task \
 [-assumes <list>] [-asserts <list>] \
 [-covers <list>] [-constants <list>] \
 [-snips <list>] [-changeats<list>] \
 [-keep_status] [-keep_task]

Set active task fvtask task

Get active task get_fvtask

EXIT VC FORMAL <Same as FPV>

Quick Reference Guide - VC Formal - Functional Safety Verification App



INPUT FILES FORMAT

RTL (Verilog, SystemVerilog, VHDL) file(s) SystemVerilog Assertion (SVA) file(s) Tool Command Language (Tcl) file(s) Standard Fault File (SFF) Fault Database (FDB)

TOOL COMMAND HELP <Same as FPV>

VF Formal launch help %vcf -help
General help groups vcf> help

List matching commands vcf> help *report**

Help for command vcf> report_fv -help

Man page for command vcf> man report_fv

List matching fml vars vcf> report_fml_var fml_max_*

List matching app vars vcf> report_app_var *fml*

RUNNING VC FORMAL <Same as FPV>

Interactive with Verdi %vcf -f run.tcl -verdi
Interactive without Verdi %vcf -f run.tcl

Batch/regression mode %vcf -f *run.tcl* -batch

Using Ultra or Elite license configuration

%vcf -f *run.tcl* -verdi -fml_ultra %vcf -f *run.tcl* -verdi -fml_elite

DESIGN SETUP & INITIALIZATION

VC FORMAL APP MODE

Set App mode set_fml_appmode FUSA

BLACKBOX SETUP <Same as FPV>

Modules set_blackbox -designs module
Instances set_blackbox -cells hier_instance

List blackboxes report_blackbox

LOAD FuSa FAULT LIST

Load FDB fusa_config -fdb_campaign *fdbname*

Load SFF file fusa_config -sff *input.sff*

COMPILE DESIGN <Same as FPV>

Read files read_file -top top -sva -format verilog \

-vcs {-f filelist}

Analyze & elaborate (unified flow)

analyze -format verilog -vcs {-f filelist}

elaborate top -sva

CLOCKS, RESETS AND CONSTANTS <Same as FPV>

Create clocks create_clock clk -period 100
Create resets create_reset rst -sense high

Add constants set constant *testmode* -value 1'b0

INITIALIZE DESIGN BY SIMULATION <Same as FPV>

To stable state sim_run -stable

Or force value sim force signal -apply 3'b000

sim run 3 -clk clk

Override state sim set state -uninitialized -user only

-apply 0

Save initial state sim_save_reset

View waveform view_trace -reset

Get initial state sim get -signals {control reg*}

DESIGN SETUP QUERY <Same as FPV>

Check setup check_fv_setup

Configure check fv_setup_config

Report results report_fv_setup -list

DESIGN COMPLEXITY QUERY <Same as FPV>

Get design data report_fv_complexity

CONFIGURE & GENERATE FuSa CHECKS

Add Observation Point fusa_observation -add obs_point

Add Detection Point fusa_detection -add det_point

Generate FuSa Checks fusa_generate

MANAGE PROPERTIES

Create property fvassume < name > -expr {< expression > }

fvassert <name> -expr {<expression>}
fvcover <name> -expr {<expression>}

Disable property fvdisable *property* **Enable property** fvenable *property*

CONFIGURE COMPUTE RESOURCES <Same as FPV>

Set max run time set_fml_var fml_max_time 24H

Set max memory set_fml_var fml_max_memory *32GB*

Set engine progress timeout

set_fml_var fml_progress_time_limit 2H

Set grid settings set grid usage -type RSH=10

set_grid_usage -file hostfile

RUN VERIFICATION

Run structural analysis

set_fml_var fusa_run_mode structural

check_fv

Run controllability analysis

set_fml_var fusa_run_mode control

check_fv

Observability analysis

set_fml_var fusa_run_mode observe

check_fv

Stop run check_fv -stop

Blocking mode check_fv -block

REPORT VERIFICATION RESULTS

Report results report_fv

Report as list report_fv -list

Report details report_fv -verbose

FuSa report fusa_report

FuSa report as list fusa_report -list

SAVE FuSa RESULTS

Save results in FDB fusa_save

Save results as SFF fusa_save -sff sff

SAVE/RESTORE SESSION <Same as FPV>

Save session save_session -session session

Restore session restore_session -session session

Start from stored session %vcf -restore -session session

VIEW TRACES FOR DEBUGGING <Same as FPV>

 Open trace
 view_trace -property property

 Open vacuity
 view_trace -vacuity property

 Open witness
 view_trace -witness property

PERFORMANCE & CONVERGENCE

SET RUN EFFORT LEVEL

 Standard proof recipe
 set_fml_var fml_effort default

 Easy proof recipe
 set_fml_var fml_effort easy

 Quick proof recipe
 set_fml_var fml_effort low

 Heavy proof recipe
 set_fml_var fml_effort high

 Bounded proof
 set_fml_var fml_effort bounded

 Falsification/covers
 set_fml_var fml_effort bug_hunting

Large number of properties


set_fml_var fml_effort No_decopmpose_expensive

MONITOR PROGRESS QUERY <Same as FPV>

Engine status report_fml_engines
Grid job status report_fml_jobs
Grid hosts status report_fml_hosts

EXIT VC FORMAL <Same as FPV>

Quick Reference Guide - VC Formal - Formal Security Verification App



INPUT FILES FORMAT <Same as FPV>

RTL (Verilog, SystemVerilog, VHDL) file(s) SystemVerilog Assertion (SVA) file(s) Tool Command Language (Tcl) file(s)

TOOL COMMAND HELP <Same as FPV>

VF Formal launch help %vcf -help
General help groups vcf> help

List matching commands vcf> help report*

Help for command vcf> report fv -help

Man page for command vcf> man report_fv

List matching fml vars vcf> report_fml_var fml_max_*

List matching app vars vcf> report_app_var *fml*

RUNNING VC FORMAL <Same as FPV>

Interactive with Verdi %vcf -f run.tcl -verdi

Interactive without Verdi %vcf -f run.tcl

Batch/regression mode %vcf -f run.tcl -batch

Using Ultra or Elite license configuration

%vcf -f *run.tcl* -verdi -fml_ultra %vcf -f *run.tcl* -verdi -fml_elite

DESIGN SETUP & INITIALIZATION

VC FORMAL APP MODE

Set App mode set_fml_appmode FSV

BLACKBOX SETUP

Modules set_blackbox -designs module
Instances set_blackbox -cells hier_instance

FSV blackbox fsv_blackbox *instance*

List blackboxes report_blackbox

COMPILE DESIGN <Same as FPV>

Read files read_file -top top -sva -format verilog \

-vcs {-f filelist}

Analyze & elaborate

analyze -format verilog -vcs {-f *filelist*}

elaborate top -sva

CLOCKS, RESETS AND CONSTANTS <Same as FPV>

Create clocks create_clock clk -period 100
Create resets create_reset rst -sense high

Add constants set constant testmode -value 1'b0

INITIALIZE DESIGN BY SIMULATION <Same as FPV>

To stable state sim run -stable

Or force value sim_force *signal* -apply *3'b000*

sim run 3 -clk clk

Override state sim set state -uninitialized -user only

-apply 0

Save initial state sim_save_reset

View waveform view_trace -reset

Get initial state sim get -signals {control reg*}

DESIGN SETUP QUERY <Same as FPV>

Check setup check_fv_setup

Configure check fv_setup_config

Report results report_fv_setup -list

DESIGN COMPLEXITY QUERY <Same as FPV>

Get design data report_fv_complexity

MANAGE PROPERTIES <Same as FPV>

Generate FSV properties

fsv_generate -src src_sig -dest dest_sig

Create property fvassume < name > -expr {< expression > }

fvassert <name> -expr {<expression>}
fvcover <name> -expr {<expression>}

Disable property fvdisable *property*

Enable property fvenable property

Change property to assertion fvassert *property* **Change property to constraint** fvassume *property*

Change property to cover fvcover property

CONFIGURE COMPUTE RESOURCES

Set max run time set fml var fml max time 24H

Set max memory set_fml_var fml_max_memory 32GB

Set engine progress timeout

set_fml_var fml_progress_time_limit 2H

Set grid settings set_grid_usage -type RSH=10

set_grid_usage -file hostfile

Set backup grid settings

set_backup_grid_usage -file hostfile

ENABLE/DISABLE VACUITY CHECK <Same as FPV>

Check vacuity set_fml_var fml_vacuity_on true

ENABLE/DISABLE WITNESS TRACE GENERATION <Same as FPV>

Find witness set fml var fml witness on false

RUN VERIFICATION <Same as FPV>

Run check_fv

Stop run check_fv -stop

Blocking mode check fv -block

Callback task check_fv -run_finish {report_fv -list}

REPORT VERIFICATION RESULTS

Report FSV properties

fsv report

Report results report_fv

Report as list report_fv -list

Report details report_fv -verbose

SAVE/RESTORE SESSION <Same as FPV>

Save session save_session -session session

Restore session restore session -session session

Start from stored session %vcf -restore -session session

VERIFICATION & DEBUG (Continued)

VIEW TRACES FOR DEBUGGING <Same as FPV>

Open trace view_trace -property property
Open vacuity view_trace -vacuity property
Open witness view trace -witness property

PERFORMANCE & CONVERGENCE

SET RUN EFFORT LEVEL

 Standard proof recipe
 set_fml_var fml_effort default

 Quick proof recipe
 set_fml_var fml_effort low

 Heavy proof recipe
 set_fml_var fml_effort high

 Bounded proof
 set_fml_var fml_effort bounded

 Falsification/covers
 set_fml_var fml_effort bug_hunting

Easy proof recipe set_fml_var fml_effort easy

No expensive decomposition proof recipe

set_fml_var fml_effort no_decompose_expensive

ENABLE RESUME FOR FSV

Enable resume set_fml_var fml_enable_resume true

MONITOR PROGRESS QUERY <Same as FPV>

Engine status report_fml_engines
Grid job status report_fml_jobs
Grid hosts status report_fml_hosts

MANAGE TASKS <Same as FPV>

Create task fvtask -create task

Copy task fvtask *new task* -copy *task*

Copy elements between tasks


fvtask new_task -copy task \
 [-assumes < list >] [-asserts < list >] \
 [-covers < list >] [-constants < list >] \
 [-snips < list >] [-changeats < list >]

Set active task fvtask task

Get active task get_fvtask

EXIT VC FORMAL <Same as FPV>

Quick Reference Guide - VC Formal - Data Path Validation App



INPUT FILES FORMAT

C/C++/SystemC files(s)

RTL (Verilog, SystemVerilog, VHDL) file(s)

SystemVerilog Assertion (SVA) file(s)

Tool Command Language (Tcl) file(s)

TOOL COMMAND HELP

VF Formal launch help %vcf -help

General help groups vcf> help Formal DPV

List matching commands vcf> help report*

Help for command vcf> listlemmas -help

RUNNING VC FORMAL <Same as FPV>

Interactive with Verdi %vcf -f run.tcl -verdi

Interactive without Verdi %vcf -f run.tcl

Batch/regression mode %vcf -f run.tcl -batch

Using Ultra or Elite license configuration

%vcf -f run.tcl -verdi -fml ultra %vcf -f run.tcl -verdi -fml_elite **DESIGN SETUP & INITIALIZATION**

SET DPV APP MODE

Set App mode set_fml_appmode DPV

Get App mode get_fml_appmode

NEW COMPILATION FLOW SETTING

C compilation set _hector_comp_use_new_flow true

RTL compilation set _hector_enable_nldm_compile true

CONFIGURE AEP CHECKS

Set AEP checks set_aep_selection default

List AEP checks list_aep_selection

BLACKBOX SETUP

Modules set blackbox module

Instances set blackbox hier instance

ignore functions "list of functions" Functions

Blackbox Report get blackbox

COMPILE DESIGN

Create design create design -name spec | impl \

-top spectop | impltop \

-clock clk -reset resetN -negReset \ -options "compilation options" \

-lang "c/c++/verilog/sverilog"

C/C++ compilation

cppan -D<defines> \

-I<include directories>\

<C/C++ filenames>

SystemC compilation

scdtan -D<defines> \

-I<include directories>\

<C/C++ filenames>

RTL compilation

vcs -sverilog -pvalue+<> -f filelist

vlogan <options> <filelist>

vhdlan <options> <filelist>

Compile design compile design spec/impl

CONSTANTS

assume -always (impl.testmode==1'b0) Add constants

MAPPING

Map by name inputs/outputs map_by_name -

specphase <phase> -implphase <phase> -inputs | -outputs

Get Map info report_dpv_mappings

DESIGN COMPLEXITY QUERY

Get design data report_fv_complexity

PROOF PROCEDURE

Set main proof procedure

set_user_assumes_lemmas_procedure "ual"

Set case split procedure

set_hector_case_splitting_procedure "case_split_strategy"

ASSUMPTIONS

Add assumptions assume (spec.opcode(1)==3'd3)

Add assumptions fvassume -expr "spec.opcode(1)==3'd3"

LEMMAS

Add lemmas

lemma (impl.vld(7) |-> (spec.out(1)==impl.res(7)))

Add lemmas

fvassert -expr "impl.vld(7) |-> (spec.out(1)==impl.res(7))"

COVER PROPERTIES

Add covers cover (impl.res(3)==4'd6)

Add covers fvcover -expr "impl.res(3) = 4'd6"

DELETE PROPERTIES

Delete lemma/assume/cover fvdelete propName>

CASE ASSUMPTIONS

Add case assume caseAssume (spec.mult(1) == 2'd0)

HDPS SETUP

Enable HDPS set_hector_rew_use_dps_engine true
Select HDPS solve script set_hector_rew_dps_solve_script
_hector_orch_custom_dps2

Set HDPS resource limit

set_hector_rew_dps_resource_limit 1200

Run All HDPS options

run_all_hdps_options -encoding [list radix4] hdps_proofname

ENABLE/DISABLE VACUITY CHECK

Check vacuity set_app_var fml_vacuity_on true

CONFIGURE COMPUTE RESOURCES

Set resource limit set resource limit 200

Set task timeout set_hector_task_timeout 1000

Set grid settings set_host_file *hostfile*

RUN VERIFICATION

Run check fv

solveNB *proofName*

solveNB init proofName

Stop run check_fv -stop

Blocking mode check_fv -block

solve *proofName*

solve init proofName

VERIFICATION & DEBUG (Continued)

REPORT VERIFICATION RESULTS

Report proofslistproofsReport prooflistproofReport taskslisttasks

Report task listtask taskID

Report assumes listassumes
Report lemmas listlemmas
Report covers listcovers

SAVE/RESTORE SESSION

Save session save_session

save_proofs

Restore session restore session

restore_proofs

Start from stored session %vcf -restore -session session

VIEW TRACES FOR DEBUGGING

Open trace view_trace -property propertyname

simcex *propertyname* -print -joint_compile

GDB trace simcex *propertyname* -gdb -print

Open vacuity view_trace -vacuity *property*

PERFORMANCE & CONVERGENCE

SET RUN EFFORT LEVEL

Custom solve script

set_custom_solve_script "orch_abo_sat"

Enable all solve scripts

set_hector_multiple_solve_scripts true

Enable selective solve scripts

set_hector_multiple_solve_scripts true

set_hector_multiple_solve_scripts_list [list scripts]

Show all solve scripts show_all_solve_scripts

Get all solve scripts get all solve scripts

MONITOR PROGRESS QUERY

Engine status report_fml_engines

Grid job status report_fml_jobs

ADD ABSTRACTIONS

Create cutpoint set_cutpoint impltop.partial

Activate cutpoint cutpoint cutname = impl.partial(3)

IDENTIFY CONFLICTNG CONSTRAINTS FOR PROOFS

Compute conflicting constraints conflictcore

PERFORMANCE & CONVERGENCE (Continued)

MANAGE TASKS <Same as FPV>

Create task fvtask -create *task*

Copy task fvtask new_task -copy task

Copy elements between tasks

fvtask new_task -copy task \
 [-assumes <list>] [-asserts <list>] \
 [-covers <list>] [-constants <list>] \
 [-snips <list>] [-changeats<list>] \
 [-keep_status] [-keep_task]

Set active taskfvtask taskGet active taskget_fvtask

EXIT VC FORMAL