# Capítulo 1 First

# 1.1. Control theory

#### 111 Basics

Taylor expansion (Linearization) of two-variable nonlinear equation.

$$f(x,y) = f(\overline{x}, \overline{y}) + \left[\frac{\partial f}{\partial x}(x - \overline{x}) + \frac{\partial f}{\partial y}(y - \overline{y})\right] + \dots$$

Matlab command to convert state space to transfer function [num,den]=ss2tf(A,B,C,D,iu) where iu must be specified for systems with more than one input.

### 1.1.2. State space

 $\mathbf{u}(t)$  is inputs vector and is of size  $p \times 1$  for a given system, i.e.  $\mathbf{u}(t) = \begin{bmatrix} u_1 \\ u_2 \end{bmatrix}$  for two input system, p=2.

 $\mathbf{y}(t)$  is the output vector of size  $q \times 1$ .

 $\mathbf{z}(t)$  is the disturbance input. Only applies to dynamical systems and is of size r imes 1

Thus we define the **state space variables** so that system output is purely in function of current system state variables and input variables.

$$\mathsf{System}\ \mathsf{Output} = f\left(\mathsf{Current}\ \mathsf{System}\ \mathsf{State},\ \mathsf{System}\ \mathsf{Input}\right)$$

We will define X or  $\mathbf{x}$  as our system state variables. There are some important aspects to note about state space variables such as

- ullet System output  $\mathbf{y}(t)$  will be a function of them
- They change over time
- They are internal to the system
- They may include system outputs (outputs will be a function of themselves in part)
- Their selection is inherent part of the system design process and there are different methods of selecting them.

2 CAPÍTULO 1. FIRST

 We will assume there is a minimal quantity of state variables that is sufficient to accurately describe the system

■ If all system inputs  $u_j$  are defined beforehand for  $t \geq t_0$  then  $\mathbf{x}(t)$  defines all system states for time  $t \geq t_0$ 

The mathematical representation of state space variables will be will be that of the state vector  $\mathbf{x}(t)$  of size  $n \times 1$ .

To model our system we then define the equations that govern it in state space<sup>1</sup>. These are the state-space equations of the system. For a dynamic system these must include a variable that serves as memory of inputs for  $t \geq t_1$ . Integrators serve as memory devices for continuous-time models, however, our state-space representation is discrete! This is when state-space variables come in handy: The outputs of integrators can be considered as the variables that define the internal state of the dynamic system (Ogata).

For a system of size p=q=n=1 one has the state-space representation defined as:

$$\dot{x}(t) = g[t_0, t, x(t), x(0), u(t)], \qquad y = h[t, x(t), u(t)]$$

For a *linear time-variant dynamical system* of arbitrary size it is convenient to represent it in it's linearized form

$$\dot{\mathbf{x}}(t) = \mathbf{A}(t)\mathbf{x}(t) + \mathbf{B}(t)\mathbf{u}(t) + \mathbf{E}(t)\mathbf{z}(t)$$
(1.1)

$$\mathbf{y}(t) = \mathbf{C}(t)\mathbf{x}(t) + \mathbf{D}(t)\mathbf{u}(t) \tag{1.2}$$

where

 $\mathbf{A}_{n \times n}$  System matrix. Relates future state change with current state. May be zero. Also referred to as the state matrix in some bibliographies.

 $\mathbf{B}_{n \times p}$  Control/input matrix. How system input influences state change. May be zero.

 $\mathbf{C}_{q \times n}$  Output matrix. How system state influences system output.

 $\mathbf{D}_{q \times p}$  Feed forward or feedthrough matrix. How system input influences system output. Is usually zero for most physical systems.

 $\mathbf{E}_{n \times r}$  Input matrix for disturbances. Applies only for dynamical systems.

the system is said to be **time-invariant** if the above matrices are not dependent of time. An example of a **time-variant** system is a spacecraft, whose mass changes due to fuel consumption.

One method of state space variable selection is **physical selection**. This method is based on energy acumulators. It can be said that the minimum number of state-space variables needed to

State space can be thought of an n-dimensional space whose axes are the state variables  $(x_1, x_2 \ldots)$ 

3

model the system accurately is equal to the number of independent energy accumulators. When state-space variable is not a energy variable it is said to be an augmented variable.

La solución general de la ecuación diferencial lineal de estados:

$$\dot{\mathbf{x}}(t) = \mathbf{A} \ \mathbf{x}(t) + \mathbf{B} \ \mathbf{u}(t)$$

es

$$\mathbf{x}(t) = e^{\mathbf{A}(t-t_0)}\mathbf{x})0 + \int_0^t e^{\mathbf{A}(t-\tau)}\mathbf{B} \ \mathbf{u}(\tau)d\tau$$

## Definition 1.1 (Matrix Exponential)

A continuación se tienen dos formas de calcular la matriz exponencial en  ${
m MATLAB}$  usando el taylor centrado en cero.

CÓDIGO 1.1: matrixexponential.m

```
A = rand(3);
t1 = 0.5;
fprintf('e^(At)=');disp(exp(A*t1));
fprintf('e^(At)=');disp(expt(t1,le4,A));
function y = expt(t,n,A)
    y = ones(size(A,1));
    for i=1:n
        y = y + (A*t).^i/factorial(i);
    end
end
```