


Answer (2 point): An electronic control unit (ECU) is an embedded system that controls one or more of the electrical subsystems in a vehicle. Sensors, actuators and ECUs are often one unit in mechatronic systems.




Answer (2 point): ECUs should be tested mandatorily. ECU integrates functionalities for calculation, analysis of sensor data and controlling actuators.

White box testing should be performed in calculation and on sensed data provided by the dedicated sensor for the ECU. Black box test should be performed in the actuator controlling against the requirement.



Aufgabe 4

From the knowledge gained during Unit 1, Please match the below elements to their correct assignment. Use Drag & Drop to put the words to the correct position.



Answer(1.5marks):

Control = ECU Input = Light Sensor

Output = LED

Aufgabe 5

Which of the following is true about Asynchronous communication?

(Please select at most 4 answers, otherwise selecting more answers will result in 0 for this question)

- If communication clock is higher than bit rate, then clock division is required
- ☐ If communication clock is higher than bit rate, then clock division is not required due to master clock
- Re-synchronisation phase is not needed

Absence of a centralised master clock

Re-synchronisation phase is necessary

Communication speed is managed through a master clock

Communication bit rate is same for all nodes



With your understanding of CAN arbitration process, determine the correct sending order from the following message-IDs, when multiple nodes in a CAN-Network are trying to send simultaneously. Move the from the left list to correct position in

0x 0FF 0x 0TE 0x 100 0x 009 0x 00C 2 0x00C 1 5 0x0FF 2 3 0x01E 3 4 0x0AC 4

Aufgabe 7

the right list. Message ID List: 0x 0AC

0x009



Answer(2marks):

229=11100101 (OE5)

197=11000101 (0C5)

In binary answer is

Mask: 11011111 (ODF)

Accept: 11x00101 => 11100101 (0E5) or 11000101 (0C5)



Answer (4 marks):

C X X X X X

Aufgabe 10 Following is an 8-bit MASK and ACCEPT configuration. Please select which of the IDs can be accepted or not using this configuration on an ECU node connected to a CAN-Bus. 0xF1 Mask: 0x01 ACCEPT: Will be Rejected Will be Accepted 0x10 X 0 0 0x01 0/ 0 0x03 0x13 X 0 0 0x0F 2 0 0xF3 0xFA X 0

0

0x09



```
(5) 89 Minuten 12 Sekunden
PIT_StopTimer(1):
7
void PIT_CHANNEL1(void) /* timer 1 interrupt function */
SIU.GPDO[59].R = 0:
    Timer is set to 100 ms
    Timer is never started
   LED 6 will turn ON only once, depending an switch input
   LED can remain permanently OFF
    ☐ LED can remain permanently ON
    Interrupt function will be only triggered when timer is started
    LED 6 will blink every 100 ms
    ☐ Interrupt function will be always triggered until program stops
    ☐ Timer is set to 1 sec
    ☐ Timer can remain permanently started
    LED 6 is turned on before timer starts
    ☐ Timer is wrongly configured
    Switch has no influence on LED
```

Aufgabe 12

What are the main ideas of the standard "AUTOSAR" (Automotive Open Systemarchitecture)?



Aufgabe 13

Explain the concept of "Complex Device Drivers" in AUTOSAR. What is it? Where is it located in the AUTOSAR architecture diagram? Why is it needed?

Answer(2marks): Complex Device Driver (CDD) enables the integration of special-purpose functionality that is not specified in AUTOSAR. The interface to RTE must be AUTOSAR compliant. Direct hardware access.

In AUTOSAR architecture diagram, it is located in the Basic Software Components. It works as a stack between the ECU and the RTE.

CDD provides hardware compatibility that is not supported, simplifies the migration process from non-AUTOSAR to AUTOSAR ECUs, time critical functions, and functional safety.

Aufgabe 14

Which elements are used to create a software architecture (application) in AUTOSAR?

Micro Senrices, Kubernetes, Cloud

Webservice, FIBEX, SVN

Software components, Database, Registers

AL Machine Learning, SVM

Software components, Ports, Interfaces, Runnables

Container, Constructor, Loops

Function, Classes, Registers, Interrupts

Aufgabe 15	
What does VFB mean in the context of AUTOSAR? State its benefit and the	software development stage in which it is used.


Answer (2): Virtual Functional Bus – VFB:

- Logical connection of software components from application with each other
- Before mapping of ports to concrete signals/bus system
- Before mapping of SWCs to ECUs (application as non distributed)

Benefits:


• Enables testing (without BSW) of software components – test not on target platform

Used in Implementation/Generation of application stage



Aufgabe 17

Put the given words to the correct position in the picture of two ECUs with AUTOSAR architecture.



Aufgabe 18 What is the main difference between static test and dynamic test? Explain shortly, in which development phases static test and dynamic test are mostly used. Aktuell geschriebene Wörter: 0

Answer(2marks):

Static test: Test object is not executed, but analyzed.


Dynamic test: Test object is executed(partly).

Static test mostly used during/at the end of implementation to save software quality and code compliance. Where dynamic test mostly used after implementation.

Aufgabe 19

The SuT (System under Test) represents the test object and test environment.


What does PoC and PoO in SuT stand for? What do they realize?





Answer(2marks):

In System under Test (SuT), Point of Control (PoC) realizes simulation of an object with test data and Point of Observation (PoO) realizes the output reading test object.



Answer(3marks):

Component Test:

• Directly after development, small units, classes or modules are tested, often white box test.

Integration Test


• Set of components is connected and tested

System Test:

• Test from customer point of view where integrated components are tested.

Acceptance Test:

• Considered as final test where test regards the user contract and user acceptance.



Testing Park Pilot of a Car

The functionality of the Park Pilot System (PPS) of a car was developed and needs to be tested. The Park Pilot System supports the driver in parking. A button with two posible states (on. off) activates or deactivates the park pilot assist,

Enshurer:

- . The park pilot can be switched on by the driver. It can be switched on when the speed from the car is less than 10 km/h
- . The park pilot will be deactivated when sensors are not working (sensor status)

Possibles values of the sensors:

 button for park pilot : 0 - OFF, 1 - ON

 current speed: < 10 km/h, >= 10 km/h

 sensor status: 0 - ERROR, 1 - WORKS

Possibles States of Park Pilot System:

0 - OFF, 1 - ON

The test engineer has defined the following truth table based on the specification.

	0
<10 km/h	0
	0
	1
>=10 km/h	0
	0
	0
	0


Question a:

Which test strategy is represented by the given truth table (for example random test strategy)?

Answer (5 marks):

a)

It is sequential test strategy.



```
Answer(6marks) a:
varBtn|varTempSensor|varHeater
0|-|0
1 <= 60 | 1
1|>60|0
Answer(6marks) b:
Start
Dialog ("Hi! Button is off and Heater is off")
varBtn=can.read(varBtn)
varTempSensor=can.read(varTempSensor)
varHeater =can.read(varHeater)
if(varBtn == 0 && varTempSensor == 0 && varHeater == 0)
{
       Success
}
else
{
       Failed
}
Dialog ("Hi! Temperature is less than 60, Button is on, and Heater is on")
varBtn =can.read(varBtn)
varTempSensor =can.read(varTempSensor)
varHeater =can.read(varHeater)
```

```
if(varBtn == 1 && varTempSensor<60 && varHeater == 1)
{
       Success
}
else
{
       Failed
}
Dialog ("Hi! Temperature is greater than 60, Button is on, and Heater is off")
varBtn =can.read(varBtn)
varTempSensor =can.read(varTempSensor)
varHeater =can.read(varHeater)
if(varBtn == 1 && varTempSensor>=60 && varHeater == 0)
{
       Success
}
else
       Failed
}
```

Aufgabe 24 Punkte: 10 Keine Antwort

Please write C-Code for the boards used in the practical to perform the following specified tasks:

- · Configure the required hardware peripherals (pins, LEDs and switches)
- . Send a CAN message with ID 3610 every 1000ms
- This message to be sent uses 3 data fields to send the following information:
 Data-byte[0]: Button 5 , Data-byte[1]: Button 6, Data-byte[2]: Light sensor value
- For the light sensor value, 8 least significant bits should be sent. The light sensor is connected to Feature "ANA IN1" shown in the table on next page.
- The board should also receive a can message with ID 3716
- The message to be received has 4 data fields. These data fields represent 4 LEDs. Please turn the LEDs "on" or "off" according to the data you get from the CAN message. The possible values for this representation are 0 and 1.
 - Data-byte[X] contains status for LED X, where X ranges from 0 to 3.
- . LED 5 blinks every second and LED 6 blinks at an interval of 200 ms.

Please use the provided information. It helps you to write the code.

Input/output

A button can be configured as digital input by writing "0x0100" to the corresponding PCR register. A pressed button or a switch on "action" results in a low signal ("0") on the pin. This signal can be checked by the input register of the corresponding pin ("SIU.GPDI[X].R", where X=corresponding PCR register number). Pins can be configured as output by writing a "0x200" to the corresponding PCR register. To set a digital output write "0" or "1" to the corresponding output register "SIU.GPDO[X].R". Analog inputs can be configured by writing a "0x2500" to the corresponding register. The converted values can be retrieved by reading the "ADC_0.CDR[2].B.CDATA" register.

You can find the PCR register numbers in the following description in Table 1.

Timer

No software interrupts need to be configured. There is only one timer available. Please use the function "PIT_ConfigureTimer(int timerChannel, int period)" to configure this timer. To start the timer use the function "PIT_StartTimer(int timerChannel)".

Parameter Value

timerChannel Timer channel to be configured period Period in milliseconds

Upon successful configuration of the timer interrupt, function "PITCHANNELOO" will be automatically called. Implement this function for timer related tasks.

CAN

To reduce the complexity of the task you may configure the CAN driver just like this:

SIU.PCR[16].B.PA = 1; /* TX CAN pin configuration */
SIU.PCR[17].B.PA = 1; /* RX CAN pin configuration */

Furthermore for sending a CAN message you just need to set the register with the following constructs. It is possible to use some of them more than once. For example, the following code sends character "a" using the message ID 10.

CAN

To reduce the complexity of the task you may configure the CAN driver just like this:

SIU.PCR[16].B.PA = 1; /* TX CAN pin configuration */

SIU.PCR[17].B.PA = 1; /* RX CAN pin configuration */

Furthermore for sending a CAN message you just need to set the register with the following constructs. It is possible to use some of them more than once. For example, the following code sends character "a" using the message ID 10.

CAN_0.8UF[0].MSG_ID.8.STD_ID = 10; /* message identifier */

CAN_B.BUT[8].CS.B.LENGTH = 1; /* message length */

CAN_RSUN[8]_DATA.8[0] = 'a'; /" data byte 0 "/

CAN_BBW [W].CS.B.CODE = 0xC; /" code for sending a message "/

Implement the function "CANRCV()" to handle the received messages. This function is called automatically if a new CAN message is received. In this function you can read the following registers within the if-condition. "X" is replaceable.

CAN_0.BUF[0].ID.B.STD_ID /* received message identifier */

CAN_0.BUF[0].DATA.B[X] /* received data byte X */

0

Feature	CPU pin name	PCR register	Comments		
LED7	PA11	11	Light when command is low		
LED6	PD11	59	Light when command is low		
LED5	PD13	61	Light when command is low		
LED4	PD14	62	Light when command is low		
LED3	PA12	12	Light when command is low		
LED2	PA13	13	Light when command is low		
LED1	PC10	42	Light when command is low		
LED0	PA9	9	Light when command is low		
BT6	PA0	0	On = low		
BT5	PA1	1	On = low		
ANA IN1	PC1	33	External analog input		
ANA IN2	PC2	34	External analog input		
ANA OUT	PC9	41	Analog output		
POT	PE1	65	Potentiometer		
TEMP	PE2	66	Temperature Sensor		

Table 1: Overview of PCR registers for I/O

Please use the following code skeleton for your answer in the text area below: -----Start of Code-------/* global variables */ /" pin configuration "/ void configure(Voxe) / SIU.PCR(JR =) SUPONIA :: SULPCRIJA = ; SIU.PCR(J.R =) SUPCRIJA :: SILLACR(] R = ; SIU.PCR() R = : SUPCRIJA :: SULPCRIJA = ; SIUPORILEPA = : SUPCRIJURA ::

/* main function */

void main(void) (

init(); /* board initialization */

configure(); /* pin configuration */

for(:) (

)

/* timer interrupt function */

void PIT_CHANNELO(void) (

```
Answer(6marks) a:
```

```
//global variables
int lightValue = ADC0.CDR[2].B.CDATA;
SIU.PCR[0].R = 0x0100; //BT5
SIU.PCR[1].R = 0x0100; //BT6
SIU.PCR[9].R = 0x0200; //LED0
SIU.PCR[42].R = 0x0200; //LED1
SIU.PCR[13].R = 0x0200; //LED2
SIU.PCR[12].R = 0x0200; //LED3
SIU.PCR[62].R = 0x0200; //LED4
SIU.PCR[61].R = 0x0200; //LED5
SIU.PCR[59].R = 0x0200; //LED6
SIU.PCR[33].R = 0x2500; //ANA IN 1
SIU.PCR[16].B.PA = 1 //Tx CAN pin config
SIU.PCR[17].B.PA = 1 //Rx CAN pin config
//Can buffer configuration
CAN_0.BUF[8].MSG_ID.B.STD_ID = 36;
CAN_0.BUF[8].CS.B.LENGTH = 3;
CAN_0.BUF[8].CS.B.CODE = 8;
//Configuration timers
PIT_ConfigureTimer(1,200);
```

```
PIT_ConfigureTimer(2,1000);
PIT_StartTimer(1);
PIT_StartTimer(2);
//inside for loop
if(CAN 0.BUF[0].ID.B.STD ID == 0x37){
      SIU.GPDO[9].R = CAN_0.BUF[0].DATA.B[0];
       SIU.GPDO[42].R = CAN_0.BUF[0].DATA.B[1];
      SIU.GPDO[13].R = CAN 0.BUF[0].DATA.B[2];
      SIU.GPDO[12].R = CAN 0.BUF[0].DATA.B[3];
}
//after main
void PIT_Channel_1(void){
       SIU.GPDO[59].R = ~SIU.GPDO[59].R;
       PIT.CHANNEL[1].TLFG.R = 1;
}
void PIT_Channel_2(void){
       SIU.GPDO[61].R = ~SIU.GPDO[61].R;
       CAN 0.BUF[8].DATA.B[0] = SIU.GPDI[0].R;
       CAN_0.BUF[8].DATA.B[1] = SIU.GPDI[1].R;
       CAN_0.BUF[8].DATA.B[2] = lightValue & 0xFF;
       CAN_0.BUF[8].CS.B.CODE = 0xC;
       PIT.CHANNEL[1].TLFG.R = 1;
}
```