
Module 5: Memory Organization

- ➤ Memory System: Basic Concepts
- ➤ Memory hierarchy
- ➤ Main Memory
- ➤ Secondary storage
- ➤ Cache memory mapping
- ➤ Cache coherence


Specification

- How much?
 - Capacity
- How fast?
 - Time is money
- How expensive?

Hierarchy List



Hierarchy List



SRAM	VERSUS	DRAM	

SRAM A type of semiconductor memory that uses bi-stable atching circuitry (flip flop) to store each bit	DRAM A type of random access semiconductor memory that stores each bit of data in a separate tiny capacitor within an integrated circuit	
Stands for Static Random Access Memory	Stands for Dynamic Random Access Memory	
Very fast	Not as fast as SRAM	
Ooes not require refresh cycles to retain data	Requires periodical refresh cycles to retain data	
Requires refreshing, it has more complex circuitry and timing requirements	Not as complex as SRAM	
Used for CPU cache	Used for the computer's main memory	
Require minimum time to access data	Requires more time to access data	
Complex structure - has flip flops	Simple structure - has a transistor and a capacitor	
Has a lower density Expensive	Has a higher density Less expensive	

REGISTERS

- 1) Registers are present inside the processor.
- They are basically a set of flip-flops.
- 3) They store data and addresses and can directly take part in arithmetic and logic operations.
- 4) They are very small in size typically **just a few bytes**.

PRIMARY MEMORY

- 1) It is the original form of memory also called as **Main memory**.
- 2) It comprises of RAM and ROM, both are Semi-Conductor memories. (chip memories)
- 3) ROM is non-volatile.
 - It is used is storing permanent information like the BIOS program.
 - It is typically of 2 MB 4 MB in size.
- 4) RAM is writable and hence is used for day-to-day operations.
 - Every file that we access from secondary memory, is **first loaded into RAM**.
 - To provide large amount of working space RAM is **typically 4 GB 8 GB**.

SECONDARY MEMORY

- The main purpose of Secondary Memory is to increase the storage capacity, at low cost.
- Its biggest component is the Hard Disk.
 This is where all the files inside a computer are stored.
- 3) It is writeable as well as non-volatile.
- 4) Typical size of a **HD** is 1 **TB**.
- 5) Disk memories are much slower than chip memories but are also much cheaper.

PORTABLE SECONDARY MEMORY

- These are required to physically transfer files between computers.
- 2) Floppy Disk: It is a magnetic form of storage. Typical Size is 1.44 MB.
- 3) CD: It is an optical form of storage. Typical Size is 700 MB.
- DVD: It is an optical form of storage. Typical Size is 4.7 MB.
- 5) Pen Drives & Memory Cards: It is a semi-conductor form of storage.
 - It is composed of FLASH ROM.
 - It's a special type of ROM that's writable as well as non-volatile.
 - Typical Size ranges form 1 GB 64 GB depending upon the cost.

CACHE MEMORIES

- 1) It is the **fastest form of memory** as it uses SRAM (Static RAM).
- The Main Memory uses DRAM (Dynamic RAM).
- 3) SRAM uses flip-flops and hence is much faster than DRAM which uses capacitors.
- 4) But SRAM is also **very expensive** as compared to DRAM.
- 5) Hence only the current portion of the file we need to access is copied from Main Memory (DRAM) to Cache memory (SRAM), to be directly accessed by the processor.
- 6) This gives maximum performance and yet keeps the cost low.
- Typical size of Cache is around 2 MB 8MB.
- If code and data are in the same cache then it is unified cache else its called split cache.
- 9) Depending upon the location of cache, it is of three types: L1, L2 and L3.
- 10) L1 cache is present inside the processor and is a split cache typically 4-8 KB.
- 11) L2 is present on the same die as the processor and is a unified cache typically 1 MB.
- 12) L3 is present outside the processor. It is also unified and is typically of 2-8 MB.

MEMORY CHARACTERISTICS

1) Location

Based on its physical location, memory is classified into three types.

- On-Chip: This memory is present inside the CPU. E.g.:: Internal Registers and L1 Cache.
- Internal: This memory is present on the motherboard. E.g.:: RAM.
- External: This memory is connected to the motherboard. E.g.:: Hard disk.

2) Storage Capacity

This indicates the **amount of data stored** in the memory. Obviously it should be **as large as possible**.


It is represented as $N \times M$.

Here,

N = **Number of memory locations** (no of words)

M = Number of pits per memory location (word size)

E.g.:: $(4K \times 8)$ means there are 4K locations of 8-bits each.



3) Transfer Modes

Data can be accessed from memory in two different ways.

- · Word Transfer: Here, if CPU needs some data, it will transfer only that amount of data.
 - E.g.:: Data accessed from **L1 Cache.**
- Block Transfer: Here, if CPU needs some data, it will transfer an entire block containing that data.
 This makes further access to remaining data of this block much faster. This is based on Principle of Spatial Locality. A processor is most likely to access data near the current location being accessed.

E.g.:: On a cache miss, processor goes to main memory and copies a block containing that data.

4) Access Modes

Memories can allow data to be accessed in two different ways.

- Serial Access: Here locations are accessed one by one in a sequential manner.
 - The access time depends on how far the target location is, from the current location.

Farther the location, more will be its access time.

E.g.:: Magnetic tapes.

- Random Access: Here all locations can be directly accessed in any random order.
 - This means all locations have the same access time irrespective of their address.

E.g.:: Most modern memories like RAM.

5) Physical Properties

There are various Physical attributes to memory.

- Writeable: Contents of the memory can be altered. E.g.:: RAM
- Non-Writeable: Contents of the memory cannot be altered. E.g.:: ROM
- Volatile: Contents of the memory are lost when power is switched off. E.g.:: RAM
- Non-Volatile: Contents of the memory are retained when power is switched off. E.g.:: ROM Most secondary memories like Hard disk are Writable as well as non-volatile.

6) Access Time (t_A)

It is the time taken between placing the request and completing the data transfer.

It should be as less as possible.

It is also known as latency.

7) Reliability

It is the **time** for which the memory is expected to **hold the data without any errors**.

It is measured as MTTF: Mean Time To Failure.

It should be as **high as possible**.

8) Cost

This indicates the **cost of storing data** in the memory.

It is expressed as Cost/bit.

It must be as low as possible.

9) Average Cost

It is the total cost per bit, for the entire memory storage.

Consider a system having two memories M₁ (RAM) & M₂ (ROM)

If C_1 is the cost of memory M_1 of size S_1

& C_2 is the cost of memory M_2 of size S_2

Then the average cost of the memory is be calculated as:

$$C_{AVG} = (C_1 S_1 + C_2 S_2) / (S_1 + S_2)$$

Small sizes of expensive memory and large size of cheaper memory lowers the average cost.

10)Hit Ratio (H)

Consider two memories M_1 and M_2 .

 M_1 is closer to the processor E.g.:: RAM, than M_2 E.g.:: Hard disk.

If the desired data is found in M_1 , then it is called a Hit, else it is a Miss.

Let N_1 be the number of **Hits** and N_2 the number of **Misses**.

The **Hit Ratio** H is defined as **number of hits divided by total attempts**.

$$H = (N_1) / (N_1 + N_2)$$

It is expressed s a percentage.

H can never be 100%. In most computers it is maintained around 98%.

From the above discussion it is clear that no single memory can satisfy all the characteristics, hence we need a hierarchy of memories.

Cache memories are the fastest but also the most costly.

Hard disk is writeable as well as non volatile and is also very inexpensive, but is much slower.

CD/DVD etc. are needed for **portability**.

ROM is nonvolatile, and is used for storing BIOS.

DRAM is writable, faster than hard disk and cheaper than SRAM hence forms most part of Main Memory.

So you want fast?

- It is possible to build a computer which uses only static RAM (see later)
- This would be very fast
- This would need no cache
 - How can you cache cache?
- This would cost a very large amount


Locality of Reference

- During the course of the execution of a program, memory references tend to cluster
- e.g. loops


Cache

- Small amount of fast memory
- placed between normal main memory and CPU
- May be located on CPU chip or module

Cache and Main Memory





(a) Single cache



(b) Three-level cache organization

Cache/Main Memory Structure






Cache operation – overview

- CPU requests contents of memory location
- Check cache for this data
- If present, get from cache (fast)
- If not present, read required block from main memory to cache
- Then deliver from cache to CPU
- Cache includes tags to identify which block of main memory is in each cache slot

Cache memory



CACHE MAPPING TECHNIQUES

Blocks are loaded from Main Memory to Cache Memory.

Cache Mapping decides which block of Main Memory comes into which block of Cache Memory.

There are several mapping techniques trying to balance between Hit Ratio, Search-time and Tag size.

Every cache block has a **Tag** indicating which block of Main Memory is mapped into that block.

A collection of such tags is called the **cache director**y, very similar to a page table.

Cache directory is a part of the cache.

Since Cache Memory is **very expensive**, we need the cache directory to be as small as possible.

That means the **Tag must be of minimum size**.

The Main Memory address, issued by the processor contains the desired block number.

This is compared to the Tag of a Cache Block, which gives the Block number that is present.


If they are equal, it's a Hit. If Not, the search may have to be repeated for several other blocks.


It is obvious to understand, the number of searches must be as low as possible.

Finally, the Mapping technique must yield maximum utilization of the Cache memory space, so that the **Hit ratio remains as High as possible**.


There are three popular Cache Mapping Techniques:


- 1) Associative Mapping also called Fully Associative Mapping
- 2) Direct Mapping also called One-Way Set Associative Mapping
- 3) Set Associative Mapping also called Two-Way Set Associative Mapping





Block = 4B






15 April 2025

Associabre Magory

	211			
	44 45 46 47			
<u></u>	32 38 34 25			
Ши— L2	60 61 62 63			
100 L	36 37 18 39			


3	1000	0.1	> sfab	Addr = 1
6	1001	10	>	Addu







Dr. S Saritha | Computer Organization & Architecture (ECE2002) | VIT-AP



ASSOCIATIVE MAPPING (FULLY ASSOCIATIVE MAPPING)

During memory operations, Blocks are loaded from Main Memory to Cache Memory.

Cache Mapping decides which block of Main Memory comes into which block of Cache Memory.

Fully Associative Mapping technique states:

Any block of Main Memory can be mapped at Any available block of Cache Memory.

There are no rules restricting the mapping at all.

This means the Full Cache is available for mapping hence the name Fully Associative.

Consider Pentium Processor Cache

Size of Main Mem: $4GB = 2^{32}$

Size of Cache Mem: $8KB = 2^{13}$

Size of Cache Block (Line): 32 bytes (words) = 2^5

No. of Blocks in Main Mem: Size of Main Memory $(2^{32}) \div$ Size of Block $(2^5) = 2^{27}$

No. of Blocks in Cache Mem: Size of Cache Memory (2^{13}) ÷ Size of Block (2^{5}) = 2^{8} = 256

Main Mem address: 32 bits (because main Mem is of $4GB = 2^{32}$)

Tag Size:

A block of Cache Memory can **contain any block** of main memory out of a possible **2**²⁷ **blocks**. Hence, the **Tag** next to every block in Cache Memory must be of **27 bits**.

Searches:

A block of main Memory can be **mapped into any block** of Cache Memory out of **256 Blocks**. Hence, we need to do **256 searches** in Cache Memory.

Method of Searching:

The Processor issues a 32 bit Main Memory address. It can be divided as:

Main Memory Address:

27 BIT	5 BIT	
Block No.	Location Within Block	

This 27 bit Block number is the block number we need to search.

The Tag of each cache block also contains a 27-bit block number.

This is the block number that's present in that respective cache block.

These two block numbers are compared. If they are equal, it's a HIT.

If not equal, the search is repeated with the Tag of the next cache block.

This is done a total of 256 times as there are 256 blocks in Cache Memory.

If none of them match with the block number we are searching, then it's a Miss.


Advantage

Since the full cache is available for mapping, it causes maximum utilization of Cache Memory hence gives the **Best Hit Ratio**.

Drawback

Tag Size too big: 27bits.

Searches are too many: 256.



DIRECT MAPPING (ONE WAY SET ASSOCIATIVE MAPPING)

Direct Mapping technique states:

Any block of Main Memory can only be mapped at ONE block of Cache Memory.

Since there is only one way of Mapping, its also called One Way Set Associative Mapping.

We treat the entire Cache as One Set.

The Main Memory is divided into Sets which are then subdivided into Blocks.

A Block of Main Mem. (of any set), can only be mapped into the same Block No. in Cache Mem.

This means, Block 0 of Main Memory (of any set), can only be mapped into Block 0 of Cache Memory. In other words, Block 0 of Cache Memory can only contain Block 0 of Main Memory but of any Set.

Consider Pentium Processor Cache

Size of Main Mem:	$4GB = 2^{32}$
Size of Cache Mem:	8KB = 2 ¹³ this is treated as One Set
Hence Size of Set:	$8KB = 2^{13}$
Size of Cache Block (Line):	32 bytes (words) = 2 ⁵
No. of Blocks in a set:	Size of Set (2^{13}) ÷ Size of Block (2^{5}) = 2^{8} = 256
No. of Sets in Main Mem:	Size of Main Mem (2^{32}) ÷ Size of Set (2^{13}) = 2^{19}
No. of Sets in Cache Mem:	1
Main Mem address:	32 bits (because main Mem is of 4GB = 2 ³²)

Tag Size:

Since, Block 0 of Cache Memory can only contain Block 0 of Main Memory but of any Set, the Tag has to only indicate the Set No. of Main Memory, from which the block is present.

As Main Memory has 2¹⁹ sets, the **Tag** size is **19 bits**.

Searches:

If we need Block 0 if Main Memory, we only need to search Block 0 of Cache Memory. Hence, we need to do only **1 search** in Cache Memory to know if it is a Hit or a Miss.

Method of Searching:

The Processor issues a 32 bit Main Memory address. It can be divided as:

Main	Memory
Ad	dress:

19 BIT	8 BIT	5 BIT
Set No.	Block No.	Location Within Block

First we look at the block no. we need, to know where we need to search.

We then look at the Set No. that we need and compare it with the Tag of the corresponding Block no in the Cache Memory.

Assume the Main Memory address is 5:0:6. This means we need location 6 of Block 0 of set 5. We go to Block 0 of Cache Memory.

It has a Tag, which gives the Set No of Main Memory whose Block 0 is present in Cache Memory.


These two set numbers are compared. If they are equal, it's a HIT, else it's a Miss.

Advantage

In 1 Search we know if it is a Hit or a Miss. Tag Size = 19 bits.

Drawback

Since the method is **very rigid**, the **Hit Ratio drops tremendously.**



SET ASSOCIATIVE MAPPING (TWO WAY SET ASSOCIATIVE MAPPING)

Two way Set Associative Mapping technique states:

A block of Main Memory can only be mapped into the same corresponding Block No. of Cache Memory, in any of the two sets.

Since there are two ways of Mapping, its called Two Way Set Associative Mapping.

We treat the entire Cache as **Two Sets**. The Main Memory is divided into Sets, subdivided into Blocks.

A Block of Main Mem. (of any set), can only be mapped into the same Block No. in Cache Memory again of any set. This means, Block 0 of Main Memory (of any set), can only be mapped into Block 0 of Cache Memory, into one of its two sets.

In other words, Block 0 of Cache Memory can only contain Block 0 of Main Memory but of any Set.

Consider Pentium Processor Cache (This is Actually how Pentium's Cache is implemented)

Size of Main Mem:

Size of Cache Mem:

Hence Size of Set:

Size of Cache Block (Line):

No. of Blocks in a set:

No. of Sets in Main Mem:

Main Mem address:

AGB = 2³²

8KB = 2¹³ ... this is treated as Two Sets

4KB = 2¹²

Size of Cache Block (Line):

32 bytes (words) = 2⁵

Size of Set (2¹²) ÷ Size of Block (2⁵) = 2⁷ = 128

Size of Main Mem (2³²) ÷ Size of Set (2¹²) = 2²⁰

2

32 bits (because main Mem is of 4GB = 2³²)

Tag Size:

Since, Block 0 of Cache Memory can only contain Block 0 of Main Memory but of any Set, the Tag has to only indicate the Set No. of Main Memory, from which the block is present.

As Main Memory has 2²⁰ sets, the **Tag** size is **20 bits**.

Searches:

If we need Block 0 if Main Memory, we only need to search Block 0 of Cache Memory, but in any of the two sets. Hence, we need **2 searches** in Cache Memory to know if it is a Hit or a Miss.

Method of Searching:

The Processor issues a 32 bit Main Memory address. It can be divided as:

Main	Memory
Ad	dress:

20 BIT	7 BIT	5 BIT
Set No.	Block No.	Location Within Block

First we look at the block no. we need, to know where we need to search.

We then look at the Set No. that we need and compare it with the Tags of the corresponding Block no in the Cache Memory, in any of the two sets.

Assume the Main Memory address is 5:0:6. This means we need location 6 of Block 0 of set 5.

We go to Block 0 of Cache Memory, in both sets.

It has a Tag, which gives the Set No of Main Memory whose Block 0 is present in Cache Memory.


These required Set no. is compared with the two Tags. If found in any of the 2, it's a HIT, else Miss.

Advantage

In 2 Searches we know if it is a Hit or a Miss. Tag Size = 20 bits.

Drawback

Since the method is **flexible**, it significantly **increases** the **Hit Ratio**.



Expanding the logic of set associative cache further, we can derive the following conclusion:

No of Ways	No of Searches	TAG SIZE	No of Blocks in a Set	
2 Way	2	20 bits	128	
4 Way	4	21 bits	64	
8 Way	8	22 bits	32	
16 Way	16	23 bits	16	
32 Way	32	24 bits	8	
64 Way	64	25 bits	4	
128 Way	128	26 bits	2	
256 Way	256	27 bits	1	
This becomes ex	This becomes exactly the same as Fully Associative: 256 Searches, 27-bit Tag			

Problem # 1 :A computer system uses 16-bit memory addresses. It has a 2K-byte cache organized in a direct-mapped manner with 64 bytes per cache block. Assume that the size of each memory word is 1 byte.

- (a) Calculate the number of bits in each of the Tag, Block, and Word fields of the memory address.
- (b) When a program is executed, the processor reads data sequentially from the following word addresses: 128, 144, 2176, 2180, 128, 2176 All the above addresses are shown in decimal values.

Assume that the cache is initially empty. For each of the above addresses, indicate whether the cache access will result in a hit or a miss.

Solution

(a) Block size = 64 bytes = 2^6 bytes = 2^6 words (since 1 word = 1 byte)

Therefore, Number of bits in the Word field = 6

Cache size = 2K-byte = 2^{11} bytes

Number of cache blocks = Cache size / Block size = $2^{11}/2^6 = 2^5$

Therefore, Number of bits in the Block field = 5

Total number of address bits = 16

Therefore, Number of bits in the Tag field = 16 - 6 - 5 = 5

For a given 16-bit address, the 5 most significant bits, represent the *Tag*, the next 5 bits represent the *Block*, and the 6 least significant bits represent the *Word*.

(b) The cache is initially empty. Therefore, all the cache blocks are invalid.

Access # 1:

Address = $(128)_{10}$ = $(0000000010000000)_2$

(Note: Address is shown as a 16-bit number, because the computer uses 16-bit addresses)

For this address, Tag = 00000, Block = 00010, Word = 000000

Since the cache is empty before this access, this will be a cache **miss**

After this access, Tag field for cache block 00010 is set to 00000

Access # 2:

Address = $(144)_{10}$ = $(000000010010000)_2$

For this address, Tag = 00000, Block = 00010, Word = 010000

Since tag field for cache block 00010 is 00000 before this access, this will be a cache <u>hit</u> (because address tag = block tag)

Access # 3:

Address = $(2176)_{10}$ = $(0000100010000000)_2$

For this address, Tag = 00001, Block = 00010, Word = 000000

Since tag field for cache block **00010** is **00000** before this access, this will be a cache <u>miss</u> (address tag \neq block tag)

After this access, Tag field for cache block 00010 is set to 00001

Access # 4:

 $Address = (2180)_{10} = (0000100010000100)_2$

For this address, Tag = 00001, Block = 00010, Word = 000100

Since tag field for cache block 00010 is 00001 before this access, this will be a cache <u>hit</u> (address tag = block tag)

Access # 5:

Address = $(128)_{10}$ = $(0000000010000000)_2$

For this address, Tag = 00000, Block = 00010, Word = 000000

Since tag field for cache block 00010 is 00001 before this access, this will be a cache \underline{miss} (address tag \neq block tag)

After this access, Tag field for cache block 00010 is set to 00000

Access # 6:

Address = $(2176)_{10}$ = $(0000100010000000)_2$

For this address, Tag = 00001, Block = 00010, Word = 000000

Since tag field for cache block 00010 is 00001 before this access, this will be a cache \underline{miss} (address tag \neq block tag)

After this access, Tag field for cache block 00010 is set to 00001

Cache hit rate = Number of hits / Number of accesses = 2/6 = 0.333

Problem # 2

Repeat Problem # 1, if the cache is organized as a 2-way set-associative cache that uses the LRU replacement algorithm.

Solution

- (a) Block size = 64 bytes = 2⁶ bytes = 2⁶ words
 Therefore, **Number of bits in the** *Word* **field = 6**Cache size = 2K-byte = 2¹¹ bytes
 Number of cache blocks per set = 2
 Number of sets = Cache size / (Block size * Number of blocks per set) = 2¹¹/(2⁶ * 2) = 2⁴
 Therefore, **Number of bits in the** *Set* **field = 4**Total number of address bits = 16
 Therefore, **Number of bits in the** *Tag* **field = 16 6 4 = 6**
- (b) The cache is initially empty. Therefore, all the cache blocks are invalid.

Access # 1:

Address = $(128)_{10}$ = $(0000000010000000)_2$

For this address, Tag = 000000, Set = 0010, Word = 000000

Since the cache is empty before this access, this will be a cache miss

After this access, Tag field for the first block in set 0010 is set to 000000

Problem # 1 :A computer system uses 16-bit memory addresses. It has a 2K-byte cache organized in a direct-mapped manner with 64 bytes per cache block. Assume that the size of each memory word is 1 byte.

- (a) Calculate the number of bits in each of the Tag, Block, and Word fields of the memory address.
- (b) When a program is executed, the processor reads data sequentially from the following word addresses: 128, 144, 2176, 2180, 128, 2176 All the above addresses are shown in decimal values.

Assume that the cache is initially empty. For each of the above addresses, indicate whether the cache access will result in a hit or a miss.

Solution

(a) Block size = 64 bytes = 2^6 bytes = 2^6 words (since 1 word = 1 byte)

Therefore, Number of bits in the Word field = 6

Cache size = 2K-byte = 2^{11} bytes

Number of cache blocks = Cache size / Block size = $2^{11}/2^6 = 2^5$

Therefore, Number of bits in the Block field = 5

Total number of address bits = 16

Therefore, Number of bits in the Tag field = 16 - 6 - 5 = 5

For a given 16-bit address, the 5 most significant bits, represent the *Tag*, the next 5 bits represent the *Block*, and the 6 least significant bits represent the *Word*.

Access # 2:

Address = $(144)_{10}$ = $(000000010010010000)_2$

For this address, Tag = 000000, Set = 0010, Word = 010000

The tag field for this address matches the tag field for the first block in set 0010. Therefore, this access will be a cache <u>hit</u>.

Access # 3:

Address = $(2176)_{10}$ = $(0000100010000000)_2$

For this address, Tag = 000010, Set = 0010, Word = 000000

The tag field for this address does not match the tag field for the first block in set 0010. The second block in set 0010 is empty. Therefore, this access will be a cache <u>miss</u>.

After this access, Tag field for the second block in set 0010 is set to 000010

Access # 4:

Address = $(2180)_{10}$ = $(0000100010000100)_2$

For this address, Tag = 000010, Set = 0010, Word = 000100

The tag field for this address matches the tag field for the second block in set 0010. Therefore, this access will be a cache <u>hit</u>.

Access # 5:

Address = $(128)_{10}$ = $(0000000010000000)_2$

For this address, Tag = 000000, Set = 0010, Word = 000000

The tag field for this address matches the tag field for the first block in set 0010. Therefore, this access will be a cache **hit**.

Access # 6:

Address = $(2176)_{10}$ = $(0000100010000000)_2$

For this address, Tag = 000010, Set = 0010, Word = 000000

The tag field for this address matches the tag field for the second block in set 0010. Therefore, this access will be a cache https://doi.org/10.11/.

Cache hit rate = Number of hits / Number of accesses = 4/6 = 0.666

Numerical problem on Direct mapping

- Q. Consider a direct mapped cache of size 16 KB with block size of 256 bytes. The size of main memory is 128 KB.
- 1. Find number of bits in tag
- 2. Find tag directory size

Main Memory

Tag

Cache Line

Block

Ans. First we have to find the number of bits in each given me Cache of size = $16 \text{ KB} = 2^{14} \text{ bytes} \Rightarrow \text{Its having } 14 \text{ bits}$

Block size = 256 bytes = 2^8 bytes => Its having 8 bits Main memory size = 128 KB = 2^{17} bytes => Its having 17 bits

Number of bits in main memory = bits in tag + bits in cache line + bits in block

Cache Line

Number of bits in Line number = Cache size / Block size = 2^{14} bytes / 2^{8} bytes = 2^{6}

Line number having 6 bits.

Number of bits in Tag

Number of bits in Tag =

Number of bits in main memory – number of bits in line number – number of bits in block

= 17 – Line bits – Block bits

= 17 - 6 - 8 = 3

Tag directory size

Tag directory size = Size of line number X Number of bits in

 $=2^{6} X 3 bits$

= 192 bits

= 192 / 8 bytes

= 24 bytes

Question: A computer has an 4 GB memory with 32-bit word sizes. Each block of memory stores 8 words. The computer has a direct-mapped cache of 64 blocks. The computer uses word level addressing. What is the address format? If we change the cache to a 2 - way set associative cache, what is the new address format?

Question: Consider a main memory of size 8MB that needs to be mapped with a cache memory of 128KB with a block size of 128 bytes. For the given hardware specifications, design the memory mapping using an 8-way set associative method. Compute the tag size, number of searches and main memory address format. Also, comment on the hit ratio of the mapping technique.