# Analog Electronics Notes

## Samyak Sheersh

#### September 30, 2023

## Contents

1 Some basic concepts		ne basic concepts	1
	1.1	Law of Mass Action	2
	1.2	Capacitance across the depletion layer	2
<b>2</b>	вјт	and Biasing	3

# 1 Some basic concepts

To manipulate currents externally, we generally need to create a gradient, which generates an electric field which can be controlled externally

Band gap in Si = 1.12eV

 $\Rightarrow$  For Silicon to function as a semiconductor,  $\frac{1}{2}k_BT \ge 1.12eV$ 

where  $k_B$  is the Boltzmann constant.

In a simple p-n junction, the p-n junction is a metallurgical junction, and at thermal equilibrium, it forms a depletion layer, which results in a built-in potential  $V_{bi}$ , due to a distribution of charge.

If the p-side is doped with  $N_a$  acceptor atoms $(cm^{-3})$  and the n-side is doped with  $N_d$  donor atoms $(cm^{-3})$ , then:

$$V_{bi} = \frac{k_B T}{q} \ln(\frac{N_a N_d}{n_i^2}) \tag{1}$$

which at  $T \approx 300K$ :

•  $V_T$  called the thermal voltage  $q = e = 1.6 * 10^{-19}$ ,

$$V_T = \frac{k_B T}{q} \approx 26mV$$

.

•  $n_i = 1.35 * 10^{10} \approx 10^{10} cm^{-3}$ 

Note that this voltage difference can not be used to extract energy if there's no temperature difference. (The Second Law of Thermodynamics)

#### 1.1 Law of Mass Action

In equilibrium:

$$n_i^2 = n * p \tag{2}$$

where n and p are the electron and hole concentration of a doped semiconductor

Generally, you dope it with either:

- donor atoms, which causes it to become an n-type semiconductor If it's doped with donor atoms, with concentration  $N_d >> n_i$ , then  $n \approx N_d$  and  $p \approx \frac{n_i^2}{N_d}$
- acceptor atoms, which causes it to become a p-type semiconductor If it's doped with donor atoms, with concentration  $N_a >> n_i$ , then  $p \approx N_a$  and  $n \approx \frac{n_i^2}{N_a}$

# 1.2 Capacitance across the depletion layer

Due to the build-up of charge across the depletion layer in reverse or zero bias (immobile as it may be), we can model this behaviour as a capactiance:

$$C_t = \frac{\epsilon A}{W_{dep}} \tag{3}$$

$$W_{dep} = \sqrt{\frac{2\epsilon}{q}(V_{bi} + V_R)\left(\frac{1}{N_a} + \frac{1}{N_d}\right)}$$
 (4)

where  $\epsilon$  is Silicon's permittivity,  $W_{dep}$  is the width of the depletion layer and  $V_R$  is the external voltage applied in reverse bias

# 2 BJT and Biasing

rarr