





FE-ROS 2021 **ROS orodja**

Sebastjan Šlajpah

Univerza v Ljubljani Fakulteta za elektrotehniko Laboratorij za robotiko

sebastjan.slajpah@fe.uni-lj.si

www.robolab.si www.cobotic.si



Vsebina

- Nodes
- Topics
- Services
- Msg & Srv files
- Actions
- Parameter
- Launch files

- Konzolni ukazi za posamezne funkcionalnosti
- Python 2.7



ROSMASTER



ROSMASTER

>> roscore

- Povezava med posameznimi funkcionalnostmi
- Lahko je samo en naenkrat
- Povezava med več ROS sistemi
- >> echo \$ROS_MASTER_URI



CATKIN WORKSPACE

• CATKIN – official build system for ROS

- >> mkdir catkin_ws
- >> cd catkin_ws
- >> mkdir src
- >> catkin make



CATKIN WORKSPACE

- Povezava konzole z ROS spremenljivkami
- >> cd devel
- >> source setup.bash
- Dodaj v bashrc.sh (avtomatsko, ko se odpre konzola)
- >> echo "source ~/catkin_ws/devel/setup.bash" >> ~/.bashrc
- >> source ~/.bashrc



Generiranje sistema

• Kodo pišeš v /catkin_ws/src mapi

>> catkin_make



PACKAGES



Packages

• Neodvisne enote, ki se jih da uporabiti na več mestih



Packages

• Neodvisne enote, ki se jih da uporabiti na več mestih

Motion planning pkg

Camera pkg

Hardware control



Nov paket

```
>> catkin_create_pkg <ime_paketa> <razširitve>
```

>> catkin_make

>> catkin_create_pkg rpi_feros rospy std_msgs actionlib_msgs



NODE





Motion planning pkg




Hardware control


























- proces, ki izvaja računanje
- program, ki teče znotraj robotske aplikacije
- združeni so v pakete
- med seboj komunicirajo (topics, servers, actions, parameter servers)

- zmanjšujejo kompleksnost kode
- koda je bolj odporna na napake
- uporaba različnih programskih jezikov



Nov Node

- >> mkdir scripts
- >> cd scripts
- >> touch my_first_node.py
- >> chmod +x my_first_node.py
- >> code my_first_node.py



```
#!/usr/bin/env python
import rospy
if name__ == '__main__':
   rospy.init_node('my_first_python_node')
   rospy.loginfo('This node has been started.')
   rospy.sleep(1)
   print('Exit now')
>> python my_first_node.py
```



DEBUG Node

- rosrun <pkg name> <node name>
- rosnode list
- rosnode info <node name>
- rosnode kill <node name>
- rosnode ping <node name>

... poganjanje

... seznam vseh aktivnih

... info o node

... ugasni node

... ping (preveri, če deluje)




- naenkrat se lahko izvaja samo en node z določenim imenom
- če želiš več istih, jih je potrebno preimenovati

```
rospy.init_node('my_first_python_node', anonymous=True)
```




TOPICS





















- Vodilo, preko katerega si nodi izmenjujejo sporočila
- Enosmerni prenos sporočil (publisher > subscriber)
- Anonimno
- Topic ima svoj tip sporočila
- ROS master skrbi za ustrezni povezavo publisher/subscriber
- Vsak node ima lahko več publishers/subscribers za različne topics



Publisher

```
pub = rospy.Publisher('topic_name', msg_type, queue_size=10)
```

Messages types:

http://wiki.ros.org/std msgs

ROS Message Types

Bool

Byte

ByteMultiArray

Char

ColorRGBA

Duration

Empty

Float32

Float32MultiArray

Float64

Float64MultiArray

Header

Int16

Int16MultiArray

Int32

Int32MultiArray

Int64

Int64MultiArray

Int8

Int8MultiArray

MultiArrayDimension

MultiArrayLayout

String

Time

UInt16

UInt16MultiArray

UInt32

UInt32MultiArray

UInt64

UInt64MultiArray

UInt8

UInt8MultiArray



Subscriber

```
sub = rospy.Subscriber('topic_name', msg_type, callback_fcn)
```




DEBUG Topic

- rostopic -h
- rostopic list
- rostopic echo <ime topica>
- rostopic info <ime topica> ... kateri tip pošilja
- rostopic pub <ime topica> + Tab za autocomplete
 - **-1** ... Enkrat pošlje
 - **-r 5** ... Pošilja s 5 Hz



Primer

• ob pritisku tipke prižgi LED





Rpi GPIO

```
import RPi.GPIO as GPIO
# Green 1 - GPIO 2
# Green 2 - GPIO 3
# Yellow 1 - GPIO 4
# Yellow 2 - GPIO 5
# Red 1 - GPIO 6
# Red 2 - GPIO 7
# Gumb 1 - GPIO 11
# Gumb 2 - GPIO 12
```

```
def resetLed():
    # nastavi in resetiraj vse LED
    for ii in range (2,8):
        GPIO.setup(ii,GPIO.OUT)
        GPIO.output(ii, False)
GPIO.setmode (GPIO.BCM)
GPIO.setup(BTN GPIO, GPIO.IN)
btn state = GPIO.input(BTN GPIO)
GPIO.cleanup()
```



SICK NanoScan3 – namestitev

>> source ~/catkin ws/install/setup.bash

```
>> sudo apt-get install ros-melodic-sick-safetyscanners
>> source /opt/ros/melodic/setup.bash
>> cd ~/catkin_ws/src/
>> git clone https://github.com/SICKAG/sick_safetyscanners.git
>> cd ..
>> catkin make install
```



SICK NanoScan3

- 1651 meritev
- Korak meritev: 0,002909 rad
- Kot skeniranja: 275°
- Topic: /sick_safetyscanners/scan
- Msg: from sensor msgs.msg import LaserScan


>> roslaunch sick_safetyscanners sick_safetyscanners.launch sensor_ip:=192.168.65.YYY host_ip:=192.168.65.XX





Naloga


• prižgi LED, ko je objekt bližje kot 0,2 m






SERVICES




















- Sistem server/klient
- Sinhrono delovanje
- Za izračunavanje in hitre akcije
- En tip sporočila za Request, drug tip sporočila za Response
- Server je samo eden, ki lahko odgovarja več klientom



Server

```
service = rospy.Service('ime_service', msg_type, handle_fcn)
```



Klient

```
rospy.wait_for_service('ime_service')

try:
    client = rospy.ServiceProxy('ime_service',msg_type)
    ...

except rospy.ServiceException as e:
    rospy.logwarn('Service failed' + str(e))
```



DEBUG Services


- rosservice list
- rosservice info <ime service>
- rosservice call <ime service>

- ... vse registrirane services
- ... info o service
- ... klic iz konzole (brez klienta)



Primer


prižgi/ugasni LED ob pritisku tipke (prekinitve)





Naloga

• s tipkami premikajte prižgano LED levo/desno





MSG & SRV



MSG in SRV

- Topic:
 - Ime:/sick safetyscanners/scan
 - Definicija sporočila MSG: sensors_msgs/LaserScan


- Service:
 - Ime: /set_led_state
 - Definicija sporočila SRV: std_srvs/SetBool
 - Request: MSG
 - Response: MSG

Request: msg

Response msg




MSG





SRV





MSG in SRV

- Uporaba MSG primitivov za definiranje sporočil
- Sporočila se lahko definira z uporabo obstoječih sporočil
- MSG:
 - std_msgs
 - sensor_msgs
 - geometry_msgs
 - actionlib_msgs
 - •
- SRV:
 - std_srvs
 - •



SRV

Request

Response



Nov MSG in SRV

>> catkin_create_pkg rpi_msgs rospy std_msgs



package.xml (rpi_msgs)

<build_depend>message_generation</build_depend>

<exec_depend>message_runtime</exec_depend>



CMakeLists.txt (rpi_msgs)

```
find package (catkin REQUIRED COMPONENTS
  rospy
  std msgs
  message generation
# Generate messages in the 'msg' folder
add_message_files(
  FILES
  IME SPOROCILA.msg
```



CMakeLists.txt (rpi_msgs)

```
# Generate added messages and services with any dependencies listed here
generate messages (
  DEPENDENCIES
  std msgs
catkin package(
   INCLUDE DIRS include
  LIBRARIES my robot msgs
 CATKIN_DEPENDS rospy std_msgs message_runtime
  DEPENDS system lib
```



Nov MSG (rpi_msgs)

- >> roscd rpi_msgs
- >> mkdir /msg
- >> touch ledStatus.msg
- >> code ledStatus.msg

int64 ledNumber
string ledStatus

>> catkin_make



Uporaba

```
package.html (rpi_feros)

<depend>my_robot_msgs</depend>

CMakeLists.txt (rpi_feros)

find_package(catkin REQUIRED COMPONENTS
   rospy
   std_msgs
   rpi_msgs
)
```



Nov SRV (rpi_msgs)

```
>> roscd rpi_msgs
>> mkdir /srv
>> touch safetyZone.srv
>> code safetyZone.srv

int16 zone
---
bool success
string message
```

>> catkin make



Uporaba

CMakeLists.txt (rpi_feros)

```
# Generate services in the 'srv' folder
add_service_files(
  FILES
  safetyZone.srv
)
```



DEBUG MSG/SRV

- rosmsg list
- rosmsg show <ime msg>
- rossrv list
- rossrv show <ime srv>




Naloga

• prižgi LED glede na razdaljo *d*:

• Zelena: *d* > 0,4 m

• Rumena: 0.4 m > d > 0.2 m


• Rdeča: *d* < 0,2 m






ACTIONS












Action Interface





- Knjižnica actionlib
- Sistem server/klient
- Asinhrono delovanje
- Za funkcionalnosti, ki trajajo dlje časa
- Lahko izvajaš druge naloge, medtem ko je klicana osnovna funkcionalnost
- Posamezna sporočila za Goal, Feedback in Result




Kako prepoznati action?

```
>> rostopic list
Struktura: namespace (as_name)
    as_name/cancel
    as_name/feedback
    as_name/goal
    as_name/result
    as_name/status
```



Naloga

• n-kratno izvajanje sekvenčnega prižiganja LED





MSG .action (rpi_msgs)

```
# goal
int16 numberOfRuns
---
# result
int16 finalRun
---
# feedback
int16 currentRun
```

>> mkdir action

>> cd ./action



CMakeLists.txt



package.xml

<build_depend>actionlib_msgs</build_depend>



SimpleActionServer

```
sas = actionlib.SimpleActionServer('name', actionSpec, goal callback,
       auto start=False)
sas.start()
def goal callback()
       sas.publish feedback( feedback )
       sas.set succeeded( result )
       if sas.is preempt requested():
             sas.set preempted()
```



SimpleActionServer

```
import actionlib
from rpi msgs.msg import runningLedAction, runningLedFeedback, runningLedResult,
ACserver = None
def goal callback(goal):
    pass
if name == ' main ':
    rospy.init node('run led server')
   ACserver = actionlib.SimpleActionServer('run_led', runningLedAction, goal_callback, False)
    GPIO.setmode(GPIO.BCM)
    # start server
   ACserver.start()
    rospy.spin()
    GPIO.cleanup()
```



SimpleActionServer

```
def goal callback(goal):
    runFeedback = runningLedFeedback()
    runResult = runningLedResult()
    # Do lots of awesome groundbreaking robot stuff here
    for ii in range(1, goal.numberofRuns+1):
        # prizgi ustrezno LED
        runFeedback.currentRun = ii
        ACserver.publish feedback(runFeedback)
    # publish the result
    runResult.finalRuns = runFeedback.currentRun
    ACserver.set_succeeded(runResult)
```



```
client = actionlib.SimpleActionClient('name', actionSpec)
client.send goal(goal) # Sends the goal to the action server.
client.wait for result() # Waits for the server to finish performing the action.
client.get result()
                             # Prints out the result of executing the action
client.get state()
                             # Get current state of the server
# define action server status
PENDING = 0
ACTIVE = 1
DONE = 2
WARN = 3
ERROR = 4
```



```
import actionlib
from rpi msgs.msg import runningLedAction, runningLedGoal
client = None
def run_led_client(goalNum):
    pass
if name == ' main ':
    rospy.init_node('run_led_client')
   GPIO.setmode(GPIO.BCM)
    try:
        result = run_led_client(goalNum = 10)
    except rospy.ROSInterruptException:
        print("Program interrupted before completion")
```





```
def run led client(goalNum):
    #... client defininiton ...
    client.send goal(goal) # Sends the goal to the action server.
    # let us do some other stuff
    current state = client.get state()
    while current state < DONE:
        # action is still active, let us do something
        current state = client.get state()
        rate.sleep()
    if current state == WARN:
        rospy.logwarn("[Warn] Warning on the action server side.")
    if current state == ERROR:
        rospy.logerr("[Error] Error on the action server side.")
    return client.get result()
```



PARAMETERS and LAUNCH FILES





Parameters

Motion planning pkg

Motion
planning
Path
correction


- Robot name
- Sensors read frequency
- Simulation mode







Parameters





Parameters

- Parameter server: slovar znotraj ROS master, globalno dosegljiv
- ROS parameter: ena spremenljivka znotraj parameter serverja
- Tipi:
 - Boolean
 - Int
 - Double
 - String
 - Lists
 - •



Parameter

```
>> rosparam set <param name> <value> ... tako ga tudi ustvariš
>> rosparam get <param name>
>> rosparam list


• Primer:
```

publish_freq = rospy.get_param('/number_publish_freq')

>> rosparam set /number publish freq 2




Launch file





Launch file





Nov .launch

```
>> catkin_create_pkg rpi_feros_bringup
>> catkin make
>> mkdir launch
>> touch feros.launch
<launch>
   <param name="/ime parametra" type="tip spremenljivke" value="vrednost"/>
   <node name="ime" pkg="paket" type="source file.py" />
</launch>
>> roslaunch rpi feros bringup feros.launch
```



Naloga

- Nadgradite SimpleActionClient s parametrom
 - Število sekvenc: /number_of_runs
- Nadgradite SimpleActionServer s parametrom
 - Hitrost izvajanja sekvence: /led_frequency
- Naredite .launch datoteko za Action Server