

1. 可從 FEM 中量到電壓值 $V_{out} = Sensitivity \cdot B$ (Sensitivity = 130)

$$I_{in} = V_{in} \cdot K = V_{in} \cdot [k_1 \ k_2 \ k_3 \ k_4 \ k_5 \ k_6]^T = V_{in} \cdot \text{diag}(K) \Rightarrow V_{in} = I_{in} \cdot [\text{diag}(K)]^{-1}$$

然後我們就有 B matrix $\Rightarrow B_{ij} = \frac{V_{out,ij}}{V_{in,ij}}$

2. 其中

$$\text{diag}(K) = \begin{bmatrix} 0.3618 & 0 & 0 & 0 & 0 & 0 \\ 0 & 0.3614 & 0 & 0 & 0 & 0 \\ 0 & 0 & 0.3536 & 0 & 0 & 0 \\ 0 & 0 & 0 & 0.3532 & 0 & 0 \\ 0 & 0 & 0 & 0 & 0.3573 & 0 \\ 0 & 0 & 0 & 0 & 0 & 0.3610 \end{bmatrix}$$