CSCI 210: Computer Architecture Lecture 23: MIPS addressing

Stephen Checkoway
Slides from Cynthia Taylor

Today's Class

Addition & Multiplication in Floating Point

Addressing in MIPs

CS History: The Deep Space Kraken

- Bug in the space simulation game Kerbal Space Program prior to 2012
- The game moved ships through space
- When ships moved at very high velocities, floating point errors would cause parts of the ship to be misaligned
- The game would interpret this as those parts breaking off the ship or colliding with each other
- Fixed it by moving space around the ship, instead of the ship through space



Floating point addition algorithm


Input: two single-precision, floating point numbers x, and y

Output: x + y

- 1. If either x or y is 0, return the other one
- 2. Denormalize x or y to give them both the larger exponent
- 3. Add the significands, taking sign into account
- 4. If the result is 0, return 0
- 5. Normalize the result

In Javascript, you perform the operation 9007199254740992 + 1. What is the result?

A. -9007199254740992



B. 9007199254740992

Reminder: 9007199254740992 is 2⁵³

C. 9007199254740993

D. This will cause an error

E. None of the above

How many times will this loop run in python?

$$a = 1000$$
while $a != 0$:
 $a -= 0.001$

- A. 1000 times
- B. 100000 times
- C. 1000000 times
- D. It will run forever
- E. None of the above

This will run forever

```
a = 1000
while a != 0:
a = 0.001
```

 a is never 0, instead it goes from 1.673494676862619e-08 to -0.000999832650532314.

 Takeaway: Float equality is hard! Usually want to check within a small range


FP Adder Hardware

Much more complex than integer adder

- Doing it in the general purpose ALU/CPU would take too long
 - Much longer than integer operations
 - Slower clock would penalize all instructions

FP adder usually takes several cycles

FP Adder Hardware



Questions on Floating Point Addition?

Multiplication in base-10 scientific notation

- Multiply $2.34 * 10^3$ and $4.56 * 10^5$
- Check sign
- Add together exponents
- Multiply fractions (with appropriate signs)
- Normalize

$$1.000_2 \times 2^{-1} \times -1.110_2 \times 2^{-2}$$

A.
$$-1.110_2 \times 2^{-1}$$

B.
$$-1.110_2 \times 2^{-2}$$

C.
$$-1.110_2 \times 2^{-3}$$

D.
$$-1.110_2 \times 2^1$$

What issues could we run into doing this in binary floating point?

A. Adding bias in exponent twice

B. Added exponent could be greater than 127 or less than -126

C. Multiplied fraction could be longer than 23 bit

D. More than one of the above

Floating point multiplication algorithm

Input: two single-precision, floating point numbers x, and y

Output: x * y

- 1. If either x or y is 0, return 0
- 2. Compute the sign of the result
- 3. Add the exponents, unbiasing first
- 4. Multiply the significands as 64-bit integers and shift right by 23 bits
- 5. Normalize the result

FP Instructions in MIPS

- FP hardware is coprocessor 1
 - Adjunct processor that extends the ISA
- Separate FP registers
 - 32 single-precision: \$f0, \$f1, ... \$f31
 - Paired for double-precision: \$f0/\$f1, \$f2/\$f3, ...
- FP instructions operate only on FP registers
 - Programs generally don't do integer ops on FP data, or vice versa
- FP load and store instructions
 - lwc1, ldc1, swc1, sdc1
 - e.g., 1dc1 \$f8, 32(\$sp)
 - Psuedoinstructions are easier to read: l.s, l.d, s.s, s.d

FP Instructions in MIPS

- Single-precision arithmetic
 - add.s, sub.s, mul.s, div.s
 - e.g., add.s \$f0, \$f1, \$f6
- Double-precision arithmetic (operates on paired registers)
 - add.d, sub.d, mul.d, div.d
 - e.g., mul.d \$f4, \$f4, \$f6

Questions about Floating Point?

Floating point is a finite approximation of the infinite number space

This approximation leads to problems

Basic Question of Addressing

 How do we specify which data to operate on (or instruction to jump to)?

Complication:

- Instructions are 32 bits.
- Memory addresses are 32 bits.
- Data is in 32 bit words.
- Can never full specify address/data in a single instruction

Register Addressing



Which register the data is in is specified in the instruction

• 32 registers = 5 bits per register address

Used in add, jr, etc


Immediate Addressing

- Immediate addressing
 op rs rt Immediate
- Data is a constant within instruction

- There is no memory address/register number, because we are just writing the information in the instruction itself
- 16 bits, can specify numbers up to $2^{16}-1 = 64 \text{ k}$

• Used in addi, ori, etc

Base + Offset Addressing




- Problem: 16 bits is not enough to address every word in memory
- Solution: Add the 16-bit offset to the 32-bit address within a register (the base)
- Used in lw, sw

Branch and Jump: Recall

- Recall the basic instruction cycle
 - IR = Memory[PC]
 - -PC = PC + 4

Both branch and jump instructions change the value of the program counter

PC-relative Addressing



 Problem: Cannot hold a 32-bit memory address in a single 32bit instruction (that also holds an opcode and two register numbers)

Solution: Add an offset to the current value of the program counter


In a program, the target of a branch (if/for) is

A. always within 2¹⁵ instructions of the branch

B. usually within 2¹⁵ instructions of the branch

C. usually more than 2^{15} instructions away from the branch

PC-relative Addressing




Take 16 bit constant, shift left 2, add to value in PC

• Can access PC +/- 2^{17} bytes = PC +/- 2^{15} instructions

Used in beq, bne

Why do we shift left by two?



- A. We use the last two bits of the PC instead
- B. We only branch to instructions that are multiples of 4 words away from the current instruction
- C. Instructions are words and addresses specify bytes, so the last two bits of the address will always be 00
- D. None of the above

Which PC value in PC-relative addressing?

```
0x42000 slt $t0, $t1, $t2

0x42004 beq $t0, $zero, target

0x42008 addi $s0, $s0, 1

...

0x????? target: ori $s0, $s0, 1
```

If the beq instruction has an immediate field of 0x0572, what is the address of the target ori instruction?

PC is the address of the *following* instruction target address: 0x42004 + 4 + (0x0572 << 2)

Branching Far Away


If branch target is too far to encode with 16-bit offset, assembler rewrites the code

```
beq $t0, $t1, far_away
becomes

bne $t0, $t1, not_equal
    j far_away
not_equal:
```

Questions on PC relative addressing?


Pseudo-direct Addressing



 Problem: Cannot hold 32 bits of a memory address in the 32-6 bits of an instruction holding an opcode

 Solution: Use the most significant bits of the PC for the missing bits

Pseudo-direct Addressing



- We have 26 bits of address in the instruction
- Shift left by two
- Concatenate first four bits of PC + 4 with address
- Used in j, jal

Consider a jal instruction at address 0xC8001074 whose 26-bit address field has the value 0x0000003. What is the address of the instruction the jal will jump to?

- A. 0x0000003
- B. 0xC000003
- C. 0xC0000007
- D. 0xC00000C
- E. 0xC800000C

Psuedo direct addressing

- Shift left by two
- Concatenate first four bits of PC + 4 with address

Questions about addressing?

Reading

• Next lecture: Datapath