# CSE 210: Computer Architecture Lecture 8: Computer Representation of MIPS instructions

Stephen Checkoway

Oberlin College

Oct. 20, 2021

Slides from Cynthia Taylor


### Announcements

Problem Set 2 due Friday

Lab 1 due Sunday

• Office Hours Friday 13:30 – 14:30

## How to Speak Computer



```
temp = v[k];
v[k] = v[k+1];
v[k+1] = temp;
```

```
Iw $15, 0($2)
Iw $16, 4($2)
sw $16, 0($2)
sw $15, 4($2)
```

**Machine Interpretation** 

### Two Key Principles of Machine Design

- 1. Instructions are represented as numbers and, as such, are indistinguishable from data
- 2. Programs are stored in alterable memory (that can be read or written to) just like data

#### Stored-program concept

- Programs can be shipped as files of binary numbers – binary compatibility
- Computers can inherit ready-made software provided they are compatible with an existing ISA and OS – leads industry to align around a small number of ISAs

#### Memory

Accounting prg (machine code) C compiler (machine code) Payroll data Source code in C for Acct prg

# What happens if someone writes new machine code in the memory where your program is stored, overwriting your program?

A. The program will crash.

B. The old instructions will run.

C. The new instructions will run.

D. None of the above

### Recall: Instruction Set Architecture

Definition of how to access the hardware from software

• Supported instructions, registers, etc . . .


# Key ISA decisions

operations

how many?

which ones

- operands
  - how many?
  - location
  - types
- instruction format
  - size
  - how many formats?



(add r1, r2, r5)

how does the computer know what 0001 0100 1101 1111 means?

# RISC versus CISC (Historically)

- Complex Instruction Set Computing
  - Larger instruction set
  - More complicated instructions built into hardware
  - Variable number of clock cycles per instruction
- Reduced Instruction Set Computing
  - Small, highly optimized set of instructions
  - Memory accesses are specific instructions
  - One instruction per clock cycle (only the very first RISCs!)

$$A = A*B$$

RISC

lw \$t0, 0(A) mul B, A

lw \$t1, 0(B)

mul \$s1, \$t0, \$t1

sw \$s1, 0(A)

### Which of these is faster?

RISC CISC

lw \$t0, 0(A) mul B, A

lw \$t1, 0(B)

mul \$s1, \$t0, \$t1

sw \$s1, 0(A)

### RISC vs CISC

#### RISC

- More work for compiler/assembly programmer
- More RAM used to store instructions
- Less complex hardware

#### CISC

- Less work for compiler/assembly programmer
- Fewer instructions to store
- More complex hardware

## So . . . Which System "Won"?

- Most processors are RISC
- BUT the x86 (Intel) is CISC
- x86 breaks down CISC assembly into multiple, RISC-like, machine language instructions
- Distinction between RISC and CISC is less clear
  - Some RISC instruction sets have more instructions than some CISC sets

# The computer figures out what format an instruction is from

A. Codes embedded in the instruction itself.


B. A special register that is loaded with the instruction.

C. It tries each format and sees which one forms a valid instruction.

D. None of the above

# Instruction Formats What does each bit mean?

- Having many different instruction formats...
  - complicates decoding
  - uses more instruction bits (to specify the format)



- 1. The REX prefix is optional, but if used must be immediately before the opcode; see Section 2.2.1, "REX Prefixes" for additional information.
- 2. For VEX encoding information, see Section 2.3, "Intel® Advanced Vector Extensions (Intel® AVX)".
- 3. Some rare instructions can take an 8B immediate or 8B displacement.

Figure 2-1. Intel 64 and IA-32 Architectures Instruction Format

Your architecture supports 16 instructions and 16 registers (0-15). You have fixed width instructions which are 16 bits. How many register operands can you specify (explicitly) in an add instruction?

- A.  $\leq 1$  operand
- B. ≤ 2 operands
- C. ≤ 3 operands
- D.  $\leq$  4 operands
- E. None of the above

Hint: Remember you need to specify which instruction it is, and all the registers

## Representing Instructions

- MIPS instructions
  - Encoded as 32-bit instruction words
  - Small number of formats encoding operation code (opcode), register numbers, ...
  - Regularity!

	6 bits	5 bits	5 bits	5 bits	5 bits	6 bits
R-type	opcode	rs	rt	rd	sa	funct
I-type	opcode	rs	rt	imm	ediate	
J-type	opcode	target				

### MIPS Instruction Formats

	6 bits	5 bits	5 bits	5 bits	5 bits	6 bits
R-type	opcode	rs	rt	rd	sa	funct
I-type	opcode	rs	rt	imm	ediate	
J-type	opcode	target				

Which row contains correct examples of instructions with

the given types?

	R-type	l-type			
Α	addi	SW			
В	addi	sub			
С	add	SW			
D	add	sub			
Е	None of the above				


### MIPS Instruction Fields

MIPS fields are given names to make them easier to refer to

op rs	rt rd	shamt	funct
-------	-------	-------	-------

```
op 6-bits opcode that specifies the operation
rs 5-bits register file address of the first source operand
rt 5-bits register file address of the second source operand
rd 5-bits register file address of the result's destination
shamt 5-bits shift amount (for shift instructions)
funct 6-bits function code augmenting the opcode
```

### MIPS Arithmetic Instructions Format



# R-format Example

ор	rs	rt	rd	shamt	funct
 6 bits	5 bits	5 bits	5 bits	5 bits	6 bits

add \$t0, \$s1, \$s2

				1/2	
CORE INSTRUCT		OPCODE			
		FOR-			/ FUNCT
NAME, MNEMO	NIC	MAT	OPERATION (in Verilog)		(Hex)
Add	add	R	R[rd] = R[rs] + R[rt]	(1)	$0/20_{hex}$
Add Immediate	addi	I	R[rt] = R[rs] + SignExtImm	(1,2)	8 <sub>hex</sub>
Add Imm. Unsigned	addiu	I	R[rt] = R[rs] + SignExtImm	(2)	9 <sub>hex</sub>
Add Unsigned	addu	R	R[rd] = R[rs] + R[rt]		$0/21_{hex}$

	,	,,
NAME	NUMBER	USE
\$zero	0	The Constant Value 0
\$at	1	Assembler Temporary
\$v0-\$v1	2-3	Values for Function Results and Expression Evaluation
\$a0-\$a3	4-7	Arguments
\$t0-\$t7	8-15	Temporaries
\$s0-\$s7	16-23	Saved Temporaries
\$t8-\$t9	24-25	Temporaries
\$k0-\$k1	26-27	Reserved for OS Kernel
\$gp	28	Global Pointer
\$sp	29	Stack Pointer
\$fp	30	Frame Pointer
\$ra	31	Return Address

# Convert this MIPS machine instruction to assembly: 000000 01110 10001 10010 00000 100010



Selection	Instruction
Α	add \$s2, \$t7, \$s4
В	add \$s1, \$t6, \$s3
С	sub \$t6, \$s1, \$s2
D	sub \$s2, \$t6, \$s1
E	None of the above

### MIPS I-format Instructions



- Immediate arithmetic and load/store instructions
  - rt: destination or source register number
  - Constant:  $-2^{15}$  to  $+2^{15}$  1 (or 0 to  $2^{16}$  for some instructions)
  - Address: offset added to base address in rs

### Machine Language – I Format



Load/Store Instruction Format:

Load Linked	11	I	R[rt] = M[R[rs] + SignExtImm]	(2,7)	30 <sub>hex</sub>
Load Upper Imm.	lui	I	$R[rt] = \{imm, 16^{\circ}b0\}$		$f_{hex}$
Load Word	lw	I	R[rt] = M[R[rs]+SignExtImm]	(2)	23 <sub>hex</sub>
Nor	nor	R	$R[rd] = \sim (R[rs] \mid R[rt])$		0 / 27 <sub>hex</sub>

NAME	NUMBER	USE
\$zero	0	The Constant Value 0
\$at	1	Assembler Temporary
\$v0-\$v1	2-3	Values for Function Results and Expression Evaluation
\$a0-\$a3	4-7	Arguments
\$t0-\$t7	8-15	Temporaries
\$s0-\$s7	16-23	Saved Temporaries
\$t8-\$t9	24-25	Temporaries
\$k0-\$k1	26-27	Reserved for OS Kernel
\$gp	28	Global Pointer
\$sp	29	Stack Pointer
\$fp	30	Frame Pointer
\$ra	31	Return Address

### Machine Language – I Format



• Immediate Addition Instruction Format:

addi \$t0, \$s3, 26

				9	
<b>CORE INSTRUCTI</b>		OPCODE			
		FOR-			/ FUNCT
NAME, MNEMO	NIC	MAT	OPERATION (in Verilog)		(Hex)
Add	add	R	R[rd] = R[rs] + R[rt]	(1)	$0/20_{hex}$
Add Immediate	addi	I	R[rt] = R[rs] + SignExtImm	(1,2)	8 <sub>hex</sub>
Add Imm. Unsigned	addiu	I	R[rt] = R[rs] + SignExtImm	(2)	$9_{\text{hex}}$
Add Unsigned	addu	R	R[rd] = R[rs] + R[rt]		$0/21_{hex}$
Add Unsigned	addu	R	R[rd] = R[rs] + R[rt]		0 / 21

	,	,,
NAME	NUMBER	USE
\$zero	0	The Constant Value 0
\$at	1	Assembler Temporary
\$v0-\$v1	2-3	Values for Function Results and Expression Evaluation
\$a0-\$a3	4-7	Arguments
\$t0-\$t7	8-15	Temporaries
\$s0-\$s7	16-23	Saved Temporaries
\$t8-\$t9	24-25	Temporaries
\$k0-\$k1	26-27	Reserved for OS Kernel
\$gp	28	Global Pointer
\$sp	29	Stack Pointer
\$fp	30	Frame Pointer
\$ra	31	Return Address

# Convert this MIPS assembly instruction to machine code

sw \$t0, 32(\$s6)

Selection	Instruction
Α	010101 11011 00100 0000 0000 0010 0000
В	101011 01000 10110 0000 0000 0010 0000
С	101011 10110 01000 0000 0000 0010 0000
D	000000 00010 00000 1010 1110 1100 1000
Е	None of the above

# Reading

Next lecture: Bit Level Operations

- Section 2.6

Problem Set 2 due Friday

Lab 1 due Sunday