# **∅** NanoEdge<sup>™</sup> Outlier Detection Demo Walkthrough

This is the full development and deployment cycle—from signal capture to embedded anomaly detection—optimized for tight SRAM and clean reproducibility.

#### Step 1: Raw DSP Signal Logging

- Run firmware with SIGNAL\_FORMAT undefined
- Watch real-time DSP output over UART (FFT bins, temp, jitter, etc.)
- Validate that your pipeline is transforming raw hardware signals correctly

### Step 2: Data Collection for Model Training

- Define SIGNAL\_FORMAT in dsp\_test.h
- Outputs one space-delimited signal vector per row (128 floats per signal window)
- Post-process as needed (e.g. limit rows with head, format for upload)
- I used my COM port app, it reads as text, saved the output, cleaned it up some.

#### 🗱 Step 3: Train Outlier Model in NanoEdge AI Studio

- Create a new **Outlier Detection** project
- Upload your signal CSV/TXT, select active dimensions
- Benchmark various libraries
- Use **Validation tab** to preview results & choose the best inference engine
- Deploy and extract the generated ZIP archive

### Step 4: Integrate Inference Library

- Copy headers (\* . h) and static library (\* . a) into STM32CubeIDE project
- Update linker settings:
  - Add Core/Lib/ path to include directories
  - Add neai lib

### 🔍 Step 5: Inference on Real Data

- Define INFERENCE\_MODE to enable inference behavior
- Convert the training signal data to comma delimited as I did, put in inference\_data.c
- Run the firmware with TExaSdisplay, PuTTY, or CubeIDE terminal
- The device will:
  - Loop over the entire const float inference\_data[495][128]
  - Copy one row at a time to a RAM buffer (inf\_call[]) to strip const
  - Run neai\_oneclass() and print detection results
- Only 512 bytes of RAM used during active inference
- For repeat step 2 if you want fresh data. My COM reader sends a file, <a href="https://github.com/stevemac321/NanoEdge\_Client">https://github.com/stevemac321/NanoEdge\_Client</a> but I do not have uart irq enabled in this project. I did not want to create a dependency on my Com reader app. But you can enable an

interrupt and can grab the USART IRQ handling code form https://github.com/stevemac321/NanoEdge\_Embedded\_Anomaly\_Detection

## 🕻 Step 6: Highlight Reusable Buffer Strategy

- Swap static arrays for a custom ru\_vec abstraction
- Confirm that inference still works with memcpy() to buffer.pbuf
- Keep inference input lean and prevent duplicate allocations