#### This week

Assignment I due Tuesday: you'll have proved your bare-metal

mettle!

Lab 2 prep

do pre-lab reading!

bring your kit



# Today: C Pointers & Arrays

- Understand str/ldr
- Understand C pointers
- ARM addressing modes, translation to/from C
- Details: volatile qualifier, bare-metal build

# Why C?

#### Higher-level abstractions, structured programming

Named variables, constants

Arithmetic/logical operators

Control flow

#### **Portable**

Not tied to particular ISA or architecture

#### Low-level enough to get to machine when needed


Bitwise operations

Direct access to memory

Embedded assembly, too!

#### **Compiler Explorer**

is a neat interactive tool to see translation from C to assembly. Let's try it now!



Configure settings to follow along:

C
ARM gcc 9.2.1 (none)
-Og

## Memory

Memory is a linear sequence of bytes

Addresses start at 0, go to 2<sup>32</sup>-1 (32-bit architecture)

#### 100000000<sub>16</sub> 4 **GB**

02000000016

512 MB

## Accessing memory in assembly

ldr copies 4 bytes from memory address to register str copies 4 bytes from register to memory address

The memory address could be:

- the location of a global or local variable or
- the location of program instructions or
- a memory-mapped peripheral or
- an unused/invalid location or ...

The 4 bytes of data being copied could be:

- an address or
- an 32-bit integer or
- 4 characters or
- an ARM instruction, or...

FSEL2: .word 0x20200008
SET0: .word 0x2020001C

Idr r0, FSEL2
mov r1, #1
str r1, [r0]

Idr r0, SET0 mov r1, #(1<<20) str r1, [r0]

And assembly code doesn't care

[8010] Memory as a linear sequence of indexed bytes 20 20 00 [800c] 20 e5 Same memory, 80 grouped into 4-byte words 10 [800c] 20200020 [8008] 00 **e**3 [8008] e5801000 a0 e3a01902 19 [8004] [8004] 02 e59f0004 [8000] e5 8003 | 9f 00 04 [8000]

Note little-endian byte ordering

# ASM and memory

At the assembly level, a 4-byte word could represent

- an address,
- an int,
- 4 characters
- an ARM instruction

Assembly has no type system to guide or restrict us on what we do with those words.

Keeping track of what's what in assembly is *hard* and very bug-prone.


# Funny program

pc is the register containing the address of the current instruction (processor updates it on each execution, changes it on branch instructions)

What does this program do?

```
loop:
[8000] ldr r1, [pc, #-4]
[8004] add r1, r1, #1
[8008] str r1, [pc, #-12]
[800c] b 0x8000
```

#### Operand 2 is special



Dest = Operand1 op Operand2

Cond 0 0 I 0 1 0 0 S Operand1 Dest Operand2


add r0, r1, #0x1f000

T=1

Rotate

Temmediate

add r0, r1, #0x1f000 sub r0, r1, #6 rsb r0, r1, #6 add r0, r1, r2, Isl #3 mov r1, r2, ror #7



# Funny program

pc is the register containing the address of the current instruction (processor updates it on each execution, changes it on branch instructions)

# Funny program

pc is the register containing the address of the current instruction (processor updates it on each execution, changes it on branch instructions)

```
What does this program do?

Adds to the add instruction

e2 81 10 01

+1 = e2 81 10 02

+2 = e2 81 10 04

+4 = e2 81 10 08

add r1, r1, #1

str r1, [pc, #-12] + 128 = e2 81 11 00
```

Operating on addresses is extremely powerful! We need some safety rails.

# C pointer vocabulary

An address is a memory location. Representation is unsigned 32-bit int.

A pointer is a variable that holds an address.

The "pointee" is the data stored at that address.

\* is the dereference operator, & is address-of.

#### C code

#### int val = 5; int \*ptr = &val;

#### Memory

0x00000005

0x0000810c

### What do C pointers buy us?


- Access specific memory by address, e.g. FSEL2
- Allow us to specify not only an address, but also what we expect to be stored at that address: the data type
  - int\* vs char\* vs key\_event\_t\*
- Access data by its offset relative to other nearby data (array elements, struct fields)
  - Storing related data in related locations organizes use of memory
- Efficiently refer to shared data, avoid redundancy/duplication
- Build flexible, dynamic data structures at runtime





```
int val = 5;
int* ptr = &val;
```

0x0000810c



0x0000810c

0x00008110


<b>*</b>	0x05	0x00	0x00	0x00
<b>/</b>	0x0c	0x81	0x00	0x00

0x0000810c

<b>—</b>	0x07	0x00	0x00	0x00
	0x0c	0x81	0x00	0x00

0x0000810c

0x00008110



0x0000810c


0x00008110

<b></b>	0x07	0x00	0x00	0x00
	0x0c	0x81	0x00	0x00

int**	dptr	=	&ptr
	<b>.</b> P <b>.</b> .		<b>SP U.</b> 3


0x0000810c

0x00008110



0x0000810c

0x00008110



0x0000810c

0x00008110

<b></b>	0x07	0x00	0x00	0x00
	0x0c	0x81	0x00	0x00

int\*\* dptr = &ptr;

0x0000810c

0x00008110

0x00008114

<b></b>	0x07	0x00	0x00	0x00
	0x0c	0x81	0x00	0x00
	0x10	0x81	0x00	0x00

\*dptr = NULL;

0x0000810c 0x00008110 0x00008114

	0
<b></b>	0
	0

	0x07	0x00	0x00	0x00
<b>&gt;</b>	0x00	0x00	0x00	0x00
•	0x10	0x81	0x00	0x00

```
char a = 'a';
char b = 'b';
char* ptr = &b;
```

0x0000810c

	-0×6	0x62		
	'a'	ʻb'	0x00	0x00
\	0x0d	0x81	0x00	0x00


```
char a = 'a';
char b = 'b';
char* ptr = &b;
```

0x0000810c

0x00008110

\*ptr = 'c';

0x0000810c



```
char a = 'a';
char b = 'b';
char* ptr = &b;


*ptr = 'c';

char** dptr = &ptr;

0x0000810c
0x00008110

0x00008110


0x00008110
0x00008111
```



```
char a = 'a';
char b = 'b';
char* ptr = &b;
```

0x0000810c

0x00008110



0x0000810c

0x00008110

char\*\* dptr = &ptr;

0x0000810c

0x00008110


0x00008114


*dptr	=	NUL	<b>L</b> ;
-------	---	-----	------------

0x0000810c

0x00008110

0x00008114





0x10 0x81 0x00 0x00

#### Pointer Quiz: & \*

```
int m, n, *p, *q;
p = &n;
*p = n; // 1. same as prev line?
q = p;
*q = *p;  // 2. same as prev line?
p = &m, q = &n;
*p = *q;
m = n; // 3. same as prev line?
```

# C pointer types

C has a type system: tracks the type of each variable.

Operations have to respect the data type.

Can't multiply int\*'s, can't deference an int

Distinguishes pointer variables by type of pointee

- Dereferencing an int\* is an int
- Dereferencing a char\* is a char

## C arrays

An array allocates multiple instances of a type contiguously in memory

```
char ab[2];
ab[0] = 'a';
ab[1] = 'b';
0x0000810c

0x61 0x62
```

0x61	0x00	0x00	0x00
0x09	0x00	0x00	0x00

### **Arrays and Pointers**

You can assign an array to a pointer

```
int ab[2] = {5, 7};
int* ptr = ab; // ptr = &(ab[0]);
```

Incrementing pointers advances address by size of type

```
ptr = ptr + 1; // now points to ab[1]
```

What does the assembly look like? What if ab is a char[2] and ptr is a char\*?

#### Pointer Arithmetic

Incrementing pointers advances address by size of type.

```
struct point {
  int x; // 32 bits, 4 bytes
  int y; // 32 bits, 4 bytes
};
struct point points[100];
struct point* ptr = points;
ptr = ptr + 1; // now points to points[1]
```

Suppose points is at address 0x100. What is the value of ptr after the last line of code?

#### Pointers and arrays

```
int n, arr[4], *p;
p = arr;
p = &arr[0];  // same as prev line
arr = p; // ILLEGAL, why?
*p = 3;
p[0] = 3; // same as prev line
n = *(arr + 1);
n = arr[1];  // same as prev line
```

#### Address arithmetic

#### Fancy ARM addressing modes

```
// constant displacement
ldr r0, [r1, #4]
ldr r0, [r1, r2] // variable displacement
ldr r0, [r1, r2, asl #3] // scaled index displacement
```

(Even fancier variants add pre/post update to move pointer along)

Q: How do these relate to accessing data structures in C?

int arr[9]; struct fraction \*f; void main(void)

Try CompilerExplorer to find out!

```
C source #1 X
                                         ARM gcc 5.4.1 (none) (Editor #1, Compiler #1) C X
                                             ARM gcc 5.4.1 (none) ▼
A \leftarrow B + \leftarrow V
                          C
                                                                             -Og
      struct fraction {
                                        A ▼ □ 11010 □ ./a.out ☑ .LX0: □ lib.f: ☑
          int numer;
  3
          int denom;
                                         };
                                           1 main:
                                                ldr r3, <u>.L</u>4
                                          3 ldr r2, [r3]
                                                 mov r3, #7
                                                 str r3, [r2, #4]
                                                 ldr r2, <u>.L4</u>+4
 10
                                                 str r3, [r2, #4]
 11
          f->denom = 7;
                                                 mov r3, #0
          arr[1] = 7;
 12
                                                 b .L2
 13
                                             .L3:
                                          10
          for (int i = 0; i < 4; i++) {
 14
                                          11
                                                 mov r1, #5
              arr[i] = 5;
 15
                                          12 ldr r2, <u>.L4</u>+4
 16
          }
                                          13
                                                 str r1, [r2, r3, asl #2]
 17
                                          14
                                                 add r3, r3, #1
```

#### C-strings

```
char *s = "Stanford";
  char arr[] = "University";
  char oldschool[] = {'L', 'e', 'l', 'a', 'n', 'd'};
  char buf[100];
                                                         0/
  char *ptr;
                                                        64
                                                        63
   which assignments are valid?
                                                        61
  ptr = s;
                                                        6c
 ptr = arr;
                                                        65
3 ptr = buf;
                                                        4c
4 	mtext{ arr = ptr};
5 buf = oldschool;
```

#### What does a typecast actually do?

#### Aside: why is this even allowed?

Casting between different types of pointers — perhaps plausible

Casting between pointers and int — sketchy

Casting between pointers and float — bizarre

```
int *p; double *q; char *s;
```

```
ch = *(char *)p;
val = *(int *)s;
val = *(int *)q;
```

#### Power of Types and Pointers

```
struct gpio {
  unsigned int fsel[6];
  unsigned int reservedA;
  unsigned int set[2];
  unsigned int reservedB;
  unsigned int clr[2];
  unsigned int reservedC;
  unsigned int lev[2];
};
```

Address	Field Name	Description	Size	Read/ Write
0x 7E20 0000	GPFSEL0	GPIO Function Select 0	32	R/W
0x 7E20 0000	GPFSEL0	GPIO Function Select 0	32	R/W
0x 7E20 0004	GPFSEL1	GPIO Function Select 1	32	R/W
0x 7E20 0008	GPFSEL2	GPIO Function Select 2	32	R/W
0x 7E20 000C	GPFSEL3	GPIO Function Select 3	32	R/W
0x 7E20 0010	GPFSEL4	GPIO Function Select 4	32	R/W
0x 7E20 0014	GPFSEL5	GPIO Function Select 5	32	R/W
0x 7E20 0018	-	Reserved	-	-
0x 7E20 001C	GPSET0	GPIO Pin Output Set 0	32	w
0x 7E20 0020	GPSET1	GPIO Pin Output Set 1	32	w
0x 7E20 0024	-	Reserved	-	-
0x 7E20 0028	GPCLR0	GPIO Pin Output Clear 0	32	w
0x 7E20 002C	GPCLR1	GPIO Pin Output Clear 1	32	w
0x 7E20 0030	-	Reserved	-	-
0x 7E20 0034	GPLEV0	GPIO Pin Level 0	32	R
0x 7E20 0038	GPLEV1	GPIO Pin Level 1	32	R

```
volatile struct gpio *gpio = (struct gpio *)0x20200000;
gpio->fsel[0] = ...
```

#### Pointers: the fault in our \*s

Pointers are ubiquitous in C, and inherently dangerous. Be vigilant!


Q. For what reasons might a pointer be invalid?

# Q. What is consequence of using an invalid pointer?









When coding directly in assembly, you get what you see.

For C source, you may need to look at what compiler has generated to be sure of what you're getting.

What transformations are legal? What transformations are desirable?

# When Your C Compiler Is Too Smart For Its Own Good


(or, why every systems programmer should be able to read assembly)

```
int i, j;
i = 1;
i = 2;
j = i;
// can be optimized to
i = 2;
j = i;
// is this ever not equivalent/ok?
```

button.c

The little button that wouldn't

#### button.c: The little button that wouldn't



Want cool diagrams like this? Check out <u>fritzing.org</u>

# Peripheral registers

These registers are mapped into the address space of the processor (memory-mapped IO).



These registers may behave **differently** than ordinary memory.

For example: Writing a I bit into SET register sets output to I; writing a 0 bit into SET register has no effect. Writing a I bit into CLR sets the output to 0; writing a 0 bit into CLR has no effect. To read the current value, access the LEV (level) register. So writing to SET can change the value of LEV, a different memory address!

Q:What can happen when compiler makes assumptions reasonable for ordinary memory that **don't hold** for these oddball registers?

#### volatile

Ordinarily, the compiler uses its knowledge of reads/writes to optimize while keeping the same externally visible behavior.

However, for a variable that can be read/written externally in a way the C compiler can't know (by another process, by hardware), these optimizations may not be valid.

The **volatile** qualifier informs the compiler that it cannot remove, coalesce, cache, or reorder references to a variable. The generated assembly must faithfully execute each access to the variable as given in the C code.

(If ever in doubt about what the compiler has done, use tools to review generated assembly and see for yourself...!)