# Field Effect Transistors

| 19.1 | <b>Types</b> | of | Field | Effect | Transis- |
|------|--------------|----|-------|--------|----------|
|      | tors         |    |       |        |          |

- 19.3 Principle and Working of JFET
- 19.5 Importance of JFET
- 19.7 JFET as an Amplifier
- 19.9 Salient Features of JFET
- 19.11 Expression for Drain Current  $(I_D)$
- 19.13 Parameters of JFET
- 19.15 Variation of Transconductance  $(g_m \text{ or } g_{fs})$  of JFET
- 19.17 JFET Biasing by Bias Battery
- 19.19 JFET with Voltage-Divider Bias
- 19.21 Practical JFET Amplifier
- 19.23 D.C. Load Line Analysis
- 19.25 Voltage Gain of JFET Amplifier (With Source Resistance R<sub>s</sub>)
- 19.27 Metal Oxide Semiconductor FET (MOSFET)
- 19.29 Symbols for D-MOSFET
- 19.31 D-MOSFET Transfer Characteristic
- 19.33 D-MOSFET Biasing
- 19.35 D-MOSFETs Versus JFETs
- 19.37 E-MOSFET Biasing Circuits



#### INTRODUCTION

n the previous chapters, we have discussed the circuit applications of an ordinary transistor. In this type of transistor, both holes and electrons play part in the conduction process. For this reason, it is some times called a bipolar transistor. The ordinary or bipolar transistor has two principal disadvantages. First, it has a low input impedance because of forward biased emitter junction. Secondly, it has considerable noise level. Although low input impedance problem may be improved by careful design and use of more than one transistor, yet it is difficult to achieve input impedance more than a few megaohms. The field effect transistor (FET) has, by virtue of its construction and biasing, large input impedance which may be more than 100 megaohms. The FET is generally much less noisy than the ordinary or bipolar transistor. The rapidly expanding FFT ing FET market has led many semiconductor market

ing managers to believe that this device will soon become the most important electronic device, primarily because of its integrated-circuit applications. In this chapter, we shall focus our attention on the construction, working and circuit applications of field effect transistors.

### 19.1 Types of Field Effect Transistors

A bipolar junction transistor (BJT) is a current controlled device i.e., output characteristics of the device are controlled by base current and not by base voltage. However, in a field effect transistor (FET), the output characteristics are controlled by input voltage (i.e., electric field) and not by input current. This is probably the biggest difference between BJT and FET. There are two basic types of


- (i) Junction field effect transistor (JFET)
- (ii) Metal oxide semiconductor field effect transistor (MOSFET)
- To begin with, we shall study about JFET and then improved form of JFET, namely; MOSFET.

### 19.2 Junction Field Effect Transistor (JFET)

A junction field effect transistor is a three terminal semiconductor device in which current conduction is by one type of carrier i.e., electrons or holes.

The JFET was developed about the same time as the transistor but it came into general use only in the late 1960s. In a JFET, the current conduction is either by electrons or holes and is controlled by means of an electric field between the gate electrode and the conducting channel of the device. The JFET has high input impedance and low noise level.

Constructional details. A JFET consists of a p-type or n-type silicon bar containing two pn junctions at the sides as shown in Fig.19.1. The bar forms the conducting channel for the charge carriers. If the bar is of n-type, it is called n-channel JFET as shown in Fig. 19.1 (i) and if the bar is of p-type, it is called a p-channel JFET as shown in Fig. 19.1 (ii). The two pn junctions forming diodes are connected \* internally and a common terminal called gate is taken out. Other terminals are source and drain taken out from the bar as shown. Thus a JFET has essentially three terminals viz., gate (G), source (S) and drain (D).



DRAIN (D) GATE (G) SOURCE (S) p-Channel JFET (ii)

Fig. 19.1

It would seem from Fig. 19.1 that there are three doped material regions. However, this is not the case. The gate material surrounds the channel in the same manner as a belt surrounding your waist.

#### **Principles of Electronics 508**

JFET polarities. Fig. 19.2 (i) shows n-channel JFET polarities whereas Fig. 19.2 (ii) shows the p-channel JFET polarities. Note that in each case, the voltage between the gate and source is such p-channel JFET polarities. Note that in each case, and the specific polarities and source and the other end as drain and source and the other end as drain terminals are interchangeable i.e., either end can be used as source and the other end as drain.




Fig. 19.2

The following points may be noted:

- The input circuit (i.e. gate to source) of a JFET is reverse biased. This means that the device has high input impedance.
- (ii) The drain is so biased w.r.t. source that drain current  $I_D$  flows from the source to drain.
- (iii) In all JFETs, source current  $I_S$  is equal to the drain current i.e.  $I_S = I_D$ .

### 19.3 Principle and Working of JFET

Fig. 19.3 shows the circuit of n-channel JFET with normal polarities. Note that the gate is reverse biased.

**Principle.** The two pn junctions at the sides form two depletion layers. The current conduction by charge carriers (i.e. free electrons in this case) is through the channel between the two depletion layers and out of the drain. The width and hence resistance of this channel can be controlled by changing the input voltage  $V_{GS}$ . The greater the reverse voltage  $V_{GS}$ , the wider will be the depletion layers and narrower will be the conducting channel. The narrower channel means greater resistance and hence source to drain current decreases. Reverse will happen should  $V_{GS}$  decrease. Thus JFET operates on the principle that width and hence resistance of the conducting channel can be varied by changing the reverse voltage  $V_{GS}$ . In other words, the magnitude of drain current  $(I_D)$  can be changed by altering  $V_{GS}$ .

**Working.** The working of *JFET* is as under:

- (i) When a voltage  $V_{DS}$  is applied between drain and source terminals and voltage on the gate is zero [ See Fig. 19.3 (i) ], the two pn junctions at the sides of the bar establish depletion layers. The electrons will flow from source to drain through a channel between the depletion layers. The size of these layers determines the width of the channel and hence the current conduction through the bar.
- (ii) When a reverse voltage  $V_{GS}$  is applied between the gate and source [See Fig. 19.3 (ii)], the width of the depletion layers is increased. This reduces the width of conducting channel, thereby increasing the resistance of n-type bar. Consequently, the current from source to drain is decreased. On the other hand, if the reverse voltage on the gate is decreased, the width of the depletion layers also decreases. This increases the width of the conducting channel and hence source to drain current.

The resistance of the channel depends upon its area of X-section. The greater the X-sectional area of this channel, the lower will be its resistance and the greater will be the current flow through it.





Fig. 19.3

It is clear from the above discussion that current from source to drain can be controlled by the application of potential (i.e. electric field) on the gate. For this reason, the device is called field effect transistor. It may be noted that a p-channel JFET operates in the same manner as an n -channel JFET except that channel current carriers will be the holes instead of electrons and the polarities of  $V_{GS}$  and  $V_{DS}$  are reversed.


Note. If the reverse voltage  $V_{GS}$  on the gate is continuously increased, a state is reached when the two depletion layers touch each other and the channel is cut off. Under such conditions, the channel becomes a nonconductor.



JFET biased for Conduction

## 19.4 Schematic Symbol of JFET

Fig. 19.4 shows the schematic symbol of JFET. The vertical line in the symbol may be thought




#### 510 Principles of Electronics

as channel and source (S) and drain (D) connected to this line. If the channel is n-type, the arrow on the gate points towards the channel as shown in Fig. 19.4 (i). However, for p-type channel, the arrow on the gate points from channel to gate [See Fig. 19.4 (ii)].

### 19.5 Importance of JFET

A JFET acts like a voltage controlled device *i.e.* input voltage  $(V_{GS})$  controls the output current. This is different from ordinary transistor (or bipolar transistor) where input current controls the output cur-




rent. Thus *JFET* is a semiconductor device acting \*like a vacuum tube. The need for *JFET* arose because as modern electronic equipment became increasingly transistorised, it became apparent that there were many functions in which bipolar transistors were unable to replace vacuum tubes. Owing to their extremely high input impedance, *JFET* devices are more like vacuum tubes than are the bipolar transistors and hence are able to take over many vacuum-tube functions. Thus, because of *JFET*, electronic equipment is closer today to being completely solid state.

The *JFET* devices have not only taken over the functions of vacuum tubes but they now also threaten to depose the bipolar transistors as the most widely used semiconductor devices. As an amplifier, the *JFET* has higher input impedance than that of a conventional transistor, generates less noise and has greater resistance to nuclear radiations.

#### 19.6 Difference Between JFET and Bipolar Transistor

The JFET differs from an ordinary or bipolar transistor in the following ways:

- (i) In a *JFET*, there is only one type of carrier, holes in *p*-type channel and electrons in *n*-type channel. For this reason, it is also called a *unipolar transistor*. However, in an ordinary transistor, both holes and electrons play part in conduction. Therefore, an ordinary transistor is sometimes called a *bipolar transistor*.
- (ii) As the input circuit (i.e., gate to source) of a *JFET* is reverse biased, therefore, the device has high input impedance. However, the input circuit of an ordinary transistor is forward biased and hence has low input impedance.
- (iii) The primary functional difference between the *JFET* and the *BJT* is that no current (actually, a very, very small current) enters the gate of *JFET* (i.e.  $I_G = 0A$ ). However, typical *BJT* base current might be a few  $\mu A$  while *JFET* gate current a thousand times smaller [See Fig. 19.5].




(ir) A bipolar transistor uses a current into its base to control a large current between collector and emitter whereas a JFET uses voltage on the 'gate' (= base) terminal to control the current between drain (= collector) and source (= emitter). Thus

a bipolar transistor gain is characterised by current gain whereas the JFET gain is characterised as a transconductance i.e., the ratio of change in output current (drain current) to the input (gate) voltage.

(v) In JFET, there are no junctions as in an ordinary transistor. The conduction is through an n- type or p-type semi-conductor material. For this reason, noise level in JFET is very small.

### 19.7 JFET as an Amplifier

Fig. 19.6 shows JFET amplifier circuit. The weak signal is applied between gate and source and amplified output is obtained in the drain-source circuit. For the proper operation of JFET, the gate must be negative w.r.t. source i.e., input circuit should always be reverse biased. This is achieved either by inserting a battery



 $V_{GG}$  in the gate circuit or by a circuit known as biasing circuit. In the present case, we are providing biasing by the battery  $V_{GG}$ .

A small change in the reverse bias on the gate produces a large change in drain current. This fact makes JFET capable of raising the strength of a weak signal. During the positive half of signal, the reverse bias on the gate decreases. This increases the channel width and hence the drain current. During the negative half-cycle of the signal, the reverse voltage on the gate increases. Consequently, the drain current decreases. The result is that a small change in voltage at the gate produces a large change in drain current. These large variations in drain current produce large output across the load  $R_L$ . In this way, *JFET* acts as an amplifier.

### 19.8 Output Characteristics of JFET

The curve between drain current  $(I_D)$  and drain-source voltage  $(V_{DS})$  of a JFET at constant gatesource voltage  $(V_{GS})$  is known as output characteristics of JFET. Fig. 19.7 shows the circuit for determining the output characteristics of JFET. Keeping  $V_{GS}$  fixed at some value, say 1V, the driansource voltage is changed in steps. Corresponding to each value of  $V_{DS}$ , the drain current  $I_D$  is noted. A plot of these values gives the output characteristic of JFET at  $V_{GS} = 1$ V. Repeating similar procedure, output characteristics at other gate-source voltages can be drawn. Fig. 19.8 shows a family of




Fig. 19.7

Scanned by CamScanner