

Embedded Systems – Fundamental Concepts

Date: 16–12–2025

Reference Books & Manuals:

- Mazidi – *AVR Microcontroller*
 - Joseph Yiu – *The Definitive Guide to ARM Cortex-M3/M4*
 - STM32 Reference Manual
 - STM32F407G-DISC1 User Manual
-

1. Microprocessor (μ P) vs Microcontroller (μ C)

- A microprocessor is a general-purpose computing device that requires external memory and - peripherals.
- A microcontroller is designed for embedded systems and integrates CPU, memory, and peripherals on a single chip.
- Microprocessors provide flexibility but consume more power and space.
- Microcontrollers are compact, low-power, and cost-effective.

Feature	Microprocessor (μ P)	Microcontroller (μ C)
Purpose	General-purpose computing	Dedicated embedded applications
CPU	ALU, registers	ALU, registers
Memory	External RAM & ROM	On-chip RAM & Flash
Peripherals	External	On-chip
Clock Speed	High	Low to medium
Power Consumption	High	Low
Cost	High	Low
Size	Large	Compact
Examples	x86, Cortex-A	AVR, PIC, Cortex-M

2. Von Neumann vs Harvard Architecture

- The difference between these architectures lies in how memory is accessed.
- Von Neumann uses a single bus for both instruction and data.
- Harvard uses separate buses, enabling parallel access.
- This makes Harvard architecture faster.

Feature	Von Neumann	Harvard
Address & Data Bus	Common	Separate
Instruction & Data Fetch	Not simultaneous	Simultaneous
Execution Speed	Slower	Faster
Cache	Unified	Separate I & D
Example	x86	AVR, ARM (Modified Harvard)

3. RISC vs CISC Architecture

- RISC and CISC differ in instruction complexity and execution style.
- CISC focuses on complex instructions to simplify compilers.
- RISC focuses on simple instructions for faster execution.
- Most embedded systems use RISC architecture.

Feature	RISC	CISC
Instruction Set	Small	Large
Instruction Type	Micro-instructions	Macro + Micro
Instruction Length	Fixed	Variable
Execution Cycles	Mostly single cycle	Variable cycles
Registers	More	Fewer
Memory Access	Load/Store	Direct memory access
Compiler Design	Complex	Easier
Execution Method	Pipeline	Instruction Queue
Examples	AVR, ARM, PIC	8086, 8051, x86

4. Memory-Mapped I/O vs I/O-Mapped I/O

- I/O devices must be accessed by the CPU using specific addressing methods.
- Memory-mapped I/O treats peripherals as memory locations.
- I/O-mapped I/O uses a separate address space.
- ARM processors mainly use memory-mapped I/O.

Feature	Memory-Mapped I/O	I/O-Mapped I/O
Address Space	Same as memory	Separate
Instructions	MOV, LDR, STR	IN, OUT
Hardware Complexity	Simple	Complex
Example	ARM	x86

5. Instruction Pipeline vs Instruction Queue

- Instruction execution can be optimized using pipelines or queues.
- An instruction queue only stores instructions before execution.
- An instruction pipeline processes multiple instructions simultaneously.
- Pipelines improve instruction-level parallelism.

Feature	Instruction Pipeline	Instruction Queue
Processing	Yes	No
Parallel Execution	Yes	No
Architecture	RISC	CISC
Examples	AVR, ARM, PIC	x86

6. Instruction Pipeline Stages

- Pipelining divides instruction execution into stages.
- Each stage works on a different instruction simultaneously.
- This improves overall CPU throughput.

Pipeline Type	Stages	Examples
2-Stage	Fetch → Execute	AVR, PIC
3-Stage	Fetch → Decode → Execute	ARM7, Cortex-M3/M4

7. Pipeline Hazards

- Pipeline hazards occur when normal instruction flow is disturbed.
- They reduce performance by stalling or flushing the pipeline.
- Hazards are mainly classified into control, data, and structural hazards.

Control Hazards

- Due to jump or conditional jump, instructions already fetched into pipeline are of no use and hence
- pipeline need to be cleared and re-filled from new (jumped) address. Obviously next instruction is not effectively completed in single CPU cycle.
- To overcome this problem, CPU can use "branch prediction" i.e. CPU predicts whether condition in current jump instruction will be true or not. Depending on that it fetches the next instructions. Some advanced CPUs also use "branch speculation". In this case next instructions are not only fetched but also processed and their result is stored temporarily. If prediction is correct, the result is utilized (for faster execution); otherwise the result is discarded.

Data Hazards

- For some instructions more CPU cycles are needed for the execution e.g. mul. If next instruction execution depends on result of previous instruction, then pipeline is stalled (paused) until current instruction is completed. Due to this effective number of CPU cycles for execution of instruction will increase.

Structural Hazards

- Due to CPU design restrictions some instructions cannot be completed immediately. e.g. If CPU is designed to write only one result into register and two results were produced in an instruction. In this case, pipeline is stalled to complete the current instruction

Hazard Type	Cause	Effect
Control Hazard	Branch / Jump	Pipeline flush
Data Hazard	Data dependency	Pipeline stall
Structural Hazard	Hardware limitation	Pipeline stall

8. AMBA – Advanced Microcontroller Bus Architecture

- AMBA is a standard bus architecture defined by ARM.
- It enables efficient communication between CPU and peripherals.
- Different AMBA buses are used based on performance needs.

Bus Type	Speed	Complexity	Used For
AHB	High	Complex	CPU, RAM, Flash, DMA
APB	Low	Simple	UART, SPI, I ² C, GPIO
AXI	Very High	Very Complex	Cortex-A SoCs

Summary

This document explains:

- μP vs μC
- Memory architectures
- RISC vs CISC
- I/O mapping methods
- Instruction execution techniques
- Pipeline hazards
- AMBA bus architecture

Embedded Systems and ARM Cortex-M beginners.