

TPS6598x FW Update From Embedded Controller Over I²C

ABSTRACT

The TPS6598x is a stand-alone USB Type-C[™] and Power Delivery (PD) controller providing cable plug and orientation detection at the USB Type-C connector. The TPS6598x contains a RAM-based processor and loads application code from an SPI Flash to operate. When a firmware (FW) or patch update for the TPS6598x is available, the FW and patch-bundle contained in the SPI Flash can be updated by an Embedded Controller (EC) communicating with the TPS6598x via I²C. The TPS6598x application code includes a set of simple ASCII commands that enables the FW update process. The EC writes data to the TPS6598x, sends these Flash-specific ASCII commands in the correct sequence to overwrite the Flash memory, and then resets the TPS6598x to begin running the new, upgraded FW. This application note explains the procedure of updating the TPS6598x FW from an EC over I²C and provides example C++ code that can be implemented on any EC.

Contents

1	Introduction			
2	Related Material			
3	Background of Firmware Update Procedure			
	3.1	Flash Memory Organization	3	
	3.2	ASCII Commands	4	
	3.3	Firmware Update Flow	5	
4	Exan	Example C-Code.		
	4.1	Excerpt of Code From "hostIF82.h" Header File	8	
	4.2	Excerpt of Code From "i2cFwUpdate82.c" C File	11	
	4.3	Code From "i2cFwUpdate82.h" Header file	18	
	4.4	Excerpt of Code From "i2cHandlerHostTo82.c" C File	18	
	4.5	Code From "i2cHandlerHostTo82.h" Header File	22	
	4.6	Excerpt of Code From "main.c" C File	22	
5	Sumi	mary	22	
6	Refe	rences	23	
		List of Figures		
1	TPS6	65982 SPI Flash Memory Organization of Region 0 and Region 1	3	
2	TPS65982D SPI Flash Memory Organization of Region 0			
3	Flow Diagram of FW Update Process			
4	Resu	ults of TPS6598x FW Update C-Code	23	
		List of Tables		
1	List o	of 4CC Commands Used in TPS6598x FW Update Over I ² C	4	
2	List o	of .c/.h Files in the TPS6598x FW Update Project	7	

USB Type-C is a trademark of USB Implementer's Forum.



Introduction www.ti.com

1 Introduction

The goal of this application note is to provide an example of how the FW update procedure of the TPS6598x can be performed from an EC over I²C. The TPS6598x is an *SPI Master* connected directly to an SPI Flash IC, containing the application code that runs on the RAM-based processor of the TPS6598x after it is loaded during the boot-up sequence. Occasionally, a TPS6598x FW update may be required to support new features of the USB PD specification or resolve interoperability issues with other products in the market. Therefore, in addition to loading application code from the SPI Flash, the TPS6598x can also erase sections of the SPI Flash memory and write new data into memory to upgrade from the current FW version to a newer FW version.

The TPS6598x is an I²C slave which can be controlled by an EC - the I²C master in the system - to modify USB Type-C and PD behavior dynamically in a system. In order for the TPS6598x to act as an SPI Master after boot and modify the Flash memory, the EC must use I²C reads, writes, and special commands to pass a new FW binary file into the TPS6598x. Finally, the EC must force a hardware reset for the TPS6598x to re-boot, load the new FW version into memory, and execute the new application code.

Although this application note is written specifically for the TPS6598x as an example, it also applies to the TPS65986 and TPS65981.

With minor modifications, these steps and instructions can be used to upgrade the firmware patch on TPS65982D. The subsequent sections will list these differences wherever applicable.

2 Related Material

The TPS6598x data sheet, the *TPS6598x and TPS65986 Firmware User's Guide* (SLVUAH7), the TPS6598X Configuration Tool, and the TPS6598X Utilities Tool are resources required to implement this FW update in an application of the TPS6598x. Tables in Appendix A of the *TPS6598x and TPS65986 Firmware User's Guide* are required to understand I²C Reads, Writes, and 4CC commands used in the FW update procedure, and the TPS6598X Utilities Tool should be used to test the I2C reads, writes, and commands before implementing C-code to perform the full FW update.



3 Background of Firmware Update Procedure

3.1 Flash Memory Organization

The firmware and patch-bundle of the TPS6598x is contained in the memory of the attached SPI Flash IC. The organization of this data in memory is explained in the TPS6598x data sheet (SLVSD02) using variables and relative locations because the TPS6598x also works in applications where the SPI Flash memory is shared with another IC. Memory organization might differ between the various variants of TPS6598x, and the EC application developers shall account for these differences when writing host-programming applications to update TPS6598x firmware and patch-bundle.

In this application note, the flash memory organization is explained based on the assumption that the SPI Flash is dedicated to the TPS6598x and not shared. For redundancy, the FW is copied into two regions, called Region 0 (low region) and Region 1 (high region). Before a FW update and after a FW update is complete, the data in Region 0 and Region 1 will be identical. If the full memory of the SPI flash is read directly, it will contain pointers and both Regions, which will simply be referred to as a "flash.bin" file.

A depiction of the full "flash.bin" flash memory organization for TPS65982 is shown in Figure 1.




Figure 1. TPS65982 SPI Flash Memory Organization of Region 0 and Region 1






Figure 2. TPS65982D SPI Flash Memory Organization of Region 0

Since Region 0 and Region 1 are copies of each other, the binary data in each region is identical. The region header and the application code combined are referred to as the "low region" and the "high region". When the FW update is performed over I²C, the input file must be a "low-region.bin" which is placed into both the low region and high region in Flash memory.

3.2 ASCII Commands

The FW update process utilizes the special 4CC ASCII character commands listed in Table 1. All of the 4CC commands that pertain specifically to the Flash IC begin with the ASCII characters 'FL" and end with 2 additional ASCII characters that help identify the function of the command. The 'GAID' command is a unique type of 4CC command which requires no data entered into the DATA1/2 register to execute. The 'GAID" command is used at the end of the FW update procedure to re-boot the TPS6598x and reload the new FW version from non-volatile Flash memory.

Table 1. List of 4CC Commands Used in TPS6598x FW Update Over I²C

Name of 4CC Command	ASCII	Hex Value	Data1/2 Input Length
Flash read region	'FLrr'	0x46 0x4C 0x72 0x72	32-bits (4 Bytes)
Flash read region	'FLem'	0x46 0x4C 0x65 0x6D	1-bit (1 Byte min.)
Flash address	'FLad'	0x46 0x4C 0x61 0x64	32-bits (4 Bytes)
Flash write data	'FLwd'	0x46 0x4C 0x77 0x64	64 Bytes
Flash verify	'FLvy'	0x46 0x4C 0x76 0x79	32-bits (4 Bytes)



Table 1. List of 4CC Commands Used in TPS6598x FW Update Over I²C (continued)

Name of 4CC Command	ASCII	Hex Value	Data1/2 Input Length
Hardware Reset of TPS6598x	'GAID'	0x47 0x41 0x49 0x44	None

When a 4CC command is given, the following steps must be performed in order:

- 1. Write input data to DATA1/2 register (0x09/0x11)
- 2. Write 4CC command characters to CMD1/2 register (0x08/0x10)
- 3. Read back data from CMD1/2 register (0x08/0x10) until it clears
 - Clear return value = 0x00 0x00 0x00 0x00
 - Incorrect command input return value = '!CMD' = 0x21 0x43 0x4D 0x44
- 4. Read back data output and error return code from DATA1/2 register (0x09/0x11)
 - This allows the TPS6598x to clear the DATA1/2 buffer and accept new data

3.3 Firmware Update Flow

The FW update procedure follows the flow depicted in Figure 3. This FW flow shows at a high level the order in which the 'FL__' commands must be completed. Intermediate I²C Reads and Writes to the CMD1/2 and DATA1/2 registers are needed to ensure timing requirements are met and buffers are cleared, and these Reads and Writes are included in the example source code provided in the next section, Example C-Code.






Figure 3. Flow Diagram of FW Update Process



4 Example C-Code

The following example code is copied from C++ source code written to test the TPS6598x FW update procedure from an embedded controller via I²C. The code is broken up into 6 files: 3 .c files and 3 .h header files. This project was tested using the TMC123GXL Tiva-C processor from Texas Instruments, but the supporting code, drivers, and libraries that are specific to the Tiva-C are outside the scope of this document because they are not relevant when implementing the TPS6598x FW update procedure on other embedded controllers. Table 2 lists the relevant .c/.h files in the project and briefly explains their purpose for performing the FW update.

Table 2. List of .c/.h Files in the TPS6598x FW Update Project

File Name	Туре	Description
hostlF82.h	Header	Header file to define Register Addresses and Register Lengths for the TPS6598x, define 4CC ASCII commands as variables, and create structures for selected Registers to define individual fields needed to perform the FW update
i2cFwUpdate82.c	C++	C file containing the core code of the FW Update procedure, the FWUpdate82() function and local functions such as RegionUpdate82() which accepts a Boolean input: '0' = Update Region 0 '1' = Update Region 1
i2cFwUpdate82.h	Header	Header file allowing the FWUpdate82() function to be called from main.c
i2cHandlerHostTo82.c	C++	C file containing the fundamental global functions used for controlling the TPS6598x: ReadllCRegister() → I²C Read – A generic I2C read function that can be used for any register of the TPS6598x WritellCRegister() → I²C Write – A generic I2C write function that can be used for any register of the TPS6598x, using the register length and data as an input ourCC_Command() → 4CC Commands – A case statement uses the switch() operator using selected 4CC variables required to perform the FW update
i2cHandlerHostTo82.h	Header	Header file allowing the "i2cHandlerHostTo82.c" functions to be called from other .c files in the project
main.c	C++	C file that initializes the Tiva-C processor appropriately, then calls the <i>FWUpdate82()</i> function in the main while loop. Because the return value is fully handled, resulting in a break regardless of the outcome, the entire project is essentially a script that runs 1 time and exits.



4.1 Excerpt of Code From "hostIF82.h" Header File

The following code is an excerpt from the "hostIF82.h" file. Code not required for the FW update procedure has been redacted.

```
#ifndef __HOSTIF82 H
#define HOSTIF82 H
#include <stdbool.h>
#include <stdint.h>
#define UART Stream ON
//***************
//*********************
//************* TPS65982 Slave Address *************
#define DefAddr1 0x38 //7-bit I2C Slave address 0 for primary interface
#define DefAddr2 0x3F //7-bit I2C Slave address 1 for primary interface
//Max Arugment Length [First Byte in I2C Read/Write is Length Byte]
#define MAX ARG LENGTH 65
//****************** Register #'s *****************
#define REG CMD1
                         0x08 //used for the primary command interface.
#define REG DATA1
                         0x09 //used for the primary command interface.
                        0x0F //FW VERSION ##.##.##.##
#define REG VERSION
#define REG CMD2
                        0x10 //used for the secondary command interface.
#define REG DATA2
                         0x11 //used for the secondary command interface.
#define REG SYS CONFIG
                         0x28 //System Config
#define REG BOOT FLAGS
                         0x2D //Boot Flags
//************** Register Lengths ***************
#define lenCMD1
                         4 //used for the primary command interface.
#define lenDATA1
                         64 //used for the primary command interface.
#define lenVERSION
                         4 // FW VERSION ##.##.##
#define lenCMD2
                         4 //used for the secondary command interface.
#define lenDATA2
                         64 //used for the secondary command interface.
#define lenSYS CONFIG
                         10 //System Config
#define lenBOOT FLAGS
                         2 //Boot Flags
//****************** 4CC Words **************
// Convert 4CC to 32 bit word - Little Endian
#define CONV_4CC_TO_WORD(_A_, _B_, _C_, _D_) ((_D_ << 24) | (_C_ << 16) | (_B_ << 8) | _A_)</pre>
                    CONV 4CC TO WORD('!','C','M','D')
#define nCMD
```



```
CONV_4CC_TO_WORD('F', 'L', 'e', 'm')
#define FLem
                    CONV_4CC_TO_WORD('F', 'L', 'a', 'd')
#define FLad
                    CONV_4CC_TO WORD('F', 'L', 'w', 'd')
#define FLwd
                    CONV 4CC TO WORD('F', 'L', 'v', 'y')
#define FLvy
                    CONV 4CC TO WORD('G', 'A', 'I', 'D')
#define GAID
//****** 82 Selected Registers Structures *******************
//Read-ONLY Registers
 //Static - Set in FW image, so can only change after successful FW update
typedef struct {
     uint32 t FW VERSION BO
                                         :8; //Byte 0 = 0x00 as of 04-12-2016
     uint32 t FW VERSION B1
                                        :8; //Byte 1 = Major Revision = 0x01 on 04-12-2016
     uint32 t FW VERSION B2
                                        :8; //Byte 2 = Minor Revision = 0x07 on 04-12-2016
     uint32 t FW VERSION B3
                                        :8; //Byte 3 = Bug Fix = 0x06 on 04-12-2016
     } tFWVersion82;
//Dynamic - Set by BOOT Code based on conditions during Boot
typedef struct {
    uint32_t BootOk
uint32_t ExtPhvSwitch
uint32_t DeadBatteryFlag
                                    :1; // Bit 0
                                 :1; // Bit 1
:1; // Bit 2
:1; // Bit 3
     uint32 t SpiFlashPresent
                                    :1; // Bit 4
    uint32 t Region0
                                   :1; // Bit 5
    uint32 t Region1
    uint32_t Region0Invalid
uint32_t Region1Invalid
uint32_t Region0FlashErr
:1; // Bit 6
:1; // Bit 7
uint32_t Region0FlashErr
:1; // Bit 8
    uint32 t Region1FlashErr :1; // Bit 9
                                  :1; // Bit 10
     uint32_t reserved1
     uint32_t UartCrcFail
                                  :1; // Bit 11
                                :1; // Bit 12
:1; // Bit 13
     uint32_t Region0CrcFail
     uint32_t Region1CrcFail
     uint32_t CustomerOtpInvalid :1; // Bit 14
                                  :1; // Bit 15
     uint32 t reserved2
 } tBootFlags82;
//Read-Write Registers (excluding CMD1 & DATA1, which are special)
 // Note: Writing to SysConfig Register causes a Disconnect on the Type-C Port
typedef struct {
     uint32 t PortInfo
                                             :3:
     uint32 t ReceptacleType
                                             :3;
     uint32_t TypeCCurrent
                                             :2;
     uint32_t VCONNsupported
                                            :2;
     uint32_t
                                            : 4:
     uint32_t HighVoltageWarningLevel :1;
    uint32_t LowVoltageWarningLevel
uint32_t OvpTripPoint
uint32_t OvpUsage
uint32_t PP_5V0config
                                          :1;
                                             :6;
                                             :2;
                                             :2;
    uint32 t PP HVconfig
                                             :2;
    uint32 t PP HVEconfig
                                            :3;
    uint32 t
                                            :1:
    uint32 t BC12enable
                                            :1;
    uint32 t USBRPenable
                                            :1;
     uint32 t USBEPenable
                                            :1;
```



```
uint32 t USB3rate
                                         :2;
    uint32_t USB2Supported
                                          :1;
   uint32_t AudioAccessorySupport :1;
uint32_t DebugAccessorySupport :1;
    uint32 t AudioAccessorySupport
   uint32 t PoweredAccessorySupport :1;
   uint32_t RSense
                                           :1;
   uint32_t TrySRCSupport
                                          :1;
    uint32_t BillboardAllowed
                                         :1;
    uint32_t
                                           :2;
   uint32_t PP_EXT_OC_Timeout
uint32_t ResetZTimeoutCount
uint32_t ResetZTimeoutClock
                                           :5;
                                           :6;
                                           :2;
    uint32 t Vout3V3SupThresh
                                           :3;
   uint32 t Vout3V3enable
                                           :1:
   uint32 t
                                           :1;
   uint32 t
                                           :2;
   uint32 t setUvpTo4P5V
                                          :1;
    uint32 t UvpTripPoint5V
                                         :3;
    uint32 t UvpUsageHV
                                          :3;
    uint32 t
                                         :7;
} tSysConfig82;
#endif // HOSTIF82 H
```

Minor modifications apply to the previous data-structures if the application is being developed for TPS65982D. Details of these modifications follow:

```
Before
typedef struct {
    uint32_t BootOk :1; // Bit 0
    ...
    ...

After
typedef struct {
    uint32_t PatchHeaderErr :1; // Bit 0
    ...
    ...
...
```

```
Before
typedef struct {
    ...
    uint32_t reserved1 :1; // Bit 10
    ...
    ...

After
typedef struct {
    ...
    uint32_t PatchDownloadErr :1; // Bit 10
    ...
    ...
    ...
    ...
...
```



4.2 Excerpt of Code From "i2cFwUpdate82.c" C File

The following code is an excerpt from the "i2cFwUpdate82.c" file. Code not required to complete the FW update procedure, such as I2C Reads and Writes for debug only, has been redacted.

```
#include <stdbool.h>
#include <stdint.h>
#include <stdio.h>
#include <stdlib.h>
#include <string.h>
// I2C FW Update files - Start
#include "i2cFwUpdate82.h"
#include "i2cHandlerHostTo82.h"
#include "hostIF82.h"
// I2C FW Update files - End
//******Global Variables***********
//Used in FW Update
tBootFlags82 BootFlags82;
tStatus82 Status82;
tSysConfig82 SysConfig82;
tFWVersion82 FWVersion82;
//********Local Variables************
//Used in FW Update
uint32 t tempData;
uint8 t i2cReadData[64];
uint8 t i2cCmdRtn[4];
uint8_t i2cWriteData[64];
uint8_t i,j,i2cDataData[64];
uint8 t i2cFlashData[64]; //Temp data
uint8_t oldVerFW82[4];
uint8 t
           newVerFW82[4];
uint3\overline{2}_t i2cDataFLemIn[2];
```



```
uint8 t count8bit;
uint32 t count32bit;
bool readError = false;
bool writeError = false;
bool fourCCerror = false;
bool rgn0Vrfy = false;
bool rgn1Vrfy = false;
bool rgnVrfy[2] = {false, false};
bool i2cFWUpdateDone = false;
//*********Local Constants************
//Used in FW Update
const uint8_t i2cDataClr[4] = \{0x00, 0x00, 0x00, 0x00\};
const uint8 t i2cDataFlrrRgn0[4] = \{0x00, 0x00, 0x00, 0x00\};
const uint8_t i2cDataFlrrRgn1[4] = \{0x01, 0x00, 0x00, 0x00\};
const uint3\overline{2} t i2cDataFlrrRgn[2] = {0x0, 0x1};
const uint32_t rgnPntr1Loc[2] = {0x0, 0x1000}; const uint32_t rgnPntr2Loc[2] = {(0x1000-0x40), (0x2000-0x40)};
const uint32 t rgnPntr1Val[2] = \{0x2000, 0x20000\};
const uint32_t rgnPntr2Val[2] = \{0x0, 0x0\};
const uint32_t rgnPntr1ValNew[2] = {0x1234, 0x12345};
const uint32_t rgnPntr2ValNew[2] = {0xDCC, 0xDCBB};
const uint32 t rgnPntrVal[2] = \{0x000020000, 0x0000200000\};
const uint32 t sectorCount = 17;
const uint32 t lowRqnFalsePntr = 0x0100E0AC;
void init64ByteDataFF(void)
          for (i = 0; i < 64; i++)
             i2cFlashData[i] = 0xFF;
void initCountUpDwn64(bool countArray[8])
     if (countArray[0]== 0)
     {
             for (i=0; i<8; i++)
             {
                     for (j=0; j<8; j++)
                              i2cFlashData[i*8+j] = i*8 + j;
             }
     else
             for (i=0; i<8; i++)
                     for (j=0; j<8; j++)
                              i2cFlashData[i*8+j] = 63-(i*8 + j);
                     }
             }
     }
bool RegionUpdate82(bool rgnNum)
     //Write new Data in Flash IC for Region0/1
     //Determine Pointer0/1 value
     fourCCerror = fourCC_Command(FLrr, (uint8_t *)&i2cDataFlrrRgn[rgnNum]);
     readError = ReadIICRegister(I2C1_BASE, DefAddr1, REG_DATA1, 4, i2cReadData);
#ifdef UART_Stream_ON
```



```
0x\%02x\%02x\%02x\%02x\n\n", \
    UARTprintf("Region 0 (or 1) Pointer =
i2cReadData[3], i2cReadData[2], i2cReadData[1], i2cReadData[0]);
    DelayInMilliseconds(1000); //Wait for 1 seconds to read UART Stream in Putty terminal
#endif
    tempData = (i2cReadData[0] | (i2cReadData[1] << 8) | (i2cReadData[2] << 16) | \
(i2cReadData[3] << 24));
    if (tempData == rgnPntrVal[rgnNum])
            i2cDataFLemIn[0] = rgnPntrVal[rgnNum];
            i2cDataFLemIn[1] = sectorCount;
            //Erase 64kB+4kB Header of Memory (17 4kB Sectors) starting at Region0/1 Pointer
            fourCCerror = fourCC_Command(FLem, (uint8_t *)&i2cDataFLemIn);
            //Point to location for Writing with Offset of Region Pointer. Same as result from FLrr
            fourCCerror = fourCC_Command(FLad, (uint8_t *)&rgnPntrVal[rgnNum]);
            count8bit = 0;
            //64kB+4kB = 65536Bytes + 4094Bytes = 69632/64 = 1088 times to write to DATA1
            for (count32bit = 0; count32bit < 1088; count32bit++)</pre>
                    initCountUpDwn64((bool *) &count8bit);
                    //Write DATA in 64 Bytes chunks
                    fourCCerror = fourCC Command(FLwd, (uint8 t *)&i2cFlashData);
                   count8bit += 1;
                   if (count8bit == 63)
                   {
                           UARTprintf("4kByte Block Written\n");
                           count8bit = 0;
            }
//Updating Data Record is optional, if Flash Images are flipped for redundancy
//currently, this code has not been fully implemented
            i2cDataFLemIn[0] = rgnPntr1Loc[rgnNum];
            i2cDataFLemIn[1] = 1;
            //Erase Region0/1 Pointers in Data by Erasing 1 4kByte sector;
            fourCCerror = fourCC Command(FLem, (uint8 t *)&i2cDataFLemIn);
            //Point to location of new Pointer 1
            fourCCerror = fourCC Command(FLad, (uint8 t *)&rgnPntr1Loc[rgnNum]);
            init64ByteDataFF();
            i2cFlashData[0] = rgnPntr1Val [rgnNum] >> 0; //replaced rgnPntr1ValNew
            i2cFlashData[1] = rgnPntr1Val [rgnNum] >> 8; //replaced rgnPntr1ValNew
            i2cFlashData[2] = rgnPntr1Val [rgnNum] >> 16; //replaced rgnPntr1ValNew
            i2cFlashData[3] = rgnPntr1Val [rgnNum] >> 24; //replaced rgnPntr1ValNew
            //Write DATA for NEW Data Record #1
            fourCC Command(FLwd, (uint8 t *)&i2cFlashData);
            //Point to location of new Pointer 2
            fourCCerror = fourCC Command(FLad, (uint8 t *)&rgnPntr2Loc[rgnNum]);
            init64ByteDataFF();
            i2cFlashData[0] = 0xFF;
            i2cFlashData[1] = 0xFF;
            i2cFlashData[2] = 0xFF;
            i2cFlashData[3] = 0xFF;
            i2cFlashData[60] = rgnPntr2Val [rgnNum] >> 0; //replaced rgnPntr2ValNew
            i2cFlashData[61] = rgnPntr2Val [rgnNum] >> 8; //replaced rgnPntr2ValNew
            i2cFlashData[62] = rgnPntr2Val [rgnNum] >> 16; //replaced rgnPntr2ValNew
            i2cFlashData[63] = rgnPntr2Val [rgnNum] >> 24; //replaced rgnPntr2ValNew
            //Write DATA for NEW Data Record #2
            fourCCerror = fourCC Command(FLwd, (uint8 t *)&i2cFlashData);
#endif
            fourCCerror = fourCC Command(FLrr, (uint8 t *)&i2cDataFlrrRqn[rqnNum]); //Determine
Pointer for Region0/1 value using NEW record
            readError = ReadIICRegister(I2C1 BASE, DefAddr1, REG DATA1, 4, i2cReadData);
```



```
#ifdef UART Stream ON
            UARTprintf("Region 0 (or 1) Pointer =
                                                                   0x\%02x\%02x\%02x\%02x\n\n'',\
i2cReadData[3], i2cReadData[2], i2cReadData[1], i2cReadData[0]);
            DelayInMilliseconds(1000); //Wait for 1 seconds to read UART Stream in Putty terminal
#endif
            \texttt{tempData} = (\texttt{i2cReadData[0]} \mid (\texttt{i2cReadData[1]} << 8) \mid (\texttt{i2cReadData[2]} << 16) \mid
(i2cReadData[3] << 24));
            fourCCerror = fourCC_Command(FLvy, (uint8_t *)&tempData); //Verify Flash is valid
            readError = ReadIICRegister(I2C1 BASE, DefAddr1, REG DATA1, 4, i2cReadData);
#ifdef UART Stream ON
            UARTprintf("Flash Verify Return Value = 0x%02x\n\n", i2cReadData[0]);
            DelayInMilliseconds (1000); //Wait for 1s to read UART Stream in Putty terminal
#endif
            if (i2cReadData[0] == 0 \times 00)
                    rgnVrfy[rgnNum] = true;
                    UARTprintf("SUCCESS: Flash Update was successful and Verified\n");
            else
             {
                    rgnVrfy[rgnNum] = false;
                    UARTprintf("FAIL: Flash Update was either unsuccessful or Not capable of being \
verified\n");
                    UARTprintf("FAIL: in v5 of this code, it is expected for Region1 to fail Flvy\n");
    else if (tempData == lowRgnFalsePntr)
    {
            UARTprintf("ABORT: Low-Region File found with offset 0x0. This is not a valid 2-region \
flash image\n");
    }
    else
     {
            UARTprintf("ABORT: Un-defined Flash Region pointer found and 'Flash-Image.bin' \
from TI Config Tool not installed correctly with offset 0x0\n");
    return rgnVrfy[rgnNum];
extern bool FWUpdate82 (void)
{
    readError = false;
    writeError = false;
    fourCCerror = false;
#ifdef UART Stream ON
    UARTprintf("\nWelcome to the TPS65982 I2C FW Update program...\n\n");
#endif
    DelayInMilliseconds (2000); //Wait for 2 seconds to read UART Stream in Putty terminal
#if 1
     // Read Version # of FW image running in code
    ReadIICRegister(I2C1 BASE, DefAddr1, REG VERSION, lenVERSION, (uint8 t *)&FWVersion82);
#ifdef UART Stream ON
    UARTprintf("OLD Version # (0xDD.MM.mm.BB) = 0x%02x.%02x.%02x.%02x.%02x.\n", \
FWVersion82.FW VERSION B3, FWVersion82.FW VERSION B2, FWVersion82.FW VERSION B1, \
FWVersion82.FW VERSION B0);
#endif
     // Read BOOT Flags 1st to determine active region
    ReadIICRegister(I2C1 BASE, DefAddr1, REG BOOT FLAGS, lenBOOT FLAGS, (uint8 t *)&BootFlags82);
#ifdef UART Stream ON
     UARTprintf("BootOk (Bit 0): %d \n", BootFlags82.BootOk);
```



```
UARTprintf("Region0 Attempted (Bit 4): %d \n", BootFlags82.Region0);
    UARTprintf("Region1 Attempted (Bit 5): %d \n", BootFlags82.Region1);
#endif
    if (BootFlags82.BootOk == 1)
    {
            // Change PortType in SysConfig to Disabled to safely disable Type-C port before FW
Update
            readError = ReadIICRegister(I2C1 BASE, DefAddr1, REG SYS CONFIG, lenSYS CONFIG, \
(uint8 t *) &SysConfig82);
            SysConfig82.PortInfo = 7; //Port Disabled
            writeError = WriteIICRegister(I2C1 BASE, DefAddr1, REG SYS CONFIG, lenSYS CONFIG, \
(uint8 t *)&SysConfig82);
            i2cFWUpdateDone = false;
            do
            {
                    if (BootFlags82.Region1 == 0) //Region0 is Valid and running because Region1 was
not attempted
                           rgn1Vrfy = RegionUpdate82(1);
                           if (rgn1Vrfy == 1)
                            {
                                   rgn0Vrfy = RegionUpdate82(0);
                                   if (rgn0Vrfy == 1)
                                           i2cFWUpdateDone = true;
                                   }
                                   else
                                   {
                                           UARTprintf("\nFAIL: Region 0 FW Update attempted and
Failed. Region 1 was successful\n");
                                           break;
                           }
                           else
                            {
                                   UARTprintf("\nFAIL: Region 1 FW Update attempted and Failed. Region
0 never attempted\n");
                                   break:
                    //Region1 is running because both Regions were attempted and Region1 has no
Warning flags
                    else if ((BootFlags82.Region1 == 1) && (BootFlags82.Region0 == 1) &&\
                            ((BootFlags82.Region1CrcFail == 0) && (BootFlags82.Region1FlashErr == 0)
&& (BootFlags82.Region1Invalid == 0)))
                    {
                           //Update & verify Region0, then repeat for Region1
                            rgn0Vrfy = RegionUpdate82(0);
                           if (rgn0Vrfy == 1)
                            {
                                   rgn1Vrfy = RegionUpdate82(1);
                                   if (rgn1Vrfy == 1)
                                   {
                                           i2cFWUpdateDone = true;
                                   else
                                           UARTprintf("\nFAIL: Region 1 FW Update attempted and
Failed. Region 0 was successful\n");
                                           break;
                                   }
                            }
                           else
                            {
                                   UARTprintf("\nFAIL: Region 0 FW Update attempted and Failed. Region
1 never attempted\n");
```



```
break;
                         }
           }while((i2cFWUpdateDone==false) && (!((readError == true) || (writeError == true) ||
(fourCCerror == true))));
           // Validate the new FW Image is running after a HW Reset
           fourCCerror = fourCC Command(GAID, (uint8 t *)&i2cDataClr);
           ReadIICRegister(I2C1 BASE, DefAddr1, REG BOOT FLAGS, lenBOOT FLAGS, (uint8 t
*) &BootFlags82);
#ifdef UART Stream ON
   UARTprintf("BootOk (Bit 0): %d \n", BootFlags82.BootOk);
#endif
           // Read Version # of NEW FW image running after FW Update
           ReadIICRegister(I2C1 BASE, DefAddr1, REG VERSION, lenVERSION, (uint8 t *)&FWVersion82);
#ifdef UART Stream ON
    FWVersion82.FW VERSION B3, FWVersion82.FW VERSION B2, FWVersion82.FW VERSION B1, \
FWVersion82.FW VERSION B0);
#endif
    else
    {
                  UARTprintf("\nBootOK was False before FW Update attempted. FW is not valid\n");
    }
    return i2cFWUpdateDone;
}
```

Minor modifications apply to the previous code-snippet if the application is being developed for TPS65982D – Details of these modifications follow:

```
Before
    ...
    const uint32_t sectorCount = 17;
    ...
    ...
    ...
    const uint32_t sectorCount = 3;
    ...
    ...
    ...
    ...
    ...
    ...
    ...
    ...
    ...
    ...
    ...
    ...
    ...
    ...
    ...
    ...
    ...
    ...
    ...
    ...
    ...
    ...
    ...
    ...
    ...
    ...
    ...
    ...
    ...
    ...
    ...
    ...
    ...
    ...
    ...
    ...
    ...
    ...
    ...
    ...
    ...
    ...
    ...
    ...
    ...
    ...
    ...
    ...
    ...
    ...
    ...
    ...
    ...
    ...
    ...
    ...
    ...
    ...
    ...
    ...
    ...
    ...
    ...
    ...
    ...
    ...
    ...
    ...
    ...
    ...
    ...
    ...
    ...
    ...
    ...
    ...
    ...
    ...
    ...
    ...
    ...
    ...
    ...
    ...
    ...
    ...
    ...
    ...
    ...
    ...
    ...
    ...
    ...
    ...
    ...
    ...
    ...
    ...
    ...
    ...
    ...
    ...
    ...
    ...
    ...
    ...
    ...
    ...
    ...
    ...
    ...
    ...
    ...
    ...
    ...
    ...
    ...
    ...
    ...
    ...
    ...
    ...
    ...
    ...
    ...
    ...
    ...
    ...
    ...
    ...
    ...
    ...
    ...
    ...
    ...
    ...
    ...
    ...
    ...
    ...
    ...
    ...
    ...
    ...
    ...
    ...
    ...
    ...
    ...
    ...
    ...
    ...
    ...
    ...
    ...
    ...
    ...
    ...
    ...
    ...
    ...
    ...
    ...
    ...
    ...
    ...
    ...
    ...
    ...
    ...
    ...
    ...
    ...
    ...
    ...
    ...
    ...
    ...
    ...
    ...
    ...
    ...
    ...
    ...
    ...
    ...
    ...
    ...
    ...
    ...
    ...
    ...
    ...
    ...
    ...
    ...
    ...
    ...
    ...
    ...
    ...
    ...
    ...
    ...
    ...
    ...
    ...
    ...
    ...
    ...
    ...
    ...
    ...
    ...
    ...
    ...
    ...
    ...
    ...
    ...
    ...
    ...
    ...
    ...
    ...
    ...
    ...
    ...
    ...
    ...
    ...
    ...
    ...
    ...
    ...
    ...
    ...
    ...
    ...
    ...
    ...
```



```
Before
    ...
#ifdef UART_Stream_ON
    UARTprintf("BootOk (Bit 0): %d \n", BootFlags82.BootOk);
    ...
    ...
#ifder
    ...
#ifdef UART_Stream_ON
    UARTprintf("PatchHeaderErr(Bit 0): %d \n", BootFlags82.PatchHeaderErr);
    ...
    ...

Note: The changes listed in this box are applicable to all references of the above 'print' statement in the sample code-snippet
```



4.3 Code From "i2cFwUpdate82.h" Header file

The following is the full code from the "i2cFwUpdate82.h" file, which is used to allow the "main.c" file to call the functions in the "i2cFwUpdate82.c" file.

```
#ifndef __I2CFWUPDATE82_H_
#define __I2CFWUPDATE82_H_
#include <stdbool.h>
#include <stdint.h>
extern bool FWUpdate82(void);
#endif // I2CFWUPDATE82 H
```

4.4 Excerpt of Code From "i2cHandlerHostTo82.c" C File

The following code is an excerpt from the "i2cHandlerHostTo82.c" file. Code not required to complete the FW update procedure, such as code that is only relevant specifically to the Tiva-C processor, has been redacted.

```
#include <stdbool.h>
#include <stdint.h>
#include <stdio.h>
```



```
#include <stdlib.h>
#include <string.h>
//I2C FW Update files - Start
#include "i2cHandlerHostTo82.h"
#include "hostIF82.h"
//I2C FW Update files - End
bool ReadIICRegister(uint32 t i2cPeripheral,uint8 t i2cSlaveAddress, uint8 t registerAddress, \
                    uint8 t readLength, uint8 t* i2cData)
{
    tI2cMsg i2cMessage;
    uint32_t result,i;
            bool error = false;
    // Send I2C Command to read which event we have received
    i2cMessage.bAllAce = false;
    i2cMessage.bRead = true;
    i2cMessage.includeLengthByte = true;
    i2cMessage.host = i2cPeripheral;
    i2cMessage.speed = 100;
    i2cMessage.targetAddress = i2cSlaveAddress;
    i2cMessage.registerAddress = registerAddress;
    i2cMessage.ucDataSize = readLength;
    result = HostCommandSend(&i2cMessage);
    if (result != 0)
    {
                            error = true;
    for (i = 0; i < i2cMessage.ucDataSize; i++)</pre>
        i2cData[i] = i2cMessage.ucData[i];
    return error;
bool WriteIICRegister(uint32 t i2cPeripheral,uint8 t i2cSlaveAddress, uint8 t registerAddress, \
                    uint8 t writeLength, uint8 t* i2cData)
    tI2cMsg i2cMessage;
    uint32_t result,i;
            bool error = false;
    // Send I2C Command to read which event we have received
    i2cMessage.bAllAce = false;
    i2cMessage.bRead = false;
    i2cMessage.includeLengthByte = true;
    i2cMessage.host = i2cPeripheral;
    i2cMessage.speed = 400;
    i2cMessage.targetAddress = i2cSlaveAddress;
    i2cMessage.registerAddress = registerAddress;
    i2cMessage.ucDataSize = writeLength;
    for (i = 0; i < i2cMessage.ucDataSize; i++)</pre>
        i2cMessage.ucData[i] = i2cData[i];
    result = HostCommandSend(&i2cMessage);
    if (result != 0)
    {
                           error = true;
    return error;
bool fourCC Command(uint32 t fourCC, uint8 t* dataData)
    uint8 t fourCCData[4];
    bool error = false;
    bool writeError = false;
    uint32 t event = 0xFFFFFFF;
    uint8_t rtnCMD[4];
```



```
uint8_t i, rtnDATA[4];
uint8 t i2cDataDataOUT[4];
bool readError = false;
DelayInMilliseconds(40); //Wait for 40ms
switch (fourCC)
{
        case FLrr:
               //Write 'FLrr' Input DATA to DATA1
               writeError = WriteIICRegister(I2C1_BASE, DefAddr1, REG_DATA1, 4, dataData);
               // Send 'FLrr' CMD to CMD1
               fourCCData[0] = 'F';
               fourCCData[1] = 'L';
               fourCCData[2] = 'r';
               fourCCData[3] = 'r';
               writeError = WriteIICRegister(I2C1 BASE, 0x38, 0x08, 4, fourCCData);
               //Handle 'FLrr' Output DATA by reading from DATA1
               break;
       } //FLrr
       case FLem:
       {
               //Handle 'FLad' Input DATA and write to DATA1
               writeError = WriteIICRegister(I2C1 BASE, DefAddr1, REG DATA1, 8, dataData);
               // Send 'FLem' CMD
               fourCCData[0] = 'F';
               fourCCData[1] = 'L';
               fourCCData[2] = 'e';
               fourCCData[3] = 'm';
               writeError = WriteIICRegister(I2C1 BASE, 0x38, 0x08, 4, fourCCData);
       } //FLem
       case FLad:
       {
               //Handle 'FLad' Input DATA and write to DATA1
               writeError = WriteIICRegister(I2C1 BASE, DefAddr1, REG DATA1, 4, dataData);
               // Send 'FLad' CMD
               fourCCData[0] = 'F';
               fourCCData[1] = 'L';
               fourCCData[2] = 'a';
               fourCCData[3] = 'd';
               writeError = WriteIICRegister(I2C1_BASE, 0x38, 0x08, 4, fourCCData);
               break:
       } //FLad
       case FLwd:
       {
               //Handle 'FLwd' Input DATA and write to DATA1
               writeError = WriteIICRegister(I2C1_BASE, DefAddr1, REG_DATA1, 64, dataData);
               DelayInMilliseconds(50); //Wait for 50ms for FW to Process 'FLwd' data
               //Send 'FLwd' CMD
               fourCCData[0] = 'F';
               fourCCData[1] = 'L';
               fourCCData[2] = 'w';
               fourCCData[3] = 'd';
               writeError = WriteIICRegister(I2C1 BASE, 0x38, 0x08, 4, fourCCData);
               break;
       } //FLwd
       case FLvy:
       {
               //Handle 'FLvy' Input DATA and write to DATA1
               writeError = WriteIICRegister(I2C1 BASE, DefAddr1, REG DATA1, 4, dataData);
               // Send 'FLvy' CMD
               fourCCData[0] = 'F';
               fourCCData[1] = 'L';
               fourCCData[2] = 'v';
```



```
fourCCData[3] = 'y';
               writeError = WriteIICRegister(I2C1_BASE, 0x38, 0x08, 4, fourCCData);
                //Handle 'FLvy' Output DATA by reading from DATA1
       break;
       } //FLvy
       case GAID:
        {
               //Write 'GAID' Input DATA (Null) to DATA1 \,
               writeError = WriteIICRegister(I2C1 BASE, DefAddr1, REG DATA1, 4, dataData);
               //***Send 'GAID' CMD with Null input DATA
               fourCCData[0] = 'G';
               fourCCData[1] = 'A';
               fourCCData[2] = 'I';
               fourCCData[3] = 'D';
               writeError = WriteIICRegister(I2C1_BASE, 0x38, 0x08, 4, fourCCData);
               DelayInMilliseconds (2000); //Wait for 2s for FW to re-load
               break:
        } //GAID
//Read Command Register
do
{
       event = 0;
       readError = ReadIICRegister(I2C1 BASE, 0x38, 0x08, 4, rtnCMD);
       if (readError != false)
        {
               error = true;
               return error;
       }
       else
        {
               for(i = 0; i < 4; i++)
                       event |= rtnCMD[i] << (i*8);
}while(!((event == 0) || (event == nCMD)));
//Read Data Register
readError = ReadIICRegister(I2C1 BASE, 0x38, 0x09, 4, rtnDATA);
if (readError != false)
{
       error = true;
        return error;
}
else
{
        for (i = 0; i < 4; i++)
       i2cDataDataOUT[i] = rtnDATA[i];
i2cDataDataOUT[0] &= 0 \times 03;
if ((i2cDataDataOUT[0] == 1) || (i2cDataDataOUT[0] == 3))
       error = true;
else if (i2cDataDataOUT[0] == 0)
        error = false;
else
       error = true;
if ((writeError == true) || (readError == true))
       error = true;
else
       error = false;
       return error;
```



4.5 Code From "i2cHandlerHostTo82.h" Header File

The following is the full code from the "i2cHandlerHostTo82.h" file, which is used to allow the "i2cFwUpdate82.c" file to call the functions in the "i2cHandlerHostTo82.c" file.

```
#ifndef __TIVAHOSTI2CHANDLER_H_
#define __TIVAHOSTI2CHANDLER_H_
#include <stdbool.h>
#include <stdint.h>

extern bool WriteIICRegister(uint32_t i2cPeripheral, uint8_t i2cSlaveAddress, \
uint8_t registerAddress, uint8_t writeLength, uint8_t* i2cData);

extern bool ReadIICRegister(uint32_t i2cPeripheral, uint8_t i2cSlaveAddress, \
uint8_t registerAddress, uint8_t readLength, uint8_t* i2cData);

extern bool fourCC_Command(uint32_t fourCC, uint8_t* dataData);

#endif // TIVAHOSTI2CHANDLER H
```

4.6 Excerpt of Code From "main.c" C File

The following code is an excerpt from the "main.c" file. Code not required for the FW update procedure has been redacted. In "main.c", the embedded processor's I/O pins must be initialized correctly for I²C communication to work properly with the TPS6598x.

```
#include <stdbool.h>
#include <stdint.h>
//I2C FW Update files - Start
#include "i2cFwUpdate82.h"
//I2C FW Update files - End
bool fwUpdateComplete = false;
int main()
{
    HostI2c1Init();
    HostI2c2Init();
    while (1)
            fwUpdateComplete = FWUpdate82(); //I2C FW Update code
            if (fwUpdateComplete == true)
            {
                    UARTprintf("Program exited successfully. FW Update complete!\n");
                    DelayInMilliseconds (100); //Wait for 100ms for UART print
                    break:
            else
                    UARTprintf("Program did not exit cleanly. FW Update failed. Try turning UART\
Stream ON to debug\n");
                    DelayInMilliseconds(100); //Wait for 100ms for UART print
                    break:
}
```

5 Summary

The results of the example code provided are shown in Figure 4. In the final implementation of the FW update procedure required in the field, the EC must receive the new binary file data from the Operating System (OS) or application processor of the product. This method varies from one system to another and is outside the scope of this application note.



www.ti.com References

In this example, instead of real data from the "low-region.bin" binary file, a function is used to generate fake data and place it in the redundant region of the Flash memory. The maximum file size of 68kB is used, so this function executes exactly 1024 times, but in the final code this function executes fewer times using the maximum length of the .bin file to determine when the 'FLwd' while() loop exits. The regionUpdate82() function can only execute twice if the 'FLvy' 4CC command returns a '0' in the least-significant bit of the DATA/12 register; as a result, using fake data always runs once and exits with an error flag that is 'true'.

Successful implementation of this code using real data from a "low-region.bin" file will pass the 'FLvy' test, execute the regionUpdate82() function twice, and exit cleanly with an error flag of 'false'. Reading back the FW image from the SPI flash directly is recommended to manually verify the results the first time the code is tested, even if the program exits cleanly.




Figure 4. Results of TPS6598x FW Update C-Code

6 References

- TPS65982 data sheet (SLVSD02)
- TPS6598x and TPS65986 Firmware User's Guide (SLVUAH7)
- TPS6598X Configuration Tool
- TPS6598X Utilities Tool
- TPS65986 data sheet (SLVSD13)
- TPS65981 data sheet (SLVSDC2)



Revision History www.ti.com

Revision History

NOTE: Page numbers for previous revisions may differ from page numbers in the current version.

С	Changes from Original (June 2016) to A Revision		
•	Changed device name globally from TPS65982 to TPS6598x	1	
•	Included language for software and firmware patches	1	
•	Added TPS65982D SPI Flash Memory Organization of Region 0 image	4	
•	Added TPS65982D modifications for data structures in the Excerpt of Code From "hostIF82.h" Header Filesection.	10	
•	Added TPS65982D modifications for data structures in the Excerpt of Code From "i2cFwUpdate82.c" C Filesection.	16	

IMPORTANT NOTICE FOR TI DESIGN INFORMATION AND RESOURCES

Texas Instruments Incorporated ('TI") technical, application or other design advice, services or information, including, but not limited to, reference designs and materials relating to evaluation modules, (collectively, "TI Resources") are intended to assist designers who are developing applications that incorporate TI products; by downloading, accessing or using any particular TI Resource in any way, you (individually or, if you are acting on behalf of a company, your company) agree to use it solely for this purpose and subject to the terms of this Notice.

TI's provision of TI Resources does not expand or otherwise alter TI's applicable published warranties or warranty disclaimers for TI products, and no additional obligations or liabilities arise from TI providing such TI Resources. TI reserves the right to make corrections, enhancements, improvements and other changes to its TI Resources.

You understand and agree that you remain responsible for using your independent analysis, evaluation and judgment in designing your applications and that you have full and exclusive responsibility to assure the safety of your applications and compliance of your applications (and of all TI products used in or for your applications) with all applicable regulations, laws and other applicable requirements. You represent that, with respect to your applications, you have all the necessary expertise to create and implement safeguards that (1) anticipate dangerous consequences of failures, (2) monitor failures and their consequences, and (3) lessen the likelihood of failures that might cause harm and take appropriate actions. You agree that prior to using or distributing any applications that include TI products, you will thoroughly test such applications and the functionality of such TI products as used in such applications. TI has not conducted any testing other than that specifically described in the published documentation for a particular TI Resource.

You are authorized to use, copy and modify any individual TI Resource only in connection with the development of applications that include the TI product(s) identified in such TI Resource. NO OTHER LICENSE, EXPRESS OR IMPLIED, BY ESTOPPEL OR OTHERWISE TO ANY OTHER TI INTELLECTUAL PROPERTY RIGHT, AND NO LICENSE TO ANY TECHNOLOGY OR INTELLECTUAL PROPERTY RIGHT OF TI OR ANY THIRD PARTY IS GRANTED HEREIN, including but not limited to any patent right, copyright, mask work right, or other intellectual property right relating to any combination, machine, or process in which TI products or services are used. Information regarding or referencing third-party products or services does not constitute a license to use such products or services, or a warranty or endorsement thereof. Use of TI Resources may require a license from a third party under the patents or other intellectual property of TI.

TI RESOURCES ARE PROVIDED "AS IS" AND WITH ALL FAULTS. TI DISCLAIMS ALL OTHER WARRANTIES OR REPRESENTATIONS, EXPRESS OR IMPLIED, REGARDING TI RESOURCES OR USE THEREOF, INCLUDING BUT NOT LIMITED TO ACCURACY OR COMPLETENESS, TITLE, ANY EPIDEMIC FAILURE WARRANTY AND ANY IMPLIED WARRANTIES OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE, AND NON-INFRINGEMENT OF ANY THIRD PARTY INTELLECTUAL PROPERTY RIGHTS.

TI SHALL NOT BE LIABLE FOR AND SHALL NOT DEFEND OR INDEMNIFY YOU AGAINST ANY CLAIM, INCLUDING BUT NOT LIMITED TO ANY INFRINGEMENT CLAIM THAT RELATES TO OR IS BASED ON ANY COMBINATION OF PRODUCTS EVEN IF DESCRIBED IN TI RESOURCES OR OTHERWISE. IN NO EVENT SHALL TI BE LIABLE FOR ANY ACTUAL, DIRECT, SPECIAL, COLLATERAL, INDIRECT, PUNITIVE, INCIDENTAL, CONSEQUENTIAL OR EXEMPLARY DAMAGES IN CONNECTION WITH OR ARISING OUT OF TI RESOURCES OR USE THEREOF, AND REGARDLESS OF WHETHER TI HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES.

You agree to fully indemnify TI and its representatives against any damages, costs, losses, and/or liabilities arising out of your non-compliance with the terms and provisions of this Notice.

This Notice applies to TI Resources. Additional terms apply to the use and purchase of certain types of materials, TI products and services. These include; without limitation, TI's standard terms for semiconductor products http://www.ti.com/sc/docs/stdterms.htm), evaluation modules, and samples (http://www.ti.com/sc/docs/sampterms.htm).

Mailing Address: Texas Instruments, Post Office Box 655303, Dallas, Texas 75265 Copyright © 2017, Texas Instruments Incorporated