HO CHI MINH CITY UNIVERSITY OF TECHNOLOGY DEPARTMENT OF TELECOMMUNICATIONS ENGINEERING



ANALOG SIGNAL PROCESSING PROJECT REPORT MATLAB SOLVER PROGRAM FOR OPERATION AMPLIFIER CIRCUITS

Lecturer: Assoc. Prof. Hà Hoàng Kha

Class: TT04 Semester: 211

Members: Lương Triển Thắng 2051194

Nguyễn Ngọc Minh Anh
Phạm Nguyễn Trung Tín
2051203

Table of Contents

| I. | Introduction to OpAmp | 3 |
|------|--|----|
| 1. | A brief look at OpAmp | 3 |
| 2. | Open-loop vs. closed-loop operation | 4 |
| a | . Open-loop | 4 |
| b | . Closed-loop | 4 |
| II. | General Knowledge for several ideal OpAmp circuits | 5 |
| 1. | Inverting amplifier circuit | 5 |
| 2. | Non-inverting amplifier circuit | 5 |
| 3. | Summing inverting amplifier circuit | 6 |
| 4. | Summing non-inverting amplifier circuit | 7 |
| III. | MATLAB Solving Program | 8 |
| 1. | Features and instructions | 8 |
| a | . Features | 8 |
| b | . Instructions | 9 |
| 2. | Examples | 9 |
| 3. | GUI designing and coding | 11 |
| IV. | Appendix | 27 |
| V. | References | 27 |
| VI. | Table of Figures | 27 |

I. Introduction to OpAmp

1. A brief look at OpAmp




Figure I-1: UA741CN IC and pinout

Operational Amplifiers, also known as Op-amps or OpAmps, are basically a voltage amplifying device designed to be used with components like capacitors and resistors, between its in and out terminals. They are essentially a core part of analog devices. OpAmp has positive and negative inputs which allow circuits that use feedback to achieve a wide range of functions. Feedback components like these are used to determine the operation of the amplifier. The amplifier can perform many different operations (resistive, capacitive, or both), giving it the name Operational Amplifier.




Figure I-2: OpAmp Schematic

Using OpAmp, it's easy to make amplifiers, comparators, log amps, filters, oscillators, data converters, level translators, references, and more. Mathematical functions like addition, subtraction, multiplication, and integration can be easily accomplished.

The operational amplifier is arguably the most useful single device in analog electronic circuitry. With only a handful of external components, it can be made to perform a wide variety of analog signal processing tasks. It is also quite affordable, most general-purpose amplifiers selling for under a dollar apiece. Modern designs have been engineered with durability in mind as well: several "op-amps" are manufactured that can sustain direct short-circuits on their outputs without damage.




Figure I-3: Schematic of LM741 from its datasheet of Texas Instruments

One key to the usefulness of these little circuits is in the engineering principle of feedback, particularly negative feedback, which constitutes the foundation of almost all automatic control processes. Its numerous practical applications include instrumentation amplifiers, digital-to-analog converters, analog computers, level shifters, filters, calibration circuits, inverters, summers, integrators, differentiators, subtractors, logarithmic amplifiers, comparators, gyrators, oscillators, rectifiers, regulators, voltage-to-current converters, current-to-voltage converters, and clippers.

2. Open-loop vs. closed-loop operation

- a. Open-loop
 - Rarely used.
 - OpAmp specification may be important.




Figure I-4: Open-loop circuit and its properties

b. Closed-loop

- Most used.
- Some sort of feedback from output to input exists.
- The input voltage V_{in} is defined according to the application.




Figure I-5: Closed-loop circuit and its properties

II. General Knowledge for several ideal OpAmp circuits

The ideal op-amp is an amplifier with infinite input impedance, infinite open-loop gain, zero out-put impedance, infinite bandwidth, and zero noise. It has positive and negative inputs which allow circuits that use feedback to achieve a wide range of functions.


Assumptions for ideal OpAmp:

- Assume that negative feedback: $V^+ = V^-$.
- Assume the input(s) resistance is finite, so $I^+ = I^- = 0$.

1. Inverting amplifier circuit


An Inverting Amplifier is a type of Operational Amplifier circuit which produces an output which is out of phase with respect to its input by 180°.

This mean that if the input pulse is positive, then the output pulse will be negative and vice versa.



2. Non-inverting amplifier circuit

A non-inverting Amplifier is an OpAmp circuit configuration that produces an amplified output signal which is in phase with the applied input signal. In other words, a non-inverting amplifier behaves like a voltage follower circuit. A non-inverting amplifier also uses a negative feedback connection, but instead of feeding the entire output signal to the input, only a part of the output signal voltage is fed back as input to the inverting input terminal of the OpAmp.



3. Summing inverting amplifier circuit

A summing amplifier is an example of an inverting amplifier with multiple inputs, enabling to effectively add several individual input signals, which proves to be useful in audio mixing applications. Its output is the sum of each input scaled by the corresponding resistor ratio.




Figure II-3: Summing Inverting OpAmp Circuit

- Since V^+ is connected to the ground, then $V^+ = V^- = 0$
- Apply KCL:

$$\begin{split} I_{1} + I_{2} + \cdots + I_{n} &= I^{-} + I_{f} \\ \Leftrightarrow I_{1} + I_{2} + \cdots + I_{n} &= I_{f} \\ \Leftrightarrow \frac{V_{in_{1}} - V^{-}}{R_{1}} + \frac{V_{in_{2}} - V^{-}}{R_{2}} + \cdots + \frac{V_{in_{n}} - V^{-}}{R_{n}} &= \frac{V^{-} - V_{out}}{R_{f}} \\ \Leftrightarrow \frac{V_{in_{1}}}{R_{1}} + \frac{V_{in_{2}}}{R_{2}} + \cdots + \frac{V_{in_{n}}}{R_{n}} &= \frac{-V_{out}}{R_{f}} \\ \Rightarrow V_{out} &= -\left(\frac{V_{in_{1}}}{R_{1}} + \frac{V_{in_{2}}}{R_{2}} + \cdots + \frac{V_{in_{n}}}{R_{n}}\right) V_{in} \end{split}$$

4. Summing non-inverting amplifier circuit

The non-inverting summing amplifier is based on around the configuration of a non-inverting operational amplifier circuit in that the input (either DC or AC) is applied to the non-inverting (+) terminal, while the required negative feedback and gain is achieved by feeding back some portion of the output signal (V_{out}) to the inverting (-) terminal.




Figure II-4: Summing Non-inverting OpAmp Circuit

Apply KCL:

$$\begin{array}{c} I_{1} + I_{2} + \cdots + I_{n} = I^{+} = 0 \\ \Leftrightarrow \frac{V_{in_{1}} - V^{+}}{R_{1}} + \frac{V_{in_{2}} - V^{+}}{R_{2}} + \cdots + \frac{V_{in_{n}} - V^{+}}{R_{n}} = 0 \\ \Leftrightarrow V^{+} = V^{-} = \frac{\frac{V_{in_{1}} + V_{in_{2}}}{R_{1}} + \frac{V_{in_{2}}}{R_{2}} + \cdots + \frac{V_{in_{n}}}{R_{n}}}{\frac{1}{R_{1}} + \frac{1}{R_{2}}} \\ \Leftrightarrow V^{-} = \frac{V_{out} - V^{-}}{R_{n}} \\ \Leftrightarrow V_{out} = \left(1 + \frac{R_{f}}{R}\right) V^{-} \\ \Leftrightarrow V_{out} = \left(1 + \frac{R_{f}}{R}\right) \frac{V_{in_{1}} + V_{in_{2}}}{\frac{1}{R_{1}} + \frac{1}{R_{2}}} + \cdots + \frac{V_{in_{n}}}{R_{n}}}{\frac{1}{R_{1}} + \frac{1}{R_{2}}} \\ \Leftrightarrow V_{out} = \left(1 + \frac{R_{f}}{R}\right) V^{-} \\ \end{cases}$$

III. MATLAB Solving Program

1. Features and instructions




Figure III-1: GUI for Operational Amplifier Solver

a. Features

- Includes four different circuits:
 - + Inverting Amplifier
 - + Non-inverting Amplifier
 - + Summing Inverting Amplifier
 - + Summing Non-inverting Amplifier
- Three different types of source signals:
 - + DC source
 - + AC source
 - + Custom function $V_{in}(t)$
- For Summing circuits, input can be maximum of 100 sources.
- Time domain can be adjusted for the graphs.
- Input and output can be plotted on a single axes.
- Resistor (potentiometer) can be a function that changes over time (must not be negative).
- All inputs accept basic operations, e.g., +, -, *, /, ^, abs, mod, log, ...

b. Instructions

- Step 1: Choose the circuit.
- Step 2:
 - + If non-summing circuit is chosen: Choose the source in "Vin source" panel then fill the value.
 - + If summing circuit is chosen:
 Fill in the value of the source and resistors in "Vin sources (for summing circuits)" panel in the exact order.

Note: The number of the Vin and the number of resistors must be equal.

- **Step 3:** Fill in the value R_f and R (if needed) in "Resistors" panel.
- Step 4: (optional)
 - + Custom the time range (tmin, tmax) to plot Vin and Vout in that range only.
 - + Tick "Plot on the same axes" to plot Vin and Vout on the same axes.
- **Step 5:** Press the "Solve" button and the results will shown up. ¹

2. Examples




Figure III-2: Inverting Amplifier with AC source

¹ Solving speed depends on your computer specs.




Figure III-3: Non-inverting Amplifier with custom function




Figure III-4: Summing Inverting Amplifier with a list of 3 Vins, 3 resistors

3. GUI designing and coding




Figure III-5: GUI designing in GUIDE

To achieve "Plot on the same axes" feature, a new axes is put on top of vin and vout graph.

After finish designing the GUI, it's time for the code.

When looking closely into the code below, the first function is GUI_OpeningFcn which clarifies the initial user interface.

Then, code lines are all "Callback" functions which are the procedures that will be performed when the users interact.

All green code lines are "comments", are also the notes about how these code's procedure is employed for and then follow pre-programming sequence. The page will be rotated to better showing the comments.

```
function varargout = GUI(varargin)
% GUI MATLAB code for GUI.fig
      GUI, by itself, creates a new GUI or raises the existing
      singleton*.
      H = GUI returns the handle to a new GUI or the handle to
       the existing singleton*.
       GUI('CALLBACK', hObject, eventData, handles,...) calls the local
       function named CALLBACK in GUI.M with the given input arguments.
       GUI('Property','Value',...) creates a new GUI or raises the
       existing singleton*. Starting from the left, property value pairs are
       applied to the GUI before GUI OpeningFcn gets called. An
       unrecognized property name or invalid value makes property application
       stop. All inputs are passed to GUI OpeningFcn via varargin.
       *See GUI Options on GUIDE's Tools menu. Choose "GUI allows only one
       instance to run (singleton)".
% See also: GUIDE, GUIDATA, GUIHANDLES
\mbox{\%} Edit the above text to modify the response to help GUI
% Last Modified by GUIDE v2.5 06-Nov-2021 22:29:48
% Begin initialization code - DO NOT EDIT
qui Singleton = 1;
gui State = struct('qui Name',
                                     mfilename, ...
    'gui Singleton', gui Singleton, ...
    'qui OpeningFcn', @GUI OpeningFcn, ...
    'gui OutputFcn', @GUI OutputFcn, ...
    'gui LayoutFcn', [], ...
    'qui Callback', []);
if nargin && ischar(varargin{1})
    gui State.gui Callback = str2func(varargin{1});
end
if nargout
    [varargout{1:nargout}] = qui mainfcn(qui State, varargin{:});
else
   qui mainfcn(qui State, vararqin(:));
% End initialization code - DO NOT EDIT
% --- Executes just before GUI is made visible.
function GUI OpeningFcn(hObject, ~, handles, varargin)
% This function has no output args, see OutputFcn.
% hObject handle to figure
% eventdata reserved - to be defined in a future version of MATLAB
% handles structure with handles and user data (see GUIDATA)
% varargin command line arguments to GUI (see VARARGIN)
% Choose default command line output for GUI
handles.output = hObject;
% Update handles structure
guidata(hObject, handles);
% UIWAIT makes GUI wait for user response (see UIRESUME)
```

```
% uiwait(handles.figure1);
axes(handles.circuit);
[im, ~, alpha] = imread('invert.png');
f = imshow(im);
set(f, 'AlphaData', alpha);
axes(handles.logobk);
[im, ~, alpha] = imread('logobk.png');
f = imshow(im):
set(f, 'AlphaData', alpha);
% --- Outputs from this function are returned to the command line.
function varargout = GUI OutputFcn(~, ~, handles)
% varargout cell array for returning output args (see VARARGOUT);
% hObject handle to figure
% eventdata reserved - to be defined in a future version of MATLAB
% handles structure with handles and user data (see GUIDATA)
% Get default command line output from handles structure
varargout{1} = handles.output;
% % % START HERE !!!
% ----- CONFIGURATION PANEL ------
% CIRCUIT SELECTING MENU
% When changing the circuit
% - Change the circuit diagram (png transparent).
% - Change back to AC source to avoid bugs.
% - If the summing circuit is selected, custom time range must be on.
function circuitselect Callback(hObject, ~, handles)
axes(handles.circuit);
if (get (hObject, 'Value') == 1)
   set(handles.customtimechkbox, 'Enable', 'on');
   set(handles.rtxtbox, 'Enable', 'on');
   set(handles.acsourcebtn, 'Value', 1);
    [im, ~, alpha] = imread('invert.png');
   summingon(false, handles);
elseif(get(hObject,'Value') == 2)
   set(handles.customtimechkbox, 'Enable', 'on');
   set(handles.rtxtbox, 'Enable', 'on');
   set(handles.acsourcebtn, 'Value', 1);
   [im, ~, alpha] = imread('noninvert.png');
    summingon(false, handles);
elseif(get(hObject,'Value') == 3)
   set(handles.customtimechkbox, 'Value',1);
   set(handles.customtimechkbox, 'Enable','off');
   set(handles.rtxtbox, 'Enable', 'off');
   set(handles.acsourcebtn, 'Value', 1);
   [im, ~, alpha] = imread('invert sum.png');
   summingon(true, handles);
elseif(get(hObject,'Value') == 4)
   set(handles.customtimechkbox, 'Value',1);
```

```
set(handles.customtimechkbox, 'Enable', 'off');
   set(handles.rtxtbox, 'Enable', 'on');
   set(handles.acsourcebtn, 'Value', 1);
   [im, ~, alpha] = imread('noninvert sum.png');
   summingon(true, handles);
end
f = imshow(im);
set(f, 'AlphaData', alpha);
function circuitselect CreateFcn(hObject, ~, ~)
if ispc && isequal(get(hObject, 'BackgroundColor'), get(0, 'defaultUicontrolBackgroundColor'))
   set(hObject, 'BackgroundColor', 'white');
end
% CUSTOM TIME RANGE CHECKBOX
function customtimechkbox CreateFcn(~, ~, ~)
function customtimechkbox Callback(~, ~, ~)
% TMIN TEXTBOX
% FEATURES:
% - Can use some simple mathematical operation, eq. +, -, *, /, ^, ...
% - Avoid some unexpected input, eg. text
% IDEAS:
% - Create of a list of text that need to be ignore.
% - If one or more ignore text contained in the text:
% + Try to evaluate it.
% + If the evaluation failed, set the text to '0'.
% - If there is no ignore text:
% + Try to convert it into (double).
% + If the conversion failed, set the text to '0'.
function tmintxtbox Callback(hObject, ~, handles)
value = get(hObject, 'String');
ignore = ["+","-","*","/","pi","^","exp","log","abs","mod"];
if (contains (value, ignore))
   try
       value = eval(value);
        set(handles.tmintxtbox, 'String', string(value));
   catch ME
        set(handles.tmintxtbox, 'String', '0');
   end
else
   value = str2double(value);
   if(isnan(value))
        set (handles.tmintxtbox, 'String', '0');
   end
end
function tmintxtbox CreateFcn(hObject, ~, ~)
if ispc && isequal (get (hObject, 'BackgroundColor'), get (0, 'defaultUicontrolBackgroundColor'))
   set(hObject, 'BackgroundColor', 'white');
end
% TMAX TEXTBOX
% FEATURES:
```

```
% - Can use some simple mathematical operation, eg. +, -, *, /, ^, ...
% - Avoid some unexpected input, eq. text
% IDEAS:
% - Create of a list of text that need to be ignore.
% - If one or more ignore text contained in the text:
% + Try to evaluate it.
% + If the evaluation failed, set the text to '0'.
% - If there is no ignore text:
% + Try to convert it into (double).
% + If the conversion failed, set the text to '0'.
function tmaxtxtbox Callback(hObject, ~, handles)
value = get(hObject, 'String');
ignore = ["+","-","*","/","pi","^","exp","log","abs","mod"];
if (contains (value, ignore))
   try
       value = eval(value);
        set(handles.tmaxtxtbox, 'String', string(value));
        set (handles.tmaxtxtbox, 'String', '0');
   end
else
   value = str2double(value);
   if(isnan(value))
        set (handles.tmaxtxtbox, 'String', '0');
   end
end
function tmaxtxtbox CreateFcn(hObject, ~, ~)
if ispc && isequal(get(hObject, 'BackgroundColor'), get(0, 'defaultUicontrolBackgroundColor'))
   set(hObject, 'BackgroundColor', 'white');
end
% PLOT ON THE SAME AXES CHECKBOX
function sameaxeschkbox Callback(~, ~, ~)
% ----- RESISTORS PANEL ------
% RF TEXTBOX
% FEATURES:
% - Can use some simple mathematical operation, eg. +, -, *, /, ^, ...
% - Avoid some unexpected input, eq. text (except "t")
% IDEAS:
% - Create of a list of text that need to be ignore.
% - If one or more ignore text contained in the text:
% + Try to evaluate it.
function rftxtbox Callback(hObject, ~, handles)
value = get(hObject, 'String');
ignore = ["+","-","*","/","pi","^","exp","log","abs","mod"];
if (contains (value, ignore))
   try
       value = eval(value);
       set(handles.rftxtbox, 'String', string(value));
   catch ME
   end
end
function rftxtbox CreateFcn(hObject, ~, ~)
```

```
if ispc && isequal(get(hObject, 'BackgroundColor'), get(0,'defaultUicontrolBackgroundColor'))
   set(hObject, 'BackgroundColor', 'white');
end
% R TEXTBOX
% FEATURES:
% - Can use some simple mathematical operation, eg. +, -, *, /, ^, ...
% - Avoid some unexpected input, eg. text (except "t")
% IDEAS:
% - Create of a list of text that need to be ignore.
% - If one or more ignore text contained in the text:
   + Try to evaluate it.
function rtxtbox Callback(hObject, ~, handles)
value = get(hObject, 'String');
ignore = ["+","-","*","/","pi","^","exp","log","abs","mod"];
if (contains (value, ignore))
   try
       value = eval(value);
        set(handles.rtxtbox, 'String', string(value));
   catch ME
   end
end
function rtxtbox CreateFcn(hObject, ~, ~)
if ispc && isequal(get(hObject, 'BackgroundColor'), get(0,'defaultUicontrolBackgroundColor'))
   set(hObject, 'BackgroundColor', 'white');
end
% ----- VIN SOURCE PANEL ------
% DC SOURCE TEXTBOX
% FEATURES:
% - Can use some simple mathematical operation, eq. +, -, *, /, ^, ...
% - Avoid some unexpected input, eg. text
% IDEAS:
% - Create of a list of text that need to be ignore.
% - If one or more ignore text contained in the text:
% + Try to evaluate it.
% + If the evaluation failed, set the text to '0'.
% - If there is no ignore text:
% + Try to convert it into (double).
   + If the conversion failed, set the text to '0'.
function dcsourcetxtbox Callback(hObject, ~, handles)
value = get(hObject, 'String');
ignore = ["+","-","*","/","pi","^","exp","log","abs","mod"];
if (contains (value, ignore))
   try
       value = eval(value);
        set(handles.dcsourcetxtbox, 'String', string(value));
   catch ME
        set(handles.dcsourcetxtbox, 'String', '0');
   end
else
   value = str2double(value);
   if(isnan(value))
        set(handles.dcsourcetxtbox, 'String', '0');
```

```
end
end
function dcsourcetxtbox CreateFcn(hObject, ~, ~)
if ispc && isequal(get(hObject, 'BackgroundColor'), get(0, 'defaultUicontrolBackgroundColor'))
    set(hObject, 'BackgroundColor', 'white');
end
% DC SOURCE RADIO BUTTON
% If selected, custom time range must be using and does not allow turning
% it off and vice versa.
function dcsourcebtn Callback(hObject, ~, handles)
if (get (hObject, 'Value') == 1)
   set(handles.customtimechkbox, 'Value',1)
   set(handles.customtimechkbox, 'Enable','off')
else
    set(handles.customtimechkbox, 'Enable','on')
end
% AC SOURCE RADIO BUTTON
% If selected, custom time range can be or not be using and allow turning
% it on or off and vice versa.
function acsourcebtn Callback(hObject, ~, handles)
if (get (hObject, 'Value') == 0)
   set(handles.customtimechkbox, 'Value',1)
   set(handles.customtimechkbox, 'Enable','off')
else
    set(handles.customtimechkbox, 'Enable', 'on')
end
% AMPLITUDE TEXTBOX
% FEATURES:
% - Can use some simple mathematical operation, eq. +, -, *, /, ^, ...
% - Avoid some unexpected input, eg. text, negative value
% IDEAS:
% - Create of a list of text that need to be ignore.
% - If one or more ignore text contained in the text:
    + Try to evaluate it, get the absolute value of it's negative.
% + If the evaluation failed, set the text to '0'.
% - If there is no ignore text:
% + Try to convert it into (double), get the absolute value of it's negative.
    + If the conversion failed, set the text to '0'.
function atxtbox Callback(hObject, ~, handles)
value = get(hObject, 'String');
ignore = ["+","-","*","/","pi","^","exp","log","abs","mod"];
if (contains (value, ignore))
   trv
        value = eval(value);
        if(value < 0)</pre>
            set(handles.atxtbox, 'String', abs(value));
        else
            set(handles.atxtbox, 'String', string(value));
        end
    catch ME
        set(handles.atxtbox, 'String', '0');
   end
e1 se
   value = str2double(value);
   if(isnan(value))
```

```
set(handles.atxtbox, 'String', '0');
    end
    if(value < 0)</pre>
        set(handles.atxtbox, 'String', abs(value));
    end
end
function atxtbox CreateFcn(hObject, ~, ~)
if ispc && isequal(get(hObject, 'BackgroundColor'), get(0, 'defaultUicontrolBackgroundColor'))
    set(hObject, 'BackgroundColor', 'white');
end
% FREQUENCY TEXTBOX
% FEATURES:
% - Can use some simple mathematical operation, eq. +, -, *, /, ^, ...
% - Avoid some unexpected input, eq. text, negative value, zero
% IDEAS:
% - Create of a list of text that need to be ignore.
% - If one or more ignore text contained in the text:
    + Try to evaluate it, get the absolute value of it's negative.
% + If it's 0 or the evaluation failed, set the text to '1'.
% - If there is no ignore text:
  + Try to convert it into (double), get the absolute value of it's negative.
    + If it's 0 or the conversion failed, set the text to '1'.
function freqtxtbox Callback(hObject, ~, handles)
value = get(hObject, 'String');
ignore = ["+","-","*","/","pi","^","exp","log","abs","mod"];
if (contains (value, ignore))
    try
        value = eval(value);
        if(value < 0)</pre>
            set(handles.freqtxtbox, 'String', abs(value));
        elseif(value == 0)
            set(handles.freqtxtbox, 'String', '1');
        else
            set(handles.freqtxtbox, 'String', string(value));
        end
    catch ME
        set(handles.freqtxtbox, 'String', '1');
    end
else
    value = str2double(value);
    if(isnan(value) || value == 0)
        set(handles.freqtxtbox, 'String', '1');
    end
    if(value < 0)</pre>
        set(handles.freqtxtbox, 'String', abs(value));
    end
end
function freqtxtbox CreateFcn(hObject, ~, ~)
if ispc && isequal(get(hObject, 'BackgroundColor'), get(0, 'defaultUicontrolBackgroundColor'))
    set (hObject, 'BackgroundColor', 'white');
end
% PHASE SHIFT TEXTBOX
```

```
% FEATURES:
% - Can use some simple mathematical operation, eq. +, -, *, /, ^, ...
% - Avoid some unexpected input, eq. text
% IDEAS:
% - Create of a list of text that need to be ignore.
% - If one or more ignore text contained in the text:
% + Try to evaluate it.
% + If the evaluation failed, set the text to '0'.
% - If there is no ignore text:
% + Try to convert it into (double).
     + If the conversion failed, set the text to '0'.
function phasetxtbox Callback(hObject, ~, handles)
value = get(hObject, 'String');
ignore = ["+","-","*","/","pi","^","exp","log","abs","mod"];
if(contains(value,ignore))
   try
        value = eval(value);
        if(value < 0)</pre>
            set(handles.phasetxtbox, 'String', abs(value));
       else
            set(handles.phasetxtbox, 'String', string(value));
        end
   catch ME
        set(handles.phasetxtbox, 'String', '0');
   end
else
   value = str2double(value);
   if(isnan(value))
        set(handles.phasetxtbox, 'String', '0');
   end
   if (value < 0)</pre>
        set(handles.phasetxtbox, 'String', abs(value));
   end
end
function phasetxtbox CreateFcn(hObject, ~, ~)
if ispc && isequal(get(hObject, 'BackgroundColor'), get(0, 'defaultUicontrolBackgroundColor'))
    set(hObject, 'BackgroundColor', 'white');
end
% DC OFFSET TEXTBOX
% FEATURES:
% - Can use some simple mathematical operation, eq. +, -, *, /, ^, ...
% - Avoid some unexpected input, eg. text
% IDEAS:
% - Create of a list of text that need to be ignore.
% - If one or more ignore text contained in the text:
% + Try to evaluate it.
% + If the evaluation failed, set the text to '0'.
% - If there is no ignore text:
% + Try to convert it into (double).
    + If the conversion failed, set the text to '0'.
function dctxtbox Callback(hObject, ~, handles)
value = get(hObject, 'String');
ignore = ["+","-","*","/","pi","^","exp","log","abs","mod"];
if (contains (value, ignore))
   try
```

```
value = eval(value);
        set (handles.dctxtbox, 'String', string(value));
   catch ME
        set(handles.dctxtbox, 'String', '0');
   end
else
   value = str2double(value);
   if(isnan(value))
        set (handles.dctxtbox, 'String', '0');
   end
end
function dctxtbox CreateFcn(hObject, ~, ~)
if ispc && isequal(get(hObject, 'BackgroundColor'), get(0, 'defaultUicontrolBackgroundColor'))
   set(hObject, 'BackgroundColor', 'white');
end
% CUSTOM FUNCTION RADIO BUTTON
% If selected, custom time range must be using and does not allow turning
% it off and vice versa.
function customfuncbtn Callback(hObject, ~, handles)
if (get (hObject, 'Value') == 1)
   set(handles.customtimechkbox, 'Value',1)
   set(handles.customtimechkbox, 'Enable', 'off')
else
    set(handles.customtimechkbox, 'Enable','on')
end
% CUSTOM FUNCTION TEXTBOX
function customfunctxtbox Callback(~, ~, ~)
function customfunctxtbox CreateFcn(hObject, ~, ~)
if ispc && isequal(get(hObject, 'BackgroundColor'), get(0, 'defaultUicontrolBackgroundColor'))
   set(hObject, 'BackgroundColor', 'white');
end
% ------ VINS AND RESISTORS (for summing circuit) PANEL -----
% VIN SUM LIST TEXTBOX
% PROBLEMS:
% - If the list has 5 itmes, and plot the 5th vin is selected, when
% removing items, the vinplottxtbox should be updated as the new max.
function vinsumlist Callback(hObject, ~, handles)
value = str2double(get(handles.vinplottxtbox,'String'));
vinlist = get(hObject, 'String');
[row, ~] = size(vinlist);
if(isnan(value))
    set (handles.vinplottxtbox, 'String', 1);
elseif(value > row)
   set(handles.vinplottxtbox,'String',string(row));
elseif (value < 1)</pre>
   set(handles.vinplottxtbox,'String','1');
end
function vinsumlist CreateFcn(hObject, ~, ~)
if ispc && isequal(get(hObject, 'BackgroundColor'), get(0, 'defaultUicontrolBackgroundColor'))
    set(hObject, 'BackgroundColor', 'white');
end
```

```
% R SUM LIST TEXTBOX
function rsumlist Callback(~, ~, ~)
function rsumlist CreateFcn(hObject, ~, ~)
if ispc && isequal (get(hObject, 'BackgroundColor'), get(0, 'defaultUicontrolBackgroundColor'))
   set(hObject, 'BackgroundColor', 'white');
% PLOT VIN SELECT TEXTBOX
% Selecting Vin to plot (summing circuit)
% FEATURES:
% - Only allow user input numbers that in the range of 1 to max of textbox
function vinplottxtbox Callback(hObject, ~, handles)
value = str2double(get(hObject, 'String'));
vinlist = get(handles.vinsumlist, 'String');
[row, ~] = size(vinlist);
if(isnan(value))
   set(hObject, 'String', 1);
elseif(value > row)
   set(hObject, 'String', string(row));
elseif (value < 1)</pre>
    set(hObject, 'String', '1');
end
function vinplottxtbox CreateFcn(hObject, ~, ~)
if ispc && isequal(get(hObject, 'BackgroundColor'), get(0, 'defaultUicontrolBackgroundColor'))
   set(hObject,'BackgroundColor','white');
end
% IF THE PROGRAM IS SOLVING
% Lock the "Solve" button and change the text into "Please wait..." and
% revert if done.
function isSolving(True, handles)
if(True == false)
   set(handles.solvebtn, 'String', 'Solve');
   set(handles.solvebtn, 'Value', 0);
   set(handles.solvebtn, 'Enable', 'on');
else
   set(handles.solvebtn, 'String', 'Please wait...');
   set(handles.solvebtn, 'Value', 1);
   set(handles.solvebtn, 'Enable', 'off');
end
% IF SUMMING CIRCUIT IS SELECTED
% Turn off all items which don't belongs to summing circuit and turn on
% all items which belongs to summing circuit and vice versa.
function summingon(istrue, handles)
if(istrue == false)
   set (handles.vinsumlist, 'Enable', 'off');
   set(handles.rsumlist,'Enable','off');
   set (handles.vinplottxtbox, 'Enable', 'off');
   set (handles.dcsourcetxtbox, 'Enable', 'on');
   set(handles.atxtbox, 'Enable', 'on');
   set (handles.freqtxtbox, 'Enable', 'on');
   set(handles.phasetxtbox, 'Enable', 'on');
    set (handles.dctxtbox, 'Enable', 'on');
   set(handles.customfunctxtbox,'Enable','on');
```

```
set (handles.dcsourcebtn, 'Enable', 'on');
   set(handles.acsourcebtn, 'Enable', 'on');
   set (handles.customfuncbtn, 'Enable', 'on');
else
   set(handles.vinsumlist, 'Enable', 'on');
   set(handles.rsumlist, 'Enable', 'on');
   set (handles.vinplottxtbox, 'Enable', 'on');
   set(handles.dcsourcetxtbox,'Enable','off');
   set(handles.atxtbox,'Enable','off');
   set(handles.freqtxtbox,'Enable','off');
   set (handles.phasetxtbox, 'Enable', 'off');
   set(handles.dctxtbox,'Enable','off');
   set(handles.customfunctxtbox,'Enable','off');
   set(handles.dcsourcebtn, 'Enable', 'off');
   set(handles.acsourcebtn, 'Enable', 'off');
   set(handles.customfuncbtn,'Enable','off');
end
% IF PLOTING ON THE SAME AXES
% Turn off vin and vout axes and turn on sameaxes and vice versa.
function isSameAxes(~, handles)
value = get(handles.sameaxeschkbox,'Value');
cla(handles.vin);
cla(handles.vout);
cla(handles.sameaxes);
if(value == 1)
   set(handles.vin,'Visible','Off');
   set(handles.vout, 'Visible', 'Off');
   set(handles.sameaxes,'Visible','On');
else
   set(handles.vin,'Visible','On');
   set(handles.vout, 'Visible', 'On');
   set(handles.sameaxes,'Visible','Off');
end
% ------ CREDITS ------
% ABOUT BUTTON
% Credits!!! Do not remove or modify. Thanks.
function aboutbtn Callback(~, ~, ~)
CreateStruct.Interpreter = 'tex';
CreateStruct.WindowStyle = 'non-modal';
message = sprintf('{\\bfHo Chi Minh City University of Technology}\n{\\bfProject:} Operational Amplifier Solver\n{\\bfSubject:} Analog Signal
Processing\n{\\bfLecturer:} Assoc Prof. Ha Hoang Kha\n{\\bfClass:} TT04 - 211\n{\\bfMembers:}\n+ Luong Trien Thang - 2051194\n+ Nguyen Ngoc Minh Anh -
2051033\n+ Pham Nguyen Trung Tin - 2051203');
uiwait(msgbox(message,CreateStruct));
% ----- MAIN PROGRAM -----
% SOLVE BUTTON (MAIN)
function solvebtn Callback(hObject, ~, handles)
if (get (hObject, 'Value') == 1)
                                                                          % If the button is clicked
   isSolving(true, handles);
                                                                          % Triggger "isSolving(true)" function.
   freq = str2double(get(handles.freqtxtbox,'String'));
                                                                              Get the value of "freq".
                                                                              If "custom time range" is not checked
   if (get(handles.customtimechkbox, 'Value') == 0)
       period = 1/freq;
                                                                                   Get the period
                                                                                   exp(delta t)+1000 is used to more percise on large interval of delta t.
       t = linspace(-period, period, round(exp(2*period)+1000));
                                                                          용
                                                                              Else
        tmin = str2double(get(handles.tmintxtbox,'String'));
                                                                                   Get tmin and tmax
```

```
tmax = str2double(get(handles.tmaxtxtbox,'String'));
    if(tmin > tmax)
                                                                         If tmin > tmax
        set(handles.tmintxtbox,'String',string(tmax));
                                                                             Swap tmin and tmax
        set(handles.tmaxtxtbox,'String',string(tmin));
                                                                         t = linspace...
        t = linspace(tmax,tmin,round(exp(abs(tmin-tmax))+1000));
    elseif(tmin == tmax)
                                                                         If tmin == tmax
        message = sprintf('tmin and tmax must not be equal.');
                                                                     용
                                                                             Showing error message
        uiwait(errordlg(message));
        isSolving(false, handles);
        return:
    else
                                                                          Else
                                                                         t = linspace...
        t = linspace(tmin, tmax, round(exp(abs(tmin-tmax))+1000));
    end
end
if (get(handles.dcsourcebtn, 'Value') == 1)
                                                                         If DC source is selected
    vin = eval(get(handles.dcsourcetxtbox,'String'));
                                                                          vin = value of dctxtbox
elseif(get(handles.acsourcebtn,'Value') == 1)
                                                                     용
                                                                         If AC source is selected
    dc = str2double(get(handles.dctxtbox,'String'));
                                                                           Get amplitude, phase and dc offset in the textboxes
    amplitude = str2double(get(handles.atxtbox,'String'));
    phase = deg2rad(str2double(get(handles.phasetxtbox,'String')));
    vin = amplitude*sin(2*pi*freq*t + phase) + dc;
                                                                             vin = A*sin(2*pi*f*t + phase shift) + DC offset
elseif(get(handles.customfuncbtn,'Value') == 1)
                                                                         If custom function is selected
        vin = eval(get(handles.customfunctxtbox,'String'));
                                                                   용
                                                                              Try to evaluate the function
    catch ME
                                                                              If failed, show the error message
        message = sprintf('Error in Vin custom function:\n%s', ME.message);
       uiwait(errordlg(message));
        isSolving(false, handles);
                                                                     % Triggger "isSolving(false)" function.
    end
end
    rf = eval([get(handles.rftxtbox,'String'),'*1000']);
                                                                   % Try to evalute Rf
catch ME
                                                                     % If failed, show the error message.
    message = sprintf('Error in Rf:\n%s', ME.message);
    uiwait(errordlg(message));
    isSolving(false, handles);
                                                                          Triggger "isSolving(false)" function.
end
    r = eval([get(handles.rtxtbox,'String'),'*1000']);
                                                                          Try to evalute R
                                                                          If failed, show the error message.
catch ME
   message = sprintf('Error in R:\n%s', ME.message);
    uiwait(errordlg(message));
    isSolving(false, handles);
                                                                          Triggger "isSolving(false)" function.
end
if (isempty(find(rf<0, 1)) == 0 || isempty(find(rf<0, 1)) == 0) % If Rf or R is/contains negative value(s), show the error message.
    message = sprintf('Resistors must not be negative.\nTry to change the time range or resistor functions.');
    uiwait (errordlg (message));
    isSolving(false, handles);
                                                                      용
                                                                              Triggger "isSolving(false)" function.
    return:
                                                                      오
                                                                              Stop the function.
end
                                                                          If inverting circuit is selected
if(get(handles.circuitselect, 'Value') == 1)
    vout = -rf.*vin/r;
                                                                     용
                                                                              Calculate vout.
elseif(get(handles.circuitselect, 'Value') == 2)
                                                                     용
                                                                          If non-inverting circuit is selected
    vout = (rf/r+1).*vin;
                                                                              Calculate vout.
elseif(get(handles.circuitselect, 'Value') == 3)
                                                                     % If summing inverting circuit is selected
```

```
vinlist = get(handles.vinsumlist, 'String');
                                                                               Get values of vinlist and rlist.
    rlist = get(handles.rsumlist, 'String');
    [row, ~] = size(vinlist);
                                                                           Get the number of rows of two of them
    [row2, \sim] = size(rlist);
                                                                           If row of vinlist is not equal to row of rlist, show the error message.
    if(row ~= row2)
       message = sprintf('The number of Vins and the number of resistors must be equal.');
       uiwait(errordlg(message));
       isSolving(false, handles);
                                                                      용
                                                                               Triggger "isSolving(false)" function.
       return;
                                                                      용
                                                                               Stop the function.
   end
                                                                      % Initiate sum.
    sum = 0:
    for i=1:row
                                                                         For each row
       trv
           r = eval([rlist{i,:},'*1000']);
                                                                     % Try to evaluate r line i
                                                                     % If failed, show the error message
       catch ME
           message = sprintf('Error in Resistors list line %d:\n%s', i, ME.message);
           uiwait(errordlg(message));
           isSolving(false, handles);
                                                                      용
                                                                               Triggger "isSolving(false)" function.
       end
       if(isempty(find(eval(rlist{i,:})<0, 1)) == 0)</pre>
                                                                      % If R line i is/contains negative value, show the error message.
           message = sprintf('Resistors must not be negative.\nTry to change the time range or resistor functions.');
           uiwait (errordlg (message));
           isSolving(false, handles);
                                                                      용
                                                                               Triggger "isSolving(false)" function.
                                                                      용
                                                                               Stop the function.
           return:
       end
       trv
           vin = eval(vinlist{i,:});
                                                                      % Try to evaluate vin line i
                                                                      % If failed, show the error message
       catch ME
           message = sprintf('Error in Vin list line %d:\n%s', i, ME.message);
           uiwait(errordlg(message));
           isSolving(false, handles);
                                                                               Triggger "isSolving(false)" function.
       end
       sum = sum + vin ./r;
                                                                           sum = sum + vin line i/r line i
   end
   vout = -sum.*rf;
                                                                      % vout = -sum*rf
   vin = eval(vinlist{str2double(get(handles.vinplottxtbox,'String')),:}); % Set vin plot according to the vinplottxtbox
elseif(get(handles.circuitselect, 'Value') == 4)
   vinlist = get(handles.vinsumlist, 'String');
    rlist = get(handles.rsumlist, 'String');
    [row, ~] = size(vinlist);
    [row2, \sim] = size(rlist);
    if(row \sim = row2)
       message = sprintf('The number of Vins and the number of resistors must be equal.');
       uiwait(errordlg(message));
       isSolving(false, handles);
                                                                           Triggger "isSolving(false)" function.
       return;
                                                                               Stop the function.
   end
    sum1 = 0;
                                                                      % Initiate sum1 and sum2.
    sum2 = 0;
    for i=1:row
       try
                                                                      % Try to evaluate r line i
           r = eval([rlist{i,:},'*1000']);
                                                                      % If failed, show the error message
       catch ME
           message = sprintf('Error in Resistors list line %d:\n%s', i, ME.message);
           uiwait(errordlg(message));
           isSolving(false, handles);
                                                                      용
                                                                               Triggger "isSolving(false)" function.
```

```
end
        if (isempty(find(eval(rlist{i,:})<0, 1)) == 0)
                                                                       % If R line i is/contains negative value, show the error message.
            message = sprintf('Resistors must not be negative.\nTry to change the time range or resistor functions.');
            uiwait(errordlg(message));
            isSolving(false, handles);
                                                                                 Triggger "isSolving(false)" function.
            return;
                                                                                Stop the function.
        end
            vin = eval(vinlist{i,:});
                                                                            Try to evaluate vin line i
        catch ME
                                                                            If failed, show the error message
            message = sprintf('Error in Vin list line %d:\n%s', i, ME.message);
            uiwait(errordlg(message));
            isSolving(false, handles);
                                                                       용
                                                                                 Triggger "isSolving(false)" function.
        end
        sum1 = sum1 + vin ./r;
                                                                             sum1 = sum1 + vin1/r1 + vin2/r2 + ...
        sum2 = sum2 + 1./r;
                                                                            sum2 = sum2 + 1/r1 + 1/r2
                                                                            Calculate vout.
    vout = (rf/r + 1).*sum1./sum2;
    vin = eval(vinlist{str2double(get(handles.vinplottxtbox,'String')),:});
end
sameAxes = get(handles.sameaxeschkbox,'Value');
                                                                            Get "plot on the same axes" value.
isSameAxes(sameAxes, handles);
                                                                            Trigger isSameAxes(true);
if (isequal(size(vin),[1 1]))
                                                                            If vin is a constant
    if(sameAxes == true)
                                                                       용
                                                                                If sameAxes is selected
        axes(handles.sameaxes);
                                                                       용
                                                                                    Select sameaxes.
        plot(t, vin*ones(size(t)));
                                                                       용
                                                                                     Generate vin as an array with the size of t and the same value.
        hold on;
    else
                                                                       용
                                                                                Else
        axes(handles.vin);
                                                                       용
                                                                                    Select vin axes.
        plot(t, vin*ones(size(t)));
                                                                       용
                                                                                     Generate vin as an array with the size of t and the same value.
        legend('Vin(t)');
    end
                                                                            Else (vin is not a constant)
e1 se
    if(sameAxes == true)
                                                                                 Same as above but plot vin directly.
        axes(handles.sameaxes);
        plot(t, vin);
        hold on;
    else
        axes(handles.vin);
        plot(t, vin);
        legend('Vin(t)');
    end
end
if (isequal(size(vout),[1 1]))
                                                                            Same as above but vout.
    if(sameAxes == true)
        axes(handles.sameaxes);
        plot(t, vout*ones(size(t)));
        hold off;
        legend('Vin(t)','Vout(t)');
    else
        axes(handles.vout);
        plot(t, vout*ones(size(t)), 'Color', [0.8500 0.3250 0.0980]);
        legend('Vout(t)');
    end
```

else

```
if(sameAxes == true)
           axes (handles.sameaxes);
           plot(t, vout);
           hold off;
           legend('Vin(t)','Vout(t)');
       else
           axes(handles.vout);
           plot(t, vout, 'Color', [0.8500 0.3250 0.0980]);
           legend('Vout(t)');
       end
   end
   gapsRatio = 0.1;
                                                                          % Gaps for 2 bound of y-axis.
   if(sameAxes == true)
                                                                          % If sameaxes is selected
       set(handles.sameaxes, 'XLim', t(size(t)));
                                                                          % Set x-axis limit = size of t.
       ylimsameaxes = get(handles.sameaxes, 'YLim');
                                                                          % Get y-axis limit then add a bit and set it to the axes.
       minsameaxes = ylimsameaxes(1);
       maxsameaxes = ylimsameaxes(2);
       set(handles.sameaxes, 'YLim', [minsameaxes-qapsRatio*abs(minsameaxes) maxsameaxes+qapsRatio*abs(maxsameaxes)]);
   else
                                                                          % Else
        set(handles.vin, 'XLim', t(size(t)));
                                                                          % Same as above but for vin and vout.
       set(handles.vout, 'XLim', t(size(t)));
       vlimVin = get(handles.vin, 'YLim');
       ylimVout = get(handles.vout, 'YLim');
       minVin = ylimVin(1);
       maxVin = ylimVin(2);
       minVout = ylimVout(1);
       maxVout = ylimVout(2);
       set(handles.vin, 'YLim', [minVin-qapsRatio*abs(minVin) maxVin+qapsRatio*abs(maxVin)]);
       set(handles.vout, 'YLim', [minVout-qapsRatio*abs(minVout) maxVout+qapsRatio*abs(maxVout)]);
   end
   if (get(handles.dcsourcebtn, 'Value') == 1 && isequal(size(vout),[1 1]))% If DC source select and vout is a constant
       set(handles.voutdctxt,'String', 'Vout = ' + string(vout));
                                                                      % Show the vout constant value.
                                                                          % Else
   else
       set (handles.voutdctxt, 'String', '');
                                                                               Show nothing.
   end
end
isSolving(false, handles);
                                                                          % Solving done! Triggger "isSolving(false)" function.
```

IV. Appendix

- The source code will be available on Github after 7th November, 2021 via this link.
- Ability to plot all $V_{in}(t)$ on the same axes (for summing circuit) will be added soon.
- Ability to plot resistor function will also be added soon.

V. References

- [1] Assoc. Prof. H. H. Kha, HCMC Univerity of Technology, "Operational Amplifier".
- [2] Assoc. Prof. H. H. Kha, HCMC Univerity of Technology, "Project OpAmp Sample".
- [3] R. Teja, "Summing Amplifier," Electronics Hub, 22 April 2021, https://www.electronicshub.org/summing-amplifier/.
- [4] M. Safwat, "How to draw any function using GUI MATLAB.," YouTube, 12 April 2017, https://www.youtube.com/watch?v=ZjH1i9SfNa0.
- [5] user3797886, rayryeng, "How do I make a png with transparency appear transparent in MatLab?," Stack Overflow, 07 August 2014, https://stackoverflow.com/questions/25172389/how-do-i-make-a-png-with-transparency-appear-transparent-in-matlab.
- [6] MATLAB, "MATLAB Documentation," MathWorks, https://www.mathworks.com/help/matlab/.
- [7] Maxim Integrated, "GLOSSARY DEFINITION FOR OP AMP," Maxim Integrated, 2020, https://www.maximintegrated.com/en/glossary/definitions.mvp/term/Op%20amp/gpk/883.
- [8] All About Circuits, "Introduction to Operational Amplifiers (Op-amps)," EETech Media, LLC., https://www.maximintegrated.com/en/glossary/definitions.mvp/term/Op%20amp/gpk/883.

VI. Table of Figures

| Figure I-1: UA741CN IC and pinout | 3 |
|--|----------|
| Figure I-2: OpAmp Schematic | |
| Figure I-3: Schematic of LM741 from its datasheet of Texas Instruments | 4 |
| Figure I-4: Open-loop circuit and its properties | 4 |
| Figure I-5: Closed-loop circuit and its properties | 5 |
| Figure II-1: Inverting OpAmp Circuit | |
| Figure II-2: Non-inverting OpAmp Circuit | |
| Figure II-3: Summing Inverting OpAmp Circuit | <i>6</i> |
| Figure II-4: Summing Non-inverting OpAmp Circuit | 7 |
| Figure III-1: GUI for Operational Amplifier Solver | |
| Figure III-2: Inverting Amplifier with AC source | 9 |
| Figure III-3: Non-inverting Amplifier with custom function | 10 |
| Figure III-4: Summing Inverting Amplifier with a list of 3 Vins, 3 resistors | 10 |
| Figure III-5: GUI designing in GUIDE | |