

Outline

- ✓ Section 1- Introduction to Verification
- ✓ Section 2- Pattern
- ✓ Section 3- Testbench
- ✓ Section 4- Environment

Outline

- ✓ Section 1- Introduction to Verification
- √ Section 2- Pattern
- ✓ Section 3- Testbench
- ✓ Section 4- Environment


What is Verification?

Verification

- To demonstrate the functional correctness of a design
- To make sure that you are implementing what you want
- To ensure the result of some transformation is as expected

✓ Verification vs. Testing

Testing: verified the design is manufacturing correctly



What is Verification?

✓ Verification == Bug Hunting


 A process in which a design is verified against a given design specification before tape out

Verification includes:

- Functionality (Main goal !!)
- Performance
- Power
- Security
- Safety

How to perform the verification?

- Simulation of RTL design model (Lab03)
- Assertions and Functional Coverage (Lab10)
- Formal verification (Lab11)
- Static and dynamic timing checks (Lab07)
- Power-aware simulations (Lab08)
- Emulation/FPGA prototyping






Introduction to Verification

✓ Stages of verification

- Preliminary verification -> Specification (ex. Output = 0 after reset)
- Broad-spectrum verification -> Test pattern (ex. Random test)
- Corner-case verification -> Special test pattern (ex. Boundary)

✓ Steps of verification


- Generate stimulus (the inputs that drive the design)
- Apply stimulus to DUT (Design Under Test)
- Capture the response
- Check for correctness
- Measure progress against overall verification goal





Stages of verification


✓ Which one to use?





Stages of verification

✓ Time consuming vs. coverage







Stages of verification

✓ Two kinds of strategies

- Directed Testing -> Check what you know
- Random Testing -> Find what you don't know










The Verilog Design Environment

- ✓ TESTBED.v (00_TESTBED)
 - Connecting testbench and design modules
 - Dump waveform
- ✓ DESIGN.v (01_RTL)
 - Design under test (DUT)
- **✓ PATTERN.v** (00_TESTBED)
 - Pattern
 - Test program





Outline

- ✓ Section 1- Introduction to Verification
- ✓ Section 2- Pattern
- ✓ Section 3- Testbench
- ✓ Section 4- Environment

Pattern

✓ A simple example

```
define CYCLE TIME 5.0
module PATTERN (
 clk, rst n, in valid, a, b, out valid, sum, overflow
output reg clk, rst n, in valid, a, b;
input out valid, sum, overflow;
real CYCLE = `CYCLE TIME;
parameter PATNUM = 100;
integer in_read, out_read, i_pat, i, latency, out_cnt;
reg [7:0] data a, data b, data sum;
reg data overflow;
initial clk = 0:
always #(CYCLE/2.0) clk = ~clk;
initial begin
 in read = $fopen("../00 TESTBED/in.txt", "r");
 out file = $fopen("../00 TESTBED/out.txt", "w");
  reset signal task;
  for (i pat = 0; i pat < PATNUM; i pat = i pat+1) begin
   input task;
   wait out valid task;
   check ans task;
   $display("PASS PATTERN NO.%4d", i pat);
 $fclose(in read);
 $fclose(out file);
  YOU PASS task;
```

```
task reset_signal_task; begin
  rst n = 1'b1;
  in valid = 1'b0;
  a = 1'bx; b = 1'bx;
  force clk = 1'b0;
  \#(0.5); rst n = 1'b0;
  #(2);
  if((out valid !== 0)||(sum !== 0)||(overflow !== 0)) begin
   $display("Output should be 0 after RESET at %4t",$time);
   $finish;
  end
  \#(10); rst n = 1'b1;
 #(3); release clk;
end
endtask
task input task; begin
  repeat($urandom_range(3, 5)) @(negedge clk);
  in valid = 1'b1;
  if ($feof(in read)) begin
   data a = $urandom;
    data b = $urandom;
  end else begin
   $fscanf(in_read, "%d %d", data_a, data_b);
  for (i = 0; i < 8; i = i+1) begin
    a = data a[i];
   b = data b[i];
   @(negedge clk);
  in valid = 1'b0;
  a = bx;
 b = bx:
end endtask
```

```
task wait out valid task; begin
  latency = 0;
 while(out_valid !== 1'b1) begin
   if(latency == 100) begin
     YOU_FAIL_task;
     $display("Latency are over 100 cycles at %8t", $time);
   latency = latency + 1;
   @(negedge clk);
  end
and andtack
task check ans task; begin
  {data_overflow, data_sum} = data_a + data_b;
  out cnt = 0;
 while (out valid === 1'b1) begin
    if (out cnt +1 > 8) begin
     YOU FAIL task;
     $display("The output count are over 8 cycles at %8t",$time);
   else begin
     if ((data sum[out cnt] !== sum) || (data overflow !== overflow)) begin
       $display("The output is wrong at %8t", $time);
       $finish:
     end
    $fdisplay(out file, "Data A: %0d, Data B: %0d, Sum: %0d, Overflow: %0d",
   data_a, data_b, sum, overflow);
   out cnt = out cnt + 1;
   @(negedge clk);
  if (out cnt < 8) begin
   YOU FAIL task;
   $display("The output count are less than 8 cycles at %8t", $time);
   $finish:
  end
end endtask
task YOU PASS task; begin
   $display ("Congratulations!");
   $display ("Your execution cycles = %5d cycles", total_latency);
   $display ("Your clock period = %.1f ns", CYCLE);
   $display ("Total Latency = %.1f ns", total_latency*CYCLE);
   $finish;
end endtask
task YOU FAIL task; begin
  $display ("Fail!");
end endtask
endmodule
```

Pattern

Port declaration

```
module PATTERN (
    clk, rst_n, in_valid, a, b, out_valid, sum, overflow
);
output reg clk, rst_n, in_valid, a, b;
input out_valid, sum, overflow;
```

```
real CYCLE = `CYCLE_TIME;
parameter PATNUM = 100;
integer in_read, out_read, i_pat, i, latency, out_cnt;
reg [7:0] data_a, data_b, data_sum;
reg data_overflow;
```

Data type declaration

```
initial begin
  in_read = $fopen("../00_TESTBED/in.txt", "r");
  out_file = $fopen("../00_TESTBED/out.txt", "w");
  reset_signal_task;
  for (i_pat = 0; i_pat < PATNUM; i_pat = i_pat+1) begin
    input_task;
  wait_out_valid_task;
  check_ans_task;
  $display("PASS_PATTERN_NO.%4d", i_pat);
end

$fclose(in_read);
$fclose(out_file);
YOU_PASS_task;
end</pre>
```

```
task reset_signal_task; begin
    rst_n = 1'b1;
    in_valid = 1'b0;
    a = 1'bx; b = 1'bx;
    force clk = 1'b0;
    #(0.5); rst_n = 1'b0;
    #(2);
    if((out_valid !== 0)||(sum !== 0)||(overflow !== 0)) begin
        $display("Output should be 0 after RESET at %4t",$time);
        $finish;
    end
    #(10): rst n = 1'b1:
```

Generate stimulus

```
task input task; begin
 repeat($urandom_range(3, 5)) @(negedge clk);
 in valid = 1'b1;
 if ($feof(in read)) begin
   data a = $urandom;
   data b = $urandom;
 end else begin
   $fscanf(in read, "%d %d", data a, data b);
  for (i = 0; i < 8; i = i+1) begin
   a = data a[i];
   b = data b[i];
   @(negedge clk);
 in valid = 1'b0;
 a = bx;
 b = bx:
end endtask
```

Check result

```
task check ans task; begin
 {data_overflow, data_sum} = data_a + data_b;
 out cnt = 0;
 while (out valid === 1'b1) begin
   if (out_cnt + 1 > 8) begin
     YOU FAIL task;
     $display("The output count are over 8 cycles at %8t",$time);
     $finish;
   end
   else begin
     if ((data sum[out cnt] !== sum) || (data overflow !== overflow)) begin
       $display("The output is wrong at %8t",$time);
       $finish:
     end
   $fdisplay(out file, "Data A: %0d, Data B: %0d, Sum: %0d, Overflow: %0d"
   data_a, data_b, sum, overflow);
   out cnt = out cnt + 1;
   @(negedge clk);
 if (out cnt < 8) begin
   YOU FAIL task;
   $display("The output count are less than 8 cycles at %8t",$time);
   $finish:
 end
end endtask
```

endmodule



Procedural Blocks

✓ Start the simulation

```
initial begin
  in read = $fopen("../00 TESTBED/in.txt", "r");
  out file = $fopen("../00 TESTBED/out.txt", "w");
  reset signal task;
  for (i_pat = 0; i_pat < PATNUM; i_pat = i_pat+1) begin</pre>
    input task;
   wait out valid task;
    check ans task;
    $display("PASS PATTERN NO.%4d", i_pat);
  end
  $fclose(in read);
  $fclose(out file);
  YOU PASS task;
end
```

Procedural Blocks

- ✓ All procedural blocks will be executed concurrently.
- ✓ Initial Blocks
 - Only be executed once

```
initial
begin
statement...
end
```

- Always Blocks
 - Will be executed if the condition is met


```
always@(condition_expression)
begin
statement...
end
```


Procedural Blocks

✓ A simple example

```
module Test (OUT, A, B, SEL);
         output A,B,SEL;
                           Port declaration
         input OUT;
         initial
         begin
                     A=0;B=0;SEL=0;
Delay and timing
                     #10
                                 A=0;B=1;SEL=1;
                     #10
                                 A=1;B=0;
                                 SEL=0;
                     #10
                                            End simulation!
                     #10
                                 $finish;
         end
         endmodule
```

- ➤ If simulation never stop, check ...
- 1. No "\$finish" in pattern
- 2. Have combinational loop in design
- 3. Have loop in pattern







Tasks

✓ Reset Task

```
define CYCLE TIME 5.0
module PATTERN (
 clk, rst_n, in_valid, a, b, out_valid, sum, overflow
output reg clk, rst_n, in_valid, a, b;
input out_valid, sum, overflow;
real CYCLE = `CYCLE_TIME;
parameter PATNUM = 100;
integer in_read, out_read, i_pat, i, latency, out_cnt;
reg [7:0] data a, data b, data sum;
reg data overflow;
initial clk = 0:
always #(CYCLE/2.0) clk = ~clk;
initial begin
 in_read = $fopen("../00_TESTBED/in.tkt", "r");
  nut file = $fonen("../00 TESTBED/out.txt", "w");
  reset signal task;
  ror (1_pat = 0; 1_pat < PATNUM; i_pat = i_pat+1) begin
   input task;
   wait out valid task;
   check_ans_task;
   $display("PASS PATTERN NO.%4d", i_pat);
 $fclose(in_read);
 $fclose(out file);
 YOU PASS task;
```

Case inequality

```
task input task; begin
 repeat($urandom range(3, 5)) @(negedge clk);
 in valid = 1'b1;
 if ($feof(in read)) begin
   data a = $urandom;
   data b = $urandom;
 end else begin
   $fscanf(in read, "%d %d", data a, data b);
 end
 for (i = 0; i < 8; i = i+1) begin
   a = data a[i];
   b = data b[i];
   @(negedge clk);
 end
 in valid = 1'b0;
 a = bx;
 b = bx:
end endtask
```



Asynchronous Reset and Clock

Asynchronous reset:

Reset signal will reset all registers on the falling edge of reset signal.

✓ Clock signal

- Clock signal should be forced to 0 before reset signal is given.
- Using always procedure to produce a duty cycle 50% clock signal
- Example:

```
reg clk, rst_n;
real CYCLE = 2.5;
initial clk = 0;
always #(CYCLE/2.0) clk = ~clk;
initial begin
    rst_n = 1'b1;
    force clk =0;
    #(0.5);    rst_n = 1'b0;
    #(10);    rst_n = 1'b1;
    #(3);    release clk;
end
```

Tasks

task reset signal task; begin

✓ Input data

```
define CYCLE TIME 5.0
module PATTERN (
 clk, rst n, in valid, a, b, out valid, sum, overflow
output reg clk, rst_n, in_valid, a, b;
input out_valid, sum, overflow;
real CYCLE = `CYCLE_TIME;
parameter PATNUM = 100;
integer in_read, out_read, i_pat, i, latency, out_cnt;
reg [7:0] data a, data b, data sum;
reg data overflow;
initial clk = 0:
always #(CYCLE/2.0) clk = ~clk;
initial begin
 in read = $fopen("../00 TESTBED/in.txt", "r");
 out file = $fopen("../00 TESTBED/out.txt", "w");
  reset_signal_task;
  for (i_pat = 0: i_pat < PATNUM; i_pat = i_pat+1) begin
   input task;
   wait out valid task;
   check ans task;
   $display("PASS PATTERN NO.%4d", i_pat);
 $fclose(in_read);
 $fclose(out file);
 YOU PASS task;
```

```
rst n = 1'b1;
  in valid = 1'b0;
  a = 1'bx; b = 1'bx;
  force clk = 1'b0;
  \#(0.5); rst n = 1'b0;
  #(2);
  if((out valid !== 0)||(sum !== 0)||(overflow !== 0)) begin
    $display("Output should be 0 after RESET at %4t", $time);
    $finish:
  end
  \#(10); rst n = 1'b1;
  #(3); release clk;
end
endtask
task input task; begin
  repeat($urandom range(3, 5)) @(negedge clk);
  in valid = 1'b1;
  if ($feof(in read)) begin
    data a = $urandom;
    data b = $urandom;
  end else begin
    $fscanf(in read, "%d %d", data a, data b);
  end
  for (i = 0; i < 8; i = i+1) begin
    a = data a[i];
    b = data b[i];
   @(negedge clk)
  end
  in valid = 1'b0;
  a = bx;
  b = bx:
end endtask
```

 Input data change at negedge clk



Pattern

Check output data

```
define CYCLE TIME 5.0
module PATTERN (
 clk, rst n, in valid, a, b, out valid, sum, overflow
output reg clk, rst n, in valid, a, b;
input out valid, sum, overflow;
real CYCLE = `CYCLE TIME;
parameter PATNUM = 100;
integer in_read, out_read, i_pat, i, latency, out_cnt;
reg [7:0] data a, data b, data sum;
reg data overflow;
initial clk = 0:
always #(CYCLE/2.0) clk = ~clk;
initial begin
 in read = $fopen("../00 TESTBED/in.txt", "r");
 out file = $fopen("../00 TESTBED/out.txt", "w");
 reset signal task;
 for (i_pat = 0; i_pat < PATNUM; i_pat = i_pat+1) begin
   input task:
   wait out valid task:
  check ans task:
   $display("PASS PATTERN NO.%4d", i_pat);
 $fclose(in read);
 $fclose(out file);
 YOU PASS task;
```

```
task check ans task; begin
 {data overflow, data sum} = data a + data b;
 out cnt = 0:
 while (out valid === 1'b1) begin
   if (out cnt + 1 > 8) begin
    YOU FAIL task;
    $display("The output count are over 8 cycles at %8t",$time);
    $finish:
   end
   else begin
    if ((data sum[out cnt] !== sum) || (data overflow !== overflow)) begin
      YOU FAIL task;
      $display("The output is wrong at %8t",$time);
      $finish:
     end
   $fdisplay(out file, "Data A: %0d, Data B: %0d, Sum: %0d, Overflow: %0d",
   data a, data b, sum, overflow);
   out cnt = out cnt + 1;
                                 Check output data at
  @(negedge clk)
                                negedge clk
 if (out cnt < 8) begin
   YOU FAIL task;
   $display("The output count are less than 8 cycles at %8t", $time);
   $finish;
 end
end endtask
```



Input Delay

✓ Consider the input interface

end


- Input signals should be synchronous to either positive clock edge or negative clock edge with specified input delays to avoid timing violation
- Assign input delays by absolute delay value

```
CLK _____
```

Assign input delays by relative delay value (relative to clock period)

@(posedge CLK) **#INDLY** IN1 = 0;

Example:





Tasks

✓ Simplified Syntax

```
task identifier;
    parameter_declaration;
    input_decleration;
    output_decleration;
    inout_declaration;
    register_declaration;

    begin
        statement;
    ....
    end
endtask
```

Tasks

✓ An example of using a task

 Task can take, drive and source global variables, when no local variables are used.

```
Global \rightarrow
              temp in = 30;
                                                        Global \rightarrow
                                                                      temp_in = 30;
              convert(temp in, temp out);
                                                                       convert;
              $display("%d,%d",temp in,temp out);
                                                                       $display("%d,%d",temp_in,temp_out);
              task convert;
                                                                       task convert;
              input [7:0] temp in;
                                                                       begin
              output [7:0] temp out;
                                                        Global
                                                                         temp_in = 20;
              begin
                                                                         temp_out = (9/5)*(temp_in+32);
 Local
                 temp_in = 20;
                                                                       end
                 temp_out = (9/5)*(temp_in+32);
                                                                       endtask
              end
              endtask
```

temp_in: 30 temp_out: 52

temp_in: 20 temp_out: 52



Task and Function

✓ To break up a task into smaller, more manageable ones, and encapsulate reusable code, you can either divide your code into modules, or you can use tasks and functions.

✓ Task

 A task is typically used to perform debugging operations, or to behaviorally describe hardware.

✓ Function

 A function is typically used to perform a computation, or to represent combinational logics.

Functions

✓ Simplified Syntax

```
function type_or_range identifier;
    parameter_declaration;
    input_decleration;
    register_declaration;

    begin
        statement;
    ....
    end
endfunction
```

Functions

✓ An example of using a function

 Although the function cannot contain timing, you can call it from a procedural block that does.

```
always@(posedge CLK)
sum = add(a,b);
...

function [7:0] add;
input [7:0] a;
input [7:0] b;
begin
add = a + b;
end
endfunction
...
```

Tasks and Functions

✓ Task

- Can have timing controls (#delay, @, wait).
- Tasks may execute in non-zero simulation time
- Can have port arguments (input, output, and inout) or none.
- Does not return a value.
- Can enable task or function.
- Not synthesizable
- Can call it from a procedural block

✓ Function

- Can't have timing controls.
- Always execute in 0 simulation time
- Has only input arguments and no output port
- Returns a single value through the function name.
- Can enable function but can't enable task.
- Synthesizable
- Can call it from a procedural block



```
task input task; begin
  repeat($urandom range(3, 5)) @(negedge clk);
  in valid = 1'b1;
  if ($feof(in read)) begin
   data a = $urandom;
                            Broad-spectrum verification
   data b = $urandom;
  end else begin
   $fscanf(in_read, "%d %d", data_a, data_b);
 end
                                       Corner-case verification
  for (i = 0; i < 8; i = i+1) begin
   a = data_a[i];
   b = data_b[i];
   @(negedge clk);
 end
  in valid = 1'b0;
 a = bx;
  b = bx:
end endtask
```



✓ Using Verilog random system task

- \$random(seed);
 - Return 32-bit signed value
 - Seed is optional
- \$urandom(seed);
 - Return 32-bit unsigned value
 - Seed is optional
- \$urandom_range(int unsigned MAX, int unsigned MIN=0);
 - Return value inside range

✓ Using high level language with file IO

- Generate random stimulus from MATLAB or Python etc. and output the stimulus into files.
- Read the files in pattern.v



✓ A simple example

```
integer SEED, number;
SEED = 123;
number = $random(SEED) % 7;
```

```
integer SEED;
reg[3:0] number;
SEED = 123;
number = $random(SEED);
number = number % 7;
```

```
integer SEED, number;
SEED = 123;
number = $urandom(SEED) % 7;
```

```
integer SEED;
reg[3:0] number;
SEED = 123;
number = $random(SEED) % 7;
```

```
integer SEED;
reg[3:0] number;
SEED = 123;
number = $random(SEED) % 'd7;
```







✓ A simple example

Produce random number in 0~6


May be negative



Correct



Correct



The value may not in range 0~6



✓ A simple example

Produce random number in 0~6

The key point is to use unsigned operation!

File I/O

✓ Open file

- \$fopen opens the specified file and returns a 32-bit descriptor.
 - file_descriptor = \$fopen("file_name", "type");
 - ◆ file_descriptor: bit 32 always be set (=1), remaining bits hold a small number indicating what file is opened.
 - type: "r", open for read; "w", open for write

```
file = $fopen("test.txt","w");
file2 = $fopen("test2.txt","w");
file3 = $fopen("test3.txt","w");
```

- multi_channel_descriptor = \$fopen("file_name");
 - ◆ Multi_channel_descriptor: bit 32 always be clear (=0), bit 0 represent standard output, each remaining bit represents a single output channel.

```
file = $fopen("test.txt");
file2 = $fopen("test2.txt");
file3 = $fopen("test3.txt");
```



File I/O

✓ Close file

- \$fclose system task closes the channels specified in the multichannel descriptor
 - \$fclose(<multichannel_descriptor>);
 - The \$fopen task will reuse channels that have been closed

File Input

✓ Read data from specific file

- \$fgetc reading a byte at a time
 - c = \$fgetc(<descriptor>);
- \$fgets reading a line at a time
 - i = \$fgets(string, <descriptor>);
- \$fscanf reading formatted data
 - i = \$fscanf(<descriptor>," text", signal,signal,...);

```
opa=101,opb=1010
opa=3,opb=12
```

```
rc = $fscanf(file input, "opa=%d, opb=%d", opa, opb);
```

- \$readmemb, \$readmemh
 - \$readmemb("file_name", memory_name [, start_address [, end_address]]);
 - \$readmemh("file_name", memory_name [, start_address [, end_address]]);

```
$readmemh ("IN.txt",in);
$readmemh ("OUT.txt",out);
```



File Input

✓ A simple example for \$readmemb

```
@002
11111111 01010101
00000000 10101010
@006
1111zzzz 00001111
```

```
@002
11111111_01010101
00000000_10101010
@006
1111zzzz_00001111
```

```
reg [7:0] meme[0:7];
$readmemb("test.txt",meme);
```

```
reg [15:0] meme[0:7];
$readmemb("test.txt",meme);
```

```
meme[0]: xxxxxxxxx meme[1]: xxxxxxxx meme[2]: 11111111 meme[3]: 01010101 meme[4]: 00000000 meme[5]: 10101010 meme[6]: 1111zzzz meme[7]: 00001111
```



File Input

✓ A special example for \$readmemb

```
reg [7:0] meme[0:7];
$readmemb("IN.txt", meme);
```

```
1 @002
2 11111111 01010101
3 00000000 10101010
4 11110000 00001111
5 @004
6 1z1z1z1z 0z0z0z0z
```

```
1 @002
2 11111111 01010101
3 00000000 10101010
4 11110000 00001111
5 zzzz0000 zzzz1111
```



File Output

✓ Display tasks that writes to specific files


- \$fdisplay, \$fwrite, \$fstrobe, \$fmonitor
 - \$fdisplay (<descriptor>,["format_specifiers",] <argument_list>);
 - \$fwrite (<descriptor>,["format_specifiers",] <argument_list>);
 - \$fstrobe (<descriptor>,["format_specifiers",] <argument_list>);
 - \$fmonitor (<descriptor>,["format_specifiers",] <argument_list>);

```
$fdisplay(file_output,"%d + %d = %d",opa,opb,sum);
```

	Active Events	
w/ newline	fdisplay	fstrobe
w/o newline	fwrite	fmonitor

Stratified Event Queue

Stratified Event Queue of Verilog






*PLI (Programming Language Interface)

Stratified Event Queue

```
1 module nb schedule1;
   3 reg a, b;
   4 integer fp;
   6 initial begin
      fp = $fopen("log.txt","w");
      a = 0:
      b = 0:
      #1:
  11
      a = 0:
  12 b = 1:
  13
      a <= b:
      b <= a:
  15
  16
      $monitor("%0dns :\$monitor: a=%b b=%b" , $stime, a, b);
  17
      $display("%0dns :\$display: a=%b b=%b" , $stime, a, b);
  18
      $strobe ("%0dns :\$strobe : a=%b b=%b\n", $stime, a, b);
        $fwrite(fp, "%0dns :\$fwrite : a=%b b=%b\n", $stime, a, b);
  20 #0 $display("%0dns :#0 : a=%b b=%b" , $stime, a, b);
  21
  22
  23 #1 $monitor("%0dns:\$monitor: a=%b b=%b" , $stime, a, b);
  24 $display("%0dns:\$display: a=%b b=%b" , $stime, a, b);
  25     $strobe ("%0dns :\$strobe : a=%b b=%b\n", $stime, a, b);
      $fwrite(fp, "%0dns :\$fwrite : a=%b b=%b\n", $stime, a, b);
  27 #0 $display("%0dns :#0 : a=%b b=%b" , $stime, a, b);
  28
  29
      $fclose(fp);
  31 end
  32
  33 initial begin
  34 $fsdbDumpfile("nb_schedule1.fsdb");
35 $fsdbDumpvars(0, nb schedule1);
   36 end
```



Result

File Output

✓ Display tasks that writes to specific files

- All these four output system tasks support multiple default bases
 - \$fdisplay /\$fdisplayb /\$fdisplayo
 - \$fwrite /\$fwriteb /\$fwriteo
 - \$fstrobe /\$fstrobeb /\$fstrobeo
 - \$fmonitor /\$fmonitorb /\$fmonitoro

```
reg [3:0] num;
initial begin
    num = 15;
    $fdisplay (f_out, "Num: %d", num);
    $fdisplayh(f_out, "Num: %d", num);
    $fdisplayb(f_out, "Num: %d", num);
    $fdisplayo(f_out, "Num: %d", num);
    $fdisplay (f_out, "Num: ", num);
    $fdisplay (f_out, "Num: ", num);
    $fdisplayh(f_out, "Num: ", num);
    $fdisplayb(f_out, "Num: ", num);
    $fdisplayo(f_out, "Num: ", num);
    $fdisplayo(f_out, "Num: ", num);
end
```

```
Num: 15
Num: 15
Num: 15
Num: 15
=======
Num: 15
Num: f
Num: 1111
Num: 17
```



File I/O

✓ Complete file I/O example

```
define CYCLE_TIME 5.0

module PATTERN (
    clk, rst_n, in_valid, a, b, out_valid, sum, overflow
);

output reg clk, rst_n, in_valid, a, b;
input out_valid, sum, overflow;

real CYCLE = `CYCLE_TIME;
parameter PATNUM = 100;
integer in_read, out_read, i_pat, i, latency, out_cnt;
reg [7:0] data_a, data_b, data_sum;
reg data_overflow;
```

Open file

```
in_read = $fopen("../00_TESTBED/in.txt", "r");
out_file = $fopen("../00_TESTBED/out.txt", "w");
reset_signal_task;
for (i_pat = 0; i_pat < PATNUM; i_pat = i_pat+1) begin
    input_task;
    wait_out_valid_task;
    check_ans_task;
    $display("PASS_PATTERN_NO.%4d", i_pat);
end

$fclose(in_read);
$fclose(out_file);</pre>
```

Close file

```
task reset signal task; begin
  rst n = 1'b1;
  in valid = 1'b0;
  a = 1'bx; b = 1'bx;
  force clk = 1'b0;
  \#(0.5); rst n = 1'b0;
  #(2);
  if((out valid !== 0)||(sum !== 0)||(overflow !== 0)) begin
   $display("Output should be 0 after RESET at %4t",$time);
  end
  \#(10); rst n = 1'b1;
 #(3); release clk;
end
endtask
task input task; begin
  repeat($urandom_range(3, 5)) @(negedge clk);
  in valid = 1'b1;
  if ($feof(in read)) begin
    data a = $urandom;
    data b = $urandom;
  end else begin
   $fscanf(in_read, "%d %d", data_a, data_b)
    Read file
    @(negedge clk);
  in valid = 1'b0;
  a = bx;
 b = bx:
end endtask
```

```
task wait out valid task; begin
  latency = 0;
 while(out_valid !== 1'b1) begin
   if(latency == 100) begin
     YOU_FAIL_task;
     $display("Latency are over 100 cycles at %8t", $time);
    latency = latency + 1;
   @(negedge clk);
and andtack
task check_ans_task; begin
  {data_overflow, data_sum} = data_a + data_b;
  out cnt = 0;
 while (out valid === 1'b1) begin
    if (out_cnt + 1 > 8) begin
     YOU FAIL task;
     $display("The output count are over 8 cycles at %8t",$time);
    else begin
    if ((data_sum[out_cnt] !== sum) || (data_overflow !== overflow)) begin
                                          ",$time);
    Write file
   $fdisplay(out file, "Data A: %0d, Data B: %0d, Sum: %0d, Overflow: %0d"
   data a, data b, sum, overflow);
   out cnt = out cnt + 1;
   @(negedge clk);
  if (out cnt < 8) begin
   YOU FAIL task;
   $display("The output count are less than 8 cycles at %8t",$time);
   $finish:
  end
end endtask
task YOU PASS task; begin
   $display ("Congratulations!");
   $display ("Your execution cycles = %5d cycles", total_latency);
   $display ("Your clock period = %.1f ns", CYCLE);
   $display ("Total Latency = %.1f ns", total_latency*CYCLE);
   $finish;
end endtask
task YOU FAIL task; begin
  $display ("Fail!");
end endtask
endmodule
```

Display Information

✓ There are mainly four kinds of instruction to display information.

```
- $display (["format_specifiers",] <argument_list>);- $write (["format_specifiers",] <argument_list>);
```

- \$strobe (["format_specifiers",] <argument_list>);
- \$monitor(["format_specifiers",] <argument_list>);

	Active Events	Monitor Events
w/ newline	display	strobe
w/o newline	write	monitor

Display Information (cont.)

✓ The following escape sequences are used for display special characters

\n	New line character	\"	" character
\t	Tab character	\o	A character specified in 1-3 octal digits
11	\ character	%%	Percent character

✓ The following table shows the escape sequences used for format specifications

specifier	Display format	specifier	Display format
%h or %H	Hexadecimal	%m or %M	Hierarchical name
%d or %D	Decimal	%s or %S	String
%o or %O	Octal	%t or %T	Current time
%b or %B	Binary	%e or %E	real number in exponential
%c or %C	ASCII character	%f or %F	Real number in decimal
%v or %V	Net signal strength	%p or %P	Array <only for="" system="" verilog=""></only>



Display Information

✓ More detail

- http://verilog.renerta.com/source/vrg00013.htm
- http://www.cnblogs.com/oomusou/archive/2011/06/25/verilog_strobe.html




Outline

- ✓ Section 1- Introduction to Verification
- √ Section 2- Pattern
- ✓ Section 3- Testbench
- ✓ Section 4- Environment

Testbench

- Encapsulate DESIGN.v and PATTERN.v to be a top verification file
- ✓ Key element
 - Timescale
 - Dump Waveform
 - Port Connection



```
timescale 1ns/10ps
 include "PATTERN.v"
 ifdef RTL
  `include "ADD.v"
 endif
 ifdef GATE
  `include "ADD SYN.v"
module TESTBED:
wire clk, rst_n, in_valid, a, b;
wire out valid, sum, overflow;
initial begin
  `ifdef RTL
   $fsdbDumpfile("ADD.fsdb");
   $fsdbDumpvars(0,"+mda");
   endif
  `ifdef GATE
   $sdf annotate("ADD SYN.sdf", u ADD);
   $fsdbDumpfile("ADD SYN.fsdb");
   $fsdbDumpvars(0,"+mda");
   endif
```

```
ADD u ADD(
    .clk(clk),
    .rst n(rst n),
    .in valid(in valid),
    .a(a),
    .b(b),
    .out valid(out valid),
    .sum(sum),
    .overflow(overflow)
PATTERN u PATTERN(
    .clk(clk),
    .rst_n(rst_n),
    .in_valid(in_valid),
    .a(a),
    .b(b),
    .out valid(out valid),
    .sum(sum),
    .overflow(overflow)
```

Timescale

√ 'timescale

- A compiler directive
- Specifies the unit of measurement for time and the degree of precision of the time
- Syntax:

`timescale <time_unit> / <time_precision>

- time_unit specifies the unit of measurement for times and delays
- time_precision specifies the degree of precision
- The time_precision must be at least as precise as the time_unit
- Valid integers are 1, 10, and 100
- Valid character strings are s, ms, us, ns, ps, and fs

Timescale

✓ A simple example:

CYCLE/2.0 = 1.25 ns
Precision requirement: 0.01ns < 100ps
Precision loss !! The CYCLE/2.0 will
become 1.3ns

'timescale Unit/Precision	Delay	Time Delay
'timescale 10ns/1ns	#5	50ns
'timescale 10ns/1ns	#5.738	57ns
'timescale 10ns/10ns	#5.5	60ns
'timescale 10ns/100ps	#5.738	57.4ns

 Note: if you use memory in your design, you should set timescale according to the timescale specified by memory file



Timescale

✓ A simple example:

```
`timescale 1ns/<del>100ps</del> → 10ps (avoid precision loss)
module TEST;
    parameter CYCLE = 2.5;
    reg CLK;
    initial CLK = 1;
    always #(CYCLE/2.0) CLK = ~CLK;
endmodule
```

CYCLE/2.0 = 1.25 ns
Precision requirement: 0.01ns < 100ps
Precision loss!! The CYCLE/2.0 will
become 1.3ns

'timescale Unit/Precision	Delay	Time Delay
'timescale 10ns/1ns	#5	50ns
'timescale 10ns/1ns	#5.738	57ns
'timescale 10ns/10ns	#5.5	60ns
'timescale 10ns/100ps	#5.738	57.4ns

 Note: if you use memory in your design, you should set timescale according to the timescale specified by memory file



- ✓ There are many different waveform file formats.
 - Value Change Dump (.VCD)
 - Included in Verilog HDL IEEE Standard
 - Wave Log File (.wlf)
 - Mentor Graphics Modelsim
 - SHM (.shm)
 - Cadence NC Verilog / Simvision
 - VPD (.vpd)
 - Synopsys VCS
 - Fast Signal DataBase (.fsdb)
 - Spring Soft (Merged with Synopsys) Debussy/Verdi

Command often used

- \$fsdbDumpfile(fsdb_name[,limit_size])
 - fsdb_name: assign waveform file name
 - (Optional) limit_size: assign the limitation of file size
- \$fsdbDumpvars([depth, instance][,"option"])
 - depth: level of waveform to be dumped
 - instance: module to be dumped
 - "option": other additional specification, ex: "+mda"
- \$sdf_annotate("sdf_file"[,instance][,config_file][,log_file][,mtm_spec][,scale_factors][,scale_type])

✓ Parameters of \$fsdbDumpvars()

- Depth
 - 0: all signals in all scopes
 - 1: all signals in current scope (scope of TESTBED.v)
 - 2: all signals in the current scope and all scopes one level below
 - n: all signals in the current scope and all scopes n-1 levels below


Option

- "+IO_only": only IO port signals will be dumped.
- "+Reg_only": only reg type signals will be dumped.
- "+all": dump all signals including the memory, MDA, packed array, structure, union and packed structure signals in all scopes specified in \$fsdbDumpvars.
- "+mda": dump all memory and MDA(multiple dimensional array) signals in all scopes specified in \$fsdbDumpvars.
- For further information, please refer http://www.eetop.cn/blog/html/55/1518355-433686.html



✓ A simple example:

- Used in RTL simulation or gate-level simulation
- Dump wave form in fsdb format for viewing in nWave
- Include timing information in the simulation



✓ A simple example:


- Used in RTL simulation or gate-level simulation
- Dump wave form in fsdb format for viewing in nWave
- Include timing information in the simulation

```
initial begin
            `ifdef RTL
                        $fsdbDumpfile("Design.fsdb");
                        $fsdbDumpvars(0,"+mda");
            `endif
            `ifdef GATE
                        $fsdbDumpfile("Design SYN.fsdb");
                        $fsdbDumpvars(0,"+mda");
                        $sdf annotate("CORE SYN.sdf", dut);
            `endif
end
                                   module dut (OUT, A, B, SEL);
                                   endmodule
    sdf
                  sdf: standard delay format
```



Port Connection

- ✓ The input and output is reverse between design.v and pattern.v.
- ✓ A simple example:





Outline

- ✓ Section 1- Introduction to Verification
- √ Section 2- Pattern
- ✓ Section 3- Testbench
- ✓ Section 4- Environment

Simulation Environment

- ✓ 00_TESTBED
 - Pattern and testbench location.
- √ 01_RTL
 - RTL code functionality simulation
- √ 02_SYN
 - Circuit synthesize
- **✓** 03_GATE
 - Gate level simulation
- **✓** 04_MEM
- √ 05_APR
- **✓** 06_POST



00_TESTBED

✓ 00_TESTBED:

- TESTBED.v
- PATTERN.v
- filelist.f: files to run simulation.

01_RTL

✓ 01_RTL:

- DESIGN.v
- O1_run_vcs_rtl: run simulation using VCS powered by Synopsys.
- 02_irun_rtl: run simulation using irun powered by Cadence.
- 03_xrun_rtl: run simulation using xrun powered by Cadence.
- O4_verdi: run debug tool using Verdi powered by Synopsys.
- O5_nWave: view waveform using nWave powered by Synopsys.
- 08 check: check the simulation result.
- 09_clean_up: clean the temporary files during simulation.
- Link:
 - PATTERN.v & TESTBED.v
 - filelist.f
- We use VCS to simulate when demo in this semester.

02 SYN

√ 02_SYN:

- syn.tcl
- O1_run_dc_shell: synthesize using Design Compiler shell
- O2_run_design_vision: synthesize using Design Vision (GUI version)
- O3_read_dv_rtl: read design (Verilog code) into Design Vision
- O4_read_ddc: read design (Design Data Checkpoint (DDC) files) into Design Vision.
- 08_check: check the synthesis result.
- 09_clean_up: clean the temporary files during synthesis.
- Generate file:
 - DESIGN_SYN.v & DESIGN_SYN.sdf

03_GATE

✓ 03_GATE:

- O1_run_vcs_rtl: run simulation using VCS powered by Synopsys.
- 02_irun_rtl: run simulation using irun powered by Cadence.
- O3_xrun_rtl: run simulation using xrun powered by Cadence.
- O4_verdi: run debug tool using Verdi powered by Synopsys.
- O5_nWave: view waveform using nWave powered by Synopsys.
- 08_check: check the simulation result.
- O9_clean_up: clean the temporary files during simulation.
- Link:
 - DESIGN_SYN.v & DESIGN_SYN.sdf
 - PATTERN.v & TESTBED.v
 - filelist.f

Supplemental Instructions

✓ Check quota

quota

```
[iclab180@ee01 ~]$ quota
Disk quotas for user iclab180 (uid 16975):
Filesystem blocks quota limit grace files quota limit grace
raid:/RAID2 73428 15728640 20971520 1134 0 0
```

✓ Pattern encryption

- ncprotect -autoprotect PATTERN.v
 - For Cadence tool: irun, xrun
- vcs +autoprotect PATTERN.v
 - Encrypt the whole content except module name.
 - For Synopsys tool: vcs
- vcs +auto2protect PATTERN.v
 - Encrypt the whole content except module name and port declaration.
 - For Synopsys tool: vcs
- Make sure there are no PATTERN.vp in the directory before encrypt.

