Roll	No.:	

# National Institute of Technology, Delhi

Name of the Examination: B. Tech

: ECE **Branch** 

Semester

: 111

Title of the Course

: Solid State Devices

Course Code : ECB 201

Time: 3 Hours

Maximum Marks: 50

- Questions are printed on BOTH sides. Answers should be CLEAR AND TO THE POINT.
- All parts of a single question must be answered together. ELSE QUESTION SHALL NOT BE EVALUATED.

### Section A

Choose the appropriate answer and write on the answer sheet only.

- Common base current gain can be increased by enhancing the injection efficiency/ [1x10=10] base transport factor/both of the above.
  - (b) Carrier recombination in E-B depletion region increases/ decreases injection efficiency.
  - (c) As reverse bias increases, collector current increases/ decreases/ remains same.
  - (d) Emitter injection efficiency increases/ decreases with increase in doping concentration at E region.
  - Lower base doping increases/ decreases base current.
  - BIT Operation is controlled by carrier transport in base through diffusion/drift (f) process.
  - Quantum mechanics is supported by Schrödinger equation/ Poisson's equation/ Shockley equation.
  - (h) With a phase shift of 90°, Lissajous figure at CRO will produce an ellipse/circle/ trapezoid.
  - In a CRO in sweep rate frequency is 100 Hz with 2 full sinusoidal cycles observed, then frequency of the input vertical voltage will be 100 Hz/200 Hz/1000Hz.
  - At pinch-off situation of a JFET, pinch-off voltage refers to the corresponding gatesource voltage/ drain source voltage/ gate- drain voltage.

#### Section B

Write brief note on following:

- Thermal runaway
  - (b) Base width narrowing and early effect.
  - Depletion mode MOSFET (c)
  - (d) Tunnel diode
  - Hall effect

[2x5=10]

#### Section C

3. In a very long p-type Si bar with area =  $0.5 \text{ cm}^2$  and Na =  $10^{17}/\text{cm}^3$ , holes are [3] injected such that steady state excess hole concentration becomes 5 x 1016/cm3 at x=0. What is the separation between  $E_{Fp}$  (Quasi Fermi Level for holes) and  $E_{c}$  at x=1000Å? [ $\mu p=500 \text{ cm}^2/\text{ V-sec}$ , Eg1.1eV] An n- type Si semiconductor sample having with equilibrium carrier concentration, [5] 4.  $n_{\text{o}}$ = 1014/cm3. After steady shining of light, let optically generated EHP's are 1013 EHP/cm<sup>3</sup>/ $\mu$ s when  $\tau_n = \tau_p = 1\mu$ s. Calculate total e<sup>-</sup> and hole concentrations after shining of light.  $[n_i=1.5 \times 10^{10}/\text{cm}^3]$ Find the positions of Quasi-Fermi levels with respect to intrinsic energy level. Draw the energy band diagram. 5. A cylindrical Si bar has 1mm length and 0.1 mm<sup>2</sup> cross-section. Find conductivity [2] and resistances for Si (ignoring minority carriers) for following cases: When pure When doped with  $10^{16}$ /cm<sup>3</sup> donors. [ $\mu_n = 1500$ cm<sup>2</sup>/V·S,  $\mu_p = 500$  cm<sup>2</sup>/V·S, (b)  $n_i = 1.5 \times 10^{10} / \text{cm}^3$ 6. Sketch and label energy band diagrams across the Metal-Semiconductor Junction of [7] all following cases (after contact only).  $[q\chi = 4.0 \text{ eV}, E_g=1.1 \text{eV}, KT=0.026 \text{eV}, n_i=1.5x]$ 1010/cm3 at 300k for Sil (a)  $q\phi_m = 4.5 \text{ eV}$ ,  $q\phi_m = 2 \text{ eV}$  for n-type for V = 0V, 0.2V(FB), +1V(RB)(b) Depletion width (if any) for above cases: 7. Consider a Si p-n junction diode of area 10<sup>-4</sup> cm<sup>2</sup> at 300k. [3] For p-type part:  $N_a = 2.5 \times 10^{15} / \text{cm}^3$  $\tau_n = 10^{-6} \, \text{s}$  $\mu_n = 1350 \text{cm}^2/\text{V} \cdot \text{s}$ For n-type part:  $N_d = 5x10^{16}/cm^3$  $\tau_{\rm p} = 10^{-7} \, \rm s$  $\mu_p = 325 \text{ cm}^2/\text{V} \cdot \text{s}$  $n_i = 1.5 \times 10^{10} / cm^3$ (a) Express Io (Reverse Saturation Current) in terms of above diode parameters and then calculate its value. Calculate total current (I) for FB of 0.6V. Section D Explain in detail the transistor amplification process with the help of graphical [3] 8. analysis. What is the implication of p-i-n diode? How it overcomes the disadvantages of p-n [2] 9. diode? 10. Define JFET parameters? [3]

Discuss briefly the formation of energy bands in an multiatomic crystal lattice.

11.

[2]

## **Useful Equations**

Fermi-Dirac 
$$e^-$$
 distribution:  $f(E) = \frac{1}{e^{(E-E_c)/kT} + 1} = e^{(E_c - E)/kT}$  for  $E \gg E_F$ 

Equilibrium: 
$$n_0 = \int_{E_c}^{\infty} f(E)N(E)dE = N_c f(E_c) = N_c e^{-(E_c + E_c)/kT}$$

$$N_c = 2\left(\frac{2\pi m_n^* kT}{h^2}\right)^{3/2} \quad N_v = 2\left(\frac{2\pi m_p^* kT}{h^2}\right)^{3/2} \quad n_0 = n_e e^{(E_r - E_s)kT}$$

$$p_0 = n_e e^{(E_r - E_s)kT}$$

$$n_0 p_0 = n_e^{(E_r - E_s)kT}$$

$$\rho_0 = N_v[1 - f(E_v)] = N_v e^{-(E_v - F_v)/kT}$$

$$n_i = N_c e^{-(E_c - E_c)/kT}, \quad p_i = N_c e^{-(E_c - E_c)/kT} \quad n_i = \sqrt{N_c N_c} e^{-E_c/2kT} = 2\left(\frac{2\pi kT}{h^2}\right)^{3/2} (m_n^* m_p^*)^{3/4} e^{-E_c/2kT}$$

$$n = Ne^{-(E_a - F_a)/kT} = n_i e^{(F_a - E_a)/kT}$$

$$p = Ne^{-(F_a - E_a)/kT} = n_i e^{(E_a - F_a)/kT}$$

$$np = n_i^2 e^{(F_a - F_a)/kT}$$

$$\frac{d\mathscr{E}(x)}{dx} = -\frac{d^2V(x)}{dx^2} = \frac{p(x)}{\epsilon} = \frac{q}{\epsilon}(p-n+N_d^2-N_d^2) \quad \mathscr{E}(x) = -\frac{dV(x)}{dx} = \frac{1}{q}\frac{dE_t}{dx}$$

$$\frac{I_{\epsilon}}{A} = J_{x} = q(n\mu_{n} + p\mu_{p})\mathcal{E}_{x} = \sigma\mathcal{E}_{x}$$

Diffusion length:  $L = \sqrt{D\tau}$  Einstein relation:  $\frac{D}{\mu} = \frac{kT}{q}$ 

Continuity: 
$$\frac{\partial p(x,t)}{\partial t} = \frac{\partial \delta p}{\partial t} = -\frac{1}{q} \frac{\partial J_p}{\partial x} - \frac{\delta p}{\tau_p} = \frac{\partial \delta n}{\partial t} = \frac{1}{q} \frac{\partial J_n}{\partial x} - \frac{\delta n}{\tau_n}$$

For steady state diffusion: 
$$\frac{d^2\delta n}{dx^2} = \frac{\delta n}{D_n \tau_n} = \frac{\delta n}{L_n^2} = \frac{d^2\delta p}{dx^2} = \frac{\delta p}{L_p^2}$$

Equilibrium: 
$$V_0 = \frac{kT}{q} \ln \frac{p_p}{p_n} = \frac{kT}{q} \ln \frac{N_u}{n_t^2/N_d} = \frac{kT}{q} \ln \frac{N_u N_d}{n_t^2}$$
  $\frac{p_p}{p_n} = \frac{n_n}{n_p} = e^{qV_u kT}$   $W = \left[\frac{2e(V_q - V)}{q} \left(\frac{N_u + N_d}{N_u N_d}\right)\right]^{1/2}$ 

Junction Depletion: 
$$C_i = \epsilon A \left[ \frac{q}{2\epsilon (V_n - V)} \frac{N_d N_a}{N_d + N_d} \right]^{1/2} = \frac{\epsilon A}{W}$$

One-sided abrupt 
$$p^*$$
- $n$ :  $x_{ab} = \frac{WN_a}{N_a + N_d} = W$   $V_0 = \frac{qN_aW^2}{2\epsilon}$ 

$$\Delta \rho_n = p(x_{mi}) - p_n = \rho_n(e^{av + t} - 1)$$

$$\delta p(x_n) = \Delta p_n e^{-x_n/t_n} = p_n (e^{qYAT} - 1)e^{-x_n/t_n}$$

Ideal diode: 
$$I = qA \left( \frac{D_g}{L_n} p_n + \frac{D_n}{L_n} n_g \right) (e^{qV/4T} - 1) = I_d(e^{qV/4T} - 1)$$

Stored charge exp. hole dist.: 
$$Q_p = qA \int_{a}^{\infty} \delta p(x_a) dx_a = qA \Delta p_a \int_{a}^{\infty} e^{-i\omega t_a} dx_a = qA L_p \Delta p_a$$

$$I_{\rho}(x_{n}=0) = \frac{Q_{\rho}}{\tau_{\rho}} = qA \frac{L_{\rho}}{\tau_{\rho}} \Delta p_{n} = qA \frac{D_{\rho}}{L_{\rho}} p_{n}(e^{-qb-kT} - 1)$$

$$I_{Ep} = qA \frac{D_{p}}{L_{p}} \left( \Delta p_{E} \coth \frac{W_{b}}{L_{p}} - \Delta p_{C} \operatorname{csch} \frac{W_{b}}{L_{p}} \right)$$

$$I_C = qA \frac{D_{\rho}}{L_{\rho}} \left( \Delta p_E \operatorname{csch} \frac{W_b}{L_{\rho}} - \Delta p_C \operatorname{ctnh} \frac{W_b}{L_{\rho}} \right) \quad \text{Substrate bias:} \quad \Delta V_T \simeq \frac{\sqrt{2\epsilon_s q N_a}}{C_i} (-V_B)^{1/2}$$

Oxide: 
$$C_i = \frac{\epsilon_i}{d}$$
 Depletion:  $C_d = \frac{\epsilon_s}{W}$  MOS:  $C = \frac{C_i C_d}{C_i + C_d}$ 

Inversion: 
$$\phi_s(\text{inv.}) = 2\phi_F = 2\frac{kT}{q}\ln\frac{N_a}{n_s}$$
 (6-15)  $W = \left[\frac{2\epsilon_s\phi_s}{qN}\right]^{1/2}$ 

$$Q_d = -qN_dW_m = -2(\epsilon_s qN_d \phi_F)^{1/2} \quad (6-32) \qquad \text{At } V_{FB}: \quad C_{FB} = \frac{C_i C_{debye}}{C_i + C_{debye}}$$

$$\Delta p_E = p_n (e^{qV_{EB}/kT} - 1)$$

$$\Delta p_C = p_n (e^{qV_{EB}/kT} - 1)$$

$$I_B = qA \frac{D_p}{L_p} [(\Delta p_E + \Delta p_C) \tanh \frac{W_h}{2L_p}]$$

$$B = \frac{I_C}{I_{Ep}} = \frac{\operatorname{csch} W_b/L_p}{\operatorname{ctnh} W_b/L_p} = \operatorname{sech} \frac{W_b}{L_p} \approx 1 - \left(\frac{W_b^2}{2L_0^2}\right).$$

(Base transport factor)

$$\gamma = \frac{I_{Ep}}{I_{En} + I_{Ep}} = \left[1 + \frac{L_p^n n_n \mu_n^p}{L_p^n p_n \mu_n^p} \tanh \frac{W_h}{L_p^n}\right]^{-1} = \left[1 + \frac{W_b n_n \mu_n^p}{L_p^n p_n \mu_n^p}\right]^{-1}$$

(Emitter injection efficiency)

$$\frac{i_C}{i_E} = B\gamma = \alpha \quad (7-3) \qquad \qquad \frac{i_C}{i_B} = \frac{B\gamma}{1 - B\gamma} = \frac{\alpha}{1 - \alpha} = \beta \quad \frac{i_C}{i_B} = \beta = \frac{\tau_\rho}{\tau_t}$$

(For 
$$\gamma = 1$$
)