

Dept. of Electrical Engineering

IIT BOMBAY

Dual Degree Project Stage 1

OpenBTS with cognitive capabilities

Authors: Swrangsar Basumatary Abrar Ahmad

 $Supervisor: \\ Prof. S N MERCHANT$

Abstract

Our goal is to set up an OpenBTS system with cognitive capabilities. We have a predefined frequency band to run our cognitive OpenBTS system in. First we sense the presence of primary users in that particular frequency band by detecting the presence of ongoing calls. If it turns out that the calls made by primary users end, then we start our secondary OpenBTS system thus allowing secondary users to make calls.

Contents

| 1 | Introduction | 1 |
|--------------|---|---|
| | 1.1 Cognitive Radio | 1 |
| | 1.2 Motivation | 1 |
| | 1.3 Organization | 1 |
| 2 | Software Defined Radio | 3 |
| | 2.1 Introduction | 3 |
| | 2.2 USRP | 3 |
| | 2.3 GnuRadio | 3 |
| | 2.4 OpenBTS | |
| 3 | Spectrum Sensing | 5 |
| | 3.1 Matched filter detection | 5 |
| | 3.2 Energy based detection | 5 |
| 4 | A cognitive base station using GnuRadio and OpenBTS | 7 |
| | 4.1 Motivation | 7 |
| \mathbf{A} | Codes | 9 |
| | A.1 senseUplinknStartBTS.pv | 9 |

Introduction

1.1 Cognitive Radio

A cognitive radio is an intelligent radio that can be programmed and configured dynamically. Its transceiver is designed to use the best wireless channels in its vicinity. Such a radio automatically detects available channels in wireless spectrum, then accordingly changes its transmission or reception parameters to allow more concurrent wireless communications in a given spectrum band at one location. This process is a form of dynamic spectrum management[1].

1.2 Motivation

Studies have shown that most of the spectrum allotted to licensed networks remain unused most of the time[2]. To utilize these unused spectral resources we can make use of dynamic spectrum management. We can allow secondary (unlicensed) users to utilize the spectrum whenever that particular spectrum becomes available. For this we need cognitive capabilities to sense the availability of the spectrum.

1.3 Organization

Software Defined Radio

2.1 Introduction

2.2 USRP

USRP (Universal Software Radio Peripheral) is a hardware kit developed by Ettus, Inc. to run software defined radio applications.

2.3 GnuRadio

2.4 OpenBTS

Spectrum Sensing

- 3.1 Matched filter detection
- 3.2 Energy based detection

A cognitive base station using GnuRadio and OpenBTS

4.1 Motivation

Appendix A

Codes

A.1 senseUplinknStartBTS.py

```
\#!/usr/bin/env python
#
# Copyright 2005,2007,2011 Free Software Foundation,
   Inc.
#
# This file is part of GNU Radio
# GNU Radio is free software; you can redistribute it
   and/or modify
# it under the terms of the GNU General Public License
   as published by
# the Free Software Foundation; either version 3, or (
   at your option)
\# any later version.
# GNU Radio is distributed in the hope that it will be
   useful,
# but WITHOUT ANY WARRANTY; without even the implied
   warranty of
# MERCHANTABILITY or FITNESS FOR A PARTICULAR PURPOSE.
    See the
# GNU General Public License for more details.
#
```

```
# You should have received a copy of the GNU General
   Public License
# along with GNU Radio; see the file COPYING.
                                               If not,
   write to
# the Free Software Foundation, Inc., 51 Franklin
   Street,
# Boston, MA 02110-1301, USA.
from gnuradio import gr, eng_notation
from gnuradio import blocks
from gnuradio import audio
from gnuradio import filter
from gnuradio import fft
from gnuradio import uhd
from gnuradio.eng_option import eng_option
from optparse import OptionParser
import sys
import math
import struct
import threading
import time
import sqlite3
import os
import subprocess
from datetime import datetime
sys.stderr.write("Warning: _this_may_have_issues_on_some
   _machines+Python_version_combinations_to_seg_fault_
   due\_to\_the\_callback\_in\_bin\_statitics.\n\n")
class ThreadClass (threading. Thread):
    def run(self):
        return
class tune (gr.feval_dd):
    This class allows C++ code to callback into python.
    def __init__(self, tb):
        gr.feval_dd.__init__(self)
```

```
self.tb = tb
def eval (self, ignore):
    This method is called from blocks.
       bin\_statistics\_f when it wants
    to change the center frequency. This method
       tunes the front
    end to the new center frequency, and returns
       the new frequency
    as its result.
    ,, ,, ,,
    \mathbf{try}:
        # We use this try block so that if
           something goes wrong
        # from here down, at least we'll have a
           prayer of knowing
        # what went wrong. Without this, you get a
            very
        # mysterious:
        #
        #
             terminate called after throwing an
           instance of
             'Swig::DirectorMethodException' \ Aborted
        #
        # message on stderr. Not exactly helpful
           ;)
        new_freq = self.tb.set_next_freq()
        # wait until msgq is empty before
           continuing
        while (self.tb.msgq.full_p()):
            \#print "msgq full, holding.."
            time. sleep (0.1)
        return new_freq
    except Exception, e:
        print "tune: LException: L", e
```

```
class parse_msg(object):
    \mathbf{def} __init__(self, msg):
        self.center\_freq = msg.arg1()
        self.vlen = int(msg.arg2())
        assert(msg.length() = self.vlen * gr.
           sizeof_float)
        # FIXME consider using NumPy array
        t = msg. to_string()
        self.raw_data = t
        self.data = struct.unpack('%df' % (self.vlen,),
class my_top_block(gr.top_block):
    \mathbf{def} __init__(self):
        gr.top_block.__init__(self)
        usage = "usage: _%prog_[options]_down_freq"
        parser = OptionParser(option_class=eng_option,
           usage=usage)
        parser.add_option("-a", "--args", type="string"
           , default="",
                           help="UHD_device_device_
                              address_args_[default=%
                              default]")
        parser.add_option("", "--spec", type="string",
           default=None,
                           help="Subdevice_of_UHD_device
                              _where_appropriate")
        parser.add_option("-A", "--antenna", type="
           string", default=None,
                           help="select_Rx_Antenna_where
                              _appropriate")
        parser.add_option("-s", "--samp-rate", type="
           eng_float", default=10e6,
                           help="set_sample_rate_[
                              default=%default]")
```

```
parser.add_option("-g", "--gain", type="
   eng_float", default=None,
                  help="set_gain_in_dB_(default
                     _is_midpoint)")
parser.add_option("", "--tune-delay", type="
   eng_float",
                  default = 0.25, metavar="SECS",
                  help="time_to_delay_(in_
                     seconds) _ after _ changing _
                     frequency [default=%
                     default]")
parser.add_option("", "-dwell-delay", type="
   eng_float",
                  default = 0.25, metavar="SECS",
                  help="time_to_dwell_(in_
                     seconds)_at_a_given_
                     frequency_[default=%
                     default]")
parser.add_option("-b", "--channel-bandwidth",
   type="eng_float",
                  default=9.7656e3, metavar="Hz
                  help="channel_bandwidth_of_
                     fft_bins_in_Hz_[default=%
                     default]")
parser.add_option("-l", "--lo-offset", type="
   eng_float",
                  default=0, metavar="Hz",
                  help="lo_offset_in_Hz_[
                     default=%default]")
parser.add_option("-q", "--squelch-threshold",
   type="eng_float".
                  default=None, metavar="dB",
                  help="squelch_threshold_in_dB
                     _[default=%default]")
parser.add_option("-F", "--fft-size", type="int
  ", default=None,
                  help="specify_number_of_FFT_
                     bins_[default=samp_rate/
                     channel_bw]")
```

```
parser.add_option("", "--real-time", action="
   store_true", default=False,
                   help="Attempt_to_enable_real-
                      time_scheduling")
(options, args) = parser.parse_args()
if len(args) != 1:
    parser.print_help()
    sys.exit(1)
self.channel\_bandwidth = options.
   channel_bandwidth
self.down_freq = eng_notation.str_to_num(args
self.up\_freq = self.down\_freq - 45e6
if not options.real_time:
    realtime = False
else:
    # Attempt to enable realtime scheduling
    r = gr.enable_realtime_scheduling()
    if r = gr.RT_OK:
        realtime = True
    else:
        realtime = False
        print "Note: _failed _to _enable _realtime _
           scheduling"
# build graph
self.u = uhd.usrp_source(device_addr=options.
   args,
                          stream_args=uhd.
                             stream_args('fc32')
                             )
# Set the subdevice spec
if ( options . spec ) :
```

```
self.u.set_subdev_spec(options.spec, 0)
\# Set the antenna
if ( options . antenna ) :
    self.u.set_antenna(options.antenna, 0)
self.u.set_samp_rate(options.samp_rate)
self.usrp_rate = usrp_rate = self.u.
   get_samp_rate()
self.lo_offset = options.lo_offset
if options.fft_size is None:
    self.fft_size = int(self.usrp_rate/self.
       channel_bandwidth)
else:
    self.fft_size = options.fft_size
self.squelch_threshold = options.
   squelch_threshold
s2v = blocks.stream_to_vector(gr.
   sizeof_gr_complex, self.fft_size)
mywindow = filter.window.blackmanharris(self.
   fft_size)
ffter = fft.fft_vcc(self.fft_size, True,
   mywindow, True)
power = 0
for tap in mywindow:
    power += tap*tap
c2mag = blocks.complex_to_mag_squared(self.
   fft_size)
tune_delay = max(0, int(round(options.
   tune_delay * usrp_rate / self.fft_size)))
    in fft_-frames
```

```
dwell\_delay = max(1, int(round(options.
       dwell_delay * usrp_rate / self.fft_size))) #
        in\ fft_-frames
    self.msgq = gr.msg\_queue(1)
    self._tune_callback = tune(self)
                                             # hang
       on to this to keep it from being GC'd
    stats = blocks.bin_statistics_f(self.fft_size,
       self.msgq,
                                     self.
                                        _tune_callback
                                        , tune_delay
                                     dwell_delay)
   # FIXME leave out the log10 until we speed it
    \#self.connect(self.u, s2v, ffter, c2mag, log,
    self.connect(self.u, s2v, ffter, c2mag, stats)
    if options.gain is None:
        # if no gain was specified, use the mid-
           point in dB
        g = self.u.get_gain_range()
        options.gain = float(g.start()+g.stop())
           /2.0
    self.set_gain (options.gain)
    print "gain =", options.gain
def set_next_freq(self):
    target_freq = self.up_freq
    if not self.set_freq(target_freq):
        print "Failed_to_set_frequency_to",
           target_freq
        sys.exit(1)
    return target_freq
```

```
def set_freq(self, target_freq):
        Set the center frequency we're interested in.
        Arqs:
            target-freq: frequency in Hz
        @rypte: bool
        r = self.u.set_center_freq(uhd.tune_request(
           target_freq, rf_freq=(target_freq + self.
           lo_offset), rf_freq_policy=uhd.tune_request.
          POLICY_MANUAL))
        if r:
            return True
        return False
    def set_gain (self, gain):
        self.u.set_gain(gain)
def main_loop(tb):
   # use a counter to make sure power is less than
       threshold
   lowPowerCount = 0
   lowPowerCountMax = 10
    print 'fft_size', tb.fft_size
   N = tb.fft_size
    while 1:
        # Get the next message sent from the C++ code (
           blocking call).
        # It contains the center frequency and the mag
           squared of the fft
```

```
m = parse_msg(tb.msgq.delete_head())
# m. center_freq is the center frequency at the
   time of capture
# m. data are the mag_squared of the fft output
#m.raw_data is a string that contains the
   binary floats.
# You could write this as binary to a file.
center_freq = m. center_freq
bins = 10
power_data = 0
for i in range (1, bins+1):
    power_data += m. data [N-i] + m. data [i]
power_data += m. data [0]
power_data /= ((2*bins) + 1)
power_db = 10*math.log10(power_data/tb.
   usrp_rate)
power_threshold = -95
if (power_db > tb.squelch_threshold) and (
   power_db > power_threshold):
    print datetime.now(), "center_freq",
       center_freq , "power_db" , power_db , "in _
       use"
    lowPowerCount = 0
else:
    print datetime.now(), "center_freq",
       center_freq , "power_db" , power_db
    lowPowerCount += 1
    if (lowPowerCount > lowPowerCountMax):
        down_freq = center_freq + 45e6
        startOpenBTS (down_freq)
        break
```

def startOpenBTS(downFrequency):

```
arfcn=int((downFrequency-935e6)/2e5)
    if (arfcn < 0):
        print "ARFCN_must_be_>_0_!!!"
        sys.exit(1)
    print 'ARFCN=', arfcn
    #DB modifications
    t = (arfcn,)
    conn=sqlite3.connect("/etc/OpenBTS/OpenBTS.db")
    cursor=conn.cursor()
    cursor.execute("update_config_set_valuestring=?_
       where _keystring = 'GSM. Radio. C0'", t)
    conn.commit()
    #start the OpenBTS
    f=subprocess. Popen (os. path. expanduser (', ~/ddp-stage
       -1-and-openbts/runOpenBTS.sh'))
    f.wait()
if _{-name_{--}} = '_{-main_{--}}':
    t = ThreadClass()
    t.start()
    tb = my\_top\_block()
    try:
        tb.start()
        main_loop(tb)
    except KeyboardInterrupt:
        pass
```

Bibliography

- [1] http://en.wikipedia.org/wiki/Cognitive_radio.
- [2] Federal Communications Commission. Spectrum policy task force. ET Docket No. 02-135, November 2002.