## Page 2

LPC3154 Powering and Unused parts

#### Page 3

LPC3154 Digital I/O

#### Page 4


JTAG Interface

### Page 5

LPC11U1x


#### Page 6


Expansion connector




UL = UnLoaded = normally not mounted component.


Default jumper settings are indicated in the schematic. However, always check jumper positions on actual boards since there is no guarantee that all jumpers are in default place.








#### SWD/JTAG Interface



#### LPC11U14 Target Side





# Expansion Connector (superset of mbed pinning)

						( I		- 1- 3/			
mbed	LPCXpresso		Dual row	holes (2x27), 100	mil spacing						
GND	GND	GNDX	<b>(</b> J6-1							J6-28 <b>)</b> ——	VIO_3V3X
VIN (4.5-14V)	VIN (4.5-5.5V)	EXT_POWX	<b>(</b> J6-2							J6-29 <b>)</b> —	
VB (battery supply)	not used		<b>—€</b> J6-3							J6-30 <b>)</b> —	
nR (reset)	PIO0_0 RESET	PIO0_0	<b>C</b> J6-4							J6-31 <b>)</b> —	
SPI1-MOSI	PIO0_9 MOSI0/SWO	PIO0_9	<b>(</b> J6-5							J6-32 <b>)</b> —	
SPI1-MISO	PIO0_8 MISO0	PIO0_8	<b>C</b> J6-6							J6-33 <b>)</b> —	
SPI1-SCK	PIO1_29 SCK0	PIO1_29	<b>(</b> J6-7							J6-34 <b>)</b> —	
GPIO	PIO0_2 SSEL0	PIO0_2	<b>(</b> J6-8							J6-35 <b>)</b> —	
UART1-TX / I2C1-SDA	PIO0_19 TXD	PIO0_19	<b>(</b> J6-9							J6-36 <b>)</b>	USB-DMX
UART1-RX / I2C1-SCL	PIO0_18 RXD	PIO0_18	<b>(</b> J6-10							J6-37 <b>)</b> ——	USB-DPX
SPI2-MOSI	PIO0_7	PIO0_7	<b>C</b> J6-11							J6-38 <b>)</b> ——	PIO0_1
SPI2-MISO	PIO1_19	PIO1_19	<b>(</b> J6-12							J6-39 <b>)</b>	PIO0_3
SPI2-SCL / UART2-TX	PIO1_20	PIO1_20	<b>C</b> J6-13							J6-40 <b>&gt;</b>	PIO0_5_
UART2-RX	PIO1_21	PIO1_21	<b>(</b> J6-14							J6-41 <b>)</b>	PIO0_4
AIN0	PIO0_11 AD0	PIO0_11	<b>C</b> J6-15							J6-42 <b>)</b> —	PIO0_21
AIN1	PIO0_12 AD1	PIO0_12	<b>(</b> J6-16							J6-43 >	PIO0_22
AIN2	PIO0_13 AD2	PIO0_13	<b>(</b> J6-17	GNDX				VIO_3V3X		J6-44 <b>)</b> ——	PIO0_23
AIN3 / AOUT	PIO0_14 AD3	PIO0_14	<b>(</b> J6-18			·				J6-45 <b>)</b>	PIO1_22
AIN4	PIO0_15 AD4/SWDIO	PIO0_15	<b>(</b> J6-19	□ Ø PAD1	—ØPAD8	-ØPAD15	-ØPAD22	□ <b>Ø</b> PAD29	— <b>⊗</b> PAD36	J6-46 )	PIO1_23
AIN5	PIO0_16 AD5	PIO0_16	<b>(</b> J6-20	- <b>Ø</b> PAD2	-ØPAD9	-ØPAD16	— <b>⊗</b> PAD23	— <b>⊗</b> PAD30	— <b>⊗</b> PAD37	J6-47 <b>)</b> ——	PIO1_24
	PIO0_17	PIO0_17	<b>(</b> J6-21	<b>-Ø</b> PAD3	- <b>Ø</b> PAD10	■PAD17  GNDX	■PAD24	— <b>⊗</b> PAD31	<b>⊸⊗</b> PAD38	J6-48 <b>)</b>	PIO1_25
	PIO0_20	PIO0_20	<b>(</b> J6-22			GINDA	_			J6-49 <b>)</b> —	PIO1_26
	PIO0_6 USB_SOFT_CONN	PIO0_6	<b>(</b> J6-23							J6-50 <b>)</b> ——	PIO1_27
	PIO0_10 SWCLK	PIO0_10	<b>(</b> J6-24							J6-51 <b>)</b> ——	PIO1_28
	PIO1_13	PIO1_13	<b>(</b> J6-25							J6-52 <b>)</b> ——	PIO1_31
	PIO1_14	PIO1_14	<b>(</b> J6-26							J6-53 <b>)</b> ——	PIO1_16
	PIO1_15	PIO1_15	<b>(</b> J6-27							J6-54 <b>)</b> ——	GNDX
			L								J

LPCX	presso	mbed
	/ out) if self e +3.3V input	VOUT (3.3V out)
not used		VU (5.0V USB out)
not used		IF+
not used		IF-
not used		RD- (Ethernet)
not used		RD+ (Ethernet)
not used		TD- (Ethernet)
not used		TD+ (Ethernet)
USB-DM		D- (USB)
USB-DP		D+ (USB)
PIO0_1		CAN-RD
PIO0_3	USB-VBUS	CAN-TD
PIO0_5	I2C-SDA	UART3-TX / I2C2-SDA
PIO0_4	I2C-SCL	UART3-RX / I2C2-SCL
PIO0_21	MAT=PWM	PWMOUT0
PIO0_22	MAT=PWM	PWMOUT1
PIO0_23		PWMOUT2
PIO1_22		PWMOUT3
PIO1_23		PWMOUT4
PIO1_24		PWMOUT5
PIO1_25		
PIO1_26		1
PIO1_27		
PIO1_28		1
PIO1_31		1
PIO1_16		
GND		1



(C) Embedded Artists AB

TITLE: LPCXpresso LPC11U14 rev A

Document Number:

REV:

Date: 2012-08-21 09:37:59

Sheet: 6/6