Interconnections: Connectivity, protocols & terminology

Nimal Skandhakumar

Faculty of Technology University of Sri Jayewardenepura

2019

Partially based on:

 Christopher Ariza. 21M.380 Music and Technology: Recording Techniques and Audio Production. Spring 2012. Massachusetts Institute of Technology: MIT OpenCourseWare, https://ocw.mit.edu. License: Creative Commons BY-NC-SA.

What is Audio Signal Flow?

- Audio
 - of or relating to sound or sound reproduction
- Audio Signal
 - a representation of sound waves in a different form (typically electrical voltage)
- Audio Signal Flow
 - the term used to describe the path an audio signal will take from source (microphone) to the speaker or recording device.

Polarity and Phase


- Sound waves alternate between high pressure and low pressure
- Electrical audio signals alternate between positive (+) and negative (-)
- Polarity indicates a positive or negative value
- Musical Sounds have a repetitive wave pattern a cycle that repeats
- Phase tells us where we are in a cycle
- Phase is measured in degrees or radians
- One complete cycle = 360 degree of phase

Signals, Voltages, and Grounds

- Analog sound can be represented as a changing voltage
- Grounds are a point of zero voltage
- For safety: a path for faulty currents
- Ground loops: grounds with differing electrical potentials on the same connection (not exactly a ground), may result in a 60 Hz hum

Audio Signal Levels

- Mic level smallest (-60 dB)
 - XLR connector
- Consumer level (-10 dB)
 - Home stereo equipment
 - Uses RCA connectors
- Line Level highest (+4 dB)
 - Professional equipment
 - 1/4-inch or XLR connector



Audio Signal Levels

- A variety of levels are used in passing signals between audio gear.
- Every input expects one type of level.
- Mismatching can result either in distortion or no usable signal.
- The type of connector (XLR, 1/4", 1/8", RCA) does NOT indicate the signal level.
- Don't assume that the levels match just because one connector fits properly with another. Inputs are generally very clearly marked.

Common Audio Connections

- Cables
- Wires (conductors): carry voltages or grounds
- Shielding: protection from electrostatic fields
- Insulation: outer level of protection
- Connectors and Jacks: provide easy interface

Common Analog Cables: Connectors

- TS
- TRS
- RCA (Phono)
- XLR



Common Analog Cables: Connectors

- Male vs. Female
 - use your imagination
 - An XLR cable generally has two genders
 - With XLR, male tends to be an output and female tends to be an input
 - 1/4-inch and RCA cables are generally male at both ends





Figure A: XLR Connectors

Common Analog Cables: Connectors



SLEEVE TIP SLEEVE TIP

Figure D: RCA Plug


Balanced vs. Unbalanced

- An audio cable is an antenna it picks up noise along its length
- The signal cannot be separated from the noise on an unbalanced signal
- Unbalanced cables require two conductors
 - Unbalanced (consumer equipment)
 - o 1/4-inch TS, RCA



Balanced vs. Unbalanced

- A balanced signal can eliminate this noise through "destructive interference"
- Balanced cables require three conductors
- Balanced (professional equipment)
 - XLR, 1/4-inch TRS



Noise

Common Analog Cables: Types


- Unbalanced
 - Two conductors: one signal, one ground
 - o SOL: -10 dBV
 - High impedance
 - Length Limit: 25 feet

- Balanced
 - Three conductors: two signals,
 one ground
 - o SOL: +4 dBu
 - Low impedance
 - Length Limit: 1000 feet
 - Active and transformer balanced



Converting from Unbalanced to Balanced

- Never use an adapter or a cable
- Direct Injection (DI) Box: convert -10 dBu to +4 dBu and balance signal
- Transformer isolation removes ground-hum noise
- Used to connect guitars, basses, keyboards, guitar/bass amp direct outs, turntables, drum machines, synths, et cetera into pro-audio inputs





More Analog Cables

- Mini Stereo: 3 conductors used for 2 unbalanced channels
- Banana: Designed for amplified signals, speaker wire
- Speakon: Designed for high-wattage, amplified signals
- Y or insert cable: 3 conductors used for 2 unbalanced signals




Figure E: Insert Plug





Digital Cables



- Types:
 - Always handle two or more channels per cable
 - Unbalanced
 - Balanced
 - Fiber Optic

Examples:

- SPDIF (Coaxial): looks like
 RCA
- AES/EBU: looks like XLR
- Toslink (2 channel optical)
- ADAT/Lightpipe (8 channel optical)
- MADI (optical or coaxial up to 64 channels)

Snakes

Bundle cables in a single insulation





Patch Bay

- Expose all inputs and outputs in one place
- Can refer to a stand-alone device, or to the I/O section of a larger device
- Bring i/o from the rear of all devices to a front-panel interface



Power: AC and DC, Phantom Power

- Alternating current (AC): 120 volts RMS in a 60 Hz sine wave
- Direct current (DC): not a sine wave
- Transformers: rectifies and smoothes AC into DC
- Phantom power: +48 Volt DC transmitted on +/- signal lines of a balanced cable

Practicals


Class Activity

Discuss in groups and formulate suitable connections needed for the setup shown in this stage plot.

Make any assumptions as necessary to complete this task.

STAGE PLOT

GROUP NAME: Berklee College of Music Bob Marley Ensemble



Project Groups

Post your group selections (with student index numbers) to LMS.

Deadline: THIS WEEK!

http://lms.tech.sjp.ac.lk/mod/forum/discuss.php?d=12

Let's do this...