03_TG_Celsius_Sensor_Control

Instructor Notes: Module 03 – Celsius Sensor & Heating Control

Module Purpose

This module introduces students to analog signal processing and real-world control logic using the TMP236 temperature sensor and relay outputs. The objective is to teach students how to:

- Read analog inputs from a sensor
- Convert voltage to Celsius and Fahrenheit
- Use smoothing (Avg_Temp) to stabilize sensor data
- Control relays with hysteresis logic
- Drive outputs (fan, heater, alarm) based on environmental conditions

This mirrors industrial use cases such as environmental chambers, HVAC systems, and process control systems. Instructors should emphasize sensor input scaling, control thresholds, and safety logic for overheat conditions.

Reference material:

<u>Arduino Explore PLC – Analog Input Basics</u>

Pre-Lab Setup

This module uses **pre-wired sensor and relay outputs**. Students do not need to modify wiring.

Required Hardware

- Arduino Opta
- TMP236 Analog Temperature Sensor
- Heating relays (Relay 1 and Relay 2)
- Optional: Fan relay and Alarm LED
- 24V DC Power Supply

- USB-C to USB-A cable
- Laptop with Arduino PLC IDE v1.0.3 or newer

Wiring Instructions

Power

- Connect 24V DC power to:
 - Opta VIN terminals (+24V and GND)
 - Relay module COM terminals

Signal

- Connect sensor and output devices to Opta:
 - TMP236 VOUT → AI0 (I1)
 - Relay 1 (Heater 1) → O1
 - Relay 2 (Heater 2) → O2
 - Optional Fan → O3
 - Optional Alarm LED → O4

Ensure the TMP236 sensor is powered (Vcc and GND).

Each relay COM terminal must receive +V for output switching.

```
"../../03_assets/03_Celsius_Sensor_Control/Module03_Wiring_DINSimul8.png" could not be found.
```

Pre-Test Program

- To demonstrate smooth analog-to-digital control loop
- To verify analog scaling matches real-world values (e.g., test with a hand warmer, cup of ice water, or potentiometer)

Use this Structured Text logic to confirm sensor and relay output behavior:

```
VAR
   Sens_temp : UINT;
   Temp_Register : REAL;
   Voltage_Output : REAL;
```

```
Degrees_Output : REAL;
  Avg\_Temp : REAL := 0.0;
  Heat_01 : BOOL := FALSE;
  Heat_02 : BOOL := FALSE;
END_VAR
Temp_Register := TO_REAL(Sens_temp);
Voltage_Output := (Temp_Register * 5.0) / 4095.0;
Degrees_Output := (100.0 * Voltage_Output) - 50.0;
Avg_Temp := (Avg_Temp * 0.9) + (Degrees_Output * 0.1);
IF Avg_Temp < 72.0 THEN</pre>
   Heat_01 := TRUE;
  Heat_02 := TRUE;
ELSIF Avg_Temp > 78.0 THEN
   Heat_01 := FALSE;
   Heat_02 := FALSE;
END_IF;
```

Use a potentiometer or known temperature source for testing.

This verifies the sensor scaling and relay logic thresholds before full deployment. It introduces students to the analog-to-digital conversion process and allows instructors to explain signal smoothing (Avg_Temp) and output control with hysteresis.

Structured Text Code

03 Celsius Sensor Control.st

Mapping

Global Variables Mapping

```
"../../03 assets/03 Celsius Sensor Control/03 global variables.png" could not be found.
```

Input Signal Mapping

```
"../../03_assets/03_Celsius_Sensor_Control/03_input_io_mapping.png" could not be found.
```

LED Output Assignment

```
"../../03 assets/03 Celsius Sensor Control/03 opta led outputs.png" could not be found.
```

Relay Output Mapping

```
"../../03 assets/03 Celsius Sensor Control/03 relay io mapping.png" could not be found.
```

IDE and Runtime Setup Tips

- Verify target board is set to Arduino Opta WiFi
- Flash bootloader before uploading code (Tools > Runtime > Flash Bootloader)
- Switch PLC to RUN mode after upload
- Use Watch and Oscilloscope tools to monitor Avg_Temp, Heat_01, and LED_RED_ALARM

Instructor Delivery Flow

- 1. Confirm wiring and 24V supply to all devices
- 2. Upload pre-test logic and verify relay function
- 3. Walk through control logic and Avg_Temp smoothing
- 4. Use **Watch Tool** to observe Avg_Temp, Heat_01, Heat_02
- 5. Use Oscilloscope Tool to monitor analog transitions in real time
- 6. Discuss runtime behavior across temperature thresholds
- 7. Assess with runtime observation and checklist
- 8. Conclude with discussion based on reflection questions

Learning Outcomes Alignment

Learning Outcome	Demonstrated Through	Measurable Indicator
Read and interpret analog input signals	Sensor input (TMP236) → Voltage_Output	Oscilloscope trace, value displayed in Watch
Convert voltage to Celsius and Fahrenheit	Structured Text math logic	Correct value for Degrees_Output, Degrees_F
Apply control logic with hysteresis	Heating ON/OFF thresholds	Heater relays activate at proper temp bounds
Monitor and debug control logic in real time	Use of Watch & Oscilloscope tools	Student correctly explains Avg_Temp behavior
Use Boolean outputs to drive relays and indicators	Fan and Alarm LED activation	Outputs toggle appropriately with temperature
Write and deploy ST code in a PLC environment	IDE use, code upload, and runtime execution	Program runs without errors; output observed

Runtime Behavior Reference

Condition	Temp (°C)	Expected Output
Cold start	<72	Heaters ON
Mid-range	72–78	Heaters maintain previous state
Warm room	>78	Heaters OFF
Overheat risk	>86	Fan ON
Alarm condition	>95	Fan ON + Alarm ON
Near threshold	78–79	Heaters remain OFF due to smoothing delay

Assessment Strategy

Method	Description
Observation	Instructor monitors student setup, runtime behavior, and I/O response
Checklist Completion	Students use module checklist for self-verification
Instructor Q&A	Student answers conceptual and technical questions post-lab
Output Verification	Relays, fan, and alarm states tested for at least 3 temperature thresholds
Reflection Questions	Students complete 3 post-lab written reflections

Watch Testing

The Watch tool allows real-time inspection of variables such as Avg_Temp, Heat_O1, and Heat_O2, making it easier to demonstrate how temperature affects control logic.

"../../03_assets/03_Celsius_Sensor_Control/Module03_Celsius_Oscilloscope.png" could not be found.

Instructors should reinforce the connection between analog voltage conversion and digital control decisions — a key skill for industrial automation.

Suggested Reflection Questions

- 1. Why is Avg_Temp used instead of raw Degrees_Output?
- 2. What industrial applications could use similar logic?
- 3. How would this system behave if the sensor was disconnected?

Learning Outcomes to Assess

Students should:

- Explain how sensor voltage is converted to temperature
- Understand why Avg_Temp is used for smoothing
- Correctly implement temperature-based control logic
- Observe and interpret behavior of relays and LEDs based on thresholds

Common Student Issues

Symptom	Fix
No temperature reading	TMP236 not powered or miswired
Relays do not activate	COM terminals missing +24V
Output flickering	Threshold too narrow – add hysteresis
Alarm or fan doesn't trigger	Avg_Temp not reaching threshold – simulate input

Instructor Delivery Flow

- 1. Confirm wiring and 24V supply to all devices
- 2. Upload pre-test logic and verify relay function

- 3. Walk through control logic and Avg_Temp smoothing
- 4. Monitor behavior using Watch and Oscilloscope
- 5. Assess with runtime observation and checklist
- 6. Conclude with discussion based on reflection questions

Suggested Instructor Folder Structure



Instructor Checklist

Sensor powered and returning valid values
Relays wired and respond to code correctly
IDE configured and project set up
Opta in RUN mode and PLC is communicating
Optional fan/alarm logic tested or simulated

Reference

- Student Guide Module 03
- Arduino PLC Course Analog Input Example
 (Used for baseline logic. Modified and extended for sensor control.)

Images and structure adapted from the official Arduino Explore PLC course under CC BY-SA 4.0 license. Attribution is required for reuse.