# **MIPS Architecture and Assembly Language Overview**

 $Adapted\ from: http://edge.mcs.dre.g.el.edu/GICL/people/sevy/architecture/MIPSRef(SPIM).html and the second seco$ 

[Register Description] [I/O Description]

## **Data Types and Literals**

#### Data types:

- Instructions are all 32 bits
- byte(8 bits), halfword (2 bytes), word (4 bytes)
- a character requires 1 byte of storage
- an integer requires 1 word (4 bytes) of storage

#### Literals:

- numbers entered as is. e.g. 4
- characters enclosed in single quotes. e.g. 'b'
- strings enclosed in double quotes. e.g. "A string"

## Registers

- 32 general-purpose registers
- register preceded by \$ in assembly language instruction two formats for addressing:
  - using register number e.g. \$0 through \$31
  - o using equivalent names e.g. \$t1, \$sp
- special registers Lo and Hi used to store result of multiplication and division
  - not directly addressable; contents accessed with special instruction mfhi ("move from Hi") and mflo ("move from Lo")
- stack grows from high memory to low memory

This is from Figure 9.9 in the Goodman&Miller text

	Register Number	Alternative Name	Description	
.	0	zero	the value 0	
,	1	\$at	(assembler temporary) reserved by the assembler	
•	2-3	\$v0 - \$v1	(values) from expression evaluation and function results	
	4-7	\$a0 - \$a3	(arguments) First four parameters for subroutine. Not preserved across procedure calls	
	8-15	\$t0 - \$t7	(temporaries) Caller saved if needed. Subroutines can use w/out saving.  Not preserved across procedure calls	
3	16-23	\$s0 - \$s7	(saved values) - Callee saved. A subroutine using one of these must save original and restore it before exiting. Preserved across procedure calls	
2	24-25	\$t8 - \$t9	(temporaries) Caller saved if needed. Subroutines can use w/out saving. These are in addition to \$t0 - \$t7 above. Not preserved across procedure calls.	
2	26-27	\$k0 - \$k1	reserved for use by the interrupt/trap handler	
1	28	\$gp	global pointer.  Points to the middle of the 64K block of memory in the static data segment.	
	29	\$sp	stack pointer Points to last location on the stack.	
1	30	\$s8/\$fp	saved value / frame pointer Preserved across procedure calls	
	31	\$ra	return address	

See also Britton section 1.9, Sweetman section 2.21, Larus Appendix section A.6

# **Program Structure**

- just plain text file with data declarations, program code (name of file should end in suffix .s to be used with SPIM simulator)
- data declaration section followed by program code section

#### **Data Declarations**

- placed in section of program identified with assembler directive .data
- declares variable names used in program; storage allocated in main memory (RAM)

## Code

• placed in section of text identified with assembler directive .text

- contains program code (instructions)
- starting point for code e.g.ecution given label main:
- ending point of main code should use exit system call (see below under System Calls)

#### Comments

- anything following # on a line
  - # This stuff would be considered a comment
- Template for a MIPS assembly language program:

## **Data Declarations**

format for declarations:

```
name: storage_type value(s)
```

- o create storage for variable of specified type with given name and specified value
- value(s) usually gives initial value(s); for storage type .space, gives number of spaces to be allocated

Note: labels always followed by colon (:)

### **Load / Store Instructions**

- RAM access only allowed with load and store instructions
- all other instructions use register operands

load:

```
lw register_destination, RAM_source
```

#copy word (4 bytes) at source RAM location to destination register.

```
lb register_destination, RAM_source
```

#copy byte at source RAM location to low-order byte of destination register,
# and sign-e.g.tend to higher-order bytes

store word:

```
sw register source, RAM destination
```

#store word in source register into RAM destination

```
sb register_source, RAM_destination
```

#store byte (low-order) in source register into RAM destination

load immediate:

```
li register_destination, value
```

#load immediate value into destination register

```
example:
        .data
                                # declare storage for var1: initial value is 23
var1:
       .word
        .text
 start:
                                        # load contents of RAM location into register $t0: $t0 = var1
        lw
                $t0, var1
                                             ("load immediate")
        li
                                        \# store contents of register $t1 into RAM: var1 = $t1
        SW
                $t1, var1
        done
```

## **Indirect and Based Addressing**

· Used only with load and store instructions

#### load address:

```
la $t0, var1
```

 copy RAM address of var1 (presumably a label defined in the program) into register \$t0

### indirect addressing:

```
lw $t2, ($t0)
```

• load word at RAM address contained in \$t0 into \$t2

```
sw $t2, ($t0)
```

• store word in register \$t2 into RAM at address contained in \$t0

#### based or indexed addressing:

```
lw $t2, 4($t0)
```

- load word at RAM address (\$t0+4) into register \$t2
- "4" gives offset from address in register \$t0

```
sw $t2, -12($t0)
```

- store word in register \$t2 into RAM at address (\$t0 12)
- · negative offsets are fine

Note: based addressing is especially useful for:

- arrays; access elements as offset from base address
- stacks; easy to access elements at offset from stack pointer or frame pointer

#### example

```
.data
                                                                                                                 .space
                                                                                                                                                                      12
array1:
                                                                                                                                                                                                                                                                                        # declare 12 bytes of storage to hold array of 3 integers
                                                                                                                  .text
                                                                                                                                                                                                                                                                                                         $\tag{\text{$\text{$\text{$\text{$\text{$\text{$\text{$\text{$\text{$\text{$\text{$\text{$\text{$\text{$\text{$\text{$\text{$\text{$\text{$\text{$\text{$\text{$\text{$\text{$\text{$\text{$\text{$\text{$\text{$\text{$\text{$\text{$\text{$\text{$\text{$\text{$\text{$\text{$\text{$\text{$\text{$\text{$\text{$\text{$\text{$\text{$\text{$\text{$\text{$\text{$\text{$\text{$\text{$\text{$\text{$\text{$\text{$\text{$\text{$\text{$\text{$\text{$\text{$\text{$\text{$\text{$\text{$\text{$\text{$\text{$\text{$\text{$\text{$\text{$\text{$\text{$\text{$\text{$\text{$\text{$\text{$\text{$\text{$\text{$\text{$\text{$\text{$\text{$\text{$\text{$\text{$\text{$\text{$\text{$\text{$\text{$\text{$\text{$\text{$\text{$\text{$\text{$\text{$\text{$\text{$\text{$\text{$\text{$\text{$\text{$\text{$\text{$\text{$\text{$\text{$\text{$\text{$\text{$\text{$\text{$\text{$\text{$\text{$\text{$\text{$\text{$\text{$\text{$\text{$\text{$\text{$\text{$\text{$\text{$\text{$\text{$\text{$\text{$\text{$\text{$\text{$\text{$\text{$\text{$\text{$\text{$\text{$\text{$\text{$\text{$\text{$\text{$\text{$\text{$\text{$\text{$\text{$\text{$\text{$\text{$\text{$\text{$\text{$\text{$\text{$\text{$\text{$\text{$\text{$\text{$\text{$\text{$\text{$\text{$\text{$\text{$\text{$\text{$\text{$\text{$\text{$\text{$\text{$\text{$\text{$\text{$\text{$\text{$\text{$\text{$\text{$\text{$\text{$\text{$\text{$\text{$\text{$\text{$\text{$\text{$\text{$\text{$\text{$\text{$\text{$\text{$\text{$\text{$\text{$\text{$\text{$\text{$\text{$\text{$\text{$\text{$\text{$\text{$\exititt{$\text{$\text{$\text{$\text{$\text{$\text{$\text{$\text{$\text{$\text{$\text{$\text{$\text{$\text{$\text{$\text{$\text{$\text{$\text{$\text{$\text{$\text{$\text{$\text{$\text{$\text{$\exititt{$\text{$\text{$\text{$\text{$\text{$\text{$\text{$\text{$\text{$\text{$\text{$\text{$\text{$\text{$\text{$\text{$\text{$\text{$\text{$\text{$\text{$\text{$\text{$\text{$\text{$\text{$\exititt{$\text{$\text{$\text{$\text{$\text{$\text{$\text{$\text{$\text{$\text{$\text{$\text{$\text{$\text{$\text{$\text{$\text{$\
      start:
                                                                                                                 la
                                                                                                                                                                          $t0, array1
                                                                                                                                                                                                                                                                                                                                                                load base address of array into register $t0
                                                                                                                                                                        $t1, 5
                                                                                                                li
                                                                                                              sw $t1, ($t0)
li $t1, 13
                                                                                                                 sw $t1, 4($t0)
                                                                                                                                                                                                                                                                                                            second array element set to 13
                                                                                                                li $t1, -7
                                                                                                                                                                                                                                                                                                                     $t1 = -7
                                                                                                                 sw $t1, 8($t0)
                                                                                                                                                                                                                                                                                                             third array element set to -7
```

# **Arithmetic Instructions**

- most use 3 operands
- all operands are registers; no RAM or indirect addressing
- operand size is word (4 bytes)

```
add
            $t0,$t1,$t2
                                       $t0 = $t1 + $t2;
                                                                      add as signed (2's complement) integers
                                        $t2 = $t3 Đ $t4
sub
            $t2,$t3,$t4
                                                                   "add immediate" (no sub immediate)
addi
            $t2,$t3, 5
                                    # $t2 = $t3 + 5;
            $t1,$t6,$t7
                                        $t1 = $t6 + $t7;
                                                                      add as unsigned integers
addu
                                        $t1 = $t6 + $t7;
subu
            $t1,$t6,$t7
                                                                      subtract as unsigned integers
                                        multiply 32-bit quantities in $t3 and $t4, and store 64-bit result in special registers Lo and Hi: (Hi,Lo) = $t3 * $t4 Lo = $t5 / $t6 (integer quotient)
Hi = $t5 mod $t6 (remainder)
move quantity in special register Hi to $t0: $t0 = Hi
move quantity in special register Lo to $t1: $t1 = Lo
mult
            $t3,$t4
div
            $t5,$t6
mfhi
            $t0
mflo
                                         used to get at result of product or quotient
            $t2,$t3 # $t2 = $t3
move
```

## **Control Structures**

### Branches

• comparison for conditional branches is built into instruction

```
b target # unconditional branch to program label target beq $t0,$t1,target # branch to target if $t0 = $t1 blt $t0,$t1,target # branch to target if $t0 < $t1 ble $t0,$t1,target # branch to target if $t0 <= $t1 bgt $t0,$t1,target # branch to target if $t0 <= $t1 bgt $t0,$t1,target # branch to target if $t0 > $t1
```

```
bge $$t0,$t1,target # branch to target if $t0 >= $t1
bne $t0,$t1,target # branch to target if $t0 <> $t1
```

#### <u>Jumps</u>

```
j target # unconditional jump to program label target
jr $t3 # jump to address contained in $t3 ("jump register")
```

#### Subroutine Calls

subroutine call: "jump and link" instruction

```
jal sub label # "jump and link"
```

- copy program counter (return address) to register \$ra (return address register)
- jump to program statement at sub\_label

subroutine return: "jump register" instruction

```
jr $ra # "jump register"
```

• jump to return address in \$ra (stored by jal instruction)

Note: return address stored in register \$ra; if subroutine will call other subroutines, or is recursive, return address should be copied from \$ra onto stack to preserve it, since jal always places return address in this register and hence will overwrite previous value

# System Calls and I/O (SPIM Simulator)

- · used to read or print values or strings from input/output window, and indicate program end
- use syscall operating system routine call
- first supply appropriate values in registers \$v0 and \$a0-\$a1
- result value (if any) returned in register \$v0

The following table lists the possible syscall services.

Service	Code in \$v0	Arguments	Results
print_int	1	\$a0 = integer to be printed	
print_float	2	\$f12 = float to be printed	
print_double	3	\$f12 = double to be printed	
print_string	4	\$a0 = address of string in memory	
read_int	5		integer returned in \$v0
read_float	6		float returned in \$v0
read_double	7		double returned in \$v0
read_string	8	\$a0 = memory address of string input buffer \$a1 = length of string buffer (n)	
sbrk	9	\$a0 = amount	address in \$v0
exit	10		

- The print\_string service expects the address to start a null-terminated character string. The
  directive asciiz creates a null-terminated character string.
- The read\_int, read\_float and read\_double services read an entire line of input up to and including the newline character.
- The read\_string service has the same semantices as the UNIX library routine fgets.
  - It reads up to n-1 characters into a buffer and terminates the string with a null character.
  - If fewer than n-1 characters are in the current line, it reads up to and including the newline and terminates the string with a null character.
- The sbrk service returns the address to a block of memory containing n additional bytes.
   This would be used for dynamic memory allocation.
- The exit service stops a program from running.

.text

\$v0, 4

1 i

main:

```
e.g. Print out integer value contained in register $t2
```

```
1 i
                           Sv0. 1
                                                      \# load appropriate system call code into register v0;
                                                      # code for printing integer is 1
                  move
                           $a0, $t2
                                                      # move integer to be printed into $a0: $a0 = $t2
                  syscall
                                                      \# call operating system to perform operation
e.g. Read integer value, store in RAM location with label int_value (presumably declared in data section)
                                                      # load appropriate system call code into register $v0;
                  li
                           $v0, 5
                                                      # code for reading integer is 5
# call operating system to perform operation
# value read from keyboard returned in register $v0;
                  svscall
                           $v0, int_value
                                                      \# store this in desired location
       Print out string (useful for prompts)
e.g.
                  .data
                  .asciiz "Print this.\n"
string1
                                                      # declaration for string variable,
                                                      # .asciiz directive makes string null terminated
```

# load appropriate system call code into register \$v0;

```
# code for printing string is 4

la $a0, string1  # load address of string to be printed into $a0

syscall  # call operating system to perform print operation

e.g. To indicate end of program, use exit system call; thus last lines of program should be:

li $v0, 10  # system call code for exit = 10

syscall  # call operating sys
```