
Benjy's Accurate Clock

Does anybody really know what time it is? Does anybody really care? -- Robert Lamm



This article describes a prototype clock I built which has the following features:


- The clock is set from <u>WWVB</u> using an inexpensive receiver module.
- The clock contains a battery backed up real-time clock (RTC) so that the time is not lost during power failures.
- When powered, the clock keeps time by monitoring a 1024 Hz. square wave produced by the RTC.
- The clock uses a 16x2 character display with an RGB configurable backlight.
- A 5-way switch is used to navigate menus to set clock options.
- A detachable loopstick antenna allows optimal antenna placement for the best signal reception and reduction of interference.


For information about the WWVB receiver I used, the time format, and notes about interference, see <u>Using the SYM-RFT-60 WWVB Receiver</u>. The WWVB signal is not available at all times of day due to longwave propagation. The signal is also subject to various types of interference including signals from the clock components.

WWVB sends one data frame over the period of one minute with each bit taking one second. The WWVB legacy format decoded by the receiver contains no error detection bits, so the clock cannot easily tell if a given frame represents a valid date and time or a corrupted date and time. The clock software deals with this in three ways:

- The frame contains marker bits which are 800 milliseconds in duration at intervals throughout the frame. If marker bits are missing where they are expected or show up at other parts of the frame, the frame is discarded.
- All BCD values are checked for consistency. For example, any frame with an hours value greater than 23 is discarded.
- Finally the clock can be configured to check for consistency for two or three consecutive frames. The frames should represent dates and times that are one minute apart. If they do not, the frames are discarded.

There are four major components of the clock (see the <u>parts list</u> below): an Arduino Pro Mini, a Maxum Integrated DS3231-based RTC, an LCD display, and a SYM-RFT-60 WWVB receiver module:





The clock is set to UTC by WWVB. The time can be displayed as UTC or some timezone offset from UTC. In normal display mode, one toggles between UTC and local time by pressing the 5-way switch up. Pressing the switch down toggles the debug display which shows the state of WWVB reception and the last time the clock was set by WWVB.


The code has several modes and options that are stored in EEPROM that is part of the CPU. The following options are settable

- The time zone for the local time. Currently, only full hour timezones are supported.
- The backlight has an RGB LED. The intensity for each color can be set.
- Both 12 hour (AM/PM) and 24 hour mode is supported for local time display. UTC is always displayed in 24 hour mode.
- WWVB mode can be set to off, "once a day", or continuous. When set to off, the WWVB receiver is ignored. In "once a day" mode, the clock will attempt synchronize with WWVB once a day at a time set

by the user. In this mode, the clock listens for valid time frames until valid data is found and the clock is set or until a preset error count is achieved. In continuous mode, the clock is set from the receiver any time a valid time is received.

The motivation for "once a day" mode is to allow the operator to select the best time of day to try to set the clock from WWVB based on longwave propagation. This mode might be useful if the clock sets to invalid times if attempts are made when propagation is poor; however, I have not seen the clock set to an invalid time.

• Because WWVB does not send error detection codes in legacy mode, the clock can be configured to look for one, two, or three consecutive WWVB frames that are consistent, i.e., the frames are one minute apart.



The Code

The clock software handles interrupts from the WWVB receiver and from the 1024 HZ square wave generated by the RTC. The latter is used to keep the time when the clock is powered. Other clocks with an RTC merely poll the time kept by the RTC rather than counting clock ticks. Both approaches will work; however, I felt that synchronization between the clock time and the WWVB time was easier running two interrupt handlers.

In normal mode (outside of the setup menus), the main routine polls the time for a change and the 5-way switch. Any time the time changes, the display is updated. Any time one of the switch contacts closes, the switch is debounced and the necessary action is taken.

When WWVB sets the clock, the main routine writes the updated time to the RTC. Because of the amount of processing when the time is set, the code delays 15 seconds before setting the RTC. This delay is the result of superstition on my part.

The software is written as a normal Arduino sketch with several additional classes. There is a DateTime class, a WWVB class, and several classes used for display of the menu items used to configure the clock. The Arduino library has a DateTime class; however, I created a custom DateTime class for the project.

Each time the 1024 Hz. clock ticks, the tick() method of the main DateTime object is called. Every 1024 ticks, the seconds counter is updated and the date and time are corrected in case of rollovers in the minutes, hours, day, month, or year fields. A pointer to the main DateTime object is given to the WWVB object. Whenever it detects the correct time, it sets the DateTime object. The main sketch polls the "changed" flag in the DateTime object to determine when the display is to be updated.

The WWVB object takes data from the WWVB receiver. It times pulses from the receiver and decides if the pulse represents a logic 0, a logic 1, a marker bit, or a pulse that is too short as the result of interference. The pulse width values for WWVB are given in the table below along with the values used by my software. The pulse widths are noticeably shorter as produced by the receiver and measured by the Arduino.

Logic Value	WWVB Pulse Duration	Measured Pulse Width
0	200 ms	90 < pulse < 225
1	500 ms	225 < pulse < 600
Marker	800 ms	pulse > 600

The menu system is primitive. In normal display mode, a scrollable list of submenus is displayed on the LCD display when the 5-way switch is pressed. The up and down positions of the switch are used to scroll through the list. Pressing the 5-way switch activates a submenu. The submenus use the up, down, right, and left positions of the switch to select and change values.

A small set of display widgets were created for common operations such as setting a time and setting an integer value such as time zone.

The software is currently not complete. The menu items to set the date and time manually are missing. Daylight Saving Time (DST) processing has not been developed, either. Although DST changes are indicated by bits in the WWVB frame, the receiver cannot always receive WWVB, so I plan to have the software change to DST at the proper time independent of WWVB. I also have to implement the ability to add a leap second when indicated by the WWVB time frame. **Update:** I completed these features (9/2014).

Developing software that deals with timezones can be tricky. <u>The Problem with Time & Timezones - Computerphile</u> is a funny and informative video about writing software to deal with clock software.

Hardware Notes

The original clock was constructed using a standard breadboard with spring clips. Once the basic system was working, I moved the Arduino, LCD display, and RTC to a PCB that has the same layout as a standard breadboard. This prototype version of the clock allows me to experiment with the placement of the WWVB receiver and antenna. The best solution to date has been to place the antenna several inches away from the PCB to avoid interference from the Arduino.

Some other clock builders have worked on shielding the WWVB receiver and/or antenna:

- WWVB Receiver Shield Enclosure
- Chrono-tomic shield helps your Arduino keep perfect time
- Build Your Own Atomic Clock Shield photo is near the bottom of the page.
- Summertime RF Propagation and the CMMR-6P-60

The last reference is part of a series that I found very helpful when I was getting started on this project.

Instead of using a standard Arduino board and RTC, the ICs from these boards could be used to make a custom clock. The Arduino Pro Mini uses an ATmega168 processor. The Arduino bootloader can be burned into a stock processor. The ChronoDot uses a Maxum Integrated DS3231. So a custom PCB could be designed to hold an ATmega168 and the DS3231 and additional components to create a neater looking and smaller clock.

I used most of the pins on the Arduino. There are two analog input pins, A6 and A7, that were not used. These pins are unlike other analog pins and cannot be used for outputs. The serial interface is still available, so the clock could provide time reports to a computer. The FTDI cable can still be connected to the Arduino to update the software.

I used connectors to make the connections between the main board and the WWVB receiver and LCD display. This arrangement provided the flexibility I needed to make changes to the hardware as the project evolved.

Performance

Articles on the WWVB propagation indicate that signal reception can be difficult during the summer months in some parts of the U.S. The signal is strongest at night, so some articles recommend that the best time for synchronization with WWVB is during nighttime hours for both the receiver and transmitter. However, I am fortunate that in my location in Virginia, my clock will synchronize with WWVB numerous times during the day even during the summer months.

The <u>The Current Readability of the WWVB Time Code</u> site gives WWVB readability for four sites in the U.S. Reviewing this site over time can help give you a feel for the reliability of WWVB signals.

The LED on the WWVB receiver board can be used to orient the antenna for a good signal. When reception is good, the LED will blink once a second for periods of 200 ms, 500 ms, and 800 ms. If the LED flickers faster than one pulse per second, there are two possible causes: poor reception and interference. In the former case, changing the antenna orientation or making another attempt at a different time might allow synchronization. In the later case, try moving the clock away from computers, microwave ovens, or other sources of interference.

Orienting the antenna takes some practice. The clock contains a debug mode which displays the state of WWVB reception and the last date and time that synchronization was attained.

Parts

- Arduino Pro Mini 328 5V from Sparkfun.
- <u>SYM-RFT-60</u> WWVB receiver module or <u>SYM-RFT-60HS</u> WWVB receiver module with a better antenna from <u>PV Electronics</u>. (I used the former, but I recommend the latter.) PV Electronics is in Kent in England, but they do ship to the States.
- RGB backlight negative LCD 16x2 from Adafruit. A standard (single color) backlight LCD display can be used instead.
- ChronoDot RTC. This is a DS3231 RTC and watch battery holder soldered to a small board.
- <u>Acrylic LCD Stand</u> from Adafruit. Note that the screws provided were too large for LCD displays from Adafruit. I substituted 2-20 screws.
- Solder-able Breadboard from SparkFun
- Miscellaneous screws and cable parts were purchased from Pololu
- <u>5V power supply</u>, e.g., 5V 2A switching power supply from Adafruit.

Acknowledgements

Sue Ellen, KD4LQO, and Mike, N4GU, listened to all the gory details as I worked on the clock. Sue Ellen gave me the WWVB receiver as a gift. Mike made some helpful suggestions about shielding and noted that he had a commercial clock with a detachable antenna. Ray, KE4TJC, forwarded me a pointer to the timezone video.

Mail questions or comments to me at benjy at tuxcat.com.

© 2014 Ben E. Cline