ECE 699: Lecture 6

Using DMA & AXI4-Stream

Required Reading

LogiCORE IP AXI DMA v7.1: Product Guide

- Chapter 1: Overview
- Chapter 2: Product Specification
- Chapter 3: Designing with the Core
- Chapter 4: Design Flow Steps
- Chapter 5: Example Design

The ZYNQ Book

- Chapter 2.3: Processing System Programmable Logic Interfaces
- Chapter 9.3: Buses
- Chapter 10.1: Interfacing and Signals

Recommended Reading

M.S. Sadri, ZYNQ Training (presentations and videos)

- Lesson 1 : What is AXI?
- Lesson 2: What is an AXI Interconnect?
- Lesson 3 : AXI Stream Interface

AXI Interfaces and Interconnects

Interface


A point-to-point connection for passing data, addresses, and hand-shaking signals between master and slave clients within the system

Interconnect

A switch which manages and directs traffic between attached AXI interfaces


Source: The Zynq Book

Interconnect vs. Interface



Source: ARM AMBA AXI Protocol v1.0: Specification

PS-PL Interfaces and Interconnects



Source: The Zynq Book

Zynq AXI PS-PL Interfaces

→ HP


- –4 x 64 bit Slave interfaces
 - Optimized for high bandwidth access from PL to external memory

▶ GP

- -2 x 32 bit Slave interfaces
 - Optimized for access from PL to PS peripherals
- -2 x 32 bit Master interfaces
 - Optimized for access from processors to PL registers

ACP

- 1 x 64 bit Slave interface
 - Optimized for access from PL to processor caches



AXI Interfaces between PS and PL

Interface Name	Interface Description	Master	Slave
M_AXI_GP0	General Purpose (AXI_GP)	PS	PL
M_AXI_GP1		PS	PL
S_AXI_GP0	General Purpose (AXI_GP)	PL	PS
S_AXI_GP1		PL	PS
S_AXI_ACP	Accelerator Coherency Port (ACP), cache coherent transaction	PL	PS
S_AXI_HP0	High Performance Ports (AXI_HP) with read/write FIFOs.	PL	PS
S_AXI_HP1		PL	PS
S_AXI_HP2	(Note that AXI_HP interfaces are sometimes referred to as AXI Fifo Interfaces, or AFIs).	PL	PS
S_AXI_HP3		PL	PS

Source: The Zynq Book

General-Purpose Port Summary

- GP ports are designed for maximum flexibility
- Allow register access from PS to PL or PL to PS
- Good for Synchronization
- Prefer ACP or HP port for data transport

High-Performance Port Summary

- HP ports are designed for maximum bandwidth access to external memory and OCM
- When combined can saturate external memory and OCM bandwidth
 - HP Ports : 4 * 64 bits * 150 MHz * 2 = 9.6 GByte/sec
 - external DDR: 1 * 32 bits * 1066 MHz * 2 = 4.3 GByte/sec
 - OCM : 64 bits * 222 MHz * 2 = 3.5 GByte/sec
- Optimized for large burst lengths and many outstanding transactions
- Large data buffers to amortize access latency
- Efficient upsizing/downsizing for 32 bit accesses


Accelerator Coherency Port (ACP) Summary

- ACP allows limited support for Hardware Coherency
 - Allows a PL accelerator to access cache of the Cortex-A9 processors
 - PL has access through the same path as CPUs including caches,
 OCM, DDR, and peripherals
 - Access is low latency (assuming data is in processor cache)
 no switches in path
- ACP does not allow full coherency
 - PL is not notified of changes in processor caches
 - Use write to PL register for synchronization
- ACP is compromise between bandwidth and latency
 - Optimized for cache line length transfers
 - Low latency for L1/L2 hits
 - Minimal buffering to hide external memory latency
 - One shared 64 bit interface, limit of 8 masters

Accelerator Architecture with Bus Slave

Pro: Simple System Architecture


Con: Limited communication bandwidth




Accelerator Architecture with DMA

Pro: High Bandwidth Communication

Con: Complicated System Architecture, High Latency



DMA Memory Transfer Operation



Source: The Zynq Book

AXI DMA-based Accelerator Communication

Write to Accelerator

- processor allocates buffer
- processor writes data into buffer
- processor flushes cache for buffer
- processor initiates DMA transfer


Read from Accelerator

- processor allocates buffer
- processor initiates DMA transfer
- processor waits for DMA to complete
- processor invalidates cache for buffer
- processor reads data from buffer

Accelerator Architecture with Coherent DMA

Pro: Low latency, high-bandwidth communication

Con: Complicated system architecture, Limited to data that fits in caches



Coherent AXI DMA-based Accelerator Communication


Write to Accelerator

- processor allocates buffer
- processor writes data into buffer
- processor flushes cache for buffer
- processor initiates DMA transfer

Read from Accelerator

- processor allocates buffer
- processor initiates DMA transfer
- processor waits for DMA to complete
- processor invalidates cache for buffer
- processor reads data from buffer

AXI Interfaces




Source: M.S. Sadri, Zynq Training

Features of AXI Interfaces


Interface	Features	
MemoryMap/Full	Traditional address/data burst (single address,multiple data)	
Streaming	Dataonly,burst	
Lite	Traditional address/data—no burst (single address,multiple data)	

Summary of AXI Full and AXI Lite Interfaces

- Memory mapped interfaces consist of 5 streams
 - Read Address
 - Read Data
 - Write Address
 - Write Data
 - Write Acknowledge
- **➤** Burst length limited to 256
- Data width limited to 256 bits for Xilinx IP
- > AXI Lite is a subset
 - no bursts
 - 32 bit data width only




AXI4 READ




AXI4 Write

Summary of AXI Stream Interface

- ➤ AXI Streams are fully handshaked
 - Data is transferred when source asserts VALID and destination asserts READY
- 'Information' includes DATA and other side channel signals
 - STRB
 - KEEP
 - LAST
 - ID
 - DEST
 - USER
- ➤ Most of these are optional




DMA Memory Transfer Operation




Source: The Zynq Book

Block Diagram of AXI DMA Core




Source: LogiCORE IP AXI DMA v7.1: Product Guide

Scatter Gather DMA Mode



Source: Symbian OS Internals/13. Peripheral Support

Customizing AXI DMA Core



Source: LogiCORE IP AXI DMA v7.1: Product Guide

Parameters of AXI DMA Core (1)

Number of Channels

the number of channels: 1..16

Memory Map Data Width

data width in bits of the AXI MM2S Memory Map Read data bus: 32, 64, 128, 256, 512 or 1,024

Stream Data Width

data width in bits of the AXI MM2S AXI4-Stream Data bus: 8, 16, 32, 64, 128, 512 or 1,024; Stream Data Width ≤ Memory Map Data Width;

Max Burst Size

maximum size of burst on the AXI4-Memory Map side of MM2S: 2, 4, 8,16, 32, 64, 128, or 256

Options of AXI DMA Core (1)

Enable Asynchronous Clocks

- 0 all clocks inputs should be connected to the same clock signal
- 1 separate asynchronous clocks for MM2S interface, S2MM interface, AXI4-Lite control interface, and the Scatter Gather Interface

Enable Scatter Gather Engine

- 0 Simple DMA Mode operation
- 1 Scatter Gather Mode operation; the Scatter Gather Engine included in AXI DMA

Options of AXI DMA Core (2)

Enable Micro DMA

- 0 regular DMA
- 1 area-optimized DMA; the maximum number of bytes per transaction = MMap_Data_width * Burst_length/8; addressing restricted to burst boundries

Enable Multi Channel Support

- 0 the number of channels fixed at 1 for both directions
- 1 the number of channels can be greater than 1

Options of AXI DMA Core (3)

Enable Control/Status Stream

- 0 no AXI4 Control/Status Streams
- 1 The AXI4 Control stream allows user application metadata associated with the MM2S channel to be transmitted to a target IP. The AXI4 Status stream allows user application metadata associated with the S2MM channel to be received from a target IP.

Width of Buffer Length Register (8-23)

For Simple DMA mode:

the number of valid bits in the MM2S_LENGTH and

S2MM_LENGTH registers

For Scatter Gather mode:

the number of valid bits used for the Control field buffer length and Status field bytes transferred in the Scatter/Gather descriptors

Options of AXI DMA Core (4)

Allow Unaligned Transfers

Enables or disables the MM2S Data Realignment Engine (DRE). If the DRE is enabled, data reads can start from any Buffer Address byte offset, and the read data is aligned such that the first byte read is the first valid byte out on the AXI4-Stream.

Use RxLength In Status Stream

Allows AXI DMA to use a receive length field that is supplied by the S2MM target IP in the App4 field of the status packet. This gives AXI DMA a pre-determined receive byte count, allowing AXI DMA to command the exact number of bytes to be transferred.

Simple DMA Transfer Programming Sequence for MM2S channel (1)

- Start the MM2S channel running by setting the run/stop bit to 1, MM2S_DMACR.RS = 1.
- 2. If desired, **enable interrupts** by writing a 1 to MM2S_DMACR.IOC_IrqEn and MM2S_DMACR.Err_IrqEn.
- 3. Write a valid source address to the MM2S_SA register.
- 4. Write the **number of bytes to transfer** in the MM2S_LENGTH register.

The MM2S_LENGTH register must be written last.

All other MM2S registers can be written in any order.


Simple DMA Transfer Programming Sequence for S2MM channel (1)

- Start the S2MM channel running by setting the run/stop bit to 1, S2MM_DMACR.RS = 1.
- 2. If desired, **enable interrupts** by by writing a 1 to S2MM_DMACR.IOC_IrqEn and S2MM_DMACR.Err_IrqEn.
- 3. Write a valid destination address to the S2MM_DA register.
- Write the length in bytes of the receive buffer in the S2MM_LENGTH register.

The S2MM_LENGTH register must be written last.


All other S2MM registers can be written in any order.

Scatter Gather DMA Mode



Source: Symbian OS Internals/13. Peripheral Support

Chain of Buffer Descriptors (BDs)



Scatter Gather DMA Transfer Programming Sequence for MM2S channel (1)

- 1. Write the address of the starting descriptor to the Current Descriptor register
- 2. Start the MM2S channel running by setting the run/stop bit to 1, MM2S_DMACR.RS = 1.
- 3. If desired, **enable interrupts** by writing a 1 to MM2S_DMACR.IOC_IrqEn and MM2S_DMACR.Err_IrqEn.
- 4. Write a valid address to the Tail Descriptor register.

Writing to the Tail Descriptor register triggers the DMA to start fetching the descriptors from the memory.

Simple DMA Transfer Programming Sequence for S2MM channel (1)

- 1. Write the address of the starting descriptor to the Current Descriptor register
- 2. Start the S2MM channel running by setting the run/stop bit to 1, S2MM_DMACR.RS = 1.
- 3. If desired, **enable interrupts** by by writing a 1 to S2MM_DMACR.IOC_IrqEn and S2MM_DMACR.Err_IrqEn.
- 4. Write a valid address to the Tail Descriptor register.

Writing to the Tail Descriptor register triggers the DMA to start fetching the descriptors from the memory.

Main Program

Main Program (1)

Main Program (2)

```
//======= Constant Definitions =========/
/* Device hardware build related constants */
#define DMA DEV ID XPAR AXIDMA 0 DEVICE ID
// use RAM0 to store the data to be transferred to
// DMA --> FPGA coprocessor
#define MEM_BASE_ADDR XPAR_PS7_RAM_0_S_AXI_BASEADDR
#define TX_BUFFER_BASE (MEM_BASE_ADDR)
#define RX BUFFER BASE (MEM BASE ADDR + 0x00001000)
#define M REG ADDR
      XPAR DMA LITE N STREAM 1 S00 AXI BASEADDR
#define M REG 0 OFFSET
      DMA LITE N STREAM_S00_AXI_SLV_REG0_OFFSET
```

Main Program (3)

```
#define RX INTR ID
      XPAR FABRIC AXI DMA 0 S2MM INTROUT INTR
#define TX INTR ID
      XPAR FABRIC AXI DMA 0 MM2S INTROUT INTR
#define INTC DEVICE ID
                        XPAR SCUGIC SINGLE DEVICE ID
#define INTC
                        XScuGic
#define INTC HANDLER
                        XScuGic InterruptHandler
/* Timeout loop counter for reset */
#define RESET TIMEOUT COUNTER 10000
/* Buffer and Buffer Descriptor related constant definitions */
#define MAX PKT LEN WORDS 8 // 8 32-bit words
#define MAX PKT LEN MAX PKT LEN WORDS*4 // 8*4 = 32 bytes
#define YES 1
#define USE_TX_CHANNEL YES
#define USE RX CHANNEL YES
```

Main Program (4)

```
static int CheckData(void);
static void TxIntrHandler(void *Callback);
static void RxIntrHandler(void *Callback);
static int SetupIntrSystem(INTC * IntcInstancePtr, XAxiDma * AxiDmaPtr,
                     u16 TxIntrld, u16 RxIntrld);
static void DisableIntrSystem(INTC * IntcInstancePtr, u16 TxIntrId,
                     u16 RxIntrld);
/* Device instance definitions */
                          /* Instance of the XAxiDma */
static XAxiDma AxiDma;
                          /* Instance of the Interrupt Controller */
static INTC Intc;
/* Flags interrupt handlers use to notify the application */
volatile int TxDone;
volatile int RxDone;
volatile int Error;
```

Main Program (5)

```
int main(void)
 int Status;
 XAxiDma Config *Config;
 xil printf("\r\n--- Entering main() --- \r\n");
 // transfer packet length to PL through AXI-Lite interface
 DMA LITE N STREAM mWriteReg(MEM BASE ADDR,
                    M REG 0 OFFSET, MAX PKT LEN WORDS);
 xil_printf("Number of words in Tx packet are %d",
          Xil In32(MEM BASE ADDR + M REG 0 OFFSET));
 // configure DMA engine
 Config = XAxiDma_LookupConfig(DMA_DEV_ID);
 if (!Config) {
       xil_printf("No config found for %d\r\n", DMA DEV ID);
       return XST FAILURE;
```

Main Program (6)

```
// Initialize DMA engine
Status = XAxiDma_CfgInitialize(&AxiDma, Config);
if (Status != XST SUCCESS) {
        xil printf("Initialization failed %d\r\n", Status);
        return XST FAILURE;
}
// check that scatter/ gather mode is disabled
if(XAxiDma HasSg(&AxiDma)){
        xil printf("Device configured as SG mode \r\n");
        return XST FAILURE;
// Set up Interrupt system
Status = SetupIntrSystem(&Intc, &AxiDma, TX_INTR_ID, RX_INTR_ID);
if (Status != XST SUCCESS) {
        xil printf("Failed intr setup\r\n");
        return XST FAILURE;
```

Main Program (7)

```
// Disable all interrupts before setup
XAxiDma IntrDisable(&AxiDma, XAXIDMA IRQ ALL MASK,
      XAXIDMA DMA TO DEVICE);
XAxiDma IntrDisable(&AxiDma, XAXIDMA IRQ ALL MASK,
      XAXIDMA DEVICE TO DMA);
// Enable all interrupts
XAxiDma_IntrEnable(&AxiDma, XAXIDMA IRQ ALL MASK,
      XAXIDMA DMA TO DEVICE);
XAxiDma IntrEnable(&AxiDma, XAXIDMA IRQ ALL MASK,
      XAXIDMA_DEVICE TO DMA);
// Initialize flags before start transfer test
TxDone = 0:
RxDone = 0:
Error = 0;
```

Main Program (8)

```
u32 *TxBufferPtr;
       TxBufferPtr = (u32 *)TX_BUFFER_BASE;
       *(TxBufferPtr) = 0x111111111;
       *(TxBufferPtr + 1) = 0x089FF0BA;
       *(TxBufferPtr + 2) = 0xA3A777E0;
       *(TxBufferPtr + 3) = 0xFF2402DB;
       *(TxBufferPtr + 4) = 0xE4308049;
       *(TxBufferPtr + 5) = 0x78F59D1B;
       *(TxBufferPtr + 6) = 0x42F9B10F;
       *(TxBufferPtr + 7) = 0x000000000;
/* Flush the SrcBuffer before the DMA transfer */
       Xil DCacheFlushRange((u32)TxBufferPtr, MAX_PKT_LEN);
/* Send a packet */
       Status = XAxiDma_SimpleTransfer(&AxiDma,(u32) TxBufferPtr,
MAX PKT LEN, XAXIDMA DMA_TO_DEVICE);
       if (Status != XST SUCCESS) { return XST FAILURE; }
       while (!TxDone);
```

Main Program (9)

Main Program (10)

```
// Wait TX done, RX done, or Error
while (!TxDone && !RxDone && !Error) { /* NOP */ }
Status = CheckData();
if (TxDone) xil printf("Transmission done \n");
              xil printf("Transmission not done \n");
else
if (RxDone)
              xil printf("Reception done \n");
              xil printf("Reception not done \n");
else
if (Error) {
xil printf("Failed test transmit %s done, receive %s done \r\n",
        TxDone? "":" not", RxDone? "":" not");
if (Error) {
       goto Done;
```

Main Program (11)

```
xil_printf("AXI DMA interrupt example test passed\r\n");

/* Disable TX and RX Ring interrupts and return success */
DisableIntrSystem(&Intc, TX_INTR_ID, RX_INTR_ID);

Done:
    xil_printf("--- Exiting main() --- \r\n");
    return XST_SUCCESS;
}
```