# CASPERGUI Documentation Release 1

**Danny Price** 

December 13, 2011

# **CONTENTS**

1	Copyright & Licensing	1			
2	Introduction	3			
3	3 Screenshots				
4	Getting Started	7			
5	Module Listing 5.1 roachnest.py 5.2 roachnest_helpers.py 5.3 ping.py 5.4 xport.py 5.5 xport.py	13			
Рy	ython Module Index	17			
Ру	ython Module Index	19			
In	ndex .	21			

**CHAPTER** 

ONE

### **COPYRIGHT & LICENSING**

ROACHNEST: A browser based user interface for monitor & control of CASPER hardware

Copyright (C) 2011 Danny Price

Everything I've written: GNU General Public License (GPL)

This program is free software: you can redistribute it and/or modify it under the terms of the GNU General Public License as published by the Free Software Foundation, either version 3 of the License, or (at your option) any later version.

This program is distributed in the hope that it will be useful, but WITHOUT ANY WARRANTY; without even the implied warranty of MERCHANTABILITY or FITNESS FOR A PARTICULAR PURPOSE. See the GNU General Public License for more details.

You should have received a copy of the GNU General Public License along with this program. If not, see <a href="http://www.gnu.org/licenses/">http://www.gnu.org/licenses/</a>>

**Everything else:** As per author's original licensing terms. Bottle.py and Flot are MIT licensed, Blueprint is a modified MIT license, sqlite3 is public domain.

### INTRODUCTION

Roachnest is a browser based Graphical User Interface (GUI) for control of CASPER hardware. This script utilises the KATCP python libraries, the bottle web framework, and sqlite3:

- http://casper.berkeley.edu/wiki/KATCP
- http://bottle.paws.de/
- http://docs.python.org/library/sqlite3.html

The HTML/CSS is based on blueprint CSS web framework, and plotting is done with HTML5/javascript flot:

- http://www.blueprintcss.org/
- http://code.google.com/p/flot/

**Warning:** I strongly suggest that this is available only through an internal network and is not made accessible via the WWW. Use at your own risk.

# **SCREENSHOTS**




Figure 3.1: Homepage: hardware management



Figure 3.2: Detailed status and board control.




Figure 3.3: Javascript plotting of snap BRAMs.



Figure 3.4: Reading and writing shared registers.

### **GETTING STARTED**

The first thing you'll need to do is to satisy the dependencies. You'll need:

```
os, sys, time, re, struct, sqlite3, bottle, numpy, katcp, paste, lxml
```

Note that paste and lxml are optional: paste improves webserver performance by using threading, and lxml is for parsing configuration files – although these won't appear until a future release!

After downloading the files, you should edit *lib/config.py*, and check that you're happy with the configuration. Note that you can change the page titles and the logo in this file.

Next, assuming you've got the dependencies sorted, all you should need to do is run:

```
>> python roachnest.py [options]
```

This would start up a webserver on localhost:8080. The options available are:

```
Options:
```

```
-h, --help show this help message and exit
-p PORT, --port=PORT Select KATCP port. Default is 7147
-i HOSTIP, --hostip=HOSTIP
change host IP address to run server. Default is localhost (127.0.0.1)
-P HOSTPORT, --hostport=HOSTPORT
change host port for server. Default is 8080
```

Once the webserver is up and running, open a browser up and surf over to localhost:8080, or if you've changed the IP address and port, type these in instead (eg. 192.168.126.6:8888). If you want the page to be viewable over a network, you'll have to use the *-hostip* option and point this to the IP address of your ethernet card.

**CHAPTER** 

**FIVE** 

### **MODULE LISTING**

#### 5.1 roachnest.py

Created by Danny Price on 2011-01-12.

Copyright (c) 2011 The University of Oxford. All rights reserved.

Roachnest is a browser based Graphical User Interface (GUI) for control of CASPER hardware. It facilitates basic monitor and control tasks, such as turning boards on and off via the XPORT, reprogramming the FPGA, reading and writing registers, and plotting the contents of shared BRAMS (snap blocks).

Roachnest also provides basic hardware management through a small sqlite database. Users can add notes, specify IP addresses, hostnames, and other basic information necessary to keep track of hardware specifics.

License: GNU GPL: http://www.gnu.org/copyleft/gpl.html

**Warning:** I strongly suggest that this is available only through an internal network and is not made accessible via the WWW. Use at your own risk.

```
roachnest.create db()
     URL: /dbcreate
     Creates a new database.
roachnest.download(filename)
     URL: /download/:filename
     Forces download of static files.
roachnest.hardware_add()
     URL: /add
     Add a new piece of kit to the database.
roachnest.hardware_edit(id)
     URL: /delete/:id
     Delete a piece of kit from the database.
roachnest.list_hardware()
     URL:/
     Index page. Lists all boards in the hardware database.
roachnest.listbof(id)
     URL: /listbof
```

Lists all bitstreams. Uses KATCP ?listbof command.

```
roachnest.listreg(id)
     URL: /listreg
     Lists registers and applies basic sorting regex. Uses KATCP ?listdev command.
roachnest.power_off(id)
     URL: /poweroff/:id
     Powers off a ROACH board using XPORT.
roachnest.power_on(id)
     URL: /poweron/:id
     Powers up a ROACH board using XPORT.
roachnest.progdev(id, bitstream)
     URL: /progdev/:bitstream
     Executes KATCP ?progdev command to program FPGA.
roachnest.server_static(path)
     URL: /files/:path#.+#
     Returns static files (eg images, css, scripts, favicons).
roachnest.snap32(id, snap_id, bytes, fmt, op)
     URL: ajax_snap/:snap_id/bytes/:bytes/fmt/:fmt
     AJAX request handler for /snap plotting page. Returns JSON data for the Flot javascript plotting library to plot.
roachnest.view_hardware(id)
     URL: /status/:id
     Provides overview of a single piece of kit.
5.2 roachnest_helpers.py
Created by Danny Price on 2011-01-12.
Copyright (c) 2011 The University of Oxford. All rights reserved.
Helper functions and classes for roachnest.
roachnest_helpers.bin2dec(binary)
     return the decimal string representation of binary
          Parameters binary: binary string:
                  binary string to reinterpret as decimal
roachnest_helpers.dbadd(hostname, MAC_address, IP_address, location, notes, serial, firmware,
                                atype, XPORT_address, ZDOK0, ZDOK1)
     Add a new piece of hardware to the database
          Parameters hostname: string:
                  Hostname of piece of hardware
              MAC_address: string:
                  MAC address of KATCP interface
              IP_address: string:
                  IP address of KATCP interface.
```

#### location: string:

Physical location of the hardware (eg Oxford DSP lab)

#### notes: string:

Any relevant notes that you may have

#### serial: string:

The serial number of the hardware.

#### firmware: :

Firmware revision information

#### atype: string:

What type of hardware is it? Options are generally ROACH, ROACH2, iBOB or BEE2

#### XPORT\_address: string:

IP address of XPORT interface.

#### **ZDOK0:** string:

Notes about what is installed in ZDOK 0.

#### **ZDOK1:** string:

Notes about what is installed in ZDOK 1.

```
roachnest_helpers.dbblank()
```

Returns a blank hardware dictionary.

Returns a BLANK python dictionary with the following entries: id, hostname, MAC\_address, IP\_address, location, notes, serial, firmware, type, XPORT\_address, ZDOK0, ZDOK1, status, XPORT\_status.

```
roachnest_helpers.dbcreate()
```

Creates a new database.

#### **Notes**

This function should only be called once, for initial database setup.

```
roachnest_helpers.dbdelete(id)
```

Deletes a piece of hardware from the database.

#### Parameters id: int:

Primary key (ID number) of record

roachnest\_helpers.dbedit (id, hostname, MAC\_address, IP\_address, location, notes, serial, firmware, atype, XPORT address, ZDOKO, ZDOK1)

Edit an exisiting piece of hardware in the database

#### Parameters id: int:

Primary key (ID number) of record

#### hostname: string:

Hostname of piece of hardware

#### **MAC\_address:** string:

MAC address of KATCP interface

#### IP\_address: string:

IP address of KATCP interface.

#### location: string:

Physical location of the hardware (eg Oxford DSP lab)

#### notes: string:

Any relevant notes that you may have

#### serial: string:

The serial number of the hardware.

#### firmware: :

Firmware revision information

#### atype: string:

What type of hardware is it? Options are generally ROACH, ROACH2, iBOB or BEE2

#### **XPORT\_address:** string:

IP address of XPORT interface.

#### **ZDOK0:** string:

Notes about what is installed in ZDOK 0.

#### **ZDOK1:** string:

Notes about what is installed in ZDOK 1.

```
roachnest_helpers.dbget (id)
```

Retrieves a hardware record from the hardware database.

#### Parameters id: integer:

primary key (ID number) of database entry

#### **Notes**

Queries database and returns a python dictionary with the following entries: id, hostname, MAC\_address, IP\_address, location, notes, serial, firmware, type, XPORT\_address, ZDOK0, ZDOK1, status, XPORT\_status.

```
roachnest_helpers.dbgetall()
```

Retrieves all records from the database.

#### **Notes**

Retrieves all records from the database. Returns a list of python dictionaries, with name: value pairs that correspond to database columns. Each python dictionary contains the following entries: id, hostname, MAC\_address, IP\_address, location, notes, serial, firmware, type, XPORT\_address, ZDOK0, ZDOK1, status, XPORT\_status.

```
\verb"roachnest_helpers.dec2bin" (\textit{decimal})
```

decimal string to reinterpret as binary

```
roachnest_helpers.dec2hex(n)
```

return the hexadecimal string representation of integer n

#### Parameters n: hexadecimal string:

hexadecimal string to reinterpret as decimal

```
roachnest_helpers.hex2dec(s)
```

return the integer value of a hexadecimal string s

#### Parameters s: decimal string:

decimal string to reinterpret as hexadecimal

```
roachnest_helpers.safe_eval(command)
```

A safer version of the eval() command, using ast.literal\_eval TODO: make this more functional, at the moment it's pretty useless.

#### Parameters command: string:

```
command to evaluate (e.g. '2**10-1').
```

```
roachnest_helpers.writereg(fpga, name, value, base=10)
```

Writes a value to an FPGA register. Very similar to fpga.write\_int, but you can specify the base (e.g. base 2 for binary)

#### Parameters fpga: katcp\_wrapper.FpgaClient object :

fpga client object (which roach board to communitcate with)

#### name: string:

register name

#### value: integer :

value to write to register

#### base: int:

base to write register. Default is 10 (decimal), but other bases may be used.

### 5.3 ping.py

Ping multiple hosts/ip addresses in parallel, using threading

**Credits:** Modified from script by Jose Porrua: http://www.joseporrua.com/2008/12/11/multi-threaded-ping-in-python However, this script didn't work for me out of the box so I modified it to get it running.

```
class ping.Host(ip)
```

Defines a host object.

Current attributes include: name, address and status.

```
ping.execute(host)
```

Executes a ping command and sets the appropriate attribute.

#### Parameters host: ping.Host:

A host object.

#### **Notes**

This is significantly different to Jose Porrua's original script, which will not match ping requests on Mac OSX. TODO: Test this on Windows and modify if required.

5.3. ping.py 13

A list of ping. Host objects

#### 5.4 xport.py

Created by Danny Price, 03 October 2011.

Based on roach\_monitor.py at: https://casper.berkeley.edu/wiki/Roach\_monitor\_and\_management\_subsystem

This module allows for communication with the ROACH X-port. ROACH has an onboard, fully independent management subsystem that can be accessed through the X-port. The X-port system monitors voltages and temperatures and will shut down the board if these are out of specification. A log is kept of the shutdown cause, its value and time.

```
class xport .Xport (ip, port)
```

tional val)
get fan speeds()

Actel Fusion X-port class, for communicating with M&C

#### **Methods**

```
clear_crashlog()
    Reset crash log counter

close()
    Close xport socket connection

connect()
    Connect to xport socket

flush()
    Flush receive buffer

get_board_time()
    Check and retrieve board uptime. Returns board up time in seconds (int).

get_channels()
    Retrieves the voltage and temperatures of the PPC, V5, PSU, and Actel chips.
    Returns a list of format: (channel name, channel state, channel min operational value, channel max opera-
```

Check and retrieve fan speeds. Returns a list of fan speeds

```
get_id()
          Return board ID and revision
     get_last_shutdown()
          Check and retrieve reason for last shutdown. Returns reason as a string
     get_power_good()
          Check and retrieve power good status of voltage regulators. Returns a list of power good signals.
     get power state()
          Check and retrive board power state. Returns power state as a string
     get_serial()
          Check and retrieve serial number. After first query the serial number is stored as class variable self.serial
     power_down()
          Power down the ROACH
     power_up()
          Power up the ROACH (Wake on LAN)
     read(addr)
          Reads a 16bit value from the Fusion part through the Xport.
     toggle_config_h()
          todo: Toggle PPC EEPROM boot (config H)
     toggle_power_on_reset()
          todo: Toggle auto power-on after hard-reset.
     warm rst()
          Reset ROACH, but not Actel
     write(addr, value)
          Writes a 16bit value to the Fusion part through the Xport.
exception xport.xportError (msg)
     A simple class for X-port error handling
```

5.4. xport.py 15

# **PYTHON MODULE INDEX**

```
p
ping, 13

r
roachnest, 9
roachnest_helpers, 10

X
xport, 14
```

18 Python Module Index

# **PYTHON MODULE INDEX**

```
p
ping, 13

r
roachnest, 9
roachnest_helpers, 10

X
xport, 14
```

20 Python Module Index

# **INDEX**

В	Host (class in ping), 13		
bin2dec() (in module roachnest_helpers), 10	I		
C clear_crashlog() (xport.Xport method), 14 close() (xport.Xport method), 14 connect() (xport.Xport method), 14 create_db() (in module roachnest), 9	list_hardware() (in module roachnest), 9 listbof() (in module roachnest), 9 listreg() (in module roachnest), 9		
dbadd() (in module roachnest_helpers), 10 dbblank() (in module roachnest_helpers), 11 dbcreate() (in module roachnest_helpers), 11 dbdelete() (in module roachnest_helpers), 11 dbedit() (in module roachnest_helpers), 11 dbget() (in module roachnest_helpers), 12 dbgetall() (in module roachnest_helpers), 12 dec2bin() (in module roachnest_helpers), 12 dec2hex() (in module roachnest_helpers), 12 download() (in module roachnest), 9  E	ping (module), 13 ping() (in module ping), 13 pingHosts() (in module ping), 14 power_down() (xport.Xport method), 15 power_off() (in module roachnest), 10 power_up() (in module roachnest), 10 power_up() (xport.Xport method), 15 printResults() (in module ping), 14 progdev() (in module roachnest), 10  R  read() (xport.Xport method), 15 roachnest (module), 9 roachnest_helpers (module), 10		
execute() (in module ping), 13	S		
F flush() (xport.Xport method), 14	safe_eval() (in module roachnest_helpers), 13 server_static() (in module roachnest), 10 snap32() (in module roachnest), 10		
G	Т		
get_board_time() (xport.Xport method), 14 get_channels() (xport.Xport method), 14 get_fan_speeds() (xport.Xport method), 14	toggle_config_h() (xport.Xport method), 15 toggle_power_on_reset() (xport.Xport method), 15		
get_id() (xport.Xport method), 14 get_last_shutdown() (xport.Xport method), 15	V		
get_power_good() (xport.Xport method), 15	view_hardware() (in module roachnest), 10		
get_power_state() (xport.Xport method), 15 get_serial() (xport.Xport method), 15	W		
H hardware_add() (in module roachnest), 9 hardware_edit() (in module roachnest), 9 hex2dec() (in module roachnest_helpers), 13	warm_rst() (xport.Xport method), 15 write() (xport.Xport method), 15 writereg() (in module roachnest_helpers), 13		



Xport (class in xport), 14 xport (module), 14 xportError, 15

22 Index