Sensing Matrices for KAGRA Main Optics Optical Lever (OpLev) Displacement Sensing System.

Tsang Terrence Tak Lun The Chinese University of Hong Kong

Last update: May 2, 2021

Contents

1	Intr	Introduction		
2	Derivation			2
	2.1	Very basic derivation		3
	2.2	Optica	al levers in KAGRA	3
		2.2.1	Horizontal optical levers	6
		2.2.2	Vertical optical levers	7
		2.2.3	Short summary	7
2.3 Cross-coupling due to misalignment		Cross-	coupling due to misalignment	7
		2.3.1	Rotation	7
		2.3.2	Miscentered beam spot	8
		2.3.3	Writing down the sensing matrix explicitly	9
		2.3.4	Length-sensing QPD misplacement	10
		2.3.5	Horizontal optical lever (with misalignment)	10
		2.3.6	Vertical optical lever (with misalignment)	11
		2.3.7	Misalignment summary	11
	2.4	Folded	l optical lever	12
3	Mea	asuring	g the sensing matrix	12

1 Introduction

Optical lever is a device used to measure angular displacement of a reflective surface. [1] It consists of a light source (e.g. superluminescent LED), the reflective surface (e.g. the suspended main optics), and beam position sensing device (e.g. Quadphotodiode (QPD)). In KAGRA, the beam used by the optical lever can also be used to measure the longitudinal displacement (along the reflective normal) of the reflective surface. This is done by sensing the beam position behind a convex lens. Although the phrase "optical lever" refers to the angular sensing part of the whole device, we refer the term "optical lever" in KAGRA to the whole device which senses all three displacements, longitudinal, pitch, and yaw.

There are two types of optical levers that are used as displacement sensors in KAGRA, regular and folded (the one used in MCo). The regular optical lever system can be subdivided into two types, horizontal (e.g. those for Type-A and Type-Bp suspensions) and vertical (e.g. Those for Type-B suspensions). Without loss of generality, we will derive the optical lever sensing matrix with a tilted plane of incidence. The derivation of the sensing matrix of a regular type is slightly different then that of a folded optical lever system. We will first derive the sensing matrix of a regular type and then modify it to fit a folded optical lever system.




Figure 1: Different types of optical lever displacement sensing systems in KAGRA

2 Derivation

This section is organized as follows, we will first derive a very basic sensing matrix¹, assuming there's no misalignment in the optical system. And then, we will derive the general sensing matrix that includes all sorts of misalignment. Lastly, we will modify the matrix for a folded optical lever configuration.

¹Here, we define the sensing matrix to be a matrix that maps sensor readouts to the displacements that we want to measure.

2.1 Very basic derivation

In the simplest case, the beam position x_1 (along the incidence plane) is related to the angular displacement θ by

$$x_1 = (2r)\,\theta,\tag{1}$$

where r is the lever arm defined by the distance between the reflective surface and the sensing device. The same beam can be used to measure the longitudinal displacement of the reflective surface, if the light beam has an angle of incidence α . In this case, the beam displacement reads

$$x_1 = (2r)\theta + (2\sin\alpha)x_L,\tag{2}$$

where x_L is the longitudinal displacement of the reflective surface. As can be seen, equation. (2) shows a coupled sensor where it reads both the angular displacement and the longitudinal shift. In KAGRA, some optical levers have a second sensor measuring the beam displacement x_2 some distance d behind a convex lens with focal length f. In this case, we obtain the second beam displacement x_2 via ray transfer matrices [2]

$$\begin{pmatrix} x_2 \\ \cdot \end{pmatrix} = \begin{bmatrix} 1 & d \\ 0 & 1 \end{bmatrix} \begin{bmatrix} 1 & 0 \\ -1/f & 1 \end{bmatrix} \begin{bmatrix} 1 & r_{\text{lens}} \\ 0 & 1 \end{bmatrix} \begin{pmatrix} (2\sin\alpha) x_L \\ 2\theta \end{pmatrix}, \tag{3}$$

where $r_{\rm lens}$ is the distance between the reflective surface and the lens. This gives

$$x_2 = (2\sin\alpha)\left(1 - \frac{d}{f}\right)x_L + 2\left[\left(1 - \frac{d}{f}\right)r_{\text{lens}} + d\right]\theta. \tag{4}$$

Furthermore, we can place the second beam displacement sensor distance behind the lens. So, if we set

$$d = \frac{r_{\text{lens}}f}{r_{\text{lens}} - f},\tag{5}$$

then the angular coupling, i.e. the second term in Eqn. (4), becomes zero, effectively making the second beam displacement sensor a "length" (length as in longitudinal displacement) sensing device. If Eqn. (5) is satisfied, then the beam displacement measured by the second senor reads

$$x_2 = \left(\frac{-2f\sin\alpha}{r_{\rm lens} - f}\right) x_L. \tag{6}$$

Now, if we put Eqn. (2) and Eqn. (6) in a matrix form, we can obtain the sensing matrix, i.e.

Then, from here, we can diagonalize² the sensors.

2.2 Optical levers in KAGRA

Before diving into the discussion of misalignment, let's rewrite the matrix so it's closer to what we see in KAGRA.

In KAGRA, we have two beam displacement sensors³, tilt-sensing QPD and length-sensing QPD. They are analogous to the first and second beam position sensors in Sec. 2.1, respectively. Each QPD has two readouts, the horizontal and the vertical displacement of the beam spot, denoted $(x_{\text{tilt}}, y_{\text{tilt}})$, and $(x_{\text{len}}, y_{\text{len}})$ for tilt-sensing QPD and length-sensing QPD respectively. Here, note that the displacements sensed by the QPDs are not, in general, parallel to the global horizontal or vertical plane, as the QPDs are virtually placed orthogonal to the beam. We are particularly interested in the optics' longitudinal x_L , pitch θ_P , and yaw θ_Y displacements. Therefore, the goal is to find a matrix that maps $\vec{x} = (x_{\text{tilt}}, y_{\text{tilt}}, x_{\text{len}}, y_{\text{len}})^T$ to longitudinal displacement, pitch angle, and yaw angle $(x_L, \theta_P, \theta_Y)^T$.

²Consider a model $\vec{y} = \mathbf{C}\vec{x}$, where \vec{y} are the measurements, and \vec{x} are the states. The goal is to define another measurement basis $\vec{y'}$ such that $\vec{y'} = \mathbf{C'}\vec{x}$, where $\mathbf{C'}$ is a diagonal matrix. It's obvious that If we define $\vec{y'} \equiv \mathbf{C}^{-1}\vec{y}$, then $\mathbf{C'}$ becomes the identity, which is a diagonal matrix. Therefore, we define \mathbf{C}^{-1} to be the sensing matrix, which maps sensor measurements to the displacements of the reflective surface.

³Some only has one, e.g. MCo.




Figure 2: Tilt-sensing optical lever setup in KAGRA.

A 3D illustration of the a general tilt-sensing optical lever setup is shown in Fig. 2. For the current discussion, let's assume that the optical lever is well aligned so the beam spot miscentering at the optics δ_x and δ_y are zero. Now, the lever arm of the optical lever can be an arbitrary vector, i.e. $\vec{r} = r_x \hat{x} + r_y \hat{y} + r_z \hat{z}$. For the purpose of this discussion, let \hat{x} be a direction aligned to the transverse direction of the main optics, \hat{y} be a direction aligned to the vertical direction of the optics, and \hat{z} be a direction aligned to the longitudinal direction of the optics. Optical levers in KAGRA are aligned on a horizontal plane (i.e. $r_y = 0$), or vertical plane (i.e. $r_x = 0$). But, let's assume that they are not zero.

If we project the beam onto a horizontal plane and a vertical plane (along the normal of the suspended optics), the beams have an incidence angle of α_h and α_v on the horizontal plane and the vertical plane, respectively. It follows that the lever arm that amplifies the pitch angle is the length of the projection of the lever arm \vec{r} on the vertical plane, r_v^4 . Similarly, the lever arm amplifying the yaw angle is the length of the projection of the lever arm on the horizontal plane, r_h . Therefore, a rotation in yaw θ_Y and pitch θ_P would cause the beam spot at the tip of the lever arm to shift by $(2r_h)\theta_Y$ and $(2r_v)\theta_P$, on the horizontal plane and vertical plane respectively. Meanwhile, a longitudinal shift x_L would cause the beam spot to shift by $(2\sin\alpha_h)x_L$ and $(2\sin\alpha_v)x_L$ on the horizontal plane and vertical plane, respectively. From here, we can write the displacement of the beam spot as measured by the tilt-sensing QPD, placed at some distance \vec{r} from the beam spot at the suspended optics plane. The beam spot displacement is simply a superposition of that caused by a rotation and a longitudinal shift,

$$x_{\text{tilt}} = (2r_h)\theta_Y + (2\sin\alpha_h)x_L,\tag{8}$$

and

$$y_{\text{tilt}} = (2r_v)\,\theta_P + (2\sin\alpha_v)\,x_L. \tag{9}$$

As for the length-sensing QPD, let's assume that beam travels some displacement \vec{r}_{lens} from the suspended optics to a convex lens with focal length f. Fig. 3 shows the length-sensing optical lever setup. Here, note that the beam in Fig. 3 is common to that in Fig. 2⁵.

Let's say the horizontal lever arm from the optics to the convex lens is $r_{lens,h}$. Again, using ray transfer matrix, we can write down the beam spot displacement at the length-sensing QPD,

$$x_{\text{len}} = (2\sin\alpha_h)\left(1 - \frac{d_h}{f}\right)x_L + 2\left[\left(1 - \frac{d_h}{f}\right)r_{\text{lens},h}, +d_h\right]\theta_Y,\tag{10}$$

⁴Think of it as a cross-product $\vec{\theta} \times \vec{r}$. For example, for pitch, $-\theta_P \hat{x} \times (r_x \hat{x} + r_y \hat{y} + r_z \hat{z}) = \theta_P (-r_y \hat{z} + r_z \hat{y})$, which is a displacement on the horizontal plane, and $r_v = \sqrt{r_y^2 + r_z^2}$ is the corresponding lever arm that amplifies pitch.

⁵In reality, there's a beamsplitter in front of the tilt-sensing QPD to divide the beam into two.




Figure 3: Length-sensing optical lever setup in KAGRA.

where d_h is the length between the lens and the length-sensing QPD on the horizontal plane, and f is the focal length of the lens. It follows that when $d_h = \frac{r_{\text{lens},h}f}{r_{\text{lens},h}-f}$, x_{len} is decoupled from yaw. But, d_h is a distance on the horizontal plane. To get back the length, d, we can simply use a similar triangle relationship, as shown in Fig. 4,

$$d_{\text{yaw}} + r_{\text{lens}} = (d_h + r_{\text{lens}h}) \frac{r_{\text{lens}}}{r_{\text{lens},h}},$$

$$d_{\text{yaw}} = (d_h + r_{\text{lens},h}) \frac{r_{\text{lens}}}{r_{\text{lens},h}} - r_{\text{lens}}$$
(11)

Here, if we set $d = d_{\text{yaw}}$, then the horizontal readout of the length-sensing QPD x_{len} will have no yaw coupling, i.e.




Figure 4: A similar triangle formed by the beam and it's projection on the horizontal plane (length-sensing QPD path).

$$x_{\rm len} = \left(\frac{-2f\sin\alpha_h}{r_{{\rm lens},h} - f}\right) x_L. \tag{12}$$

However, in this case, the vertical readout y_{len} is **not** decoupled from pitch, in general. Now, if we set $d = d_{\text{yaw}}$, then, on the vertical plane, d_v reads, again, from similar triangle relation,

$$d_{v} = (d_{\text{yaw}} + r_{\text{lens}}) \frac{r_{\text{lens},v}}{r_{\text{lens}}} - r_{\text{lens},v}$$

$$= (d_{h} + r_{\text{lens},h}) \frac{r_{\text{lens},v}}{r_{\text{lens},h}} - r_{\text{lens},v}$$

$$= \left(\frac{r_{\text{lens},h}f}{r_{\text{lens},h} - f} + r_{\text{lens},h}\right) \frac{r_{\text{lens},v}}{r_{\text{lens},h}} - r_{\text{lens},v}$$

$$= \left(\frac{r_{\text{lens},h}}{r_{\text{lens},h} - f} - 1\right) r_{\text{lens},v}$$

$$= \frac{r_{\text{lens},v}f}{r_{\text{lens},h} - f}$$
(13)

whereas if we want y_{len} to be decoupled from pitch, we need to set

$$d_v = \frac{r_{\text{lens},h}f}{r_{\text{lens},h} - f},\tag{14}$$

In general, $r_{\text{lens},h} \neq r_{\text{lens},v}$. So, we cannot simultaneously decouple pitch and yaw from the length-sensing readout. And, if we choose to set $d = d_{\text{yaw}}$, i.e. to minimize yaw coupling, the vertical length-sensing QPD readout reads

$$y_{\text{len}} = (2\sin\alpha_v) \left(1 - \frac{d_v}{f}\right) x_L + 2\left[\left(1 - \frac{d_v}{f}\right) r_{\text{lens},v} + d_v\right] \theta_P$$

$$= (2\sin\alpha_v) \left(\frac{r_{\text{lens},h} - r_{\text{lens},v} - f}{r_{\text{lens},h} - f}\right) x_L + 2\left[\left(\frac{r_{\text{lens},h} - r_{\text{lens},v} - f}{r_{\text{lens},h} - f}\right) r_{\text{lens},v} + \frac{r_{\text{lens},v}f}{r_{\text{lens},h} - f}\right] \theta_P$$

$$= (2\sin\alpha_v) \left(\frac{r_{\text{lens},h} - r_{\text{lens},v} - f}{r_{\text{lens},h} - f}\right) x_L + 2\left[\left(\frac{r_{\text{lens},h} - r_{\text{lens},v}}{r_{\text{lens},h} - f}\right) r_{\text{lens},v}\right] \theta_P.$$
(15)

Here, note that if the length of the projections are equal, i.e. $r_{lens,h} = r_{lens,h}$, then vertical readout of the length-sensing QPD is decoupled from pitch. This refers to a rather interesting configuration, where the incidence plane of the beam is rotated 45° along the z-axis with respect to the vertical plane.

Without loss of generality, let's assume arbitrary⁶ d_h and d_v , and write the sensing matrix $\mathbf{C}_{\text{align}}$ for a perfectly aligned optical lever. If we ensemble Eqn. (8), (9), (10), and the first line of (15) into a matrix form, we get

$$\begin{pmatrix} x_L \\ \theta_P \\ \theta_Y \end{pmatrix} = \mathbf{C}_{\text{align}} \begin{pmatrix} x_{\text{tilt}} \\ y_{\text{tilt}} \\ x_{\text{len}} \\ y_{\text{len}} \end{pmatrix}, \tag{16}$$

where

$$\mathbf{C}_{\text{align}} = \begin{bmatrix} 2\sin\alpha_h & 0 & 2r_h \\ 2\sin\alpha_v & 2r_v & 0 \\ 2\sin\alpha_h \left(1 - \frac{d_h}{f}\right) & 0 & 2\left[\left(1 - \frac{d_h}{f}\right)r_{\text{lens},h} + d_h\right] \\ 2\sin\alpha_v \left(1 - \frac{d_v}{f}\right) & 2\left[\left(1 - \frac{d_v}{f}\right)r_{\text{lens},v} + d_v\right] & 0 \end{bmatrix}^+, \tag{17}$$

Here, $\left[\cdot\right]^{+}$ is the pseudoinverse of $\left[\cdot\right]$, and $\left[\cdot\right]^{+}\left[\cdot\right] = \mathbf{I}$.

2.2.1 Horizontal optical levers

Eqn. (16) gives a general relationship between the QPD readouts and the displacements of the optics without misalignments. It can be drastically simplified if we further assume that the incidence plane is aligned to the horizontal plane (e.g. Type-Bp and Type-A) or the vertical plane (e.g. Type-B). For horizontal optical levers, $\alpha_v = 0$. This gives $y_{\text{tilt}} = (2r_v) \theta_P$ and $y_{\text{len}} = 2 \left[\left(1 - \frac{d_v}{f} \right) r_{\text{lens},v} + d_v \right] \theta_P$, which are not independent from each other. We can choose to omit the readout y_{len} and hence the sensing matrix for a horizontal optical lever is

$$\begin{pmatrix} x_L \\ \theta_P \\ \theta_Y \end{pmatrix} = \begin{bmatrix} 2\sin\alpha_h & 0 & 2r_h \\ 0 & 2r_v & 0 \\ \frac{-2f\sin\alpha_h}{r_{\text{lens},h} - f} & 0 & 0 \end{bmatrix}^{-1} \begin{pmatrix} x_{\text{tilt}} \\ y_{\text{tilt}} \\ x_{\text{len}} \end{pmatrix},$$
(18)

where we've assumed $d = d_h = \frac{r_{\text{lens},h}f}{r_{\text{lens},h}-f}$. Note that on a horitonzal setup, the beam is on the horizontal plane so the horizontal lever arm $r_h = r$. Furthermore, the projection on the vertical plane is simply $r_v = r \cos \alpha_h$. Similarly, the horizontal arm displacement from the optics to the lens $r_{\text{lens},h} = r_{\text{lens}}$.

⁶They can't be completely arbitrary. They must be related via the angle between the horizontal plane and the plane of incidence. But, I don't want to introduce that unnecessary parameter.

2.2.2 Vertical optical levers

Like in Sec. 2.2.1, without further derivation, we can write the sensing matrix for a vertical optical lever setup.

$$\begin{pmatrix} x_L \\ \theta_P \\ \theta_Y \end{pmatrix} = \begin{bmatrix} 0 & 0 & 2r_h \\ 2\sin\alpha_v & 2r_v & 0 \\ \frac{-2f\sin\alpha_v}{r_{\text{lens},v} - f} & 0 & 0 \end{bmatrix}^{-1} \begin{pmatrix} x_{\text{tilt}} \\ y_{\text{tilt}} \\ y_{\text{len}} \end{pmatrix},$$
(19)

where we've set $d = d_v = \frac{r_{\text{lens},v}f}{r_{\text{lens},v}-f}$. Again, for a vertical setup, $r_v = r$, $r_h = r\cos\alpha_v$, and $r_{\text{lens},v} = r_{\text{lens}}$.

2.2.3 Short summary

We have derived the sensing matrix, Eqn. (16), assuming no misalignment, for a general optical lever setup with a tilted incidence plane. From that, we reduced the general matrix to Eqn. (18) and (19), which corresponds to the sensing matrix for a horizontal optical lever setup and vertical optical lever setup, respectively. In general, the angle of incidence, arm lengths, and focal length are known. Therefore, Eqn. (18) and (19) can be used as initial sensing matrices for the Type-Bp/Type-A and Type-B optical levers, respectively.

2.3 Cross-coupling due to misalignment

Eqn. (18) and (19) give initial sensing matrices for converting the QPD readouts $(x_{\text{tilt}}, y_{\text{tilt}}, x_{\text{len}}, y_{\text{len}})$ to longitudinal x_L , pitch θ_P , and yaw θ_Y . However they are "initial" sensing matrix only There might still be residual cross-couplings between channels and the sensing matrices must be processed to minimize these couplings. In this section, we will discuss 3 mechanisms due to misalignment of the optical lever that could lead to cross-coupling between the three displacements. And, we will modify Eqn. (16) accordingly.

2.3.1 Rotation

There's no reason why the QPD is exactly aligned to the a desired frame in the first place. In fact, the QPD frame can easily be rotated with respective to the desired frame. There are many ways how this could happen. For example, the QPD could be physically rotated. Or maybe there's a steering mirror in the middle that caused this rotation. Therefore, we must that this effect into account and make necessary corrections.




Figure 5: A rotational between the "yaw-pitch" frame (primed frame in red) and the tilt-sensing QPD frame (unprimed frame in black).

Take the tilt-sensing QPD for example. Fig. 5 shows a rotation between the "yaw-pitch" frame and the tilt-sensing QPD frame. In the figure, red axes indicates the direction of the beam spot displacement when subjected to a pure

yaw displacement and pure pitch displacement. This means that, the primed horizontal displacement x'_{tilt} reads

$$x'_{\text{tilt}} = (2r_h)\,\theta_V + (2\sin\alpha_h)\,x_L,\tag{20}$$

and the primed vertical displacement reads

$$y'_{\text{tilt}} = (2r_v)\,\theta_P + (2\sin\alpha_v)\,x_L. \tag{21}$$

These should be the quantities that we are reading, but instead, we are reading the QPD readouts $x_{\rm tilt}$ and $y_{\rm tilt}$.

Here, the primed frame is a rotated by an angle ϕ_{tilt} compared to the QPD frame. Hence, we can relate the two frames via

$$\begin{bmatrix} \cos \phi_{\text{tilt}} & \sin \phi_{\text{tilt}} \\ -\sin \phi_{\text{tilt}} & \cos \phi_{\text{tilt}} \end{bmatrix} \begin{pmatrix} x_{\text{tilt}} \\ y_{\text{tilt}} \end{pmatrix} = \begin{pmatrix} x'_{\text{tilt}} \\ y'_{\text{tilt}} \end{pmatrix}. \tag{22}$$

A similar operation can be done to the length-sensing readout x_{len} and y_{len} , but with a different angle ϕ_{len} . So, Eqn. (16) must be modified to

$$\begin{pmatrix} x_L \\ \theta_P \\ \theta_Y \end{pmatrix} = \mathbf{C}_{\text{align}} \mathbf{C}_{\text{rotation}} \begin{pmatrix} x_{\text{tilt}} \\ y_{\text{tilt}} \\ x_{\text{len}} \\ y_{\text{len}} \end{pmatrix}, \tag{23}$$

where C_{align} is the sensing matrix for the perfectly aligned optical lever, i.e. sensing matrix in Eqn. (16), and

$$\mathbf{C}_{\text{rotation}} = \begin{bmatrix} \cos \phi_{\text{tilt}} & \sin \phi_{\text{tilt}} & 0 & 0\\ -\sin \phi_{\text{tilt}} & \cos \phi_{\text{tilt}} & 0 & 0\\ 0 & 0 & \cos \phi_{\text{len}} & \sin \phi_{\text{len}}\\ 0 & 0 & -\sin \phi_{\text{len}} & \cos \phi_{\text{len}} \end{bmatrix}$$
(24)

is the matrix to correct rotated QPDs.

There's a caveat in this correction, that is, we assume the QPD axes are orthogonal. While this is a very legitimate assumption, this may not be the case if the 4 photodiodes of the QPD has slightly different sensitivities. In this case, we should rotate the axes separately with different angles. However, we shouldn't allow such asymmetric rotation since the calibrations will not be preserved. So, it's meaningless to include this kind of correction into the sensing matrix. Instead, it should be corrected during the calibration stage, where the problem should have been discovered. Or we can simply discover this by observing the fluctuation in QPD sum. If the sensitivities don't match, then there will be large fluctuation in the QPD sum.

There's also an important note here. The rotational transformation should be applied directly to the QPD beam spot displacements readout, not the calibrated yaw-pitch readouts. This is as basic as knowing that matrices don't commute. But, for some reason people, were still doing this in KAGRA, where a rotation was applied to the initially calibrated yaw and pitch readout. This can, of course, decouple yaw and pitch. But, it will completely mess up the calibration because pitch and yaw don't necessarily have the same lever arm coupling.

2.3.2 Miscentered beam spot

Previous derivation assumes that the beam hits the optics at the center of rotation. But, in general, the beam will be miscentered by some small amount δ_x and δ_y in the horizontal and vertical direction, respectively, as shown in Fig. 2 and Fig. 3. In this case, rotation-to-longitudinal cross-couplings will be introduced.

Fig. 6 shows a horizontally miscentered optical lever beam. In Eqn. (2), the displacement $(2 \sin \alpha) x_L$ is the shift of the beam from the original optical axis. If the beam spot is off-centered, say by an amount of δ_x in the horizontal direction, a rotation in the yaw direction will also introduce a longitudinal shift of the beam spot at the optics plane by an amount of $\delta_x\theta_Y$. This correspond to a parallel beam shift by an amount of $(2 \sin \alpha_h) \delta_x\theta_Y^7$. Similarly, if the beam spot is off-centered in the vertical direction by an amount δ_y , a rotation in the pitch direction will introduce a longitudinal shift of $\delta_y\theta_P$. This correspond to a parallel beam shift by an amount of $(2 \sin \alpha_v) \delta_y\theta_P$.

⁷To the first order correction only. In reality, the angle of incidence is $\alpha_h + 2\theta_Y$, but not α_h . Here, we assume θ_Y is small, so $\sin \alpha_h \approx \sin (\alpha_h + 2\theta_Y)$




Figure 6: The beam spot of the optical lever beam at the optics plane is miscentered by an amount of δ_x horizontally with respect to the rotational axis.

Note that the first row of Eqn. (16) longitudinal shift of the optics x_L . To correct for miscentered beam spot, we can simply replace x_L by the longitudinal shift of the beam spot at the optics plane, i.e. $x_L + \delta_y \theta_P + \delta_x \theta_Y$. This correspond to multiplying a matrix on the left-hand side of the equation, i.e.

$$\begin{pmatrix} x_L + \delta_y \theta_P + \delta_x \theta_Y \\ \theta_P \\ \theta_Y \end{pmatrix} = \begin{bmatrix} 1 & \delta_y & \delta_x \\ 0 & 1 & 0 \\ 0 & 0 & 1 \end{bmatrix} \begin{pmatrix} x_L \\ \theta_P \\ \theta_Y \end{pmatrix}. \tag{25}$$

Therefore, to account for beam miscentering, Eqn. 23 must be further modified to

$$\begin{pmatrix} x_L \\ \theta_P \\ \theta_Y \end{pmatrix} = \mathbf{C}_{\text{miscenter}} \mathbf{C}_{\text{align}} \mathbf{C}_{\text{rotation}} \begin{pmatrix} x_{\text{tilt}} \\ y_{\text{tilt}} \\ x_{\text{len}} \\ y_{\text{len}} \end{pmatrix}, \tag{26}$$

where

$$\mathbf{C}_{\text{miscenter}} = \begin{bmatrix} 1 & \delta_y & \delta_x \\ 0 & 1 & 0 \\ 0 & 0 & 1 \end{bmatrix}^{-1}.$$
 (27)

2.3.3 Writing down the sensing matrix explicitly

Now, the sensing matrix

$$\mathbf{C}_{\text{sensing}} = \mathbf{C}_{\text{miscenter}} \mathbf{C}_{\text{align}} \mathbf{C}_{\text{rotation}} \tag{28}$$

is a 3×4 matrix with no zero element, as in, includes all longitudinal-to-pitch, longitudinal-to-yaw, pitch-to-longidinal, pitch-to-yaw, yaw-to-longitudinal, and yaw-to-pitch cross-couplings. And, it provides a correct calibration from beam spot displacements at the tilt-sensing and length-sensing QPDs to the suspended optics' longitudinal displacement, pitch angle, and yaw angle. And, in fact, Eqn. (26) is the most general sensing matrix for an optical

lever setup in KAGRA. To write down the sensing matrix explicitly, we have

$$\mathbf{C}_{\text{sensing}} = \begin{pmatrix} \begin{bmatrix} \cos \phi_{\text{tilt}} & -\sin \phi_{\text{tilt}} & 0 & 0 \\ \sin \phi_{\text{tilt}} & \cos \phi_{\text{tilt}} & 0 & 0 \\ 0 & 0 & \cos \phi_{\text{len}} & -\sin \phi_{\text{len}} \\ 0 & 0 & \sin \phi_{\text{len}} & \cos \phi_{\text{len}} \end{bmatrix} \\ \begin{bmatrix} 2\sin \alpha_h & 0 & 2r_h \\ 2\sin \alpha_v & 2r_v & 0 \\ 2\sin \alpha_h \left(1 - \frac{d_h}{f}\right) & 0 & 2\left[\left(1 - \frac{d_h}{f}\right)r_{\text{lens},h} + d_h\right] \\ 2\sin \alpha_v \left(1 - \frac{d_v}{f}\right) & 2\left[\left(1 - \frac{d_v}{f}\right)r_{\text{lens},v} + d_v\right] & 0 \end{bmatrix} \begin{bmatrix} 1 & \delta_y & \delta_x \\ 0 & 1 & 0 \\ 0 & 0 & 1 \end{bmatrix} \end{pmatrix}^+. (29)$$

2.3.4 Length-sensing QPD misplacement

In this section, we will discuss angle-to-longitudinal cross-coupling due to a misplaced length-sensing QPD. This section is not as important since we add nothing to Sec. 2.3.3. Instead, we will discuss a degenerating angle-to-longitudinal coupling mechanism, that cannot be distinguished from that in Sec. 2.3.2.

In Sec. 2.3.2, we discussed an angle-to-longitudinal cross-coupling mechanism due to a miscentered beam. But, this is not the only way angular displacements can be cross-coupled to longitudinal readout. If fact, as we have already seen in Sec. 2.2, the length-sensing QPD readouts is only decoupled from pitch or yaw, when placed at a particular point. In particular, for a horizontal or vertical optical lever setup, we need to place the length-sensing QPD at

$$d = \frac{r_{\text{lens}}f}{r_{\text{lens}} - f} \tag{30}$$

behind the lens for a horizontal or vertical optical lever setup, so there exists axis x'_{len} (horizontal optical lever) or y'_{len} (vertical optical lever) that only reads longitudinal displacement. How can we place it so exactly at that point? The answer is we can't. Tradition wisdom says that we can do so by exciting yaw or pitch resonance and then adjust the position of the length-sensing QPD to minimize it. Even if we can excite the optics in pure yaw or pitch resonance, minimizing the coupling is not the correct thing to do. This is because we expect to see some angular-to-longitudinal cross-couplings due to a miscentered beam, as discussed in Sec. 2.3.2! Unless we know exactly how is the beam miscentered, there's no way to finely adjust the position of the length-sensing QPD. Therefore, we must expect some misalignment, say we placed the length-sensing QPD at

$$d_{\text{misalign}} = d + \delta_d. \tag{31}$$

Consider a horizontal setup, in this case, the length-sensing QPD reads

$$x'_{\text{len}} = -\left(\frac{2f\sin\alpha_h}{r_{\text{lens}} - f}\right)x_L - \left(\frac{2\delta_d\sin\alpha_h}{f}\right)x_L - \left(\frac{2\delta_x f\sin\alpha_h}{r_{\text{lens}} - f}\right)\theta_Y - 2\delta_d\left(\frac{r_{\text{lens}} - f}{f}\right)\theta_Y.,\tag{32}$$

where the second term and the forth term are additional terms due to misplacement of the length-sensing QPD, and the third term is due to miscentering of the optical lever beam at the optics plane. There are two things we can infer from Eqn. 32. Firstly, the longitudinal displacement will be miscalibrated, if we don't know the misplacement δ_d . Secondly, we cannot estimate the misplacement δ_d , unless we know the beam spot offset δ_x , or vice-versa. But, as we shall see later, there's a chance that we can estimate δ_d by from the inter-calibration between the optical lever and the displacements from sensors of upper stages.

2.3.5 Horizontal optical lever (with misalignment)

Without further derivation, we can right the sensing matrix for a horizontal setup,

$$\begin{pmatrix} x_L \\ \theta_P \\ \theta_Y \end{pmatrix} = \mathbf{C}_{\text{sensing},h} \begin{pmatrix} x_{\text{tilt}} \\ y_{\text{tilt}} \\ x_{\text{len}} \\ y_{\text{len}} \end{pmatrix}, \tag{33}$$

where

where
$$\mathbf{C}_{\text{sensing},h} = \begin{bmatrix} 2\sin\alpha_h & 2\delta_y\sin\alpha_h & 2\delta_x\sin\alpha_h + 2r_h \\ 2\sin\alpha_v & 2\delta_y\sin\alpha_v + 2r_v & 2\delta_x\sin\alpha_v \\ \frac{-2f\sin\alpha_h}{r_{\text{lens}}-f} - \frac{2\delta_d\sin\alpha_h}{f} & \frac{-2f\delta_y\sin\alpha_h}{r_{\text{lens}}-f} & \frac{-2f\delta_x\sin\alpha_h}{r_{\text{lens}}-f} - 2\delta_d\left(\frac{r_{\text{lens}}-f}{f}\right) \end{bmatrix}^{-1} \\ \begin{bmatrix} \cos\phi_{\text{tilt}} & \sin\phi_{\text{tilt}} & 0 & 0 \\ -\sin\phi_{\text{tilt}} & \cos\phi_{\text{tilt}} & 0 & 0 \\ 0 & 0 & \cos\phi_{\text{len}} & \sin\phi_{\text{len}} \end{bmatrix}, \quad (34)$$

and we've further assumed a nonzero vertical angle of incidence α_v , as part of the misalignment. And again, for a horizontal setup, $r_h \approx r$, $r_v \approx r \cos \alpha_h$, $r_{\text{lens},h} \approx r_{\text{lens}}$, and that the length-sensing QPD is placed at $d_h \approx d = r_{\text{lens},h}$ $\frac{r_{\mathrm{lens}}f}{r_{\mathrm{lens}}-f}+\delta_d.$

Vertical optical lever (with misalignment)

Similarly, we can write the sensing matrix for a vertical setup,

$$\begin{pmatrix} x_L \\ \theta_P \\ \theta_Y \end{pmatrix} = \mathbf{C}_{\text{sensing},v} \begin{pmatrix} x_{\text{tilt}} \\ y_{\text{tilt}} \\ x_{\text{len}} \\ y_{\text{len}} \end{pmatrix}, \tag{35}$$

where

where
$$\mathbf{C}_{\text{sensing},v} = \begin{bmatrix} 2\sin\alpha_h & 2\delta_y\sin\alpha_h & 2\delta_x\sin\alpha_h + 2r_h \\ 2\sin\alpha_v & 2\delta_y\sin\alpha_v + 2r_v & 2\delta_x\sin\alpha_v \\ \frac{-2f\sin\alpha_h}{r_{\text{lens}} - f} - \frac{2\delta_d\sin\alpha_h}{f} & \frac{-2f\delta_y\sin\alpha_h}{r_{\text{lens}} - f} & \frac{-2f\delta_x\sin\alpha_h}{r_{\text{lens}} - f} - 2\delta_d\left(\frac{r_{\text{lens}} - f}{f}\right) \end{bmatrix}^{-1} \begin{bmatrix} \cos\phi_{\text{tilt}} & \sin\phi_{\text{tilt}} & 0 & 0 \\ -\sin\phi_{\text{tilt}} & \cos\phi_{\text{tilt}} & 0 & 0 \\ 0 & 0 & -\sin\phi_{\text{len}} & \cos\phi_{\text{len}} \end{bmatrix}. \quad (36)$$

Note that Eqn. (34) and Eqn. (36) are not the same. The difference is in the rotational correction, i.e. the last row of the second matrix. And, for a vertical setup, $r_v \approx r$, $r_h \approx r \cos \alpha_v$, $r_{\mathrm{lens},v} \approx r_{\mathrm{lens}}$, and that the length-sensing QPD is placed at $d_v \approx d = \frac{r_{\text{lens}}f}{r_{\text{lens}}-f} + \delta_d$.

Misalignment summary

We have derived the sensing matrix Eqn. (26) for a general optical lever. We have included rotation misalignment, with tilt-sensing QPD and length-sensing QPD rotated by an amount of ϕ_{tilt} and ϕ_{len} , respectively, with respect to the "yaw-pitch" frame. We have also discussed the angle-to-longitudinal cross-coupling induced by with an optical lever beam offset by δ_x and δ_y horizontally and vertically, respectively, at the optics plane. We then discussed the effect of misplaced length-sensing QPD, by an amount of δ_d , which is the same as that of a miscentered beam. Lastly, we write down the sensing matrix with misalignment for a horizontal optical lever and vertical optical lever, in Eqn. (34) and Eqn. (36), respectively.

2.4Folded optical lever




Figure 7: A schematic of the folded optical lever setup in KAGRA.

3 Measuring the sensing matrix

References

- [1] Tak Lun Terrence Tsang. BS and SR TM optical lever (oplev) diagonalization matrix. https://gwdoc.icrr.u-tokyo.ac.jp/cgi-bin/private/DocDB/ShowDocument?docid=10189.
- [2] Wikipedia contributors. Ray transfer matrix analysis Wikipedia, the free encyclopedia. https://en.wikipedia.org/w/index.php?title=Ray_transfer_matrix_analysis&oldid=1018856234, 2021. [Online; accessed 27-April-2021].