LOAD BALANCING UNSTRUCTURED MESHES FOR MASSIVELY PARALLEL TRANSPORT SWEEPS

A Thesis

by

TAREK HABIB GHADDAR

Submitted to the Office of Graduate and Professional Studies of Texas A&M University in partial fulfillment of the requirements for the degree of

MASTER OF SCIENCE

Chair of Committee, Dr. Jean Ragusa
Committee Members, Dr. Jim Morel
Dr. Bojan Popov

Head of Department, Dr. Yassin Hassan

May 2016

Major Subject: Nuclear Engineering

Copyright 2016 Tarek Habib Ghaddar

ABSTRACT

Lorem ipsum dolor sit amet, consectetur adipiscing elit. Integer lectus quam, condimentum quis bibendum eu, sollicitudin eget lacus. Praesent non sodales odio. Class aptent taciti sociosqu ad litora torquent per conubia nostra, per inceptos himenaeos. Nulla ac luctus sapien. Morbi cursus sapien eget lorem fermentum hendrerit. Nam ac erat dui, in cursus velit. Vivamus hendrerit porttitor nisi, ut porttitor lorem volutpat eget. In ligula ligula, euismod ut condimentum sit amet, pulvinar sit amet diam. Pellentesque interdum, ipsum ullamcorper consequat dignissim, sem arcu egestas mauris, vitae interdum sem tortor ut ante. Nunc blandit laoreet nisi, non rutrum lorem hendrerit quis. Cras nunc diam, convallis et feugiat at, auctor id libero. Nunc facilisis massa eu eros imperdiet vestibulum. Vestibulum ante ipsum primis in faucibus orci luctus et ultrices posuere cubilia Curae; Donec non velit vitae tortor blandit semper.

Etiam vitae dolor nulla. Ut eros odio, rhoncus eget placerat vitae, elementum ac ante. Proin vitae odio eu nisl pharetra mattis. Pellentesque habitant morbi tristique senectus et netus et malesuada fames ac turpis egestas. Phasellus fermentum lacus consectetur neque consequat ullamcorper. Cras blandit urna non dui consequat molestie. Curabitur viverra nibh at nisi semper faucibus. Nam egestas mauris a enim dignissim nec consectetur tortor rutrum. Mauris at nisi in est luctus congue ut mattis est. Ut pretium, mi quis elementum cursus, ante eros suscipit ligula, ut porttitor elit leo sed turpis. Nam sed dui ligula.

ACKNOWLEDGEMENTS

Lorem ipsum dolor sit amet, consectetur adipiscing elit. Integer lectus quam, condimentum quis bibendum eu, sollicitudin eget lacus. Praesent non sodales odio. Class aptent taciti sociosqu ad litora torquent per conubia nostra, per inceptos himenaeos. Nulla ac luctus sapien. Morbi cursus sapien eget lorem fermentum hendrerit. Nam ac erat dui, in cursus velit. Vivamus hendrerit porttitor nisi, ut porttitor lorem volutpat eget. In ligula ligula, euismod ut condimentum sit amet, pulvinar sit amet diam. Pellentesque interdum, ipsum ullamcorper consequat dignissim, sem arcu egestas mauris, vitae interdum sem tortor ut ante. Nunc blandit laoreet nisi, non rutrum lorem hendrerit quis. Cras nunc diam, convallis et feugiat at, auctor id libero. Nunc facilisis massa eu eros imperdiet vestibulum. Vestibulum ante ipsum primis in faucibus orci luctus et ultrices posuere cubilia Curae; Donec non velit vitae tortor blandit semper.

Etiam vitae dolor nulla. Ut eros odio, rhoncus eget placerat vitae, elementum ac ante. Proin vitae odio eu nisl pharetra mattis. Pellentesque habitant morbi tristique senectus et netus et malesuada fames ac turpis egestas. Phasellus fermentum lacus consectetur neque consequat ullamcorper. Cras blandit urna non dui consequat molestie. Curabitur viverra nibh at nisi semper faucibus. Nam egestas mauris a enim dignissim nec consectetur tortor rutrum. Mauris at nisi in est luctus congue ut mattis est. Ut pretium, mi quis elementum cursus, ante eros suscipit ligula, ut porttitor elit leo sed turpis. Nam sed dui ligula.

NOMENCLATURE

B/CS Bryan/College Station

HSUS Humane Society of the United States

P Pressure

T Time

TVA Tennessee Valley Authority

TxDOT Texas Department of Transportation

This page is optional.

TABLE OF CONTENTS

Pa	.ge
ABSTRACT	ii
ACKNOWLEDGEMENTS	iii
NOMENCLATURE	iv
TABLE OF CONTENTS	v
LIST OF FIGURES	vi
LIST OF TABLES	vii
1. INTRODUCTION	1
1.1 Parallelization of Transport Sweeps	4 5
2. THE TRANSPORT EQUATION	

LIST OF FIGURES

FIGUR	E	Page
1.1	Three different partitioning schemes in 2D, from left to right: KBA, volumetric non-overloaded, and volumetric overloaded	6
2.1	A demonstration of a sweep on a structured and unstructured mesh	4
2.2	A task dependence graph of the unstructured mesh example in Fig. 2.1.	5

LIST OF TABLES

TABLE

INTRODUCTION

When running any massively parallel code, load balancing is a priority in order to achieve the best possible parallel efficiency. A load balanced problem has an equal number of degrees of freedom per processor. Load balancing is important in order to minimize idle time for all processors by equally distributing (as much as possible) the work each processor has to do.

The concepts and results presented in this thesis are used by PDT, Texas A&M University's massively parallel deterministic transport code. It is capable of multi-group simulations and employs discrete ordinates for angular discretization. PDT features steady-state, time-dependent, criticality, and depletion simulations. It solves the transport equation for neutron, thermal, gamma, coupled neutron-gamma, electron, and coupled electron-photon radiation. PDT has been shown to scale on logically Cartesian grids out to 750,000 cores. Logically Cartesian grids contain regular convex grid units that allow for vertex motion inside them, in order to conform to curved shapes.

The following are the since completed goals of the thesis:

- Implement unstructured meshing capability in PDT for 2D and 2D extruded problems.
- Generate unstructured mesh in parallel using the same partitioning scheme and number of processors as the sweep.
- Perform stitching between meshed subdomains to preserve interface continuity.
- Implement load balancing algorithm for unstructured meshes in PDT. A load balanced problem would be defined by f in the pseudocode, or the subset with the maximum number of cells, divided by the average number of cells per subset.
- Verify and test code to prove load balancing algorithm effectiveness.

• Show results of the parallel transport sweeps for benchmark problems.

1.1 Parallelization of Transport Sweeps

As mentioned in the previous section, a transport sweep is set up by overlaying a domain with a finite element mesh. The sweep then solves the transport equation cell by cell using a discontinuous finite element approach. The order of which cell to solve first is given by a task dependence graph, as shown in Fig. 2.2. The transport sweep can be solved in parallel in order to obtain the solution faster, as well as distribute the memory to many processors for memory intensive cases. In PDT, a transport sweep can be performed on a structured Cartesian mesh, and the work proposed utilizes transport sweeps on an unstructured mesh. Performing a transport sweep on an unstructured mesh presents two big challenges: performing a transport sweep on a massively parallel scale in an efficient manner and keeping non-concave sub-domains due to the nature of the transport sweeps on structured meshes. As part of previous efforts in PDT, researchers have come to outline three important properties for parallel sweeps.

A parallel sweep algorithm is defined by three properties[?]:

- partitioning: dividing the domain among available processors
- aggregation: grouping cells, directions, and energy groups into tasks
- scheduling: choosing which task to execute if more than one is available

The basic concepts of parallel transport sweeps, partitioning, aggregation, and scheduling, are most easily described in the context of a structured transport sweep. A structured transport sweep takes place on a Cartesian mesh. Furthermore, the work proposed utilizes aspects of the structured transport sweep.

If M is the number of angular directions per octant, G is the total number of energy groups, and N is the total number of cells, then the total fine grain work units is 8MGN.

The factor of 8 is present as M directions are swept for all 8 octants of the domain. The finest grain work unit is the calculation of a single direction and energy groups unknowns in a single cell, or $\psi_{m,g}$ for a single cell.

In a regular grid, we have the number of cells in each Cartesian direction: N_x, N_y, N_z . These cells are aggregated into "cellsets". If M is the total number of angular directions, G is the total number of energy groups, and N is the total number of cells, then the total fine grain work units is 8MGN. The factor of 8 is present as M directions are swept for all 8 octants of the domain. The finest grain work unit is the calculation of a single direction and energy groups unknowns in a single cell, or $\psi_{m,g}$ for a single cell.

Fine grain work units are aggregated into coarser-grained units called *tasks*. A few terms are defined that describe how each variable is aggregated.

- $A_x = \frac{N_x}{P_x}$, where N_x is the number of cells in x and P_x is the number of processors in x
- $A_y = \frac{N_y}{P_y}$, where N_y is the number of cells in y and P_y is the number of processors in y
- $N_g = \frac{G}{A_g}$
- $N_m = \frac{M}{A_m}$
- $N_k = \frac{N_z}{P_z A_z}$
- $N_k A_x A_y A_z = \frac{N_x N_y N_z}{P_x P_y P_z}$

It follows that each process owns N_k cell-sets (each of which is A_z planes of A_xA_y cells), $8N_m$ direction-sets, and N_g group-sets for a total of $8N_mN_gN_k$ tasks.

One task contains $A_x A_y A_z$ cells, A_m directions, and A_g groups. Equivalently, a task is the computation of one cellset, one groupset, and one angleset. One task takes a stage to complete. This is particularly important when comparing sweeps to the performance models.

Equation (1.1) approximately defines parallel sweep efficiency. This can be calculated for specific machinery and partitioning parameters by substituting in values calculated

using Eqs. (1.5), (1.6), and (1.7).

$$\varepsilon = \frac{T_{\text{task}} N_{\text{tasks}}}{[N_{\text{stages}}][T_{\text{task}} + T_{\text{comm}}]}$$

$$= \frac{1}{[1 + \frac{N_{\text{idle}}}{N_{\text{tasks}}}][1 + \frac{T_{\text{comm}}}{T_{\text{task}}}]}$$
(1.1)

Equations (1.2) and 1.3 show how T_{comm} and T_{task} are calculated:

$$T_{\text{comm}} = M_L T_{\text{latency}} + T_{\text{byte}} N_{\text{bytes}}$$
 (1.2)

$$T_{\text{task}} = A_x A_y A_z A_m A_g T_{\text{grind}}$$
 (1.3)

where T_{latency} is the message latency time, T_{byte} is the time required to send one byte of message, N_{bytes} is the total number of bytes of information that a processor must communicate to its downstream neighbors at each stage, and T_{grind} is the time it takes to compute a single cell, direction, and energy group. M_L is a latency parameter that is used to explore performance as a function of increased or decreased latency. If a high value of M_L is necessary for the model to match computational results, improvements should be made in code implementation.

1.1.1 KBA Partitioning for Structured Grids

Several parallel transport sweep codes use KBA partitioning in their sweeping, such as Denovo [?] and PARTISN [?]. The KBA partitioning scheme and algorithm was developed by Koch, Baker, and Alcouffe [?].

The KBA algorithm traditionally chooses $P_z = 1$, $A_m = 1$, $G = A_g = 1$, $A_x = N_x/P_x$, $A_y = N_y/P_y$, with A_z being the selectable number of z-planes to be aggregated into each task. With $N_k = N_z/A_z$, each processor performs $N_{\text{tasks}} = 8MN_k$ tasks. With the KBA algorithm, $2MN_k$ tasks are pipelined from a given corner of the 2D processor layout. The far corner

processor remains idle for the first $P_x + P_y - 2$ stages, which means that an octant-pair (or quadrant) sweep completes in $2MN_k + P_x + P_y - 2$ stages. If an octant-pair sweep does not begin until the previous pair's finishes, the full sweep requires $8MN_k + 4(P_x + P_y - 2)$ stages, which means the KBA parallel efficiency is:

$$\varepsilon_{KBA} = \frac{1}{\left[1 + \frac{4(P_x + P_y - 2)}{8MN_k}\right]\left[1 + \frac{T_{\text{comm}}}{T_{\text{rask}}}\right]}$$
(1.4)

1.1.2 The Structured Transport Sweep in PDT

The minimum possible number of stages for given partitioning parameters P_i and A_j is $2N_{\text{fill}} + N_{\text{tasks}}$. N_{fill} is both the minimum number of stages before a sweepfront can reach the center-most processors and the number needed to finish a direction's sweep after the center-most processors have finished. Equations (1.5), (1.6), and (1.7) define N_{fill} , N_{idle} , and N_{tasks} :

$$N_{\text{fill}} = \frac{P_x + \delta_x}{2} - 1 + \frac{P_y + \delta_y}{2} - 1 + N_k \left(\frac{P_z + \delta_z}{2} - 1\right)$$
 (1.5)

$$N_{\text{idle}} = 2N_{\text{fill}} \tag{1.6}$$

$$N_{\text{tasks}} = 8N_m N_{\varrho} N_k \tag{1.7}$$

where δ_u is 1 for P_u odd, and 0 for P_u even.

Figure 1.1 shows three different partitioning schemes used in transport sweeps, KBA (which is defined in the previous section), volumetric non-overloaded, and volumetric overloaded. Volumetric non-overloaded requires that all cells owned by a processor are contiguous, where as volumetric non-overloaded partitioning does not have this restriction.

9	10	11	12	13	14	15	16	44	12	15	16	11	12	11	12	15	16	15	16
	10							11				9	10						
	10							9	10	13	14								16
9	10	11	12	13	14	15	16	9				9							14
	2							2	4	7	8	3							8
1	2	3	4	5	6	7	8	3				1	2	1	2	5	6	5	6
	2							4	2	5	6	3							8
1	2	3	4	5	6	7	8	'				1	2	1	2	5	6	5	6

Figure 1.1: Three different partitioning schemes in 2D, from left to right: KBA, volumetric non-overloaded, and volumetric overloaded.

The overloaded volumetric partitioning proceeds as follows:

- 1. In a 2D (3D) domain, cellsets are divided into 4 (8) spatial quadrants (octants), with an equal number of cellsets in each SQO (SQO is defined as a spatial quadrant or octant).
- 2. Assign 1/4 of the processors (1/8) in 3D to each SQO.
- 3. Choose the individual overload factors ω_x , ω_y , and ω_z and individual processor counts P_x , P_y , and P_z , such that $\omega_x \omega_y \omega_z = \omega_r$ and $P_x P_y P_z = P$, with all P_u even. ω_u is defined as the number of cellsets assigned to each P_u .
- 4. An array of $\omega_x \cdot \omega_y \cdot \omega_z$ "tiles" in each SQO. Each tile is an array of $1/2P_x \cdot 1/2P_y \cdot 1/2P_z$ cellsets. These cellsets are mapped one-to-one to the $1/2P_x \cdot 1/2P_y \cdot 1/2P_z$ processors assigned to the SQO, using the same mapping in each tile.

Each tile has a logically identical layout of cellsets, and each processor owns exactly one cellset in each tile in its SQO. This makes each processor responsible for ω_r cellsets.

In order to properly outline the optimal scheduling rules, the variables X, Y, and Z are defined as $P_u/2$ for each respective direction u = x, y, z. This splits up the processor layout into octants, where each processor has an index (i, j, k) determining where it is in the layout. Tiles are also indexed and referred to in the same way with the notation T(i, j, k).

The optimal scheduling algorithm rules are as follows:

- 1. If $i \le X$, then tasks with $\Omega_x > 0$ have priority, while for i > X, tasks with $\Omega_x < 0$ have priority.
- 2. If multiple ready tasks have the same sign on Ω_x , apply rule 1 to j, Y, Ω_y .
- 3. If multiple ready tasks have the same sign on Ω_x and Ω_y , apply rule 1 to k, Z, Ω_z .
- 4. If multiple tasks are ready in the same octant, then priority goes to the cellset for which the priority octant has greatest downstream depth.
- 5. If multiple ready tasks are in the same octant and have the same downstream depth of graph in x, then priority goes to the cellset for which the priority octant has greatest downstream depth of graph in y.
- 6. If multiple ready tasks are in the same octant and have the same downstream depth of graph in x and y, then priority goes to the cellset for which priority octant has greatest depth of graph in z.

This ensures that each SQO orders the octants: the one it can start right away (A), three that have one sign difference from A(B,C, and D), three that have two sign differences $(\bar{D},\bar{C},\bar{B})$, and one in opposition to its primary (\bar{A}) . For example, if octant A is octant (+x,+y,+z), then it's secondary octants (only one sign change at a time) would be octants (-x,+y,+z), (+x,-y,+z) and (+x,+y,-z).

There are three constraints in order to achieve the optimal stage count. In these constraints, $M = \omega_g \omega_m / 8$, which is the number of tasks per octant per cellset.

- 1. $M \ge 2(Z-1)$
- 2. $\omega_z M \ge 2(Y-1)$
- 3. If $\omega_x > 1$, then $\omega_y \omega_z M \ge X$

Constraint 1 ensures that there is no idle time between a processor finishing an octant's work in one tile and beginning that octant's work on the next tile in the same tile-column; processor P(1,Y,1) finishing its tile $T(1,\omega_y,1)$ octant C work and beginning its octant B work; processor P(X,1,1) finishing its tile $T(\omega_x,1,1)$ octant D work and beginning its

octant B work. Constraint 2 ensures that there is no idle time time between a processor finishing an octant's work for one z column of tiles and beginning that octant's work on the next column; processor P(X,1,1) finishing its tile $T(\omega_x,1,1)$ octant D work available to it and beginning its octant C work. Constraint 3 ensures that there is no idle time between a processor finishing an octant's work for one yz plane of tiles and beginning that octant's work in the next plane.

As a result of these constraints, there is no idle time for a variety of situtations. At large processor counts, the product $\omega_m \omega_g$ must be large, which requires $N_m N_g$ be large. This means that a weak scaling series refined only in space, but only coarsely refined in angle and energy, will eventually fail the constraints.

The optimal efficiency formula changes slightly from the KBA and hybrid KBA partitioning method in order to account for the overload factors. The only change is in the $\frac{N_{idle}}{N_{tasks}}$ term, as shown in Eq. (1.8).

$$\varepsilon_{opt} = \frac{1}{\left[1 + \frac{P_x + P_y + P_z - 6}{\omega_g \omega_m \omega_r}\right] \left[1 + \frac{T_{\text{comm}}}{T_{\text{task}}}\right]}$$
(1.8)

1.1.3 The Unstructured Transport Sweep

In an unstructured mesh, the number of cells cannot be described in the same way as an unstructured mesh. In PDT specifically we initially subdivide the domain into subsets, which are just rectangular subdomains. Within each subset, an unstructured mesh is created. This creates a pseudo-regular grid. These subsets become the N_x, N_y, N_z equivalent for an unstructured mesh. The spatial aggregation in a PDT unstructured mesh is done by aggregating subsets into cellsets.

While the structured PDT transport sweep has scaled well out to 750,000 cores, similar levels of parallel scaling have not been achieved using unstructured sweeps yet. Pautz

proposed a new list scheduling algorithm has been constructed for modest levels of parallelism (up to 126 processors)[?].

There are three requirements for a sweep scheduling algorithm to have. First, the algorithm should have low complexity, since millions of individual tasks are swept over in a typical problem. Second, the algorithm should schedule on a set of processors that is small in comparison to the number of tasks in the sweep graph. Last, the algorithm should distribute work in the spatial dimension only, so that there is no need to communicate during the calculation of the scattering source.

Here is the pseudocode for the algorithm:

Assign priorities to every cell-angle pair

Place all initially ready tasks in priority queue

While (uncompleted tasks)

For i=1,maxCellsPerStep

Perform task at top of priority queue
Place new on-processor tasks in queue
Send new partition boundary data
Receive new partition boundary data
Place new tasks in queue

An important part of the algorithm above is the assigning priorities to tasks. Specialized prioritization heuristics generate partition boundary data as rapidly as possible in order to minimize the processor idle time.

Nearly linear speedups were obtained on up to 126 processors. Further work is being done for scaling to thousands of processors.

1.1.3.1 Cycle Detection

A cycle is a loop in a directed graph and they can occur commonly in unstructured meshes. However, they do not exist in 2D triangular extruded problems and, because our domain partitioning is convex, arbitrary degenerate polygons appearing on subdomain boundaries will not produce cycles. Even though they are not applicable to this application of unstructured transport sweeps, they are discussed here for completeness.

Cycles can cause hang time in the problem, as a processor will wait for a message that might will never come. This means that the computation for one or more elements will never be completed. The solution to this is to "break" any cycles that exist by removing an edge of the task dependence graph (TDG). Old flux information is used on a particular element face in the domain. Most of the time, the edge removed is oriented obliquely with respect to the radiation direction.

Algorithms for finding cycles are called *cycle detection* algorithms. This must be done efficiently in parallel, both because the task dependence graph is distributed and because the finite element grid may be deforming every timestep and changing the associated TDG.

Cycle detection utilizes two operations: trim and mark. Trimming identifies and discards elements which are not in cycles. At the beginning of cycle detection, graphs are trimmed in the downwind direction, then the remaining graphs are trimmed in the upwind direction. A pivot vertex is then selected in each graph. Graph vertices are then marked as upwind, downwind, or unmarked. Then, if any vertices are both upwind and downwind, the cycle is these vertices plus the pivot vertex. An edge is removed between 2 cycle vertices, and 4 new graphs are created: a new cycle, the upwind vertices without the cycle, the downwind vertices without the cycle, and a set of unmarked vertices. This recursively continues until all cycles are eliminated.

2. THE TRANSPORT EQUATION

The steady-state neutron transport equation describes the behavior of neutrons in a medium and is given by Eq. (2.1):

$$\vec{\Omega} \cdot \vec{\nabla} \psi(\vec{r}, E, \vec{\Omega}) + \Sigma_t(\vec{r}, E) \psi(\vec{r}, E, \vec{\Omega}) = \int_0^\infty dE' \int_{4\pi} d\Omega' \Sigma_s(\vec{r}, E' \to E, \Omega' \to \Omega) \psi(\vec{r}, E', \vec{\Omega}') + S_{ext}(\vec{r}, E, \vec{\Omega}),$$
(2.1)

where $\vec{\Omega} \cdot \vec{\nabla} \psi$ is the leakage term and $\Sigma_t \psi$ is the total collision term (absorption, outscatter, and within group scattering). These are the loss terms of the neutron transport equation. The right hand side of Eq. (2.1) represents the gain terms, where S_{ext} is the external source of neutrons and $\int_0^\infty dE' \int_{4\pi} d\Omega' \Sigma_s(E' \to E, \Omega' \to \Omega) \psi(\vec{r}, E', \vec{\Omega}')$ is the inscatter term, which represents all neutrons scattering from energy E' and direction $\vec{\Omega}'$ into energy dE about energy E and $d\Omega$ about direction $\vec{\Omega}$.

Without loss of generality for the research problem at hand, we assume isotropic scattering for simplicity. The double differential scattering cross section, $\Sigma_s(E' \to E, \Omega' \to \Omega)$, no longer depends on direction and is divided by 4π to reflect isotropic behavior. This yields:

$$\vec{\Omega} \cdot \vec{\nabla} \psi(\vec{r}, E, \vec{\Omega}) + \Sigma_{t}(\vec{r}, E) \psi(\vec{r}, E, \vec{\Omega}) = \frac{1}{4\pi} \int_{0}^{\infty} dE' \Sigma_{s}(\vec{r}, E' \to E) \int_{4\pi} d\Omega' \psi(\vec{r}, E', \vec{\Omega}') + S_{ext}(\vec{r}, E, \vec{\Omega})$$

$$= \frac{1}{4\pi} \int_{0}^{\infty} dE' \Sigma_{s}(\vec{r}, E' \to E) \phi(\vec{r}, E') + S_{ext}(\vec{r}, E, \vec{\Omega}),$$
(2.2)

where we have introduced the scalar flux as the integral of the angular flux:

$$\phi(\vec{r}, E') = \int_{4\pi} d\Omega' \psi(\vec{r}, E', \vec{\Omega}'). \tag{2.3}$$

The next step to solving the transport equation is to discretize in energy, yielding Eq. (2.4) the multigroup transport equation:

$$\vec{\Omega} \cdot \vec{\nabla} \psi_g(\vec{r}, \vec{\Omega}) + \Sigma_{t,g}(\vec{r}) \psi_g(\vec{r}, \vec{\Omega}) = \frac{1}{4\pi} \sum_{g'} \Sigma_{s,g' \to g}(\vec{r}) \phi_{g'}(\vec{r}) + S_{ext,g}(\vec{r}, \vec{\Omega}), \quad \text{for } 1 \le g \le G$$

$$(2.4)$$

where the multigroup transport equations now form a system of coupled equations.

Next, we discretize in angle using the discrete ordinates method[?], whereby an angular quadrature $(\vec{\Omega}_m, w_m)_{1 \le m \le M}$ is used to solve the above equations along a given set of directions $\vec{\Omega}_m$:

$$\vec{\Omega}_{m} \cdot \vec{\nabla} \psi_{g,m}(\vec{r}) + \Sigma_{t,g}(\vec{r}) \psi_{g,m}(\vec{r}) = \frac{1}{4\pi} \sum_{g'} \Sigma_{s,g' \to g}(\vec{r}) \phi_{g'}(\vec{r}) + S_{ext,g,m}(\vec{r}), \qquad (2.5)$$

where the subscript m is introduced to describe the angular flux in direction m. We notice that the subscript is not added to our inscatter term because of the isotropic scattering assumption and because the scalar flux does not depend on angle. However, in order to evaluate the scalar flux, we employ the angular weights w_m and the angular flux solutions ψ_m to numerically perform the angular integration:

$$\phi_g(\vec{r}) \approx \sum_{m=1}^{m=M} w_m \psi_{g,m}(\vec{r}). \tag{2.6}$$

From Equation (2.4), it is clear that we are solving a sequence of transport equations, one equation per group. Therefore, all transport equations are of the following form:

$$\vec{\Omega}_m \cdot \vec{\nabla} \psi_m(\vec{r}) + \Sigma_t(\vec{r}) \psi_m(\vec{r}) = \frac{1}{4\pi} \Sigma_s(\vec{r}) \phi(\vec{r}) + q_m^{ext+inscat}(\vec{r}) = q_m(\vec{r}), \qquad (2.7)$$

where the group index notation is omitted for brevity.

In order to obtain the solution for this discrete form of the transport equation, an iter-

ative process called source iteration is introduced. This is shown by a simplified transport equation Eq. (2.8):

$$\vec{\Omega}_m \cdot \vec{\nabla} \psi_m^{(l+1)}(\vec{r}) + \Sigma_t \psi_m^{(l+1)}(\vec{r}) = q_m^{(l)}(\vec{r}), \tag{2.8}$$

where the right hand side terms of Eq. (2.5) have been combined into one general source term, q_m . The angular flux of iteration (l+1) is calculated using the (l^{th}) value of the scalar flux.

After the angular and energy dependence have been accounted for, Eq. (2.8) must be discretized in space as well. This is done by meshing the domain and solving the spatial problem one cell at a time for a given direction. The solution across a cell interface is connected based on an upwind approach, where face outflow radiation becomes face inflow radiation for the downwind cells. Sweeping the mesh and solving one cell at a time is possible utilizing one of three popular discretization techniques: finite difference[?], finite volume[?], or discontinuous finite element[?]. Figure 2.1 shows the sweep ordering for a given direction on both a structured and unstructured mesh.




Figure 2.1: A demonstration of a sweep on a structured and unstructured mesh.

The number in each cell represents the order in which the cells are solved. All cells must receive the solution downwind from them before solving for their own solution. This dependency can be represented and stored as a task dependence graph, shown in Fig. 2.2.




Figure 2.2: A task dependence graph of the unstructured mesh example in Fig. 2.1.

fix spacing in bibliography, if any...