

Hot-removing storage from a MetroCluster FC configuration

ONTAP MetroCluster

netapp-ivanad, ntap-bmegan April 12, 2021

Table of Contents

Hot-removing storage from a Me	etroCluster FC configuration	
3 3		

Hot-removing storage from a MetroCluster FC configuration

You can hot-remove drive shelves—physically remove shelves that have had the aggregates removed from the drives—from a MetroCluster FC configuration that is up and serving data. You can hot-remove one or more shelves from anywhere within a stack of shelves or remove a stack of shelves.

- Your system must be a multipath HA, multipath, quad-path HA, or quad-path configuration.
- In a four-node MetroCluster FC configuration, the local HA pair cannot be in a takeover state.
- · You must have already removed all aggregates from the drives in the shelves that you are removing.



If you attempt this procedure on non-MetroCluster FC configurations with aggregates on the shelf you are removing, you could cause the system to fail with a multidrive panic.

Removing aggregates involves splitting the mirrored aggregates on the shelves you are removing, and then re-creating the mirrored aggregates with another set of drives.

Disk and aggregate management

 You must have removed drive ownership after removing the aggregates from the drives in the shelves that you are removing.

Disk and aggregate management

• If you are removing one or more shelves from within a stack, you must have factored the distance to bypass the shelves that you are removing.

If the current cables are not long enough, you need to have longer cables available.

This task applies to the following MetroCluster FC configurations:

- Direct-attached MetroCluster FC configurations, in which the storage shelves are directly connected to the storage controllers with SAS cables
- Fabric-attached or bridge-attached MetroCluster FC configurations, in which the storage shelves are connected using FC-to-SAS bridges

Steps

- 1. Verify the operation of the MetroCluster configuration in ONTAP:
 - a. Check whether the system is multipathed:
 node run -node node-name sysconfig -a
 - b. Check for any health alerts on both clusters:

```
system health alert show
```

c. Confirm the MetroCluster configuration and that the operational mode is normal:

```
metrocluster show
```

d. Perform a MetroCluster check:

metrocluster check run

e. Display the results of the MetroCluster check:

metrocluster check show

f. Check for any health alerts on the switches (if present):

storage switch show

g. Run Config Advisor.

NetApp Downloads: Config Advisor

- h. After running Config Advisor, review the tool's output and follow the recommendations in the output to address any issues discovered.
- 2. Set the privilege level to advanced:

set -privilege advanced

- 3. Verify that no mailbox drive is on the shelves: storage failover mailbox-disk show
- 4. Remove the shelf according to the steps for the relevant scenario.

Scenario	Steps
To remove an aggregate when the shelf contains either unmirrored, mirrored, or both types of aggregate	
	b. Use the standard procedure to remove ownership of all drives in that shelf, and then physically remove the shelf.
	Follow the instructions in the SAS Disk Shelves Service Guide for your shelf model to hot-remove shelves.

To remove a plex from a mirrored aggregate, you need to unmirror the aggregate.

a. Identify the plex that you want to remove by using the run -node local sysconfig -r command.

In the following example, you can identify the plex from the line Plex /dpg_mcc_8020_13_a1_aggr1/plex0. In this case, the plex to specify is plex0.

```
dpgmcc 8020 13 a1a2::storage
aggregate> run -node local
sysconfig -r
*** This system has taken over
dpg-mcc-8020-13-a1
Aggregate
dpg_mcc_8020_13_a1_aggr1
(online, raid dp, mirrored)
(block checksums)
 Plex
/dpg_mcc_8020_13_a1_aggr1/plex
O (online, normal, active,
pool0)
   RAID group
/dpg_mcc_8020_13_a1_aggr1/plex
0/rg0 (normal, block
checksums)
     RAID Disk Device
HA SHELF BAY CHAN Pool Type
RPM Used (MB/blks)
(MB/blks)
_____
     dparity mcc-cisco-8Gb-
fab-2:1-1.126L16 0c
                       32 15
FC:B 0 SAS 15000
272000/557056000
274845/562884296
     parity mcc-cisco-8Gb-
fab-2:1-1.126L18 Oc
                       32 17
FC:B 0 SAS 15000
272000/557056000
274845/562884296
     data mcc-cisco-8Gb-
fab-2:1-1.126L19 0c
                       32 18
FC:B 0 SAS 15000
```

272000/557056000

Copyright Information

Copyright © 2021 NetApp, Inc. All rights reserved. Printed in the 4.8.5 No part of this document covered by copyright may be reproduced in any form or by any means-graphic, delectronic, ommechanical, and uding photocopying, recording, taping, or storage in an electronic retrieval system without prior written permission of the copyright owner.

FC:B

O

SAS 15000

Software derived from copyrighted NetApp material is subject to the following license and disclaimer:

THIS SOFTWARE IS PROVIDED BY NETAPP "AS IS" AND WITHOUT ANY EXPRESS OF MERCHANTABILITY WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, WHICH ARE HEREBY DISCLAIMED, IN NO EVENT SHALL NETAPP BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS NATERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE 8020 13 at aggr1/plex

NetApp reserves the right to change any products described herein at any time, and without notice. NetApp assumes no responsibility or liability arising from the use of products described herein, except as expressly agreed to in writing by NetApp. The use or purchase of this product does not wonvey a license under any patent rights, trademark rights, or any other intellectual property rights of NetApp 0 13 al aggr1/plex

The product described in this manual may be protected by one or more U.S. patents, foreign patents, or pending applications.

RESTRICTED RIGHTS LEGEND: Use, duplication, or disclosure by the overhine it is subject to restrictions as set forth in subparagraph (c)(1)(ii) of the Rights in Technical Data and Computer Software clause at DFARS 252.277-7103 (October 1988) and FAR 52-227-19 (June 1987). RPM Used (MB/blks) Phys

Trademark Information

NETAPP, the NETAPP logo, and the marks listed at http://www.netapp.com/TM are trademarks of NetApp, Inc. Other company and product names may be trademarks of their respective owners. ----

dparity mcc-cisco-8Gb-

fab-3:1-1.126L37 Od 34 10

FC:A 1 SAS 15000

272000/557056000

(MB/blks)

274845/562884296

280104/573653840

parity mcc-cisco-8Gb-

fab-3:1-1.126L14 Od 33 13

FC:A 1 SAS 15000

272000/557056000

280104/573653840

data mcc-cisco-8Gb-

fab-3:1-1.126L41 Od 34 14

FC:A 1 SAS 15000

272000/557056000 280104/573653840

> data mcc-cisco-8Gbo-3:1-1.126L15 0d 33 14

fab-3:1-1.126L15 0d FC:A 1 SAS 15000

272000/557056000

4

280104/573653840 data mcc-cisco-8Gbfab-3:1-1.126L45 0d 34 18 FC:A 1 SAS 15000 272000/557056000 280104/573653840

b. Use the storage aggregate plex delete
-aggregate aggr_name -plex
plex name command to remove the plex.

plex defines the plex name, such as plex3 or plex6.

c. Use the standard procedure to remove ownership of all drives in that shelf, and then physically remove the shelf.

Follow the instructions in the SAS Disk Shelves Service Guide for your shelf model to hotremove shelves.