Relative Hz difference of PSDS - LTD (i.e. $|f_{PSDS}(t) - f_{LTD}(t)| \times 60$ Hz)

 $\Delta\omega = 1 - \omega$

$$\dot{\omega}_{sys} = \frac{1}{2H_{sys}} \left(\frac{P_{acc,sys}}{\omega_{sys}(t)} - D_{sys} \Delta \omega_{sys}(t) \right)$$

ACE Conventions: Positive ACE denotes over generation. B (the frequency bias) is negative.

$$ACE_{tie\ line} = P_{gen} - P_{load} - P_{sched\ interchange}$$

$$ACE_{frequency\ bias} = 10B(f_{actual} - f_{sched})f_{base}$$

$$ACE = ACE_{tie\ line} - ACE_{frequency\ bias}$$

One way to think of deviation plots is $LTD_{data} + Deviation_{data} = PSDS_{data}$. (Assuming all time step issues are handled appropriately.)

$$\%_{diff} = \frac{|x - y|}{\frac{x + y}{2}} * 100\%$$

Distribution of accelerating power based on inertia:

$$P_{e,i}(t) = P_{e,i}(t-1) - \Delta P_{acc,sys}(t) \frac{H_i}{H_{sus}}$$

The theoretical steady state frequency was calculated as

$$f_{ss} = f_{ref} + \Delta f = f_{ref} + \frac{\Delta P}{S_{base}\beta} \tag{1}$$

When R is a Pu value, β for N governor equipped machines is calculated as

$$\beta = \sum_{i=1}^{N} \frac{1}{R_i \frac{S_{\text{Base}}}{M_{\text{Base}}}} \tag{2}$$

Additionally, in a system with N generators, the weighted system frequency, f_w , is calculated as

$$f_w \text{ Pu} = \sum_{i=1}^{N} \frac{f_i}{f_{\text{Base}}} \frac{H_i M_{\text{Base}_i}}{H_{\text{sys}}}$$
 (3)

where
$$H_{\text{sys}} = \sum_{i=1}^{N} H_i M_{\text{Base}_i}$$
 (4)

If IACE is to be added using the weight option:

$$ACE = ACE * (1 - IACEweight) + IACE * IACEweight * IACEscale$$

Else:

$$ACE = ACE + IACE * IACEscale$$