Step Controller / Perturbance

- Control Action: Change any settable quantity on any controllable device existing in the power-flow base case.
- Basic Requirements
 - 1. Value changes by %, absolute, or relative to original value.
 - 2. Time input: start time
- State change Requirements
 - 1. Generator inertia must be handled correctly
 - 2. Starting Generator Mechanical power should be definable.
- Examples
 - 1. Step load up 5% at t_1
 - 2. Open branch at t_1
 - 3. Increase P_M by 25 MW at t_1

Ramp Controller / Perturbance

- Control Action: Change any non-binary settable quantity on any controllable device existing in the power-flow base case.
- Basic Requirements
 - 1. Value changes by %, absolute, or relative to original value.
 - 2. Time inputs: start time, ramp A time, hold time, ramp B time
 - 3. NOTE: For single ramp operation, hold time and ramp B time are zero.
- Examples
 - 1. Ramp $P_M + 5\%$ at t_1 over t_2 seconds
 - 2. Ramp P_{ref} to 60 MW from t_1 to t_2 , hold for t_3 seconds, then ramp down 5 MW over t_4 seconds.

Definite Time Controller (DTC)

- Will be defined in a .dtc file to allow for easier integration into simulation.
- Control Action: Change the status bit on any controllable device(s) existing in the power-flow base case based on any other value in the system.
- Basic Requirements
 - Binary or 'Analog' settable reference input(s) (bus voltage, MW output, system frequency ...)
 - 2. Threshold inputs: set level L_S (turn on), reset level L_R (turn off)
 - 3. Time inputs: set time (time $\pm L_S$ before turning on), reset time (time $\mp L_R$ before turning off), reclose time (time required after a reset before a set can be performed)
 - 4. NOTE: reclose time can be set to zero, but will only act on next time step.
- Feature Requests
 - 1. Ability to add custom control law
 - 2. Ability to use arbitrary Inputs
 - 3. Ability to trigger Steps or Ramps (?)
- Basic Example: Using a voltage sensitive base case with an available shunt cap; ramp real power of a load. When bus voltage at the cap drops below 0.95 PU for 30 seconds, insert cap.
- Advanced Example: Using a voltage sensitive base case with a wind power plant (WWP) and an available shunt cap on the low side of the WPP transformer; ramp WPP up and commensurate hydro down. When WPP high-side voltage drops below 0.95 for 30 seconds **AND** WPP MW export is positive, insert cap.

Capacitor Group (Cap Bank)

- \approx A DTC with multiple cap references.
- Control Action: Change status bit(s) on a finite set of shunt capacitors existing in the power-flow base case.
- Basic Requirements
 - 1. Group can have a variable amount of capacitors.
 - 2. Capacitor status controllable via bus voltage.
 - 3. Order of Caps switched in can be defined.
- Feature Requests
 - 1. Ability to add custom control law
 - 2. Ability to use arbitrary Inputs
- Example
 - 1. Starting with a voltage sensitive base case, ramp real power on a load in a region where two or more shunt caps are available. When reference bus voltage for the cap group drops below 0.95 for 30 seconds, insert one of the available caps. Wait n_1 seconds. If voltage still below 0.95 insert additional cap.

Generator Group (Discrete Power Plant)

- \approx A DTC with multiple generator references.
- Control Action: Change status bit(s) and total P_{gen} on a finite set of generators existing in the power-flow base case.
- Basic Requirements
 - 1. Group can have a variable amount of generators.
 - 2. Generator status and P_{gen} controllable via P_{ref} value sent from scheduling controller.
 - 3. Ability to add custom control law.
- Feature Requests
 - 1. Ability to use arbitrary Inputs
- Examples
 - 1. Starting with any base case, ramp Pref and some load equally. When all generators in group are operating above 80%, bring on new generator and give some load (initial mechanical power).

Power Plant Agent

- Control Action: Change a single generator object in the base case such that it **acts** like multiple generators.
- Basic Requirements
 - 1. Change Pmax, Qmax, H, Pm, Pgen as appropriate ...
- Feature Requests
 - 1. Ability to add custom control law
 - 2. Ability to use arbitrary Inputs
- Examples
 - 1. Same as Generator Group Case
- May be easier to code in a separate file (the dtc file).

Automatic Generator Control

- Only one allowed per area
- Control Action: Change status bit(s) and total P_{gen} on a finite set of generators existing in the power-flow base case.
- Basic Requirements
 - 1. ACE calculated by:

$$ACE = \sum_{i=1}^{N} P_{gen_i} - \sum_{i=1}^{N} P_{load} - 10\beta\Delta\omega$$

(Or as a sum of station control error SCE)

- 2. Generator status and P_{gen} controllable via P_{ref} value sent from scheduling controller.
- 3. Ability to add custom control law
- Feature Requests
 - 1. Ability to use arbitrary Inputs
- Examples
 - 1. In a multi-area system where each area has a schedulted tie-lie flow, cause some kind of perturbance and allow AGC to act to eliminate ACE.