



Turtlebot 3 Connection



What are we going to use?









In Simulation

Run Docker Container

Access a new folder


cd <Folder name>

Check the files within a folder

Is

Command window comands

1	Access Docker folder	cd ros-2023-thd/
2	to access the docker environment	home/tcc/ros2_turtlebot3\$ bash run_docker.sh
3	to access a new tab in the docker environment	home/tcc/ros2_turtlebot3\$ bash into_docker.sh



Run turtlebot3 Gazebo simulation

Access a new folder

cd <Folder name>

Check the files within a folder

Is

Each commands should be run in a new terminal or new tab of the current terminal


to launch Simulation World (inside Docker)

/ws_slam# ros2 launch turtlebot3_gazebo
turtlebot3_world.launch.py


/ws_slam# ros2 launch turtlebot3_cartographer
cartographer.launch.py use_sim_time:=True

to launch a control Node
(inside Docker)

/ws_slam# ros2 run turtlebot3_teleop
teleop_keyboard



Windows after launching Gazebo and SLAM nodes



6

Control Turtlebot to create the map of World environment




Control Your Turtlebot3 Moving around

w asd x

w/x : increase/decrease linear velocity a/d : increase/decrease angular velocity

space key, s : force stop

CTRL-C to quit



Until the entire map is created

Save the map

Open a new terminal

ros2 run nav2_map_server map_saver_cli -f /ws_slam/map

Enjoy navigation

Close the SLAM node

CTRL + C


Run Navigation node

ros2 launch turtlebot3_navigation2 navigation2.launch.py use_sim_time:=True map:=/ws_slam/map.yaml

Estimate Initial Pose

The goal is to tell the Navigation node where the current pose of the robot on the map


- 1. Click the **2D Pose Estimate** button in the RViz2 menu
- 2.Click on the map where the actual robot is located and drag the large green arrow toward the direction where the robot is facing.



Estimate Initial Pose

The goal is to tell the Navigation node where the current pose of the robot on the map


3. Repeat step 1 and 2 until the LDS sensor data is overlayed on the saved map.



Set Navigation Goal

The goal is to tell the Navigation node where the destination is

- 1. Click the Navigation 2 Goal button in the RViz2 menu.
- 2.Click on the map to set the destination of the robot and drag the green arrow toward the direction where the robot will be facing.



Simulation ends

In real Arena







Connect PC to Turtlebot via Ethernet cable Configure Turtlebot to connect to WLAN











Connect your PC to "Access Point" and connect Turtlebot to the common "Access Point"



Check the Turtlebot's IP Address using the monitor (Slide 5)

turtlebot's_IP_Address

Network Configuration Get into Turtlebot via Ethernet cable

The goal is to configure Turtlebot to connect to WLAN

Before turning ON the Turtlebot

Connect

ETHERNET cable: Turtlebot to Laptop

Turn ON Turtlebot Turn OFF WLAN on Laptop






Network Configuration Get into Turtlebot via Ethernet cable

- 1. Click on the network icon in your system tray (on the upper top of the screen).
- 2. Select **Settings** → **Network**.
- 3. Choose your **Network** and click the **\$\pi\$** gear/settings button at the **Wired** section.
- 4. Go to the IPv4 tab.
 - Change the **Method** from Automatic (DHCP) to **Manual**.
 - Under **Addresses**, click Add and enter:
 - Address: 192.168.0.5
 - Netmask: 255.255.255.0
 - Gateway: 192.168.0.1
- 5. Click Apply, then disconnect and reconnect the wired connection.





Network Configuration Get into Turtlebot via Ethernet cable

The goal is to configure Turtlebot to connect to WLAN



Before turning ON the Turtlebot

Connect

ETHERNET cable: Turtlebot to Laptop





Turn ON Turtlebot
Turn OFF WLAN on Laptop

verify IP discovery

\$ ping 192.168.0.12

Until receive

PING 192.168.0.12 (192.168.0.12) 56(84) bytes of data. 64 bytes from 192.168.0.12: icmp_seq=1 ttl=117 time=5.92 ms 64 bytes from 192.168.0.12: icmp_seq=2 ttl=117 time=7.07 ms

••

get into Turtlebot via SSH

\$ ssh ubuntu@192.168.0.12

Login User

Username: ubuntu Password: turtlebot







Connect PC to Turtlebot via Ethernet cable Configure Turtlebot to connect to WLAN

WLAN: Tutututu

Password: 12345678Cham

open WLAN configuration via netplan Yaml file

ubuntu@192.168.0.12\$ sudo nano /etc/netplan/

press Tab

after modification save files and reboot

press Ctrl + S press Ctrl + X

ubuntu@192.168.0.12\$ sudo reboot

After rebooting, Get into Turtlebot one more time Check Turtlebot WLAN IP Address



ubuntu@192.168.0.12\$ ip a

2: wlan0: <BROADCAST, MULTICAST, UP, LOWER_UP> mtu 1500 qdisc noqueue state UP group default qlen 1000 link/ether AA:BB:CC:DD:EE:FF brd ff:ff:ff:ff:ff
inet 192.168.XXX.YYY/24 brd 192.168.XXX.255 scope global dynamic noprefixroute wlan0 valid_lft 53412sec preferred_lft 53412sec

Turtlebot3_IP_Address: 192.168.XXX.YYY

Connect LAPTOP to the same WLAN







WLAN: Tutututu


Password: 12345678Cham

DOMAIN ID in ROS2


ROS2 communication between Nodes requires them to be in the same **DOMAIN ID**.

Nodes could be either Robots or Computational Unit

The **DOMAIN ID** is used to compute the UDP ports that will be used for discovery and communication



Get into Turtlebot via WLAN using Turtlebot3 IP Address



verify IP discovery

\$ ping 192.168.XXX.YYY

Until receive

PING 192.168.0.12 (192.168.0.12) 56(84) bytes of data. 64 bytes from 192.168.0.12: icmp_seq=1 ttl=117 time=5.92 ms 64 bytes from 192.168.0.12: icmp_seq=2 ttl=117 time=7.07 ms

• •

get into Turtlebot via SSH

\$ ssh ubuntu@192.168.XXX.YYY

Login User

Username: ubuntu Password: turtlebot

Define ROS Domain ID in Turtlebot

\$ nano ~/.bashrc

A Note file will open

The following lines must be added for setting the communication

\$ source ~/.bashrc

After Saving and Closing, the file needs to be sourced

NOTE: Should be different from your colleagues

Define IP Addresses within Docker

\$ gedit ~/.bashrc

A Note file will open

The following lines must be added for the set communication

\$ export ROS_DOMAIN_ID=<Your_desired_ID>

\$ source ~/.bashrc

After Saving and Closing, the file needs to be sourced

NOTE: Should be different from your colleagues

Bringup Turtlebot

\$ ssh ubuntu@Turtlebot3_IP_Address Example: ssh ubuntu@198.168.122.18

The command window will show the next message

password: turtlebot

Then

ros2 launch turtlebot3_bringup robot.launch.py

SLAM and Navigation

Follow the same procedure as in Simulation from Page 4

DEGENDORF INSTITUTE OF TECHNOLOGY