
10a. Analog Out, a fading LED (for UNO)

PWM, short for Pulse Width Modulation, is a technique used to encode analog signal level into a digital one.

There are 6 PMW interfaces on an Arduino Uno: Digital pins 3, 5, 6, 9, 10, and 11, all are indicated with a ~ (tilde).

We will explore this PWM magic by changing the brightness of a LED over time.

Circuit



Code

```
void setup() {
 // nothing happens in setup
void loop() {
  // fade in from min to max in increments of ? points:
 for (int fadeValue = 0 ; fadeValue <= 255; fadeValue += fadeAmount) {</pre>
   // sets the value (range from 0 to 255):
   analogWrite(ledPin, fadeValue);
   // wait for 30 milliseconds to see the dimming effect
   delay(30);
 // fade out from max to min in increments of ? points:
 for (int fadeValue = 255 ; fadeValue >= 0; fadeValue -= fadeAmount) {
   // sets the value (range from 0 to 255):
   analogWrite(ledPin, fadeValue);
   // wait for 30 milliseconds to see the dimming effect
   delay(30);
 }
```