1. Carrier Concentration

a) Intrinsic Semiconductors

- Pure single-crystal material

For an intrinsic semiconductor, the concentration of electrons in the conduction band is equal to the concentration of holes in the valence band.

We may denote,

 n_i : intrinsic electron concentration p_i : intrinsic hole concentration

However,

 $n_i = p_i$

Simply,

 n_i : intrinsic carrier concentration, which refers to either the intrinsic electron or hole concentration

Commonly accepted values of n_i at $T = 300^{\circ}$ K

Silicon	$1.5 \times 10^{10} \text{cm}^{-3}$
Gallium arsenide	$1.8 \times 10^6 \text{ cm}^{-3}$
Germanium	$2.4 \times 10^{13} \text{ cm}^{-3}$

b) Extrinsic Semiconductors

- Doped material

The doping process can greatly alter the electrical characteristics of the semiconductor. This doped semiconductor is called an extrinsic material.

n-Type Semiconductors (negatively charged electron by adding donor) p-Type Semiconductors (positively charged hole by adding acceptor)

c) Mass-Action Law

 n_0 : thermal-equilibrium concentration of electrons p_0 : thermal-equilibrium concentration of holes

 $n_0 p_0 = n_i^2 = f(T)$ (function of temperature)

The product of n_0 and p_o is always a constant for a given semiconductor material at a given temperature.

d) Equilibrium Electron and Hole Concentrations

```
Let,
n_0: thermal-equilibrium concentration of electrons
p_0: thermal-equilibrium concentration of holes
n_d: concentration of electrons in the donor energy state
p_a: concentration of holes in the acceptor energy state
N_d: concentration of donor atoms
N_a: concentration of acceptor atoms
N_d^+: concentration of positively charged donors (ionized donors)
N_a: concentration of negatively charged acceptors (ionized acceptors)
By definition,
N_d^+ = N_d - n_d
Na^{-} = N_a - p_a
by the charge neutrality condition,
n_0 + Na^{-} = p_0 + N_d^{+}
n_0 + (N_a - p_a) = p_0 + (N_d - n_d)
assume complete ionization,
p_a=n_d=0
then, eq # becomes,
n_0 + N_a = p_0 + N_d
by eq # and the Mass-Action law (n_0p_0 = n_i^2)

n_0 = \frac{1}{2}\{(N_d - N_a) + ((N_d - N_a)^2 + 4n_i^2)^{1/2}\}, where N_d > N_a (n-type)

p_0 = \frac{1}{2}\{(N_a - N_d) + ((N_a - N_d)^2 + 4n_i^2)^{1/2}\}, where N_a > N_d (p-type)
n_0 = p_0 = n_i, where N_a = N_d (intrinsic)
If N_d - N_a >> n_i,
n_0 = N_d - N_a, p_0 = n_i^2 / (N_d - N_a)
If N_a - N_d >> n_i,
then
p_0 = N_a - N_d, n_0 = n_i^2 / (N_a - N_d)
```

Example 1)

Determine the thermal equilibrium electron and hole concentrations for a given doping concentration.

Consider an n-type silicon semiconductor at $T = 300^{\circ}$ K in which $N_d = 10^{16}$ cm⁻³ and $N_a = 0$. The intrinsic carrier concentration is assumed to be $n_i = 1.5 \times 10^{10}$ cm⁻³.

- Solution

The majority carrier electron concentration is $n_o = \frac{1}{2} \{ (N_d - N_a) + ((N_d - N_a)^2 + 4n_i^2)^{1/2} \} \approx 10^{16} \text{ cm}^{-3}$ The minority carrier hole concentration is $p_0 = n_i^2 / n_0 = (1.5 \times 10^{10})^2 / 10^{16} = 2.25 \times 10^4 \text{ cm}^{-3}$

- Comment

 $N_d >> n_i$, so that the thermal-equilibrium majority carrier electron concentration is essentially equal to the donor impurity concentration. The thermal-equilibrium majority and minority carrier concentrations can differ by many orders of magnitude.

Example 2)

Determine the thermal equilibrium electron and hole concentrations for a given doping concentration.

Consider an germanium sample at $T = 300^{\circ}$ K in which $N_d = 5 \times 10^{13}$ cm⁻³ and $N_a = 0$. Assume that $n_i = 2.4 \times 10^{13}$ cm⁻³.

- Solution

The majority carrier electron concentration is $n_o = \frac{1}{2} \{ (5 \times 10^{13}) + ((5 \times 10^{13})^2 + 4(2.4 \times 10^{13})^2)^{1/2} \} = 5.97 \times 10^{13} \text{ cm}^{-3}$ The minority carrier hole concentration is $p_0 = n_i^2 / n_0 = (2.4 \times 10^{13})^2 / (5.97 \times 10^{13}) = 9.65 \times 10^{12} \text{ cm}^{-3}$

- Comment

If the donor impurity concentration is not too different in magnitude from the intrinsic carrier concentration, the thermal-equilibrium majority carrier electron concentration is influenced by the intrinsic concentration.

Example 3)

Determine the thermal equilibrium electron and hole concentrations in a compensated ntype semiconductor.

Consider a silicon semiconductor at $T = 300^{\circ}$ K in which $N_d = 10^{16}$ cm⁻³ and $N_a = 3 \times 10^{15}$ cm⁻³. Assume that $n_i = 1.5 \times 10^{10}$ cm⁻³.

- Solution

The majority carrier electron concentration is $n_o = \frac{1}{2} \{ (10^{16} - 3 \times 10^{15}) + ((10^{16} - 3 \times 10^{15})^2 + 4(1.5 \times 10^{10})^2)^{1/2} \} \approx 7 \times 10^{15} \text{ cm}^{-3} \text{ The minority carrier hole concentration is}$ $p_0 = n_i^2 / n_0 = (1.5 \times 10^{10})^2 / (7 \times 10^{15}) = 3.21 \times 10^4 \text{ cm}^{-3}$

- Comment

If we assume complete ionization and if Nd - Na >> ni, the the majority carrier electron concentration is, to a very good approximation, just the difference between the donor and acceptor concentrations.