## Contents

1	Introduction			
	1.1	Motivation and Introduction	1	
	1.2	The Wireless Spectrum	2	
	1.3	Assessment & Delivery	3	
	1.4	Module Outline	3	
	1.5	Textbooks	3	
	1.6	Basics of Wireless Communication	4	
		1.6.1 Main components of a transmitter	4	
		1.6.2 Main components of a receiver	4	
		[Lecture on 1.	.2]	

# 1 Introduction

Dr. Declan Delaney

## 1.1 Motivation and Introduction

- 1. Signals travel without wires
  - (a) In this module, signals travel as radio waves (optical and acoustic systems ignored)
- 2. Applications are mostly in communications
  - (a) Signals modulated to carry information
  - (b) Many familiar applications such as radar, navigation, etc.

Example: Modern smart phone has approximately 9 distinct wireless systems. Try identifying them?

- NFC
- Cellulars
  - -2G
  - -3G
  - -4G
  - -5G

- GPS
- Bluetooth
- WiFi
- UWB
- Lidar

## **Advantages of Wireless**

- Mobility
- Good for one-to-many transmissions
- Cheap

Increasingly used for high capacity point-to-point links (cheaper than wired) (e.g. to serve remote areas)

#### Advantages of Wired

- Very little leakage
- No interference
- Multiple systems can operate adjacently without issue

but considerably more overheads. Suitable for super high capacity lines (eg. fibre-optic transatlantic cables)

# 1.2 The Wireless Spectrum

The EM spectrum is a shared and limited resource.

Mostly regulated by government agencies.

Frequencies must be carefully given out, but can be reused at different locations as we will see.

Overview of a wireless system:

- Start with raw data
- Source coding (compression)
- Channel coding (error detection & error correction)
- Modulation
- TX
- RX
- Demodulation

- Channel decoding
- Source decoding

This module is mainly about modulation and TX/RX, the rest is information theory.

# 1.3 Assessment & Delivery

Component	Timing	Weight
Lab Assignments	Varied (4 labs)	25%
Online BS quizzes	?	25%
Final Exam		50%

Open book final with emphasis on design and problem solving

## 1.4 Module Outline

- (1) Radio Link Design
  - Link budget?
  - How far? How much power?
- (2) Non-Linear System
- (3) Frequency Generation and Synthesis
- (4) Transmitter Design
  - Requirements and specifications
  - Transmitter architecture choices
- (5) Noise
  - Sources of noise
  - Noise analysis, low-noise design
- (6) Receiver Design
  - Requirements and specifications
  - Receiver architecture choices
- (7) Transceiver Design
  - Transmitter and receiver combined!
- (8) Antennas and Propagation
  - Review of antenna theory
  - Practical antennas and propagation of radio waves
- (9) System-Level Issues and Examples

### 1.5 Textbooks

Purely optional, module notes should be sufficient.

- "Microwave and RF Design of Wireless Systems" by David M. Pozar
- "Antennas" by John D. Kraus

[Lecture on 1.3]

#### 1.6 Basics of Wireless Communication

Amplifier to increase signal power enough to drive the antenna

## Multiple Access

- CSMA: Listen to the channel, send if it's clear
- FDMA: Frequency divided MA
- TDMA: Time divided MA

You require a 'guard band' between frequency bands where no data is sent to avoid interference

CDMA is a good way to overcome this waste, ODMA is an even better approach

#### 1.6.1 Main components of a transmitter

- Signal is 'mixed' (modulated) with an oscillator at the frequency of the channel being used
  - The frequency has to be adjustable to allow for different channels
- A power amp is required to power an antenna

Amp goes first because high-frequency amplification is a fucking nightmare

#### 1.6.2 Main components of a receiver

Signal arrives on an antenna (which collects EM waves in the vicinity, sometimes in a preferred direction, and puts them on a cable, waveguide, or circuit board track)

RX:

- Receive at very low power
- Select and amplify the desired signal
- Estimate the original signal

The signal is too weak to demodulate, so you need a high-frequency amplifier before the demodulator.

For most of this module, we will look at block-level circuits and not worry about precise circuit design.

Channel capacity (Shannon-Hartley):  $C = B \times \log_2(1 + \frac{S}{N})$ 

- C is channel capacity (eg. bits per second)
- B is bandwidth (Hz)
- $\frac{S}{N}$  is the signal-to-noise ratio

#### Cellular:

- $\bullet$  2G operated at 800-900 MHz and 64 kHz channels
- 3G operated at 1-2 GHz and got 8 MHz channels
- 4G operates at up to 5 GHz and 50-100 MHz channels
- 5G has channels up to 10 GHz

The increase in speed is partially due to better MA schemes, but mainly due to the bigger bandwidth.

Other options to increase capacity:

- Increase SNR
  - Increase power (limited by regulations)
  - or reduce noise (choose a frequency with less background?)