

Figure 1: Cosine law.

$$\begin{split} l_{plate}^2 &= l_i^2 + l_{motor}^2 - 2l_i l_{motor} \cos \alpha \\ \alpha &= \cos^{-1} \left( \frac{l_i^2 + l_{motor}^2 - l_{plate}^2}{2l_i l_{motor}} \right) \end{split}$$




Figure 2: Motor orientations.




Figure 3: Diagram describing the plate vectors.




Figure 4: Motor A at rest.




Figure 5: Gamma absolute motor angle calculation.

Define the rotation matrix for a tilt about the X and Y axis.

$$\begin{aligned} & \overset{Body}{plat}R = Y_{rot} * X_{rot} \rightarrow \text{Rotation of platform w. r. t. body} \\ & Y_{rot} = \begin{bmatrix} \cos\theta & 0 & \sin\theta \\ 0 & 1 & 0 \\ -\sin\theta & 0 & \cos\theta \end{bmatrix} \\ & X_{rot} = \begin{bmatrix} 1 & 0 & 0 \\ 0 & \cos\phi & -\sin\phi \\ 0 & \sin\phi & \cos\phi \end{bmatrix} \\ & \overset{B}{p}R = \begin{bmatrix} \cos\theta & 0 & \sin\theta \\ 0 & 1 & 0 \\ -\sin\theta & 0 & \cos\theta \end{bmatrix} * \begin{bmatrix} 1 & 0 & 0 \\ 0 & \cos\phi & -\sin\phi \\ 0 & \sin\phi & \cos\phi \end{bmatrix} \\ & \overset{B}{p}R = \begin{bmatrix} \cos\theta & \sin\theta\sin\phi & \sin\theta\cos\phi \\ 0 & \cos\phi & -\sin\phi \\ -\sin\theta & \cos\theta\sin\phi & \cos\phi\cos\phi \end{bmatrix} \end{aligned}$$

Backwards-solve the rotation matrix that will transform a unit  $\hat{k}$  vector to the plane's normalized normal vector.

$$\begin{bmatrix} \cos\theta & \sin\theta\sin\phi & \sin\theta\cos\phi \\ 0 & \cos\phi & -\sin\phi \\ -\sin\theta & \cos\theta\sin\phi & \cos\phi\cos\phi \end{bmatrix} \begin{bmatrix} 0 \\ 0 \\ 1 \end{bmatrix} = \hat{N} = \begin{bmatrix} N_x \\ N_y \\ N_z \end{bmatrix}$$
$$\begin{bmatrix} \sin\theta\cos\phi \\ -\sin\phi \\ \cos\phi\cos\phi \end{bmatrix} = \begin{bmatrix} N_x \\ N_y \\ N_z \end{bmatrix}$$
$$\phi = \sin^{-1}(-N_y)$$
$$\theta = \sin^{-1}(\frac{N_x}{\cos\phi})$$
$$\theta = \sin^{-1}(\frac{N_x}{\cos\phi})$$

Once that is solved, substitute in  $\emptyset$  and  $\theta$  into the matrix. Then, apply that rotation to the  $\overrightarrow{p_{\iota-plane}}$  vector to solve for the magnitude and direction of the rotated vector  $\overrightarrow{p_{\iota-body}}$  to use in the  $\overrightarrow{l_{\iota}}$  equation.

$$\overrightarrow{p_{\iota-body}} = \overset{Body}{p_{lat}} R * \overrightarrow{p_{\iota-plat}}$$

$$\overrightarrow{p_{\iota-body}} = \begin{bmatrix} \cos\theta & \sin\theta\sin\phi & \sin\theta\cos\phi \\ 0 & \cos\phi & -\sin\phi \\ -\sin\theta & \cos\theta\sin\phi & \cos\phi\cos\phi \end{bmatrix} * \overrightarrow{p_{\iota-plat}}$$

For angles  $\theta_y = 5^{\circ}$  and  $\phi_x = 5^{\circ}$ , we can calculate  $\vec{N}$  as follows.

$$\begin{bmatrix} \sin 5^{\circ} \cos 5^{\circ} \\ -\sin 5^{\circ} \\ \cos 5^{\circ} \cos 5^{\circ} \end{bmatrix} = \begin{bmatrix} N_{x-norm} \\ N_{y-norm} \\ N_{z-norm} \end{bmatrix} = \begin{bmatrix} 0.08682 \\ -0.08716 \\ 0.99240 \end{bmatrix}$$

For angles  $\theta_y = 5^\circ$  and  $\phi_x = 5^\circ$ , we can calculate  $\overrightarrow{l_a}$  as follows for Motor A. Given  $\overrightarrow{p_{a-plat}} = \begin{bmatrix} 0 \\ 15 \\ 0 \end{bmatrix}$ ,

$$\overrightarrow{p_{a-body}} = \begin{bmatrix} \cos 5^{\circ}, & \sin 5^{\circ}, \sin 5^{\circ}, & \sin 5^{\circ}, \cos 5^{\circ}, \\ 0 & \cos 5^{\circ}, & -\sin 5^{\circ}, \\ -\sin 5^{\circ}, & \cos 5^{\circ}, \sin 5^{\circ}, & \cos 5^{\circ}, \cos 5^{\circ}, \end{bmatrix} * \begin{bmatrix} 0 \\ 15 \\ 0 \end{bmatrix} = \begin{bmatrix} 0.11394 \\ 14.94293 \\ 1.30236 \end{bmatrix}$$

Recall, 
$$\overrightarrow{l_a} = \overrightarrow{T} + \overrightarrow{p_{a-body}} - \overrightarrow{b_a}$$
. Given  $\overrightarrow{T} = \begin{bmatrix} 0 \\ 0 \\ 8 \end{bmatrix}$  and  $\overrightarrow{b_a} = \begin{bmatrix} 0 \\ 12 \\ 0 \end{bmatrix}$ ,

$$\vec{l_a} = \begin{bmatrix} 0 \\ 0 \\ 8 \end{bmatrix} + \begin{bmatrix} 0.11394 \\ 14.94293 \\ 1.30236 \end{bmatrix} - \begin{bmatrix} 0 \\ 12 \\ 0 \end{bmatrix} = \begin{bmatrix} 0.11394 \\ 2.94293 \\ 9.30236 \end{bmatrix}$$

For a known  $\overrightarrow{l_a} = \begin{bmatrix} 0.11394 \\ 2.94293 \\ 9.30236 \end{bmatrix}$ , we can calculate the relative motor angle  $\alpha_{plate-leg}$  as follows. Given  $l_{motor-leg} = 3$  and  $l_{plate-leg} = 6$ ,

$$\begin{aligned} |\vec{l_a}| &= \sqrt{0.11394^2 + 2.94293^2 + 9.30236^2} = 9.7574 \\ \alpha_{plate-leg} &= \cos^{-1} \left( \frac{l_a^2 + l_{motor-leg}^2 - l_{plate-leg}^2}{2l_a l_{motor-leg}} \right) = \cos^{-1} \left( \frac{9.7574^2 + 5^2 - 8^2}{2 \times 9.7574 \times 5} \right) = 54.8268^{\circ} \end{aligned}$$


After obtaining the relative motor angle, we can find the angle  $\beta_a$  of  $\overrightarrow{l_a}$  with respect to the unit  $\widehat{k}$  vector. See absolute motor angle.png for more details.

$$\beta_a = \cos^{-1}(\frac{\hat{k} \cdot \vec{l_a}}{|\hat{k}||\vec{l_a}|}) = \cos^{-1}\left(\frac{\begin{bmatrix} 0\\0\\1\end{bmatrix} \cdot \begin{bmatrix} 0.11394\\2.94293\\9.30236\end{bmatrix}}{9.7574}\right) = 17.5670^{\circ}$$


Subtracting  $\alpha_{plate-leg}$  and  $\beta_a$  from 90° yields the absolute motor angle  $\gamma_a$  w. r. t. the horizontal.

$$\gamma_a = 90^{\circ} - \alpha_{plate-leg} - \beta_a = 90^{\circ} - 54.8268^{\circ} - 17.5670 = 17.61^{\circ}$$

For a direction vector of  $\vec{v} = \begin{bmatrix} 1 \\ 0 \\ 0 \end{bmatrix}$  and a tilt magnitude of  $\theta = 5^\circ$ , the normal vector of the plate can be calculated. First, the axis of rotation is determined to be  $\vec{v}_{rot-axis} = \begin{bmatrix} 0 \\ 1 \\ 0 \end{bmatrix}$ , which is the orthogonal vector to the direction vector in the x-y plane.



Then, the plate is tilted about this axis in the direction of the direction vector, about magnitude  $\theta$ . Vector decomposition is used to determine the new, rotated direction vector.



Given the rotated direction vector and the axis of rotation, these are crossed to find the third orthogonal vector, which is the normal vector to the plane.

$$\vec{N} = \vec{v}_{rot-axis} \times \vec{v}_{rot} = \begin{bmatrix} 0 \\ 1 \\ 0 \end{bmatrix} \times \begin{bmatrix} 0.996 \\ 0 \\ -0.087 \end{bmatrix} = \begin{bmatrix} -0.087 \\ 0 \\ -0.996 \end{bmatrix}$$

The vector is multiplied by -1 to ensure the Z-direction is positive.

$$\vec{N} = \begin{bmatrix} 0.087\\0\\0.996 \end{bmatrix}$$

