University of California, Riverside

EE 106 PROGRAMMING PRACTICAL ROBOTS

Spring 2024

Lab 7 Report


05/18, 2024

Name	SID	Section	Group Number
Thong Thach Hung Nguyen	862224662 862221239	21	04


1. Problem Statement

The objective of this lab is to understand the finite state machine of the robot so the robot can move in the left-wall following based on Finite State Machine. By detailing the challenges associated with navigation and sensing, and outlining the methods to address them, we will also introduce the concept of a Finite State Machine (FSM). This FSM will be integrated into the development of our behavior framework. From that we can build the state for the robot to go left, go right, or go straight. The goal/objective of the robot is to follow the left wall.

The finite state machine:



Left Side	Front Side	Action
Free	Free	Left
Free	Occupied	Right
Occupied	Free	Forward
Occupied	Occupied	Right



2. Design Idea

The main goal of this lab is to create the open list for all the possible nodes that are connected to the start node

Once all the nodes are planned, the next step is to calculate the cost to take from each node to the other node

If one of the node is the obstacle or the obstacle is inside the closed_list, then it will be skipped


If the current node has a better path then it will add to the set or update to the cost of the node and add it to the parent node. If the node is found the shortest path, it will update the current node to that parent cost-to-go amount

It will keep repeating again, and again until it reaches the goal


As the motion planning starts to mapping out all the possible nodes and paths, until it reaches the goal. Motion planning will calculate all the cost-to-go to each nodes and starts to eliminate all the longest cost to go from one node to other node, only leaves with small cost. After that, it will update to the current node. More explanation will be based on the "How to run code section".

3. Results

For complex world result:




For more complex world result:



4. Appendix (optional)

1) How to run the code

Understanding the finite state machine for the left wall following:



For the complex world:

STEP 1:

Setting up the parameter for the PD controller:

class PDController:

```
def __init__(self, P=1.0, D=0.1, set_point=0.0):
    self.Kp = P
    self.Kd = D
    self.set_point = set_point # reference (desired value)
    self.previous_error = 0

def update(self, current_value):
    # calculate P_term and D_term
    # e = r - y
    error = self.set_point - current_value
    P_term = self.Kp * error
    D_term = self.Kd * (error - self.previous_error)
    self.previous_error = error
    return P_term + D_term
```

```
def setPoint(self, set_point):
    self.set_point = set_point
    self.previous_error = 0

def setPD(self, P=0.0, D=0.0):
    self.Kp = P
    self.Kd = D
```

STEP 2

Next, setting up all the parameters for the Publishers and Suscribers, and the TransformListerner for the robot

After that, setting up the state machine for the robot facing in which way/ directions, and the goal tolerance

Continue on, setting up the PDController() function to initialize the pd control for the robot

```
class Turtlebot():
 def init (self, goal x, goal y, csv file):
   # Data to be taken from Launch File. Don't Edit
   self.goal x = goal x
   self.goal y = goal y
    self.csv file = csv file
   # Initialize subscribers and publishers
   self.lidar sub = rospy.Subscriber('/scan', LaserScan, self.lidar callback)
    self.vel pub = rospy.Publisher("/mobile base/commands/velocity", Twist,
queue size=10)
    self.odom sub = rospy.Subscriber("odom", Odometry, self.odom callback)
   self.rate = rospy.Rate(10)
    self.listener = tf.TransformListener()
   # Initialize state variables
   self.left = "O"
   self.front = "F"
   self.wall = "S"
    self.state = "forward"
    self.current facing = 0 # straight
```

```
self.logging_counter = 0
self.left_min_dist = 100
self.forward_min_dist = 999
self.pose = Pose2D()
self.goal_tolerance = 0.3
self.trajectory = list()
self.angular_threshold = 0.003
self.pd_control = PDController()
self.pd_control.setPD(1.0, 0.1)
```

STEP 3:

Initialize the angle for the left state and the right state

Initialize the state of the robot is facing (directions)

```
self.control_list = [pi/2, pi]
   self.control list2 = [pi/2, 0]
   # Define Finite-State Machine matrix by NumPy
   self.state transition matrix = np.array([
      # Left Side: Free
      [ # Front side: free -> Left
        [1],
        # Front side: Occupied -> Right
        [2]
      ],
      # Left Side: Occupied
      [ # Front side: free -> Forward
        [0],
        # Front side: Occupied -> Right
        [2]
   1)
   # Define state and condition encoding
   self.state encoding = {'forward': 0, 'left': 1, 'right': 2}
   self.state decoding = {0: 'forward', 1: 'left', 2: 'right'}
   self.condition encoding = {'F': 0, 'O': 1} # F: free; O: Occupied
```

```
self.current_facing_decoding = {0: "straight", -1: "small_left", -2: "medium_left", -3:
"large_left",
1: "small_right", 2: "medium_right", 3: "large_right"}
```

Break out:

Intialize the angle

```
self.control list = [pi/2, pi]
```

```
self.control list2 = [pi/2, 0]
```

```
self.control_list = [pi/2, pi] for the left state
```

self.control list2 = [pi/2, 0] for the right state

Initialize the state of the robot is facing:

Define state and condition encoding

STEP 4:

```
def run(self):
    # Don't edit anything
    while not rospy.is_shutdown():
        self.update_state() # Update the robot's state based on sensor readings
        # Publish velocity commands based on the current state
        self.publish_velocity()
        # Sleep to maintain the loop rate
        self.rate.sleep()
```

Publish velocity commands based on the current state

STEP 5:

```
def update_state(self):
    # State machine to update the robot's state based on sensor readings
    current_state_encoding = self.state_encoding[self.state]
    left_cond_encoding = self.condition_encoding[self.left]
    front_cond_encoding = self.condition_encoding[self.front]

# Write code to encode current state and conditions
# Get the new state from the state transition matrix
    new_state_encoded = self.state_transition_matrix[left_cond_encoding,
front_cond_encoding][0]

# Decode the new state
    self.state_decoding[new_state_encoded]
```

Update the state function

STEP 6: important step

```
def publish velocity(self):
   vel = Twist()
   # Publish velocity commands based on the current facing direction
   # Fill in the velocities, keep the values small
   # Keep editing values in the given range till the robot moves well.
   # Velocity values are good in the range of (0.01 to 0.2)
   # Angular Velocities are good in the range of (-0.08 to 0.08)
   if self.current facing decoding[self.current facing] == "straight": #0
      vel.linear.x = 0.2
      vel.angular.z = 0.0
   if self.current facing decoding[self.current facing] == "small left": #-1
      vel.linear.x = 0.1
      vel.angular.z = 0.03 \# 0.03
   if self.current facing decoding[self.current facing] == "medium left": #-2
      vel.linear.x = 0.1
      vel.angular.z = 0.05 \# 0.05
   if self.current facing decoding[self.current facing] == "small right": #1
      vel.linear.x = 0.1
      vel.angular.z = -0.03 \# 0.03
   if self.current facing decoding[self.current facing] == "medium right": #2
      vel.linear.x = 0.1
```

```
vel.angular.z = -0.05 \# -0.05
print(self.left + ' ' + self.front + ' ' + self.wall + ' ' +
   str(round(self.left min dist, 3)) + ' ' + str(round(self.forward min dist, 3)) +
   '' + self.state + '' + str(self.current facing))
if self.state == "left":
  "if len(self.control list) < 1:
     rospy.signal shutdown('Received shutdown message')'"
  for i in range(5):
     vel.linear.x = 0.2
     vel.angular.z = 0.0
     self.vel pub.publish(vel)
     self.rate.sleep()
  # use PD controller to control the angle: from Lab 5
  pd control=PDController()
  pd control.setPoint(self.control list[0])
  while abs(self.pose.theta -self.control list[0]) > self.angular threshold:
     adjust pos = pd control.update(self.pose.theta)
     vel.angular.z = max(-0.8,min(adjust pos*2.5,0.8))
     self.vel pub.publish(vel)
     self.rate.sleep()
  rospy.loginfo("done with turning left")
  self.control list.pop(0)
  # move forward a bit: from lab 4
  for i in range(5):
    vel.linear.x = 0.2
     vel.angular.z = 0.0
     self.vel pub.publish(vel)
     self.rate.sleep()
elif self.state == "right":
  if len(self.control list2) < 1:
     rospy.signal shutdown('Received shutdown message')
```

```
# use PD controller to control the angle: from Lab 5
    pd control=PDController()
    pd control.setPoint(self.control list2[0])
    while abs(self.pose.theta -self.control list2[0]) > self.angular threshold:
       adjust pos = pd control.update(self.pose.theta)
       vel.angular.z = max(-0.8,min(adjust pos*2.5,0.8))
       self.vel pub.publish(vel)
       self.rate.sleep()
    rospy.loginfo("done with turning right")
    self.control list2.pop(0)
    for i in range(5):
       vel.linear.x = 0.2
       vel.angular.z = 0.0
       self.vel pub.publish(vel)
       self.rate.sleep
  else:
    self.vel pub.publish(vel)
def lidar callback(self, data):
  self.left min dist = 100
  # Update the forward distance with the distance directly in front of the robot
  if str(data.ranges[0]) == "inf":
    self.forward min dist = 999
  else:
    self.forward_min_dist = data.ranges[0]
```

The main goal of this publish velocity() function is to define the state of the robot.

```
if self.current facing decoding[self.current facing] == "straight": #0
```

```
vel.linear.x = 0.2
vel.angular.z = 0.0
```

```
if self.current_facing_decoding[self.current_facing] == "small_left": # -1
    vel.linear.x = 0.1
    vel.angular.z = 0.03 #0.03
if self.current_facing_decoding[self.current_facing] == "medium_left": # -2
    vel.linear.x = 0.1
    vel.angular.z = 0.05 #0.05
if self.current_facing_decoding[self.current_facing] == "small_right": # 1
    vel.linear.x = 0.1
    vel.angular.z = -0.03 #0.03
if self.current_facing_decoding[self.current_facing] == "medium_right": # 2
    vel.linear.x = 0.1
    vel.angular.z = -0.05 #-0.05
print(self.left + ' ' + self.front + ' ' + self.wall + ' ' +
    str(round(self.left_min_dist, 3)) + ' ' + str(round(self.forward_min_dist, 3)) +
    ' ' + self.state + ' ' + str(self.current_facing))
```

This state machine above will initialize all the forward movements and the angular movement of the robot.

```
When the state = left:

if self.state == "left":
```

```
"if len(self.control list) < 1:
  rospy.signal shutdown('Received shutdown message')'"
for i in range(5):
  vel.linear.x = 0.2
  vel.angular.z = 0.0
  self.vel pub.publish(vel)
  self.rate.sleep()
# use PD controller to control the angle: from Lab 5
pd control=PDController()
pd control.setPoint(self.control list[0])
while abs(self.pose.theta -self.control list[0]) > self.angular threshold:
  adjust pos = pd control.update(self.pose.theta)
  vel.angular.z = max(-0.8,min(adjust pos*2.5,0.8))
  self.vel pub.publish(vel)
  self.rate.sleep()
rospy.loginfo("done with turning left")
```

```
self.control_list.pop(0)

# move forward a bit: from lab 4
for i in range(5):
    vel.linear.x = 0.2
    vel.angular.z = 0.0
    self.vel_pub.publish(vel)
    self.rate.sleep()
```

In the left state, first the robot will move forward a bit,

```
for i in range(5):
    vel.linear.x = 0.2
    vel.angular.z = 0.0
    self.vel_pub.publish(vel)
    self.rate.sleep()
```

Next:

```
# use PD controller to control the angle: from Lab 5
pd_control=PDController()
pd_control.setPoint(self.control_list[0])
while abs(self.pose.theta -self.control_list[0]) > self.angular_threshold:
    adjust_pos = pd_control.update(self.pose.theta)
    vel.angular.z = max(-0.8,min(adjust_pos*2.5,0.8))
    self.vel_pub.publish(vel)
    self.rate.sleep()
rospy.loginfo("done with turning left")
self.control_list.pop(0)
```

Based on this code above, the goal is rotating based on the desire rotaion on the left state. The robot will compare its current angle, self.pose.thetha, with the desire angle rotation, self.control_list[0]. If the range difference is greater than the threshold (0.003), then it keeps rotating based on the tunned PD controller. If the range difference is smaller than the threshold, the robot will stop.

After that, it will pop the first angle so the next angle rotation will be ready to be executed.

```
When the state = right:
```

The process is very similar to the left state

```
elif self.state == "right":
```

```
if len(self.control list2) < 1:
     rospy.signal shutdown('Received shutdown message')
  # use PD controller to control the angle: from Lab 5
  pd control=PDController()
  pd control.setPoint(self.control list2[0])
  while abs(self.pose.theta -self.control list2[0]) > self.angular threshold:
    adjust pos = pd control.update(self.pose.theta)
    vel.angular.z = max(-0.8,min(adjust pos*2.5,0.8))
    self.vel pub.publish(vel)
    self.rate.sleep()
  rospy.loginfo("done with turning right")
  self.control list2.pop(0)
  for i in range(5):
    vel.linear.x = 0.2
    vel.angular.z = 0.0
    self.vel pub.publish(vel)
    self.rate.sleep
else:
  self.vel pub.publish(vel)
```

```
# use PD controller to control the angle: from Lab 5
pd_control=PDController()
pd_control.setPoint(self.control_list2[0])
```

```
while abs(self.pose.theta -self.control_list2[0]) > self.angular_threshold:
    adjust_pos = pd_control.update(self.pose.theta)
    vel.angular.z = max(-0.8,min(adjust_pos*2.5,0.8))
    self.vel_pub.publish(vel)
    self.rate.sleep()
    rospy.loginfo("done with turning right")
    self.control_list2.pop(0)
```

Based on this code above, the goal is rotating based on the desire rotaion on the right state. The robot will compare its current angle, self.pose.thetha, with the desire angle rotation, self.control_list[0]. If the range difference is greater than the threshold (0.003), then it keeps rotating based on the tunned PD controller. If the range difference is smaller than the threshold, the robot will stop.

After that, it will pop the first angle so the next angle rotation will be ready to be executed.

```
for i in range(5):
    vel.linear.x = 0.2
    vel.angular.z = 0.0
    self.vel_pub.publish(vel)
    self.rate.sleep

else:
    self.vel_pub.publish(vel)
```

Continue moving forward

If the state is not left, or right, just publish the velocity of the robot.

For the LIDAR CALLBACK function():

```
def lidar_callback(self, data):
    self.left_min_dist = 100

# Update the forward distance with the distance directly in front of the robot
    if str(data.ranges[0]) == "inf":
        self.forward_min_dist = 999
```

```
else:
      self.forward min dist = data.ranges[0]
    # transform the lidar points frame /rplidar link from to another frame: from lab 3 and
lab 2
    #listener = tf.TransformListener()
    (trans, rot) = self.listener.lookupTransform('/base link', '/rplidar link', rospy.Time(0))
    # Process the LIDAR data and transform the points to the robot's coordinate frame
(another frame you specified)
    for i in range(len(data.ranges)):
      # get the left side lidar data
      if i * data.angle increment < 1.59 and i * data.angle increment > 1.55:
         if str(data.ranges[i]) == "inf":
           dist = 9999
         else:
           dist = data.ranges[i]
         (x, y) = self.calculate position of range(dist, i, data.angle increment,
data.angle min)
         transformed point = np.dot(tf.transformations.quaternion matrix(rot),
np.array([x, y, 0, 1]))
         left dist = transformed point[1]
         if left dist < self.left min dist:
           self.left min dist = left dist
    # Update left and forward state
    if self.left min dist < 0.5:
      self.left = "O"
    else:
      self.left = "F"
    if self.forward min dist < 0.5:
      self.front = "O"
    else:
      self.front = "F"
    # Set wall state
```

```
if self.left_min_dist < 0.3:
    self.wall = "C"
else:
    self.wall = "S"</pre>
```

Breakout the code explanation:

```
def lidar_callback(self, data):
    self.left_min_dist = 100

# Update the forward distance with the distance directly in front of the robot
    if str(data.ranges[0]) == "inf":
        self.forward_min_dist = 999
    else:
        self.forward_min_dist = data.ranges[0]

# transform the lidar points frame /rplidar_link from to another frame: from lab 3 and
lab 2
    #listener = tf.TransformListener()
    (trans, rot) = self.listener.lookupTransform('/base_link', '/rplidar_link', rospy.Time(0))
```

Initialize the transformation and rotation for the lidar

If the robot distance of the lidar is at infinity, so set the forward direction equals to 999

If not, then start the forward min dist

Next, processing the LIDAR data and transform the points to the robot's coordinate frame

If the data angle increment is < 1.59 or > 1.55:

-> the range of the data is infinity

```
for i in range(len(data.ranges)):
    # get the left side lidar data
    if i * data.angle_increment < 1.59 and i * data.angle_increment > 1.55:
        if str(data.ranges[i]) == "inf":
            dist = 9999
        else:
            dist = data.ranges[i]
```

```
(x, y) = self.calculate_position_of_range(dist, i, data.angle_increment,
data.angle_min)

transformed_point = np.dot(tf.transformations.quaternion_matrix(rot),
np.array([x, y, 0, 1]))

left_dist = transformed_point[1]
    if left_dist < self.left_min_dist:
        self.left_min_dist = left_dist</pre>
```

For the segment code above, call the calculate position of range()

The calculate position of range() function is:

def calculate_position_of_range(self, range, index, angle_increment,
angle_min):

```
# Calculate the position of a range measurement in the LIDAR frame
angle = index * angle_increment + angle_min
x = range * np.cos(angle)
y = range * np.sin(angle)
return x, y
```

The range is the distance measurement from the LIDAR sensor

np.cos(angle) calculates the cosine of the angle, and when this value is multiplied by the range, it gives the x-coordinate. Similar to the y-coordinate

 ${\bf 4-dimensional\ for\ the\ transform_point}$

if left dist < self.left min dist:

keep the minimum distance as the left_min_dist

For the FORWARD STATE:

```
if self.left_min_dist < 0.5:
        self.left = "O"
else:
        self.forward_min_dist < 0.5:
        self.front = "O"
else:
        self.front = "F"

# Set wall state
if self.left_min_dist < 0.3:
        self.wall = "C"
else:
        self.wall = "S"</pre>
```

For the LEFT

Update current_facing direction

if the robot is too close, take the medium_right facing; if it is too far, take the medium left facing

For this small right and small left are used to fine-tune the navigation.

```
# The basic idea is:

# if the robot is too close, take the medium_right facing; if it is too far, take the medium_left facing

# For this small_right and small_left are used to fine-tune the navigation.

if self.left_min_dist < 0.3:

self.current_facing = 1

elif self.left_min_dist < 0.25:

self.current_facing = 2

elif (self.left_min_dist > 0.35) and (self.forward_min_dist < 2):

self.current_facing = 1

elif (self.left_min_dist > 0.35) and (self.forward_min_dist < 1):

self.current_facing = 2

elif (self.left_min_dist > 0.35) and (self.forward_min_dist > 2):

self.current_facing = 2
```

```
elif (self.left_min_dist > 0.4) :
    self.current_facing = -2
else:
    self.current_facing = 0
```

For the ODOM CALLBACK function():

def odom callback(self, data):

```
# get the position of the robot
pose = data.pose.pose
self.pose.x = pose.position.x
self.pose.y = pose.position.y
quaternion = (
  pose.orientation.x,
  pose.orientation.y,
  pose.orientation.z,
  pose.orientation.w
euler = tf.transformations.euler from quaternion(quaternion)
self.pose.theta = euler[2]
# Append pose data to the trajectory
self.logging counter += 1
if self.logging counter == 100:
  self.logging counter = 0
  self.trajectory.append([self.pose.x, self.pose.y])
  rospy.loginfo("Save point")
# If the goal is reached, stop the robot and save the trajectory
if sqrt((self.pose.x - self.goal x)**2 + (self.pose.y - self.goal y)**2) < self.goal tolerance:
  rospy.loginfo("Goal reached")
  self.stop()
  self.save trajectory()
  rospy.signal shutdown('Goal reached')
```

Breakout the code segment:

```
self.pose.x = pose.position.x
self.pose.y = pose.position.y
quaternion = (
    pose.orientation.x,
    pose.orientation.y,
    pose.orientation.z,
    pose.orientation.w
)
euler = tf.transformations.euler_from_quaternion(quaternion)
self.pose.theta = euler[2]
```

Get the position of x,y for ROS of odometry

-> rospy.Subscriber("odom", Odometry, self.odom_callback)

```
quaternion = (
    pose.orientation.x,
    pose.orientation.y,
    pose.orientation.z,
    pose.orientation.w
    )
    euler = tf.transformations.euler_from_quaternion(quaternion)
    self.pose.theta = euler[2]
```

For the rotation of x,y,z,w

Next,

Append pose data to the trajectory

```
self.logging_counter += 1
if self.logging_counter == 100:
    self.logging_counter = 0
    self.trajectory.append([self.pose.x, self.pose.y])
    rospy.loginfo("Save point")
```

Next,

If the goal is reached, stop the robot and save the trajectory

To calculate the goal distance, the formula is

```
x= sqrt((self.pose.x - self.goal_x)**2 + (self.pose.y - self.goal_y)**2)
If x< self_goal.toleracne (0.003) then the goal is reached</pre>
```

```
if sqrt((self.pose.x - self.goal_x)**2 + (self.pose.y - self.goal_y)**2) < self.goal_tolerance:
    rospy.loginfo("Goal reached")
    self.stop()
    self.save_trajectory()
    rospy.signal_shutdown('Goal reached')</pre>
```

Last step for the main function():

def main(args):

```
# Initialize ROS Node
 rospy.init node('left wall follower', anonymous=True)
 # Get parameters from the launch file
 goal x = rospy.get param('goal x')
 goal y = rospy.get param('goal y')
 csv file = rospy.get param('csv file')
 # Create an instance of the Turtlebot class
 robot = Turtlebot(goal x, goal y, csv file)
 try:
   rospy.spin()
 except KeyboardInterrupt:
   print("Shutting down")
if name == ' main ':
 try:
    main(sys.argv)
 except rospy.ROSInterruptException:
   rospy.loginfo("Action terminated.")
```

FOR THE MORE COMPLEX WORLD:

The step is exactly the same as the complex world. The only thing we modified is adding the angle angle, pi, into the self arrayas the following below:

```
self.control list = [pi/2, pi,pi/2) References
```

That's all for this lab.

The external source is only: <u>Welcome to UCR EE106 — UCR EE106 Spring 2024 0.1</u> <u>documentation (ucr-ee106.readthedocs.io)</u> and the help from TA

3) Scripts

For the complex world:

```
#!/usr/bin/env python3
import roslib
roslib.load manifest('ee106s24')
import rospy
import sys
import tf
import numpy as np
from math import pi, sqrt
from std msgs.msg import String
from sensor msgs.msg import LaserScan
from geometry msgs.msg import Twist, Pose2D
from nav msgs.msg import Odometry
import os
class PDController:
 def init (self, P=1.0, D=0.1, set point=0.0):
   self.Kp = P
   self.Kd = D
   self.set point = set point # reference (desired value)
    self.previous error = 0
 def update(self, current value):
   # calculate P term and D term
    error = self.set point - current value
   P term = self.Kp * error
   D term = self.Kd * (error - self.previous error)
   self.previous error = error
    return P_term + D_term
 def setPoint(self, set point):
```

```
self.set point = set point
    self.previous error = 0
 def setPD(self, P=0.0, D=0.0):
    self.Kp = P
    self.Kd = D
class Turtlebot():
 def init (self, goal_x, goal_y, csv_file):
    # Data to be taken from Launch File. Don't Edit
    self.goal x = goal x
    self.goal y = goal y
    self.csv file = csv file
    # Initialize subscribers and publishers
    self.lidar sub = rospy.Subscriber('/scan', LaserScan, self.lidar callback)
    self.vel pub = rospy.Publisher("/mobile base/commands/velocity", Twist,
queue size=10)
    self.odom sub = rospy.Subscriber("odom", Odometry, self.odom callback)
    self.rate = rospy.Rate(10)
    self.listener = tf.TransformListener()
    # Initialize state variables
    self.left = "O"
    self.front = "F"
    self.wall = "S"
    self.state = "forward"
    self.current facing = 0 # straight
    self.logging counter = 0
    self.left min dist = 100
    self.forward min dist = 999
    self.pose = Pose2D()
    self.goal tolerance = 0.3
    self.trajectory = list()
    self.angular threshold = 0.003
    self.pd control = PDController()
    self.pd control.setPD(1.0, 0.1)
    # For the complex world map
    self.control list = [pi/2, pi]
```

```
self.control list2 = [pi/2, 0]
   # Define Finite-State Machine matrix by NumPy
   self.state transition matrix = np.array([
      # Left Side: Free
      [ # Front side: free -> Left
        [1],
        # Front side: Occupied -> Right
        [2]
      1,
      # Left Side: Occupied
      [ # Front side: free -> Forward
        [0],
        # Front side: Occupied -> Right
   1)
   # Define state and condition encoding
   self.state encoding = {'forward': 0, 'left': 1, 'right': 2}
   self.state decoding = {0: 'forward', 1: 'left', 2: 'right'}
   self.condition encoding = {'F': 0, 'O': 1} # F: free; O: Occupied
   self.current facing decoding = {0: "straight", -1: "small left", -2: "medium left", -3:
"large left",
                      1: "small right", 2: "medium right", 3: "large right"}
   self.run()
 def run(self):
   # Don't edit anything
   while not rospy.is shutdown():
      self.update state() # Update the robot's state based on sensor readings
      # Publish velocity commands based on the current state
      self.publish velocity()
      # Sleep to maintain the loop rate
      self.rate.sleep()
 def update state(self):
   # State machine to update the robot's state based on sensor readings
   current state encoding = self.state encoding[self.state]
   left cond encoding = self.condition encoding[self.left]
   front cond encoding = self.condition encoding[self.front]
```

```
# Write code to encode current state and conditions
    # Get the new state from the state transition matrix
    new state encoded = self.state transition matrix[left cond encoding,
front cond encoding][0]
    # Decode the new state
    self.state = self.state decoding[new state encoded]
 def publish velocity(self):
    vel = Twist()
   # Publish velocity commands based on the current facing direction
   # Fill in the velocities, keep the values small
   # Keep editing values in the given range till the robot moves well.
   # Velocity values are good in the range of (0.01 to 0.2)
   # Angular Velocities are good in the range of (-0.08 to 0.08)
   if self.current_facing_decoding[self.current_facing] == "straight": # 0
      vel.linear.x = 0.2
      vel.angular.z = 0.0
    if self.current facing decoding[self.current facing] == "small left": #-1
      vel.linear.x = 0.1
      vel.angular.z = 0.03 \# 0.03
   if self.current facing decoding[self.current facing] == "medium left": #-2
      vel.linear.x = 0.1
      vel.angular.z = 0.05 \# 0.05
    if self.current facing decoding[self.current facing] == "small right": #1
      vel.linear.x = 0.1
      vel.angular.z = -0.03 \# 0.03
   if self.current facing decoding[self.current facing] == "medium right": #2
      vel.linear.x = 0.1
      vel.angular.z = -0.05 \# -0.05
    print(self.left + ' ' + self.front + ' ' + self.wall + ' ' +
       str(round(self.left min dist, 3)) + ' ' + str(round(self.forward min dist, 3)) +
       '' + self.state + '' + str(self.current facing))
   if self.state == "left":
      "if len(self.control list) < 1:
         rospy.signal shutdown('Received shutdown message')'"
```

```
for i in range(5):
    vel.linear.x = 0.2
    vel.angular.z = 0.0
    self.vel pub.publish(vel)
    self.rate.sleep()
  # use PD controller to control the angle: from Lab 5
  pd control=PDController()
  pd control.setPoint(self.control list[0])
  while abs(self.pose.theta -self.control list[0]) > self.angular threshold:
    adjust pos = pd control.update(self.pose.theta)
    vel.angular.z = max(-0.8,min(adjust pos*2.5,0.8))
    self.vel pub.publish(vel)
    self.rate.sleep()
  rospy.loginfo("done with turning left")
  self.control list.pop(0)
  # move forward a bit: from lab 4
  for i in range(5):
    vel.linear.x = 0.2
    vel.angular.z = 0.0
    self.vel pub.publish(vel)
    self.rate.sleep()
elif self.state == "right":
  if len(self.control list2) < 1:
     rospy.signal shutdown('Received shutdown message')
  # use PD controller to control the angle: from Lab 5
  pd control=PDController()
  pd control.setPoint(self.control list2[0])
  while abs(self.pose.theta -self.control list2[0]) > self.angular threshold:
    adjust pos = pd control.update(self.pose.theta)
    vel.angular.z = max(-0.8,min(adjust pos*2.5,0.8))
    self.vel pub.publish(vel)
```

```
self.rate.sleep()
      rospy.loginfo("done with turning right")
      self.control list2.pop(0)
      for i in range(5):
        vel.linear.x = 0.2
        vel.angular.z = 0.0
        self.vel pub.publish(vel)
        self.rate.sleep
    else:
      self.vel pub.publish(vel)
 def lidar callback(self, data):
    self.left min dist = 100
   # Update the forward distance with the distance directly in front of the robot
   if str(data.ranges[0]) == "inf":
      self.forward min dist = 999
    else:
      self.forward min dist = data.ranges[0]
   # transform the lidar points frame /rplidar link from to another frame: from lab 3 and
lah 2
    #listener = tf.TransformListener()
   (trans, rot) = self.listener.lookupTransform('/base link', '/rplidar link', rospy.Time(0))
   # Process the LIDAR data and transform the points to the robot's coordinate frame
(another frame you specified)
    for i in range(len(data.ranges)):
      # get the left side lidar data
      if i * data.angle_increment < 1.59 and i * data.angle_increment > 1.55:
        if str(data.ranges[i]) == "inf":
           dist = 9999
        else:
```

```
dist = data.ranges[i]
         (x, y) = self.calculate position of range(dist, i, data.angle increment,
data.angle min)
         transformed point = np.dot(tf.transformations.quaternion matrix(rot),
np.array([x, y, 0, 1]))
         left dist = transformed point[1]
         if left dist < self.left min dist:
           self.left min dist = left dist
    # Update left and forward state
    if self.left min dist < 0.5:
      self.left = "O"
    else:
      self.left = "F"
    if self.forward min dist < 0.5:
      self.front = "O"
    else:
      self.front = "F"
    # Set wall state
    if self.left min dist < 0.3:
      self.wall = "C"
    else:
      self.wall = "S"
    # Update current facing direction
    # The basic idea is:
    # if the robot is too close, take the medium right facing; if it is too far, take the
medium left facing
    # For this small right and small left are used to fine-tune the navigation.
    if self.left min dist < 0.3:
      self.current facing = 1
    elif self.left min dist < 0.25:
      self.current facing = 2
    elif (self.left min dist > 0.35) and (self.forward min dist < 2):
      self.current facing = 1
    elif (self.left min dist > 0.35) and (self.forward min dist < 1):
      self.current facing = 2
```

```
elif (self.left min dist > 0.35) and (self.forward min dist > 2):
    self.current facing = -1
  elif (self.left min dist > 0.4):
    self.current facing = -2
  else:
    self.current facing = 0
def odom callback(self, data):
  # get the position of the robot
  pose = data.pose.pose
  self.pose.x = pose.position.x
  self.pose.y = pose.position.y
  quaternion = (
    pose.orientation.x,
    pose.orientation.y,
    pose.orientation.z,
    pose.orientation.w
  euler = tf.transformations.euler from quaternion(quaternion)
  self.pose.theta = euler[2]
  # Append pose data to the trajectory
  self.logging counter += 1
  if self.logging counter == 100:
    self.logging counter = 0
    self.trajectory.append([self.pose.x, self.pose.y])
    rospy.loginfo("Save point")
  # If the goal is reached, stop the robot and save the trajectory
  if sqrt((self.pose.x - self.goal x)**2 + (self.pose.y - self.goal y)**2) < self.goal tolerance:
    rospy.loginfo("Goal reached")
    self.stop()
    self.save trajectory()
    rospy.signal shutdown('Goal reached')
def stop(self):
  # Stop the robot
  vel = Twist()
  vel.linear.x = 0.0
  vel.angular.z = 0.0
```

```
self.vel pub.publish(vel)
 def save trajectory(self):
    # Save the trajectory to a CSV file
    "with open(self.csv file, 'w') as f:
     for pose in self.trajectory:
        f.write(f"{pose[0]},{pose[1]}\n")'"
    np.savetxt(self.csv file, np.array(self.trajectory), fmt='\%f', delimiter=',')
 def calculate position of range(self, range, index, angle increment, angle min):
   # Calculate the position of a range measurement in the LIDAR frame
    angle = index * angle increment + angle min
    x = range * np.cos(angle)
   y = range * np.sin(angle)
    return x, y
'''if name ==' main ':
 try:
   # Initialize the ROS node
    rospy.init node('turtlebot navigation', anonymous=True)
   # Get parameters from the launch file
    goal x = rospy.get param("\sim goal x", 5.0)
    goal y = rospy.get param("\sim goal y", 5.0)
    csv file = rospy.get param("~csv file", "/home/desktop/trajectory.csv")
   # Create the Turtlebot object and start the navigation
    turtlebot = Turtlebot(goal x, goal y, csv file)
 except rospy.ROSInterruptException:
   pass'''
def main(args):
 # Initialize ROS Node
 rospy.init node('left wall follower', anonymous=True)
 # Get parameters from the launch file
 goal x = rospy.get param('goal x')
 goal y = rospy.get param('goal y')
 csv file = rospy.get param('csv file')
 # Create an instance of the Turtlebot class
 robot = Turtlebot(goal x, goal y, csv file)
```

```
try:
    rospy.spin()
    except KeyboardInterrupt:
    print("Shutting down")

if __name__ == '__main__':
    try:
    main(sys.argv)
    except rospy.ROSInterruptException:
    rospy.loginfo("Action terminated.")
```

MORE COMEPLEX WORLD:

```
#!/usr/bin/env python3
import roslib
roslib.load manifest('ee106s24')
import rospy
import sys
import tf
import numpy as np
from math import pi, sqrt
from std msgs.msg import String
from sensor msgs.msg import LaserScan
from geometry msgs.msg import Twist, Pose2D
from nav_msgs.msg import Odometry
import os
class PDController:
 def init (self, P=1.0, D=0.1, set point=0.0):
    self.Kp = P
    self.Kd = D
    self.set point = set point # reference (desired value)
    self.previous error = 0
 def update(self, current value):
```

```
# calculate P term and D term
    error = self.set point - current value
    P term = self.Kp * error
    D term = self.Kd * (error - self.previous error)
    self.previous error = error
    return P term + D term
 def setPoint(self, set point):
    self.set point = set point
    self.previous error = 0
 def setPD(self, P=0.0, D=0.0):
    self.Kp = P
    self.Kd = D
class Turtlebot():
 def init (self, goal x, goal y, csv file):
    # Data to be taken from Launch File. Don't Edit
    self.goal x = goal x
    self.goal y = goal y
    self.csv file = csv file
    # Initialize subscribers and publishers
    self.lidar sub = rospy.Subscriber('/scan', LaserScan, self.lidar callback)
    self.vel pub = rospy.Publisher("/mobile base/commands/velocity", Twist, queue size=10)
    self.odom sub = rospy.Subscriber("odom", Odometry, self.odom callback)
    self.rate = rospy.Rate(10)
    self.listener = tf.TransformListener()
    # Initialize state variables
    self.left = "O"
    self.front = "F"
    self.wall = "S"
    self.state = "forward"
    self.current facing = 0 # straight
    self.logging counter = 0
    self.left min dist = 100
    self.forward min dist = 999
    self.pose = Pose2D()
```

```
self.goal tolerance = 0.3
  self.trajectory = list()
  self.angular threshold = 0.003
  self.pd control = PDController()
  self.pd control.setPD(1.0, 0.1)
  # For the complex world map
  self.control list = [pi/2, pi,pi/2]
  self.control list2 = [pi/2, 0]
  # Define Finite-State Machine matrix by NumPy
  self.state transition matrix = np.array([
     # Left Side: Free
     [ # Front side: free -> Left
       [1]
       # Front side: Occupied -> Right
       [2]
     # Left Side: Occupied
     [ # Front side: free -> Forward
       [0]
       # Front side: Occupied -> Right
       [2]
  # Define state and condition encoding
  self.state encoding = {'forward': 0, 'left': 1, 'right': 2}
  self.state decoding = {0: 'forward', 1: 'left', 2: 'right'}
  self.condition encoding = {'F': 0, 'O': 1} #F: free; O: Occupied
  self.current facing decoding = {0: "straight", -1: "small left", -2: "medium left", -3:
                       1: "small_right", 2: "medium_right", 3: "large_right"}
  self.run()
def run(self):
  # Don't edit anything
  while not rospy.is shutdown():
     self.update state() # Update the robot's state based on sensor readings
     # Publish velocity commands based on the current state
     self.publish velocity()
```

```
# Sleep to maintain the loop rate
      self.rate.sleep()
 def update state(self):
    # State machine to update the robot's state based on sensor readings
    current state encoding = self.state encoding[self.state]
    left cond encoding = self.condition encoding[self.left]
    front cond encoding = self.condition encoding[self.front]
    # Write code to encode current state and conditions
    # Get the new state from the state transition matrix
    new state encoded = self.state transition matrix[left cond encoding,
front cond encoding [0]
    # Decode the new state
    self.state = self.state decoding[new state encoded]
 def publish velocity(self):
    vel = Twist()
    # Publish velocity commands based on the current facing direction
    # Fill in the velocities, keep the values small
    # Keep editing values in the given range till the robot moves well.
    # Velocity values are good in the range of (0.01 to 0.2)
    # Angular Velocities are good in the range of (-0.08 to 0.08)
    if self.current facing decoding[self.current facing] == "straight": #0
      vel.linear.x = 0.2
      vel.angular.z = 0.0
    if self.current facing decoding[self.current facing] == "small left": #-1
      vel.linear.x = 0.1
      vel.angular.z = 0.03 \# 0.03
    if self.current facing decoding[self.current facing] == "medium left": #-2
      vel.linear.x = 0.1
      vel.angular.z = 0.05 \# 0.05
    if self.current facing decoding[self.current facing] == "small right": #1
      vel.linear.x = 0.1
      vel.angular.z = -0.03 \#0.03
    if self.current facing decoding[self.current facing] == "medium right": #2
      vel.linear.x = 0.1
      vel.angular.z = -0.05 \# -0.05
```

```
print(self.left + ' ' + self.front + ' ' + self.wall + ' ' +
   str(round(self.left_min_dist, 3)) + ' ' + str(round(self.forward_min_dist, 3)) +
   '' + self.state + '' + str(self.current facing))
if self.state == "left":
  if len(self.control list) < 1:
     rospy.signal shutdown('Received shutdown message')
  for i in range(5):
     vel.linear.x = 0.15
     vel.angular.z = 0.0
     self.vel_pub.publish(vel)
     self.rate.sleep()
  # use PD controller to control the angle: from Lab 5
  pd control=PDController()
  pd control.setPoint(self.control list[0])
  while abs(self.pose.theta -self.control list[0]) > self.angular threshold:
     adjust pos = pd control.update(self.pose.theta)
     vel.angular.z = max(-0.8,min(adjust pos*2.5,0.9))
     self.vel pub.publish(vel)
     self.rate.sleep()
  rospy.loginfo("done with turning left")
  self.control list.pop(0)
  # move forward a bit: from lab 4
  for i in range(15):
     vel.linear.x = 0.2
     vel.angular.z = 0.0
     self.vel_pub.publish(vel)
     self.rate.sleep()
elif self.state == "right":
  if len(self.control list2) < 1:
     rospy.signal shutdown('Received shutdown message')
```

```
# use PD controller to control the angle: from Lab 5
     pd control=PDController()
     pd control.setPoint(self.control list2[0])
     while abs(self.pose.theta -self.control list2[0]) > self.angular threshold:
       adjust pos = pd control.update(self.pose.theta)
       vel.angular.z = max(-0.8,min(adjust pos*2.5,0.9))
       self.vel pub.publish(vel)
       self.rate.sleep()
     rospy.loginfo("done with turning right")
     self.control list2.pop(0)
     for i in range(6):
       vel.linear.x = 0.2
       vel.angular.z = 0.0
       self.vel pub.publish(vel)
       self.rate.sleep
     self.vel pub.publish(vel)
def lidar callback(self, data):
  self.left min dist = 100
  # Update the forward distance with the distance directly in front of the robot
  if str(data.ranges[0]) == "inf":
     self.forward min dist = 999
  else:
     self.forward min dist = data.ranges[0]
  # transform the lidar points frame /rplidar link from to another frame: from lab 3 and lab 2
  #listener = tf.TransformListener()
  (trans, rot) = self.listener.lookupTransform('/base link', '/rplidar link', rospy.Time(0))
```

```
# Process the LIDAR data and transform the points to the robot's coordinate frame (another
frame you specified)
    for i in range(len(data.ranges)):
       if i * data.angle increment < 1.59 and i * data.angle increment > 1.55:
         if str(data.ranges[i]) == "inf":
            dist = 9999
         else:
            dist = data.ranges[i]
         (x, y) = \text{self.calculate position of range}(\text{dist, i, data.angle increment, data.angle min})
         transformed point = np.dot(tf.transformations.quaternion matrix(rot), np.array([x, y, 0, y, 0]))
1]))
         left dist = transformed point[1]
         if left dist < self.left min dist:
            self.left min dist = left dist
    # Update left and forward state
    if self.left min dist < 0.5:
       self.left = "O"
    else:
       self.left = "F"
    if self.forward min dist < 0.5:
       self.front = "O"
    else:
      self.front = "F"
    # Set wall state
    if self.left min dist < 0.3:
       self.wall = "C"
    else:
       self.wall = "S"
    # Update current facing direction
    # The basic idea is:
    # if the robot is too close, take the medium right facing; if it is too far, take the medium left
```

```
if self.left min dist < 0.3:
     self.current facing = 1
  elif self.left min dist < 0.25:
     self.current facing = 2
  elif (self.left min dist > 0.35) and (self.forward min dist < 2):
     self.current facing = 1
  elif (self.left min dist > 0.35) and (self.forward min dist < 1.5):
     self.current facing = 2
  elif (self.left min dist > 0.3) and (self.forward min dist > 2):
     self.current facing = -1
  elif (self.left min dist > 0.35):
     self.current facing = -2
  else:
     self.current facing = 0
def odom callback(self, data):
  # get the position of the robot
  pose = data.pose.pose
  self.pose.x = pose.position.x
  self.pose.y = pose.position.y
  quaternion = (
     pose.orientation.x,
     pose.orientation.y,
     pose.orientation.z,
     pose.orientation.w
  euler = tf.transformations.euler from quaternion(quaternion)
  self.pose.theta = euler[2]
  # Append pose data to the trajectory
  self.logging counter += 1
  if self.logging counter == 100:
     self.logging counter = 0
     self.trajectory.append([self.pose.x, self.pose.y])
  if sqrt((self.pose.x - self.goal x)**2 + (self.pose.y - self.goal y)**2) < self.goal tolerance:
     rospy.loginfo("Goal reached")
```

```
self.stop()
      self.save trajectory()
      rospy.signal shutdown('Goal reached')
 def stop(self):
    vel = Twist()
    vel.linear.x = 0.0
    vel.angular.z = 0.0
    self.vel pub.publish(vel)
 def save trajectory(self):
    # Save the trajectory to a CSV file
    np.savetxt(self.csv file, np.array(self.trajectory), fmt='%f', delimiter=',')
 def calculate position of range(self, range, index, angle increment, angle min):
    # Calculate the position of a range measurement in the LIDAR frame
    angle = index * angle increment + angle min
    x = range * np.cos(angle)
    y = range * np.sin(angle)
    return x, y
"'if name == ' main ':
 try:
    # Initialize the ROS node
    rospy.init node('turtlebot navigation', anonymous=True)
    # Get parameters from the launch file
    goal x = rospy.get param("\sim goal x", 5.0)
    goal y = rospy.get param("\sim goal y", 5.0)
    csv file = rospy.get param("~csv file", "/home/desktop/trajectory.csv")
    # Create the Turtlebot object and start the navigation
    turtlebot = Turtlebot(goal x, goal y, csv file)
 except rospy.ROSInterruptException:
def main(args):
```

```
# Initialize ROS Node
 rospy.init_node('left_wall_follower', anonymous=True)
 # Get parameters from the launch file
 goal x = rospy.get param('goal x')
 goal y = rospy.get param('goal y')
 csv_file = rospy.get_param('csv_file')
 # Create an instance of the Turtlebot class
 robot = Turtlebot(goal_x, goal_y, csv_file)
 try:
    rospy.spin()
 except KeyboardInterrupt:
    print("Shutting down")
if __name__ == '__main__':
 try:
    main(sys.argv)
 except rospy.ROSInterruptException:
    rospy.loginfo("Action terminated.")
```