



# DERCENTE PERENTANCE

ONE DRONE TO RULE THEM ALL





# **Project overall goal**

- Take control of multiple drones
  - Some existing military solutions
  - No civil solution







## **Project overall goal**

- Take control of multiple drones
  - Some existing military solutions
  - No civil solution



#### Our goals:

- Reduced cost
- No drone falling implied
- High number of compatible drones
- Usable on public events, by civilians











## **Syma - Introduction**

The goal of the attack is to highjack a Syma X5C-1 Drone in flight



#### **Documentation and markings tell us:**

- Not WIFI
- Frequency band 2.4 GHz
- 4 Channels






## Syma - Step 1 - Finding Radio Channels

#### Using an USRP B200 SDR with GnuRadio:

- USRP Source
- FFT and Waterfall Sinks
- Browse all channels by 1MHz steps

#### → Tx power received on channels:

- 10:2.410 GHz
- 31:2.431 GHz
- 42:2.442 GHz
- 66:2.466 GHz









## Syma - Step 2 - Finding Radio Modulation

#### <u>Using an USRP B200 SDR with GnuRadio:</u>

- **USRP Source**
- File Sink

#### **Opening file with Baudline:**





Constant amplitude → Not ASK. Could be (G)FSK or PSK







## Syma - Step 2 - Finding Radio Modulation

#### Trying GFSK as it is widely used for small electronics

- USRP Source
- Low Pass Filter
- **Quadrature Demod**
- File Sink
- Save bit stream

#### **Opening file with Baudline:**










## Syma – Step 3 – Understanding Data Link Layer



→ This kind of preamble is mostly used for Rx synchronisation

#### Message is 18 bytes (including preamble)



hexdump -C test3.raw (recorded bit stream)






## Syma – Step 3 – Understanding Data Link Layer


#### Introducing the nRF24l01+ module:

- Transceiver GFSK 2.4GHz on SPI bus
- Very popular module (on drones, RF mouses, DIY projects, ...)
- Come with 2 predefined packet based datalink layers (Basic or Enhanced Shockburst)
- Using 0xAA or 0x55 as preamble
- Using 3 to 5 bytes address
- Using variable payload length (up to 32 bytes in basic mode)
- Can use CRC on 1 or 2 bytes (optional)



Drone preamble is 0xAA which may mean that it is using a nR24l01+

→ Need to see if the rest of the frame matches





## Syma - Step 3 - Understanding Data Link Layer

With the help of a python script, we guessed the field sizes from the bit stream recorded with GnuRadio

https://github.com/chopengauer/nrf analyze/blob/master/nrf24 analyzer.py

```
[root@tigrou Syma X5C-1]# ../../nrf analyze/nrf24 analyzer.py
Start
OPosition 483 offset 483
                                Address alca201670
                                                         Data 00000000002000000176
                                                                                          CRC c711
                                                                                                          Len 10 preamb = aa
OPosition 9226 offset 8743
                                 Address alca201670
                                                         Data 00000000002000000003
                                                                                          CRC da12
                                                                                                          Len 10 preamb = aa
OPosition 16875 offset 7649
                                 Address alca201670
                                                         Data 00000000002000000176
                                                                                          CRC c711
                                                                                                          Len 10 preamb = aa
OPosition 17968 offset 1093
                                 Address alca201670
                                                         Data 00000000002000000176
                                                                                          CRC c711
                                                                                                          Len 10 preamb = aa
OPosition 25617 offset 7649
                                Address alca201670
                                                         Data 00000000002000000176
                                                                                          CRC c711
                                                                                                          Len 10 preamb = aa
OPosition 26710 offset 1093
                                 Address alca201670
                                                         Data 00000000002000000003
                                                                                          CRC da12
                                                                                                           Len 10 \text{ preamb} = aa
                                Address alca201670
OPosition 34359 offset 7649
                                                         Data 00000000002000000176
                                                                                          CRC c711
                                                                                                          Len 10 preamb = aa
OPosition 35452 offset 1093
                                 Address alca201670
                                                         Data 00000000002000000176
                                                                                          CRC c711
                                                                                                          Len 10 preamb = aa
OPosition 44195 offset 8743
                                 Address alca201670
                                                         Data 00000000002000000003
                                                                                          CRC da12
                                                                                                          Len 10 preamb = aa
                                 Address alca201670
                                                                                          CRC c711
OPosition 51845 offset 7650
                                                         Data 00000000002000000176
                                                                                                          Len 10 preamb = aa
OPosition 52937 offset 1092
                                 Address alca201670
                                                         Data 00000000002000000176
                                                                                          CRC c711
                                                                                                          Len 10 preamb = aa
OPosition 60588 offset 7651
                                 Address alca201670
                                                         Data 00000000002000000176
                                                                                          CRC c711
                                                                                                          Len 10 preamb = aa
OPosition 61681 offset 1093
                                 Address alca201670
                                                         Data 00000000002000000003
                                                                                          CRC da12
                                                                                                           Len 10 \text{ preamb} = aa
OPosition 69331 offset 7650
                                 Address alca201670
                                                         Data 00000000002000000176
                                                                                          CRC c711
                                                                                                          Len 10 preamb = aa
OPosition 79166 offset 9835
                                 Address alca201670
                                                         Data 00000000002000000003
                                                                                          CRC da12
                                                                                                          Len 10 preamb = aa
OPosition 87909 offset 8743
                                 Address alca201670
                                                         Data 0000000002000000176
                                                                                          CRC c711
                                                                                                           Len 10 \text{ preamb} = aa
```

In a nutshell:

Preamble	Address	Syma Protocol	DataLink CRC
(1 byte)	(5 bytes)	(10 bytes)	(2 bytes)
0xaa	0xa1ca201670		

Note: If we would not have had a SDR, we could have used a pseudo-promiscuous mode of the nRF24l01+ by tuning the module out of its specification. This is quite tricky. Refer to the full report for more information.






## Syma - Step 4 - Understanding Syma Protocol

## We built a live analyser

- With Raspberry PI and nRF24l01+
- **OLED Screen added for THCon**
- → By moving the RC controls, we could observe the payload.

## Finally, Syma Protocol is quite simple...\*

\*Except Byte 10: A pseudo CRC built as a XOR of bytes 1 to 9 and added to 0x55



Preamble	Address	Altitude	Pitch	Roll	Yaw	Other Stuff	Syma « CRC »	DataLink CRC
(1 byte)	(5 bytes)	(1 byte)	(1 byte)	(1 byte)	(1 byte)	(5 bytes)	(1 byte)	(2 bytes)
0xaa	0xa1ca201670							

... Now we were ready to implement!

... so we added a USB Gamepad, tuned the code ...


... and finally attacked!






## **Syma – Attack Characteristics**

- Attack is only working when the drone is already paired with a controller
  - → Some binding protocol exists (out of scope)
- Drone receives orders both from legit pilot and from predator
  - → Attack succeeds because the predator emits a lot more frames than the official remote
- We created a logger with RPI and nRF24l01+ to visualize the difference







## **Syma - Conclusion**

- Syma Protocol quite simple (1 byte per command, no encryption, ...)
- Highjacking a Syma X5C-1 requires very few ressources:
  - 1 Raspberry Pi Zero W (~10€)
  - 1 nRF24l01+ (~0.5€)
  - A few cables
  - 1 USB Gamepad (~5€)
- Attack is:
  - Hard to detect by the pilot
  - Easy to detect by an engineer (SDR, ...)
  - Almost impossible to stop without jamming and thus loosing the drone





## **The Parrot AR. Drone 2.0**

- Developed by a French company
- Released in 2012
- **Features:** 
  - OS: Linux 2.6.32
  - CPU: ARM Cortex A8
  - Autonomy: 12"
  - Optional GPS
- Controlled by WiFi
  - Open WiFi network
  - iOS/Android app









## **The Parrot AR. Drone 2.0**

- Developed by a French company
- Released in 2012
- **Features:** 
  - OS: Linux 2.6.32
  - CPU: ARM Cortex A8
  - Autonomy: 12"
  - Optional GPS
- Controlled by WiFi
  - Open WiFi network
  - iOS/Android app











## **Parrot – Attack principle**

- Based on a existing attack (Samy Kamkar)
  - Discover drones' WiFi network and clients Scapy sniff instead of airodump-ng
  - Disconnect client from network aireplay-ng
  - Connect to network and control the drone ardrone-webflight







Real connection







## **Parrot – Attack principle**


- Based on a existing attack (Samy Kamkar)
  - Discover drones' WiFi network and clients Scapy sniff instead of airodump-ng
  - Disconnect client from network aireplay-ng
  - Connect to network and control the drone ardrone-webflight







Deauth. attack









## **Parrot – Attack principle**

- Based on a existing attack (Samy Kamkar)
  - Discover drones' WiFi network and clients Scapy sniff instead of airodump-ng
  - Disconnect client from network aireplay-ng
  - Connect to network and control the drone ardrone-webflight














# **Parrot – WiFi network discovering with Scapy**








Passive scan






# **Parrot – WiFi network discovering with Scapy**








Passive scan

90:03: b7:c8:68: d0





## **Parrot - WiFi network discovering with Scapy**



Beacon < Hidden SSID: Beacon <SSID A> Beacon <SSID B>

Active scan

Passive scan


90:03: b7:c8:68: d0

Organisationally Unique Identifier (OUI) **Network Interface** Controller (NIC) specific





## **Parrot - WiFi network discovering with Scapy**



Beacon < Hidden SSID: Beacon <SSID A> Beacon <SSID B>

Active scan Passive scan

90:03: b7:c8:68: d0

Manufacturer filtering



Organisationally Unique Identifier (OUI) **Network Interface** Controller (NIC) specific





- Raspberry Pi Zero W
  - Bluetooth adapter
  - WiFi adapter
  - SPI bus
  - Lightweight







- Raspberry Pi Zero W
  - Bluetooth adapter
  - WiFi adapter
  - SPI bus
  - Lightweight



Tried reducing network adapter count





- Raspberry Pi Zero W
  - Bluetooth adapter
  - WiFi adapter
  - SPI bus
  - Lightweight



- Tried reducing network adapter count
- Network to control board:
  - Bluetooth PAN
  - SSH connection






- Raspberry Pi Zero W
  - Bluetooth adapter
  - WiFi adapter
  - SPI bus
  - Lightweight



- Tried reducing network adapter count
- Network to control board:
  - Bluetooth PAN
  - SSH connection
- ardrone-webflight moved to attacker's computer







## **Parrot - Protection means**

#### Use Parrot's solution

- Associate MAC address of real pilot
- Bypassed by MAC spoofing

#### Do not send beacon frames

- Active search of WiFi networks
- Eventually brute-force searching

## **Encrypt WiFi trafic**

- Using WPA
- Parrot Bepop example





Parrot Bepop





## **Drone-predator hacking Parrot – Demo**





## **Questions**

# QUESTIONS



## Promiscous mode with nRF24l01+

Preamble (1 byte)

Address (3-5 bytes)

Payload (0-32 bytes)

CRC (0-2 bytes)

#### No promiscuous mode but :

- Receiver does not check for preamble (0xAA), just checking the address
- Part before preamble is often interpreted as 0x00
- Configuration register can be set at '00' even if it is out of spec. In this case the addess is 2 bytes

03	SETUP_AW		***************************************		Setup of Address Widths (common for all data pipes)
	Reserved	7:2	000000	R/W	Only '000000' allowed
	AW	1:0	11	R/W	RX/TX Address field width
	30°0°00				'00' - Illegal '01' - 3 bytes '10' - 4 bytes '11' – 5 bytes LSByte is used if address width is below 5 bytes

→ We can configure pseudo-promiscous mode by setting 0x00AA as a receiver address.