TinyOS

Hands-on Session



Goals

- 1.Install TinyOS
- 2.Layout of tinyos-2.x
- 3. Write two applications
 - (A) DisseminationDemoClient
 - (B) CollectionsDemoClient



Options


- LiveCD
 - XubunTOS
 - Customized Ubuntu 8.10 LiveCD



- Native
 - Linux
 - .rpm packages
 - .deb packages



- MacOS X
 - stow
 - macports



Recommended



Other Options

VMware

- Jetos
 - based on JeOS (Ubuntu Server 8.04)
 - optimized for ssh access
 - very small: 190MB compressed
- Lenny
 - based on Debian 5.0 "Lenny"
 - graphical interface using XFCE
 - bigger: 300MB compressed
- XubunTOS



Components

- NesC: nesc_*.deb
- Cross compiler
 - binutils: msp430-binutils-tinyos_*.deb
 - gcc: msp430-gcc-tinyos_*.deb
 - libc: msp430-libc-tinyos_*.deb
 - gdb (optional)
- Deputy: deputy-tinyos_*.deb



Environment

```
export TOSROOT=$HOME/local/src/tinyos-2.x
export TOSDIR=$TOSROOT/tos

export MAKERULES=$TOSROOT/support/make/Makerules

export CLASSPATH=$TOSROOT/support/sdk/java/tinyos.jar:.
export PYTHONPATH=$TOSROOT/support/sdk/python
```



Architectures

- AVR
 - mica2, mica2dot
 - micaz
 - btnode
 - IRIS

- ARM
 - imote2

- MSP430
 - telosb, sky
 - shimmer
 - eyesIFX
 - tinynode
 - epic
- 8051
 - CC2430
 - CC1110/CC1111



```
+ tinyos-2.x
+ apps
+ docs
+ support
+ tools
+ tos
```



```
+ apps
  + Blink
  + Null
  + RadioCountToLeds
  + MultihopOscilloscope
  + tests
+ docs
+ support
+ tools
+ tos
```



```
+ apps
+ docs
+ html
+ pdf
+ txt
+ ...
+ support
+ tools
+ tos
```



```
+ apps
+ docs
+ support
  + make
    - Makerules
    + avr/
    + msp/
  + sdk
+ tools
+ tos
```



```
+ apps
+ docs
+ support
  + make
  + sdk
    + c
    + cpp
    + java
    + python
+ tools
+ tos
```



```
+ support
  + sdk
    + c
      + blip
      + sf
    + cpp
      + sf
    + java
      - tinyos.jar
    + python
      + tinyos
      - tos.py
```



```
+ apps
+ docs
+ support
+ tools
+ tos
  + chips
  + interfaces
  + lib
  + platforms
  + sensorboards
  + systems
  + types
```



```
+ tos
  + chips
    + atm128
    + msp430
    + pxa27x
    + cc2420
    + cc1000
    + at45db
    + stm25p
    + sht11
```



```
+ tos
  + chips
  + interfaces
    - Boot.nc
    - SplitControl.nc
    - StdControl.nc
  + lib
  + platforms
  + sensorboards
  + systems
  + types
```



```
+ tos
  + lib
    + net
    + printf
    + timer
    + tosthreads
    + serial
      SerialActiveMessageC.nc
      - SerialAMSenderC.nc
      - SerialAMReceiverC.nc
```



```
+ tos
  + lib
    + net
      + ctp
      + 4bitle
      + drip
      + Deluge
      + dip
      + blip
      + ...
```



- + tos
 - + systems
 - AMReceiverC.nc
 - AMSenderC.nc
 - MainC.nc
 - LedsC.nc
 - TimerMilliC.nc
 - . . .



```
+ tos
  + chips
  + interfaces
  + lib
  + platforms
  + sensorboards
  + systems
  + types
    - TinyError.h
    - messssage.h
```



Applications

DisseminationDemo CollectionDemo



DisseminationDemo



DisseminationDemo


DisseminationDemoClient

- start the radio
- start Drip
- when a new value is received print its contents




- start the radio
- start Drip
- start a periodic timer
- on each firing or the timer increment a counter and disseminate it





DisseminationDemoClient





DisseminationDemoClient

Interfaces

- Boot
- StdControl
- SplitControl
- DisseminationValue<t>

Components

- MainC
- ActiveMessageC
- DisseminationC
- DisseminatorC



tos/interfaces/Boot.nc

```
interface Boot {
  event void booted();
}
```



tos/interfaces/StdControl.nc

```
interface StdControl
{
   command error_t start();
   command error_t stop();
}
```



tos/interfaces/SplitControl.nc

```
interface SplitControl
{
  command error_t start();
  event void startDone(error_t error);
  command error_t stop();
  event void stopDone(error_t error);
}
```



tos/lib/net/DisseminationValue.nc

```
interface DisseminationValue<t> {
  command const t* get();
  command void set(const t*);
  event void changed();
}
```



tos/system/MainC.nc

```
configuration MainC {
  provides interface Boot;
  uses interface Init as SoftwareInit;
}
implementation {
  ...
}
```



tos/platforms/telosa/ActiveMessageC.nc

```
configuration ActiveMessageC {
  provides {
    interface SplitControl;
implementation {
```



tos/lib/net/drip/DisseminationC.nc

```
configuration DisseminationC {
  provides interface StdControl;
}
implementation {
  ...
}
```



tos/lib/net/drip/DisseminatorC.nc



Makefile

COMPONENT=DisseminationDemoClientAppC

```
CFLAGS += -I%T/lib/net
CFLAGS += -I%T/lib/net/drip
CFLAGS += -I%T/lib/printf
include $(MAKERULES)
```



Commands

- \$ make telosb
- \$ make telosb install,42
- \$ tos-dump.py serial@/dev/ttyUSB0:115200



Summary

```
tos/interfaces/Boot.nc
tos/interfaces/StdControl.nc
tos/interfaces/SplitControl.nc
```

```
tos/system/MainC.nc
tos/platforms/telosa/ActiveMessageC.nc
tos/lib/net/drip/DisseminationC.nc
tos/lib/net/drip/DisseminatorC.nc
```



DisseminationDemoClientAppC.nc

```
configuration DisseminationDemoClientAppC { }
implementation
 components MainC;
 components DisseminationC;
 components new DisseminatorC(nx uint32 t, 2009);
 components DisseminationDemoClientC;
 components ActiveMessageC;
 DisseminationDemoClientC.Boot -> MainC;
 DisseminationDemoClientC.DisseminationStdControl -> DisseminationC;
 DisseminationDemoClientC.DisseminationValue -> DisseminatorC;
 DisseminationDemoClientC.RadioSplitControl -> ActiveMessageC;
```



DisseminationDemoClientC.nc

```
module DisseminationDemoClientC
  uses {
    interface Boot;
    interface DisseminationValue<nx_uint32_t>;
    interface StdControl as DisseminationStdControl;
    interface SplitControl as RadioSplitControl;
implementation
  nx uint32 t counter;
  event void Boot.booted()
    call RadioSplitControl.start();
```



DisseminationDemoClientC.nc

```
module DisseminationDemoClientC
implementation
  event void RadioSplitControl.startDone(error t error)
    call DisseminationStdControl.start();
  event void DisseminationValue.changed()
    printf("R: %lu\n", *(call DisseminationValue.get()));
    printfflush();
  event void RadioSplitControl.stopDone(error t error) { }
```

http://docs.tinyos.net/index.php/lpsn2009-tutorial



CollectionDemo



CollectionDemo


CollectionDemoClient


- start the radio
- start CTP
- start a periodic timer
- on each firing or the timer increment a counter and sent it over CTP

CollectionDemoServer

- start the radio
- start CTP
- when a new value is received print its contents









Interfaces

- Boot
- StdControl
- SplitControl
- Send
- Timer<TMilli>

Components

- MainC
- ActiveMessageC
- CollectionC
- CollectionSenderC
- TimerMilliC



Interfaces

- Boot
- StdControl
- SplitControl
- Send
- Timer<TMilli>

Components

- MainC
- ActiveMessageC
- CollectionC
- CollectionSenderC
- TimerMilliC



tos/interfaces/Send.nc

```
interface Send {
  command error_t send(message_t* msg, uint8_t len);
  event void sendDone(message_t* msg, error_t error);
  command uint8_t maxPayloadLength();
  command void* getPayload(message_t* msg, uint8_t len);
  command error_t cancel(message_t* msg);
}
```



tos/lib/net/ctp/CollectionC.nc

```
configuration CollectionC {
   provides {
     interface StdControl;
     ...
  }
}
implementation {
   ...
}
```



tos/lib/net/ctp/CollectionSenderC.nc

```
generic configuration
CollectionSenderC(collection_id_t collectid) {
  provides {
    interface Send;
    interface Packet;
  }
}
implementation {
    ...
}
```



tos/system/TimerMilliC.nc

```
generic configuration TimerMilliC() {
  provides interface Timer<TMilli>;
}
implementation {
  ...
}
```



Makefile

COMPONENT=CollectionDemoClientAppC

```
CFLAGS += -I%T/lib/net
CFLAGS += -I%T/lib/net/ctp
CFLAGS += -I%T/lib/net/4bitle
CFLAGS += -I%T/lib/printf
include $(MAKERULES)
```



Summary

```
tos/interfaces/Boot.nc
tos/interfaces/StdControl.nc
tos/interfaces/SplitControl.nc
tos/interfaces/Send.nc
tos/lib/timer/Timer.nc
```

tos/system/MainC.nc
tos/system/TimerMilliC.nc
tos/platforms/telosa/ActiveMessageC.nc
tos/lib/net/ctp/CollectionC.nc
tos/lib/net/ctp/CollectionSenderC.nc



```
configuration CollectionDemoClientAppC { }
implementation
 components MainC;
 components ActiveMessageC;
 components CollectionC;
 components new CollectionSenderC(16);
 components new TimerMilliC() as Timer;
 components CollectionDemoClientC;
 CollectionDemoClientC.Boot -> MainC;
 CollectionDemoClientC.RadioSplitControl -> ActiveMessageC;
 CollectionDemoClientC.CollectionStdControl -> CollectionC;
 CollectionDemoClientC.Send -> CollectionSenderC;
 CollectionDemoClientC.Timer -> Timer;
```



```
module CollectionDemoClientC
  uses {
    interface Boot;
    interface SplitControl as RadioSplitControl;
    interface StdControl as CollectionStdControl;
    interface Send;
    interface Timer<TMilli>;
implementation
  message_t smsg;
  typedef nx struct {
    nx uint8 t string[8];
    nx uint16 t counter;
  } name t;
  name t *name;
```

```
module CollectionDemoClientC
implementation
  event void Boot.booted()
    name = call Send.getPayload(&smsg, sizeof(name_t));
    strcpy((char*)name->string, "name");
    name->counter = 0;
    call RadioSplitControl.start();
```



```
module CollectionDemoClientC
implementation
  event void RadioSplitControl.startDone(error_t error)
    call CollectionStdControl.start();
    call Timer.startPeriodic(1024);
```



```
module CollectionDemoClientC
implementation
  event void Timer.fired()
    error t error;
    name->counter++;
    error = call Send.send(&smsg, sizeof(name t));
    printf("S: %d %d\n", name->counter, error);
    printfflush();
  event void Send.sendDone(message t* msg, error t error) { }
  event void RadioSplitControl.stopDone(error t error) { }
```



http://docs.tinyos.net/index.php/lpsn2009-tutorial



The End.

