

# ECE291

## Lecture 9

*Interrupt implementation  
(part of the magic explained!)*

# Lecture outline

- Interrupt vectors
- Software interrupts
- Hardware interrupts
- 8259 Programmable Interrupt Controller
- Writing your own handlers
- Installing handlers

# Interrupts

- Triggers that cause the CPU to perform various tasks on demand
- Three kinds:
  - Software interrupts – initiated by the INT instruction
  - Hardware interrupts – originate in peripheral hardware
  - Exceptions – occur in response to error states in the processor
- Regardless of source, they are handled the same
  - Each interrupt has a unique interrupt number from 0 to 255. These are called **interrupt vectors**.
  - For each interrupt vector, there is an entry in the interrupt vector table.
  - The interrupt vector table is simply a jump table containing segment:offset addresses of procedures to handle each interrupt
  - These procedures are called ***interrupt handlers*** or ***interrupt service routines (ISR's)***

# Interrupt vectors

- The first 1024 bytes of memory (addresses 00000 – 003FF) always contain the interrupt vector table. Always. Never anything else.
- Each of the 256 vectors requires four bytes—two for segment, two for offset

Memory address (hex)	Interrupt function pointer
003FC	INT 255
4 * x	INT x
00008	INT 2
00004	INT 1
00000	INT 0

# Software interrupts

- Essentially just function calls using a different instruction to do the calling
- Software interrupts give you access to “built-in” code from BIOS, operating system, or peripheral devices
- Use the INT instruction to “call” these procedures

# The INT and IRET instructions

- Syntax: INT imm8
- Imm8 is an interrupt vector from 0 to 255
- INT does the following:
  - Pushes flag register (pushf)
  - Pushes return CS and IP
  - Far jumps to [0000:(4\*imm8)]
  - Clears the interrupt flag disabling the interrupt system
- IRET is to INT what RET is to CALL
  - Pops flag register
  - Performs a far return


# Things to notice

- The interrupt vector table is just a big permanently located jump table
- The values of the jump table are pointers to code provided by bios, hardware, the os, or eventually 291 students
- Interrupt service routines preserve the flags – the state of the computer should be completely unaltered by an ISR

# Hardware interrupts

- Alert the processor of some hardware situation that needs tending to
  - A key has been pressed
  - A timer has expired
  - A network packet has arrived
- Same software calling protocol
- Additional level of complexity with the interrupt “call” not coming from your program code
- Can happen at any time during the execution of your program

# The 80x86 interrupt interface




- Device generates request signal
- Device supplies interrupt vector number on data bus
- Processor completes the execution of current instruction and executes ISR corresponding to the interrupt vector number on the data bus
- ISR upon completion acknowledges the interrupt by asserting the INTA signal

# But wait there's more...

- The above setup could get complicated with multiple devices generating multiple interrupts connected to the same few pins on the processor
- Enter the 8259 Programmable Interrupt Controller


# The 8259 PIC



# The 8259 PIC

- The PIC is programmed with a base interrupt vector number
  - “0” corresponds to this base
  - “1” corresponds to this base + 1
  - “ $n$ ” corresponds to this base +  $n$
- For example, if the PIC is programmed with a base interrupt vector of 8, then “0” corresponds to interrupt vector 8

# The whole enchilada



# Typical IRQ assignments

- IRQ 0: Timer (triggered 18.2/second)
- IRQ 1: Keyboard (keypress)
- IRQ 2: Slave PIC
- IRQ 3: Serial Ports (Modem, network)
- IRQ 5: Sound card
- IRQ 6: Floppy (read/write completed)
- IRQ 8: Real-time Clock
- IRQ 12: Mouse
- IRQ 13: Math Co-Processor
- IRQ 14: IDE Hard-Drive Controller

# Interrupt priority

- Lower interrupt vectors have higher priority
- Lower priority can't interrupt higher priority
  - ISR for INT 21h is running
    - Computer gets request from device attached to IRQ8 (INT 78h)
    - INT 21h procedure must finish before IRQ8 device can be serviced
  - ISR for INT 21h is running
    - Computer gets request from Timer 0 IRQ0 (INT 8h)
    - Code for INT 21h gets interrupted, ISR for timer runs immediately, INT21h finishes afterwards

# Servicing an interrupt

- Complete current instruction
- Preserve current context
  - PUSHF Store flags to stack
  - Clear Trap Flag (TF) & Interrupt Flag (IF)
  - Store return address to stack  
PUSH CS, PUSH IP
- Identify Source
  - Read 8259 PIC status register
  - Determine which device (N) triggered interrupt
- Activate Interrupt Service Routine
  - Use N to index vector table
  - Read CS/IP from table
  - Jump to instruction

- Execute Interrupt Service Routine
  - usually the handler immediately re-enables the interrupt system (to allow higher priority interrupts to occur) (STI instruction)
  - process the interrupt
- Indicate End-Of-Interrupt (EOI) to 8259 PIC
  - `mov al, 20h`
  - `out 20h, al`  
*;transfers the contents of AL to I/O port 20h*
- Return (IRET)
  - POP IP (Far Return)
  - POP CS
  - POPF (Restore Flags)

# Interrupt service routines

- Reasons for writing your own ISR's

- to supersede the default ISR for internal hardware interrupts (e.g., division by zero)
- to chain your own ISR onto the default system ISR for a hardware device, so that both the system's actions and your own will occur on an interrupt (e.g., clock-tick interrupt)
- to service interrupts not supported by the default device drivers (a new hardware device for which you may be writing a driver)
- to provide communication between a program that terminates and stays resident (TSR) and other application software

# Interrupt service routines

## • DOS facilities to install ISRs

Function	Action
INT 21h Function 25h	Set Interrupt vector
INT 21h Function 35h	Get Interrupt vector
INT 21h Function 31h	Terminate and stay resident

## • Restrictions on ISRs

- Currently running program should have no idea that it was interrupted.
- ISRs should be as short as possible because lower priority interrupts are blocked from executing until the higher priority ISR completes

# Interrupt Service Routines

- ISRs are meant to be short
  - keep the time that interrupts are disable and the total length of the service routine to an **absolute minimum**
  - remember after interrupts are re-enabled (STI instruction), interrupts of the same or lower priority remain blocked if the interrupt was received through the 8259A PIC
- ISRs can be interrupted
- ISRs must be in memory
  - Option 1: Redefine interrupt only while your program is running
    - the default ISR will be restored when the executing program terminates
  - Option 2: Use DOS Terminate-and-Stay-Resident (TSR) command to load and leave program code permanently in memory

# Installing ISRs

Let **N** be the interrupt to service

- Read current function pointer in vector table
  - Use DOS function 35h
  - Set **AL = N**
  - Call DOS Function **AH = 35h, INT 21h**
  - Returns: **ES:BX** = Address stored at vector N
- Set new function pointer in vector table
  - Use DOS function 25h
  - Set **DS:DX** = New Routine
  - Set **AL = N**
  - DOS Function **AH = 25h, INT 21h**

# Installing ISR

- Interrupts can be installed, chained, or called
- Install New interrupt  
**replace old interrupt**

**MyIntVector**

Save Registers  
Service Hardware  
Reset PIC  
Restore Registers  
IRET

- Chain into interrupt  
**Service myCode first**

**MyIntVector**

Save Registers  
MyCode  
Restore Registers  
JMP CS:Old\_Vector

- Call Original Interrupt  
**Service MyCode last**

**MyIntVector**

PUSHF  
CALL CS:Old\_Vector  
Save Registers  
MyCode  
Restore Registers  
IRET

# Interrupt Driven I/O

- Consider an I/O operation, where the CPU constantly tests a port (e.g., keyboard) to see if data is available
  - CPU polls the port if it has data available or can accept data
- Polled I/O is inherently inefficient
- Wastes CPU cycles until event occurs
- Analogy:* Checking your watch every 30 seconds until your popcorn is done, or standing at the door until someone comes by
- Solution is to provide **interrupt driven I/O**
- Perform regular work until an event occurs
- Process event when it happens, then resume normal activities
- Analogy:* Alarm clock, doorbell, telephone ring

# Timer interrupt example

- In this example we will replace the ISR for the Timer Interrupt
- Our ISR will count the number of timer interrupts received
- Our main program will use this count to display elapsed time in minutes and seconds

# Timer interrupt - main proc skeleton

```
;===== Variables =====
; Old Vector (far pointer to old interrupt function)
oldv    RESW   2
count   DW 0    ;Interrupt counter (1/18
               sec)
scount  DW 0    ;Second counter
mcount  DW 0    ;Minute counter
pbuf    DB 8    ;Minute counter
;===== Main procedure =====
..start
...
;----Install Interrupt Routine-----
call Install
;Main program (print count values)
.showc
Mov ax, [mcount] ;Minute Count
...
```

```
call pxy
mov ax, [scount] ;Second Count
...
call pxy
mov ax,[count] ;Interrupt Count (1/18 sec)
...
call pxy
mov ah,1
int 16h          ;Check for key press
jz   .showc       ;Quit on any key
;
;---- Uninstall Interrupt Routine-----
call UnInst      ;Restore original INT8
...
call mpxit
```

# Timer interrupt – complete main proc

..start

```
mov ax, cs           ;Initialize DS=CS
mov ds, ax
mov ax, 0B800h       ;ES=VideoTextSegment
mov es, ax
call install         ;Insert my ISR
```

showc:

```
mov ax, [mcount]     ;Minute Count
mov bx, pbuf
call binasc
mov bx, pbuf
mov di,0             ;Column 0
mov ah,00001100b    ;Intense Red
call pxy

mov ax,[scount]      ;Second Count
mov bx,pbuf
call binasc
mov bx, pbuf
```

```
mov di,12            ;Column 6 (DI=12/2)
mov ah,00001010b    ;Intense Green
call pxy

mov ax,[count]        ;Int Count (1/18th sec)
mov bx,pbuf
call binasc
mov bx, pbuf
mov ah,00000011b    ;Cyan
mov di,24            ;Column 12 (DI=24/2)
call pxy
mov ah,1
int 16h              ;Key Pressed ?
jz showc

Call UnInst          ;Restore original INT8
mov ax,4c00h
int 21h              ;Normal DOS Exit
```

# Timer interrupt – PXY and Install interrupt

```
:pxy (bx = *str, ah = color, di = column)
pxy
    mov al, [bx]
    cmp al, '$'
    je .pxydone
    mov es:[di+2000], ax
    inc bx
    add di,2
    jmp pxy
.pxystart
    ret
===== Install Interrupt =====
install
    ;Install new INT 8 vector
    push es
    push dx
    push ax
    push bx
```

```
    mov al, 8      ;INT = 8
    mov ah, 35h    ;Read Vector Subfunction
    int 21h       ;DOS Service

    mov word [oldv+0], bx
    mov word [oldv+2], es
    mov al, 8      ;INT = 8
    mov ah, 25h    ;Set Vector Subfunction

    mov dx, myint ;DS:DX point to function
    int 21h       ;DOS Service

    pop bx
    pop ax
    pop dx
    pop es
    ret
```

# Timer interrupt – uninstall interrupt

```
===== Uninstall Interrupt =====
```

```
UnInst          ; Uninstall Routine (Reinstall old vector)
```

```
push ds
push dx
push ax
mov dx, word [oldv+0]
mov ds, word [oldv+2]

mov al, 8      ; INT = 8
mov ah, 25h    ; Subfunction = Set Vector
int 21h        ; DOS Service

pop ax
pop dx
pop ds
ret
```

# Timer interrupt – ISR code

===== ISR Code =====

myint

```
push ds      ;Save all registers  
push ax  
mov ax, cs   ;Load default segment  
mov ds, ax  
pushf        ;Call Orig Function w	flags  
call far [oldv] ;Far Call to existing routine  
  
inc word [count]          ;Increment Interrupt count  
cmp word [count],18  
jne .myintdone
```

```
inc word [scount]      ;Next second  
mov word [count], 0  
cmp word [scount], 60  
jne .myintdone  
inc word [mcount]      ; Next minute  
mov word [scount], 0  
  
.myintdone  
mov al, 20h    ;Reset the PIC  
out 20h, al    ;End-of-Interrupt signal  
pop ax         ;Restore all Registers  
pop ds  
iret          ;Return from Interrupt
```

# The complete code with exe

- [www.ece.uiuc.edu/ece291/lecture/timer.asm](http://www.ece.uiuc.edu/ece291/lecture/timer.asm)
- [www.ece.uiuc.edu/ece291/lecture/timer.exe](http://www.ece.uiuc.edu/ece291/lecture/timer.exe)

# Replacing An Interrupt Handler

```
;install new interrupt vector
%macro setInt 3 ;Num, OffsetInt, SegmentInt
    push ax
    push dx
    push ds

    mov dx, %2
    mov ax, %3
    mov ds, ax
    mov al, %1
    mov ah, 25h ;set interrupt vector
    int 21h

    pop ds
    pop dx
    pop ax
%endmacro
```

```
;store old interrupt vector
%macro getInt 3 ;Num, OffsetInt, SegmentInt
    push bx
    push es

    mov al, %1
    mov ah, 35h ;get interrupt vector
    int 21h
    mov %2, bx
    mov %3, es

    pop es
    pop bx
%endmacro
```

# Replacing An Interrupt Handler

```
CR EQU 0dh  
LF EQU 0ah
```

```
SEGMENT stkseg STACK  
    resb 8*64  
stacktop:
```

```
SEGMENT code
```

```
Warning DB "Overflow - Result Set to  
ZERO!!!!",CR,LF,0
```

```
msgOK DB "Normal termination", CR, LF, 0
```

```
old04hOffset      RESW  
old04hSegment     RESW
```

```
New04h ;our new ISR for int 04  
;occurs on overflow  
sti   ;re-enable interrupts  
  
mov  ax, Warning  
push ax  
call putStr ;display message  
xor  ax, ax ;set result to zero  
cwd  ;AX to DX:AX  
  
iret
```

# Replacing An Interrupt Handler

```
.start
    mov ax, cs
    mov ds, ax

    ;store old vector
    getInt 04h, [old04hOffset], [old04hSegment]

    ;replace with address of new int handler
    setInt 04h, New04h, cs

    mov al, 100
    add al, al
    into ;calls int 04 if an overflow occurred
    test ax, 0FFh
    jz Error
```

```
    mov ax, msgOK
    push ax
    call putStr
```

Error:

```
;restore original int handler
setInt 04h, [old04hOffset], [old04hSegment]
```

```
    mov ax, 4c00h
    int 21h
```

## NOTES

- INTO is a conditional instruction that acts only when the overflow flag is set
- With INTO after a numerical calculation the control can be automatically routed to a handler routine if the calculation results in a numerical overflow.
- By default Interrupt 04h consists of an IRET, so it returns without doing anything.