

# **KnowHow**

# SystemVerilog Assertions Tutorial

#### Introduction

Assertions are primarily used to validate the behaviour of a design. ("Is it working correctly?") They may also be used to provide functional coverage information for a design ("How good is the test?"). Assertions can be checked dynamically by simulation, or statically by a separate property checker tool – i.e. a formal verification tool that proves whether or not a design meets its specification. Such tools may require certain assumptions about the design's behaviour to be specified.

Contact Us

For more information about any of the Doulos training services

get in touch »

In SystemVerilog there are two kinds of assertions: immediate (assert) and concurrent (assert property). Coverage statements (cover property) are concurrent and have the same syntax as concurrent assertions, as do assume property statements. Another similar statement – expect – is used in testbenches; it is a procedural statement that checks that some specified activity occurs. The three types of concurrent assertion statement and the expect statement make use of sequences and properties that describe the design's temporal behaviour – i.e. behaviour over time, as defined by one or more clocks.

#### **Immediate Assertions**

Immediate assertions are procedural statements and are mainly used in simulation. An assertion is basically a statement that something must be true, similar to the if statement. The difference is that an if statement does not assert that an expression is true, it simply checks that it is true, e.g.:

```
if (A == B) ... // Simply checks if A equals B assert (A == B); // Asserts that A equals B; if not, an error is generated
```

If the conditional expression of the immediate assert evaluates to X, Z or 0, then the assertion fails and the simulator writes an error message. An immediate assertion may include a pass statement and/or a fail statement. In our example the *pass statement* is omitted, so no action is taken when the assert expression is true. If the pass statement exists:

```
assert (A == B) $display ("OK. A equals B");
```

it is executed immediately after the evaluation of the assert expression. The statement associated with an else is called a *fail statement* and is executed if the assertion fails:

```
assert (A == B) $display ("OK. A equals B");
else $error("It's gone wrong");
```

Note that you can omit the pass statement and still have a fail statement:

```
assert (A == B) else $error("It's gone wrong");
```

The failure of an assertion has a severity associated with it. There are three severity system tasks that can be included in the fail statement to specify a severity level: \$fatal, \$error\$ (the default severity) and \$warning. In addition, the system task \$info\$ indicates that the assertion failure carries no specific severity.

Here are some examples:

The pass and fail statements can be any legal SystemVerilog procedural statement. They can be used, for example, to write out a message, set an error flag, increment a count of errors, or signal a failure to another part of the testbench.

```
AeqB: assert (a === b)
  else begin error_count++; $error("A should equal B"); end
```

#### **Concurrent Assertions**

The behaviour of a design may be specified using statements similar to these:

"The Read and Write signals should never be asserted together."

"A Request should be followed by an Acknowledge occurring no more than two clocks after the Request is asserted."

Concurrent assertions are used to check behaviour such as this. These are statements that assert that *specified properties* must be true. For example,

```
assert property (!(Read && Write));
```

asserts that the expression Read && Write is never true at any point during simulation.

Properties are built using sequences. For example,

```
assert property (@(posedge Clock) Req |-> ##[1:2] Ack);
```

where Req is a simple sequence (it's just a boolean expression) and ##[1:2] Ack is a more complex sequence expression, meaning that Ack is true on the next clock, or on the one following (or both). |-> is the implication operator, so this assertion checks that whenever Req is asserted, Ack must be asserted on the next clock, or the following clock.

Concurrent assertions like these are checked throughout simulation. They usually appear outside any initial or always blocks in modules, interfaces and programs. (Concurrent assertions may also be used as statements in initial or always blocks. A concurrent assertion in an initial block is only tested on the first clock tick.)

The first assertion example above does not contain a clock. Therefore it is checked at every point in the simulation. The second assertion is only checked when a rising clock edge has occurred; the values of Reg and Ack are sampled on the rising edge of Clock.

# **Implication**

The *implication* construct (|->) allows a user to monitor sequences based on satisfying some criteria, e.g. attach a precondition to a sequence and evaluate the sequence only if the condition is successful. The left-hand side operand of the implication is called the *antecedent sequence* expression, while the right-hand side is called the *consequent sequence expression*.

If there is no match of the *antecedent sequence expression*, implication succeeds vacuously by returning true. If there is a match, for each successful match of the *antecedent sequence expression*, the *consequent sequence expression* is separately evaluated, beginning at the end point of the match.

There are two forms of *implication*: overlapped using operator |->, and non-overlapped using operator |->.

For overlapped implication, if there is a match for the *antecedent sequence expression*, then the first element of the *consequent sequence expression* is evaluated on the same clock tick.

```
s1 |-> s2;
```

In the example above, if the sequence s1 matches, then sequence s2 must also match. If sequence s1 does not match, then the result is true. For non-overlapped implication, the first element of the *consequent sequence expression* is evaluated on the next clock tick.

```
s1 |=> s2;
```

The expression above is basically equivalent to:

```
'define true 1
s1 ##1 'true |-> s2;
```

where `true is a boolean expression, used for visual clarity, that always evaluates to true.

## **Properties and Sequences**

In these examples we have been using, the properties being asserted are specified in the assert property statements themselves. Properties may also be declared separately, for example:

```
property not_read_and_write;
  not (Read && Write);
endproperty assert property (not_read_and_write);
```

Complex properties are often built using sequences. Sequences, too, may be declared separately:

```
sequence request
  Req;
endsequence

sequence acknowledge
  ##[1:2] Ack;
endsequence

property handshake;
  @(posedge Clock) request |-> acknowledge;
endproperty

assert property (handshake);
```

## **Assertion Clocking**

Concurrent assertions (assert property and cover property statements) use a generalised model of a clock and are only evaluated when a clock tick occurs. (In fact the values of the variables in the property are sampled right at the end of the previous time step.) Everything in between clock ticks is ignored. This model of execution corresponds to the way a RTL description of a design is interpreted after synthesis. A clock tick is an atomic moment in time and a clock ticks only once at any simulation time. The clock can actually be a single signal, a gated clock (e.g. (clk && GatingSig)) or other more complex expression. When monitoring asynchronous signals, a simulation time step corresponds to a clock tick.

The clock for a property can be specified in several ways:

o Explicitly specified in a sequence:

```
sequence s;
  @(posedge clk) a ##1 b;
endsequence
property p;
  a |-> s;
endproperty
assert property (p);
```

o Explicitly specified in the property:

```
property p;
  @(posedge clk) a ##1 b;
endproperty
assert property (p);
```

o Explicitly specified in the concurrent assertion:

```
assert property (@(posedge clk) a ##1 b);
```

o Inferred from a procedural block:

```
property p;
   a ##1 b;
endproperty
always @(posedge clk) assert property (p);
```

o From a clocking block (see the Clocking Blocks tutorial):

```
clocking cb @(posedge clk);
  property p;
  a ##1 b;
  endproperty
endclocking
assert property (cb.p);
```

o From a default clock (see the Clocking Blocks tutorial):

```
default clocking cb;
```

## **Handling Asynchronous Resets**

In the following example, the disable iff clause allows an asynchronous reset to be specified.

```
property p1;
  @(posedge clk) disable iff (Reset) not b ##1 c;
endproperty
assert property (p1);
```

The not negates the result of the sequence following it. So, this assertion means that if Reset becomes true at any time during the evaluation of the sequence, then the attempt for p1 is a success. Otherwise, the sequence b ##1 c must never evaluate to true.

#### **Sequences**

A sequence is a list of boolean expressions in a linear order of increasing time. The sequence is true over time if the boolean expressions are true at the specific clock ticks. The expressions used in sequences are interpreted in the same way as the condition of a procedural if statement.

Here are some simple examples of sequences. The ## operator delays execution by the specified number of clocking events, or clock cycles.

The \* operator is used to specify a consecutive repetition of the left-hand side operand.

The \$ operator can be used to extend a time window to a finite, but unbounded range.

```
a ##1 b [*1:$] ##1 c // E.g. a b b b c
```

The [-> or goto repetition operator specifies a non-consecutive sequence.

```
a ##1 b[->1:3] ##1 c // E.g. a !b b b !b !b b c
```

This means a is followed by any number of clocks where c is false, and b is true between 1 and three times, the last time being the clock before c is true.

The [= or *non-consecutive repetition* operator is similar to *goto repetition*, but the expression (b in this example) need not be true in the clock cycle before c is true.

```
a ##1 b [=1:3] ##1 c // E.g. a !b b b !b !b b !b c
```

# **Combining Sequences**

There are several operators that can be used with sequences:

The binary operator and is used when both operand expressions are expected to succeed, but the end times of the operand expressions can be different. The end time of the end operation is the end time of the sequence that terminates last. A sequence succeeds (i.e. is true over time) if the boolean expressions containing it are true at the specific clock ticks.

```
s1 and s2 // Succeeds if s1 and s2 succeed. The end time is the // end time of the sequence that terminates last
```

If s1 and s2 are sampled booleans and not sequences, the expression above succeeds if both s1 and s2 are evaluated to be true. The binary operator intersect is used when both operand expressions are expected to succeed, and the end times of the operand expressions must be the same.

```
s1 intersect s2 // Succeeds if s1 and s2 succeed and if end time of s1 is // the same with the end time of s2
```

The operator or is used when at least one of the two operand sequences is expected to match. The sequence matches whenever at least one of the operands is evaluated to true.

```
s1 or s2 // Succeeds whenever at least one of two operands s1 // and s2 is evaluated to true
```

The <u>first\_match</u> operator matches only the first match of possibly multiple matches for an evaluation attempt of a sequence expression. This allows all subsequent matches to be discarded from consideration. In this example:

```
sequence fms;
  first_match(s1 ##[1:2] s2);
endsequence
```

whichever of the (s1 ##1 s2) and (s1 ##2 s2) matches first becomes the result of sequence fms.

The throughout construct is an abbreviation for writing:

```
(Expression) [*0:$] intersect SequenceExpr
```

i.e. Expression throughout SequenceExpr means that Expression must evaluate true at every clock tick during the evaluation of SequenceExpr.

The within construct is an abbreviation for writing:

```
(1[*0:$] ##1 SeqExpr1 ##1 1[*0:$]) intersect SeqExpr2
```

i.e. SequenceExpr1 within SequenceExpr2 means that SeqExpr1 must occur at least once entirely within SeqExpr2 (both start and end points of SeqExpr1 must be between the start and the end point of SeqExpr2).

#### **Variables in Sequences and Properties**

Variables can be used in sequences and properties. A common use for this occurs in pipelines:

```
`define true 1

property p_pipe;
  logic v;
  @(posedge clk) (`true, v=DataIn) ##5 (DataOut === v);
endproperty
```

In this example, the variable v is assigned the value of <code>DataIn</code> unconditionally on each clock. Five clocks later, <code>DataOut</code> is expected to equal the assigned value. Each invocation of the property (here there is one invocation on every clock) has its own copy of v. Notice the syntax: the assignment to v is separated from a sequence expression by a comma, and the sequence expression and variable assignment are enclosed in parentheses.

## **Coverage Statements**

In order to monitor sequences and other behavioural aspects of a design for *functional coverage*, **cover property** statements can be used. The syntax of these is the same as that of **assert property**. The simulator keeps a count of the number of times the property in the cover property statement holds or fails. This can be used to determine whether or not certain aspects of the designs functionality have been exercised.

```
module Amod2(input bit clk);
bit X, Y;
sequence s1;
  @(posedge clk) X ##1 Y;
endsequence
CovLavel: cover property (s1);
...
endmodule
```

SystemVerilog also includes covergroup statements for specifying functional coverage. These are introduced in the Constrained-Random Verification Tutorial.

#### **Assertion System Functions**

SystemVerilog provides a number of system functions, which can be used in assertions.

\$rose, \$fell and \$stable indicate whether or not the value of an expression has changed between two adjacent clock ticks. For example,

```
assert property
  (@(posedge clk) $rose(in) |=> detect);
```

asserts that if in changes from 0 to 1 between one rising clock and the next, detect must be 1 on the following clock. This assertion,

```
assert property
  (@(posedge clk) enable == 0 |=> $stable(data));
```

states that data shouldn't change whilst enable is 0.

The system function \$past returns the value of an expression in a previous clock cycle. For example,

states that q increments, provided reset is low and enable is high.

Note that the argument to \$past may be an expression, as shown above.

The system functions <code>\$onehot</code> and <code>\$onehot0</code> are used for checking one-hot encoded signals. <code>\$onehot(expr)</code> returns true if exactly one bit of <code>expr</code> is high; <code>\$onehot0(expr)</code> returns true if at most one bit of <code>expr</code> is high.

```
assert property (@(posedge clk) $onehot(state));
```

There are other system functions.

# **Binding**

We have seen that assertions can be included directly in the source code of the modules in which they apply. They can even be embedded in procedural code. Alternatively, verification code can be written in a separate program, for example, and that program can then be bound to a specific module or module instance.

For example, suppose there is a module for which assertions are to be written:

```
module M (...);
  // The design is modelled here
endmodule
```

The properties, sequences and assertions for the module can be written in a separate program:

```
program M_assertions(...);
   // sequences, properties, assertions for M go here
endprogram
```

This program can be bound to the module M like this:

```
bind M M_assertions M_assertions_inst (...);
```

The syntax and meaning of M assertions is the same as if the program were instanced in the module itself:

```
module M (...);
  // The design is modelled here
  M_assertions M_assertions_inst (...);
endmodule
```

#### **Prev Next**

©Copyright 2005-2018 Doulos. All rights reserved.